


## CDCNET Network Operations and Analysis



60461520

 CONTROL DATA

# **CDCNET**

## **Network Operations and Analysis Manual**

### **Usage**

**This product is intended for use only as described in this document. Control Data cannot be responsible for the proper functioning of undescribed features and parameters.**

# Manual History

---

| Revision | System Version/<br>PSR Level | Date           |
|----------|------------------------------|----------------|
| A        | 1.0/647                      | December 1985  |
| B        | 1.1/664                      | September 1986 |
| C        | 1.2/678                      | April 1987     |
| D        | 1.2.5/688                    | Septemper 1987 |
| E        | 1.3/700                      | April 1988     |
| F        | 1.4/713                      | December 1988  |
| G        | 1.5.1/739                    | December 1989  |
| H        | 1.5.2/750                    | June 1990      |
| J        | 1.5.3/765                    | January 1991   |

This manual is revision J, printed in January 1991. It reflects CDCNET version 1.5.3 at PSR level 765, for operation on NOS version 2.7.1 at PSR level 750 and NOS/VE version 1.5.3 at PSR level 765.

This manual includes references to the CDCNET Network Management Station and changes to the Remote Line Monitor screens.

Also, various technical and editorial changes were made.

©1985, 1986, 1987, 1988, 1989, 1990, 1991 by Control Data Corporation  
All rights reserved.  
Printed in the United States of America.

# Contents

---

|   |      |   |      |
|---|------|---|------|
| <b>About This Manual</b> .....                                      | 7    | <b>Network Performance Analyzer (NPA) Functional Overview</b> .....             | 5-1  |
| Audience .....  | 7    | NPA Features .....  | 5-1  |
| Organization .....  | 8    | Functional Overview .....   | 5-4  |
| Conventions .....   | 9    | How To Initiate NPA Reports ....  | 5-12 |
| Related CDCNET Manuals .....  | 10   | NPA Report Generation Example .   | 5-14 |
| Additional Related Manuals .....                                    | 15   | How To Enter NPA Commands in Screen Mode Format (NOS Only).....                 | 5-17 |
| Ordering Manuals .....  | 15   | How to Enter NPA Commands in Line Mode Format.....                              | 5-28 |
| Submitting Comments .....   | 16   | How To Get Help on NPA Procedures.....  | 5-35 |
| Central Software Support Hotline ..                                 | 16   |   |      |
| <br><b>Introduction to Network Operations and Analysis</b> .....    | 1-1  | <br><b>NPA Reports and Report Formats</b> .....                                 | 6-1  |
| Network Operations Concepts .....                                   | 1-2  | Common Report Format Features .   | 6-1  |
| Network Operator Utility (NETOU) .....                              | 1-14 | Expected Operating Limits .....   | 6-7  |
| Session Control .....   | 1-14 | Log Message ID .....  | 6-7  |
| Network Control .....   | 1-14 | Specific Reports .....  | 6-8  |
| Network Performance Analyzer ..                                     | 1-15 |   |      |
| NPA Reports and Report Formats .....                                | 1-15 | <br><b>How To Create Customized NPA Reports Using IPF2 Database Files</b> ..... | 7-1  |
| How To Create Customized NPA Reports Using IPF2 Database Files..... | 1-15 | Customized Software Error Report Example.....                                   | 7-1  |
| Device Interface Dump Analyzer .                                    | 1-16 | Creating a Customized NPA Summary Accounting Statistics Report Example.....     | 7-13 |
| Network Analysis .....  | 1-16 |   |      |
| <br><b>Network Operator Utility (NETOU)</b> .....                   | 2-1  | <br><b>Device Interface Dump Analyzer</b> ..                                    | 8-1  |
| Common Network Operations Features.....                             | 2-1  | How To Initiate the Dump Analyzer.....  | 8-2  |
| Operations in a NOS/VE Environment.....                             | 2-13 | Dump Analyzer Conventions .....   | 8-4  |
| Operations in a NOS Environment.....                                | 2-17 | How To Retrieve a DI Dump File.....   | 8-5  |
| <br><b>NETOU Session Control Procedures</b> .....                   | 3-1  | How To Use the Dump Analyzer Input File.....                                    | 8-9  |
| Session Control on NOS/VE .....                                     | 3-2  | How To Manage Dump Analyzer Output.....   | 8-10 |
| Session Control on NOS .....  | 3-9  | How To End a Dump Analyzer Session .....  | 8-12 |
| <br><b>NETOU Network Control Procedures</b> .....                   | 4-1  | How To Transfer Dump Files Between NOS/VE and NOS.....                          | 8-12 |
| Recordkeeping .....   | 4-1  | Sample Input File for NOS/VE or NOS.....  | 8-13 |
| Network Operation Commands ....                                     | 4-3  |   |      |
| Advanced Activities .....   | 4-16 |   |      |



|  |             |  |                |
|--|-------------|--|----------------|
| Sample Output File for NOS/VE<br>or NOS.....               | 8-14        | <b>System Tables .....</b>                       | <b>F-1</b>     |
| Summary of ANACD<br>Subcommands.....                       | 8-15        | Executive Error Table .....                      | F-2            |
| <b>Analyzing the Network .....</b>                         | <b>9-1</b>  | System Configuration Table .....                 | F-8            |
| Analysis Tools .....                                       | 9-1         | System Data Record .....                         | F-12           |
| How Networks Are Formed .....                              | 9-2         | Hardware Status Tables .....                     | F-14           |
| Analyzing Network Configuration ..                         | 9-2         | Link Information Block .....                     | F-19           |
| Analyzing DI Hardware<br>Configurations.....               | 9-9         | Timer Queue .....                                | F-21           |
| Analyzing Line and Terminal<br>Connections.....            | 9-24        | Directory Data Stores .....                      | F-23           |
| <b>Remote Line Monitor Utility<br/>(RLM).....</b>          | <b>10-1</b> | OSI IS-IS Routing Data Store ....                | F-30           |
| Starting a Remote Line Monitor<br>Session .....            | 10-1        | Terminal Support Debug Table ...                 | F-39           |
| Main Menu Screen .....                                     | 10-2        | Batch Data Service Debug Table .                 | F-41           |
| Screens .....  | 10-4        | Batch Gateway Debug Table .....                  | F-43           |
| Data Integrity .....                                       | 10-12       | Operator Support Application<br>Table.....       | F-46           |
| Data Formats .....   | 10-12       | Loader Entry Point Table .....                   | F-50           |
| Display Formats .....                                      | 10-13       | System Memory Management<br>Table.....           | F-52           |
| Security .....   | 10-21       | Tree Root Structure .....                        | F-53           |
| Cancelling the DI Remote Line<br>Monitor.....              | 10-21       | <b>Line and Terminal Control<br/>Blocks.....</b> | <b>G-1</b>     |
| <b>Glossary .....</b>                                      | <b>A-1</b>  | Allocated Line Control Block .....               | G-2            |
| <b>Character Set .....</b>                                 | <b>B-1</b>  | Configured Line Control Block ....               | G-3            |
| <b>DI Reset Codes .....</b>                                | <b>C-1</b>  | Terminal Cluster Control Block ...               | G-5            |
| Suggested Actions Based on DI<br>Reset Codes.....          | C-2         | Terminal Device Control Block ....               | G-6            |
| <b>Procedures to Enhance Operator<br/>Environment.....</b> | <b>D-1</b>  | Data Connection Control Block ....               | G-9            |
| CDCNET Network Management<br>Procedures for NOS/VE.....    | D-1         | Batch Device Control Block .....                 | G-12           |
| CDCNET Network Management<br>Procedures for NOS.....       | D-5         | Batch Output Connection Control<br>Block.....    | G-14           |
| <b>MPB Memory Map .....</b>                                | <b>E-1</b>  | Batch Input Connection Control<br>Block.....     | G-15           |
| MPB RAM Tables .....                                       | E-2         | Batch Input/Output Station<br>Control Block..... | G-16           |
| MPB-II Memory Map and<br>Address Mapping.....              | E-9         | SCFS Connection Control Block ..                 | G-18           |
|  |             | TIP Interface Record Table .....                 | G-19           |
|  |             | Printer Terminal Model Record ..                 | G-20           |
|  |             | <b>Task and Queue Control Blocks .</b>           | <b>H-1</b>     |
|  |             | <b>Stack Frames .....</b>                        | <b>I-1</b>     |
|  |             | <b>Dump Analyzer Error Messages ..</b>           | <b>J-1</b>     |
|  |             | <b>Index .....</b>                               | <b>Index-1</b> |

## Figures

|   |      |  |       |
|---|------|--|-------|
| 1-1. Example of Physical Names . . . . .                      | 1-9  | 7-6. Customized Terminal Support<br>Accounting Statistics Report . . . . . | 7-33  |
| 2-1. NETOU Operating<br>Environment for NOS/VE . . . . .      | 2-14 | 9-1. Network Configuration Map . . . . .                                   | 9-3   |
| 2-2. NETOU Operating<br>Environment for NOS . . . . .         | 2-18 | 9-2. Summary of Board Status<br>Table Relationships . . . . .              | 9-11  |
| 2-3. NETOU K-Display Format . . . . .                         | 2-23 | 9-3. Terminal Control Block<br>Relationships . . . . .                     | 9-26  |
| 4-1. X.25 Gateway Example . . . . .                           | 4-28 | 9-4. Control Block Pointers . . . . .                                      | 9-26  |
| 5-1. Data Reformatting Process . . . . .                      | 5-7  | 10-1. Main Menu Screen . . . . .   | 10-2  |
| 5-2. HRDWRP1 Report Heading<br>Page . . . . .                 | 5-15 | 10-2. Setup Screen . . . . .   | 10-4  |
| 5-3. HRDWRP1 Report Data Page . . . . .                       | 5-16 | 10-3. File Management Screen . . . . .                                     | 10-6  |
| 6-1. Standard Report Heading . . . . .                        | 6-2  | 10-4. Format and Edit Screen . . . . .                                     | 10-10 |
| 6-2. Report Heading with Log IDs . . . . .                    | 6-3  | 10-5. Edit Screen . . . . .  | 10-11 |
| 6-3. Report Heading with Log IDs<br>and Severity . . . . .    | 6-4  | 10-6. ASYNC-ASCII Display . . . . .  | 10-15 |
| 7-1. Software Error Message Report<br>(SFTWRP1) . . . . .     | 7-2  | 10-7. ASYNC-HEX Display . . . . .  | 10-17 |
| 7-2. NPBSERR File . . . . .                                   | 7-6  | 10-8. HASP-ASCII Display . . . . .   | 10-18 |
| 7-3. Customized Software Error<br>Message Report . . . . .    | 7-12 | 10-9. HASP-HEX Display . . . . .   | 10-20 |
| 7-4. NPBSUMM File . . . . .                                   | 7-14 | E-1. Board Slot Addressing . . . . .                                       | E-1   |
| 7-5. NPBSUMM Log Message/Data<br>Field Associations . . . . . | 7-24 | E-2. MBP-II Memory Map . . . . .   | E-10  |
|   |      | F-1. Least Cost Routing Data Store . . . . .                               | F-30  |
|   |      | G-1. ALCB Record . . . . .   | G-2   |
|   |      | I-1. Stack Area Structure . . . . .  | I-3   |

## Tables

|  |      |   |      |
|--|------|---|------|
| 2-1. NOS Host Console Escape<br>Sequences and Displays . . . . .               | 2-29 | 6-10. Field Definitions for Session<br>Statistics Report . . . . .          | 6-59 |
| 5-1. Statistics Commands and<br>Message Numbers . . . . .                      | 5-11 | 6-11. Field Definitions for Software<br>Error Message Reports . . . . .     | 6-65 |
| 6-1. Field Definitions for<br>Configuration Report . . . . .                   | 6-13 | 6-12. Field Definitions for TELNET<br>Statistics Reports . . . . .          | 6-69 |
| 6-2. Field Definitions for Connection<br>Statistics Reports . . . . .          | 6-18 | 6-13. Field Definitions for Terminal<br>Statistics Reports . . . . .        | 6-73 |
| 6-3. Field Definitions for DI<br>Utilization Statistics Reports . . . . .      | 6-24 | 6-14. Field Definitions for User<br>Statistics Report . . . . .             | 6-76 |
| 6-4. Field Definitions for ESCI<br>Statistics Reports . . . . .                | 6-29 | 6-15. Field Definitions for X.25<br>Connection Statistics Reports . . . . . | 6-80 |
| 6-5. Field Definitions for Event Log<br>Messages Reports . . . . .             | 6-36 | 9-1. Network Analysis Tools . . . . .                                       | 9-1  |
| 6-6. Field Definitions for HDLC<br>Interface Statistics Reports . . . . .      | 6-41 | 9-2. Summary of Board Status<br>Tables . . . . .                            | 9-10 |
| 6-7. Field Definitions for Hardware<br>Error Message Reports . . . . .         | 6-48 | 9-3. Device State . . . . .   | 9-12 |
| 6-8. Field Definitions for Online<br>Loader System Statistics Report . . . . . | 6-51 | 9-4. Device Status . . . . .  | 9-12 |
| 6-9. Field Definitions for Mainframe<br>Channel Statistics Reports . . . . .   | 6-56 | 9-5. Summary of Terminal Control<br>Blocks . . . . .                        | 9-24 |
|  |      | 9-6. NPA Reports . . . . .  | 9-37 |
|  |      | B-1. ASCII Character Set . . . . .  | B-1  |

|  |      |   |      |
|--|------|---|------|
| C-1. Numerical List of DI Reset Codes .....  | C-1  | F-29. Batch Gateway Debug Record .                        | F-43 |
| E-1. MPB RAM Tables .....  | E-2  | F-30. Operator Support Record .....                       | F-47 |
| E-2. Board Map Common Information .....  | E-5  | F-31. Operator Table Entry .....                          | F-49 |
| E-3. ICB Read Register Zero .....  | E-6  | F-32. Loader Entry Point .....                            | F-51 |
| F-1. Executive Error Table .....   | F-2  | F-33. System Memory Management Table .....                | F-52 |
| F-2. Error Buffers .....   | F-3  | F-34. Tree Root Structure .....                           | F-53 |
| F-3. CASE exec_error_codes of bus_error_i, address_error_i for MPB .....           | F-4  | G-1. Allocated Line Control Block (ALCB) .....            | G-2  |
| F-4. CASE exec_error_codes of smm_single_bit_error_i, smm_double_bit_error_i ..... | F-4  | G-2. Configured Line Control Block (CLCB) .....           | G-3  |
| F-5. CASE exec_error_codes of ICA-II .....   | F-4  | G-3. Terminal Cluster Control Block (TCCB) .....          | G-5  |
| F-6. CASE exec_error_codes of bus_error_i, address_error_i for MPB-II .....        | F-5  | G-4. Terminal Device Control Block (TDCB) .....           | G-6  |
| F-7. System Configuration Table .....  | F-8  | G-5. TDCB, Case CPT_VTP .....                             | G-7  |
| F-8. System Data Record .....  | F-12 | G-6. TDCB, Case CPT_BTP .....                             | G-8  |
| F-9. Major Card Status Table Entry .....   | F-14 | G-7. TDCB/CPT_BTP, Case BU_DEVICE .....                   | G-8  |
| F-10. LIM Status Table Entry .....   | F-15 | G-8. TDCB/CPT_BTP, Case BU_STREAM .....                   | G-8  |
| F-11. Port Status Table Entry .....  | F-16 | G-9. Data Connection Control Block (DCCB) .....           | G-9  |
| F-12. SMM Bank Table Type .....  | F-17 | G-10. DCCB, Case CPT_VTP .....                            | G-10 |
| F-13. Bank Tables Field (SMM Bank Table Type) .....                                | F-17 | G-11. DCCB, Case CPT_BTP .....                            | G-11 |
| F-14. PMM Bank Table Type .....  | F-18 | G-12. Batch Device Control Block (BDCB) .....             | G-12 |
| F-15. Link Interface Block .....   | F-19 | G-13. BDCB, Case BU_DEVICE ...                            | G-13 |
| F-16. Timer Queue .....  | F-22 | G-14. BDCB, Case BU_STREAM ...                            | G-13 |
| F-17. Directory Data Stores .....  | F-23 | G-15. Batch Output Connection Control Block (BOCCB) ..... | G-14 |
| F-18. Registration Data Store .....  | F-25 | G-16. Batch Input Connection Control Block (BICCB) .....  | G-15 |
| F-19. Translation Data Store .....   | F-27 | G-17. Input/output Station Control Block (IOSCB) .....    | G-16 |
| F-20. Translation Request Data Store .....   | F-29 | G-18. IOSCB, Case SU_PUBLIC, SU_PRIVATE .....             | G-17 |
| F-21. IS-IS Routing Data Stores .....  | F-30 | G-19. IOSCB, Case SU_NTF .....                            | G-17 |
| F-22. Least Cost Routing Data Store Row .....                                      | F-32 | G-20. SCFS Connection Control Block (SCCB) .....          | G-18 |
| F-23. Least Cost Routing Data Store Entry .....                                    | F-33 | G-21. TIP Interface Record Table (TIRT) .....             | G-19 |
| F-24. Local DCN Data Store Entry .....   | F-35 | G-22. Printer Terminal Model Record .....                 | G-20 |
| F-25. Received DCN Data Store Entry .....  | F-37 | H-1. Task Control Block .....                             | H-1  |
| F-26. DCN Definition Entry .....   | F-38 | H-2. Queue Control Block .....                            | H-3  |
| F-27. TSD Debug Record .....   | F-39 |   |      |
| F-28. Batch Data Service Debug Record .....  | F-41 |   |      |

# About This Manual

---

This manual describes the functions, procedures and commands associated with network operations of a CONTROL DATA® Distributed Communications Network (CDCNET). It presents CDCNET network operations concepts and guides you through the first steps of network operations.

## Audience

This manual is written for the person needing information about CDCNET network operations activities and how to initiate them. The reader should have knowledge of NOS/VE and/or NOS concepts and operations, as well as an understanding of CDCNET's general purposes and concepts, as described in the CDCNET Conceptual Overview.

### NOTE

---

If you are doing operations on a CDCNET Network Management Station, refer to the CDCNET Network Management Station manual. The CDCNET Network Management Station has utilities similar to NETOU and NPA. The CDCNET Network Management Station does not have a Dump Analyzer. Because of this, the chapters describing NETOU, Dump Analyzer, and NPA in this manual do not apply to CDCNET Network Management Station.

---

## Organization

The following chapters are contained in this manual.

Chapter 1 gives you an overview of CDCNET from a network operator's perspective. You will learn about your role in the network, concepts important to you as a network operator, as well as the kinds of activities you may perform during operations.

Chapter 2 describes the Network Operator Utility (NETOU), which you use to monitor, control, and dynamically reconfigure CDCNET. NETOU is described for both NOS/VE and NOS environments.

Chapter 3 describes the NETOU session control procedures.

Chapter 4 is NETOU network control procedures.

Chapter 5 describes the Network Performance Analyzer (NPA).

Chapter 6 describes the reports and report formats generated by NPA.

Chapter 7 describes how to create customized NPA reports using IPF2 database files.

Chapter 8 describes the Device Interface Dump Analyzer.

Chapter 9 describes how to use NETOU, NPA, and the Dump Analyzer to analyze a network.

Chapter 10 describes how to use the Remote Line Monitor.

The appendixes include additional information to aid in understanding CDCNET.

- Appendix A contains a glossary of terms.
- Appendix B contains the ASCII character set.
- Appendix C contains the DI reset codes.
- Appendix D contains the procedures to enhance operator environment.
- Appendix E contains the Dump Analyzer MPB memory map.
- Appendix F contains the Dump Analyzer system tables.
- Appendix G contains the Dump Analyzer line and terminal control blocks.
- Appendix H contains the Dump Analyzer task and queue control blocks.
- Appendix I contains the Dump Analyzer error messages.

## Conventions

The terms logic board and board are used interchangeably in this manual. They refer to any of the printed circuit board assemblies housed in the device interface (DI), such as the processor board, memory boards and line interface modules.

The terms Ethernet<sup>1</sup> and IEEE 802.3 are used interchangeably in CDCNET manuals. Ethernet refers to a network standard developed by Xerox, Intel, and DEC (Digital Equipment Corporation). IEEE 802.3 is the IEEE adaptation of that standard. The term IEEE 802.3 is a more precise label for the network standard. However, many network operations commands and software programs use the term Ethernet. CDCNET products covered by these standards are compatible with both IEEE 802.3 and Ethernet V.2.

The NOS 2 Operations and Analysis handbooks use the term COP (CDCNET Operator), which is the type of network operator described in this manual.

When descriptions and procedures apply to both a mainframe device interface (MDI) and a mainframe terminal interface (MTI), the term MDI is used for both device interface types. If it is necessary to specify both MDIs and MTIs in a section, they are specified in the initial instance, but from then on, only MDI is used.

All numbers in this manual are decimal (base 10) unless specifically identified as octal (base 8) or hexadecimal (base 16).

---

1. Ethernet is a registered trademark of the Xerox Corporation.

## Related CDCNET Manuals

### Manual Abstracts

Following is a brief description of each CDCNET manual.

|  |   |
|--|---|
| Conceptual Overview                            | Discusses CDCNET in conceptual terms. It provides a broad view of CDCNET that explains the theoretical nature of this product. It does not attempt to define which particular product capabilities and features are currently available and which ones will follow in subsequent releases.  |
| Product Descriptions                           | Provides reference, planning, and training information for customers who own or are interested in owning CDCNET products, and for Control Data personnel who use or work on CDCNET. The manual describes hardware and software products, provides information on how to select and use various types of network cables, and provides network configuration examples.  |
| Terminal Interface                             | This is the primary manual for end-users who use interactive terminals to access computer services connected to CDCNET. The manual explains general terminal interface concepts, terminal commands and attributes, and connection attributes. For the advanced user, site administrator, and network analysts it also covers more advanced topics such as virtual and transparent modes, resolving communications problems, and the various terminal protocols supported by CDCNET. |
| Access Guide                                   | This online manual guides the novice user through the process of accessing and using computer services through CDCNET. It includes procedures for connecting, disconnecting, and managing connections; displaying and changing terminal attributes; and terminal user exception processing. The more experienced user can find additional related information in the CDCNET Terminal Interface manual.  |
| TCP/IP Programming Interfaces and Applications | Describes how to access the utilities that implement the TCP/IP protocols through CDCNET. The manual assumes the user is familiar with CDCNET terminal and connection attributes; knows the service title to access; and has some working knowledge and understanding of TCP/IP protocols.  |
| Batch Device User Guide                        | Describes how to operate batch devices connected to CDCNET. It assumes the user is familiar with NOS and/or NOS/VE operating systems and with CDCNET access to these operating systems. The manual defines the concepts of I/O stations and provides the procedures for defining and controlling these stations. The online manual is available with NOS/VE and NOS operating systems.  |



**Hardware Installation  
and Troubleshooting**

Contains hardware installation procedures and troubleshooting guidelines for CDCNET hardware products and associated I/O cables. The manual is intended for individuals who install and check out CDCNET hardware products, operate them, add options to them, and maintain them.

**Configuration Guide**

Documents how to configure CDCNET software after it is installed on an operating system, and describes the responsibilities of the CDCNET network administrator. This manual also documents the Manage CDCNET Configuration Utility (MANCC), a utility for creating and editing files defining a CDCNET network.

**DI Dump Analyzer**

This manual is an online version of the DI Dump Analyzer section of the CDCNET Network Operations and Analysis manual. The manual is for CDCNET analysts who are familiar with Control Data host computer operating system concepts and operations. The manual describes how to use information from the Analyze CDCNET Dump (ANACD) utility to help troubleshoot network problems. Available with NOS/VE only.

**Network Operations and  
Analysis**

This manual documents how to monitor, control, and reconfigure CDCNET using the CDCNET Network Operator Utility (NETOU). The Network Operations section walks an operator through operations concepts, basic and advanced operations activities, and elementary troubleshooting decisions.

The Network Analysis section describes the tools and methods used to analyze CDCNET performance including: instructions for using the CDCNET DI Dump Analyzer, a list of DI reset codes, a map of fixed address memory, and definitions of important system data structures.

The NPA section of the manual provides information on how to generate various types of NPA reports and provides examples and descriptions of all NPA reports.

|                                   |  |
|-----------------------------------|--|
| Diagnostic Messages               | <p>This manual is for network operators, network analysts, and programmers. The manual provides sorted lists of diagnostic messages and command responses issued by the CDCNET software. The primary sorted list of diagnostic messages describes the event causing each message and the appropriate user action. The primary sorted list of command responses describes the event causing the command response. Secondary sorted lists of diagnostic messages and command responses provide a cross reference of diagnostic message number and command response number to the CDCNET software products that issue the messages or command responses.</p> <p>The printed version of this manual is no longer available. However, a copy of the messages file can be printed on site. Available with both NOS/VE and NOS operating systems.</p> |
| Commands                          | <p>This manual contains all of the CDCNET Operator/Analyst commands. This manual is intended for operators, systems analysts, support engineers, and other experienced users.</p>  |
| CDCNET Network Management Station | <p>This manual documents how to install, configure, and operate the CDCNET Network Management Station. The manual is for CDCNET operators and administrators having previous experience as a UNIX system administrator.</p>  |

## Manual History

Not all sites find it convenient or expedient to install each new version and PSR level of CDCNET software. This presents a problem in maintaining sets of manuals that reflect installed software when later versions of CDCNET software are available but not installed. The following CDCNET Manual History table helps users to assemble and maintain the appropriate documentation by indicating which manual revisions support each release of CDCNET.

## Manual/Audience Matrix

The CDCNET Manual/Audience matrix helps site planners, administrators, and users to determine their CDCNET documentation needs. The matrix categorizes each manual according to its type: overview, reference, tutorial, and so on. It then defines the audience of each manual in general terms: customer, end-user, LAN installer, and so on. Sites may have different audience designations for their audience, or may combine user functions.

**CDCNET MANUAL HISTORY**  
**RELEASE 1.3 - 1.5.3**

| CDCNET MANUALS   | CDCNET RELEASE DATE/VERSION/PSR LEVEL |                          |                            |                            |                            |                            |
|--|---------------------------------------|--------------------------|----------------------------|----------------------------|----------------------------|----------------------------|
|  | APR. '88<br>R1.3<br>L700              | DEC. '88<br>R1.4<br>L716 | JUN. '89<br>R1.4.2<br>L727 | DEC. '89<br>R1.5.1<br>L739 | JUN. '90<br>R1.5.2<br>L750 | JAN. '91<br>R1.5.3<br>L765 |
|  | MANUAL REVISION                       |                          |                            |                            |                            |                            |
| CONCEPTUAL OVERVIEW<br>60461540                          | -                                     | -                        | -                          | -                          | C                          | -                          |
| PRODUCT DESCRIPTIONS<br>60460590                         | B                                     | C                        | -                          | D                          | -                          | E                          |
| TERMINAL INTERFACE<br>60463850                           | D                                     | E                        | -                          | F                          | G                          | -                          |
| ACCESS GUIDE (ONLINE NOS)<br>CDCNETA                     | X                                     | X                        | -                          | X                          | -                          | -                          |
| ACCESS GUIDE (ONLINE NOS/VE)<br>CDCNET_ACCESS            | X                                     | X                        | -                          | X                          | X                          | -                          |
| TCP/IP APPLICATIONS<br>60000214                          | B                                     | C                        | D                          | E                          | F                          | G                          |
| BATCH DEVICE USER GUIDE<br>60463863                      | D                                     | E                        | -                          | F                          | -                          | G                          |
| BATCH DEVICE USER GUIDE (ONLINE NOS/VE)<br>CDCNET_BATCH  | X                                     | X                        | -                          | X                          | -                          | X                          |
| BATCH DEVICE USER GUIDE (ONLINE NOS)<br>CDCNETB          | X                                     | X                        | -                          | X                          | -                          | -                          |
| HARDWARE INSTALLATION AND<br>TROUBLESHOOTING<br>60000348 | *                                     | A                        | -                          | B                          | -                          | -                          |
| CONFIGURATION GUIDE<br>60461550                          | E                                     | F                        | -                          | G                          | H                          | J                          |
| DI DUMP ANALYZER (ONLINE NOS/VE)<br>ANACD                |                                       | A                        | -                          | B                          | -                          | -                          |
| NETWORK OPERATIONS AND ANALYSIS<br>60461520              | E                                     | F                        | -                          | G                          | H                          | J                          |
| DIAGNOSTICS MESSAGES (ONLINE NOS)<br>CNETMSG             | X                                     | X                        | X                          | X                          | X                          | X                          |
| DIAGNOSTICS MESSAGES (ONLINE NOS/VE)<br>CDCNET_MSGS      | X                                     | X                        | X                          | X                          | X                          | X                          |
| CDCNET COMMANDS<br>60000414                              |                                       |                          |                            | A                          | B                          | C                          |
| CDCNET NETWORK MANAGEMENT STATION<br>60000568            |                                       |                          |                            |                            |                            | A                          |

**NOTES:**

M05352

- MANUAL NOT AFFECTED BY THE RELEASE.
- \* RELEASES SUPPORTED BY LAN INSTALLATION MANUAL, DI INSTALLATION AND CHECKOUT MANUAL, AND TROUBLESHOOTING GUIDE.
- X INDICATES ONLINE MANUAL WAS UPDATED FOR THAT RELEASE.



SHADED BOXES INDICATE THE LATEST REVISION LEVEL FOR THE MANUAL.

**CDCNET  
MANUAL/AUDIENCE  
MATRIX**

| CDCNET<br>MANUAL/AUDIENCE<br>MATRIX           |               | AUDIENCE |          |               |                   |                  |                     |                 |                    |            |
|---|---------------|----------|----------|---------------|-------------------|------------------|---------------------|-----------------|--------------------|------------|
|   |               | Customer | End-User | LAN Installer | Customer Engineer | Network Operator | CE Support Engineer | Network Analyst | Site Administrator | Programmer |
| CDCNET MANUALS                                | MANUAL TYPE   |          |          |               |                   |                  |                     |                 |                    |            |
| Conceptual Overview                           | Overview      |          |          |               |                   |                  |                     |                 |                    |            |
| Product Descriptions                          | Reference     |          |          |               |                   |                  |                     |                 |                    |            |
| Terminal Interface                            | User Guide    |          |          |               |                   |                  |                     |                 |                    |            |
| Access Guide                                  | User Guide    |          |          |               |                   |                  |                     |                 |                    |            |
| TCP/IP Programming Interface and Applications | Reference     |          |          |               |                   |                  |                     |                 |                    |            |
| Batch Device User Guide                       | User Guide    |          |          |               |                   |                  |                     |                 |                    |            |
| Hardware Installation And Troubleshooting     | Maintenance   |          |          |               |                   |                  |                     |                 |                    |            |
| Configuration Guide                           | Ref./Tutorial |          |          |               |                   |                  |                     |                 |                    |            |
| DI Dump Analyzer                              | Ref./Tutorial |          |          |               |                   |                  |                     |                 |                    |            |
| Commands                                      | Reference     |          |          |               |                   |                  |                     |                 |                    |            |
| Network Operations And Analysis               | Ref./Tutorial |          |          |               |                   |                  |                     |                 |                    |            |
| Diagnostics Messages                          | Reference     |          |          |               |                   |                  |                     |                 |                    |            |
| CDCNET Network Management Station             | Ref./Tutorial |          |          |               |                   |                  |                     |                 |                    |            |

M05353

## Additional Related Manuals

The following manuals contain helpful information.

| <b>Manual</b>   | <b>Publication<br/>Number</b> |
|---|-------------------------------|
| Common Maintenance Software Interface                         | 60455980                      |
| Concurrent Maintenance Library for Virtual Environment        | 60000019                      |
| Network Access Method (NAM) Network Definition Language (NDL) | 60480000                      |
| NOS/VE System Usage   | 60464014                      |
| NOS/VE Commands and Functions                                 | 60464018                      |
| NOS Version 2 Reference Set, Volume 3                         | 60459680                      |
| NOS Version 2 Reference Set, Volume 4                         | 60459690                      |
| NOS Version 2 Analysis Handbook                               | 60459300                      |
| NOS/VE System Performance and Maintenance, Volume 1           | 60463915                      |
| NOS/VE Network Management                                     | 60463916                      |
| Remote Batch Facility Reference Manual                        | 60499600                      |
| IPF2 Reference Manual   | 84001950                      |
| NOS Version 2 Installation Handbook                           | 60459320                      |
| NOS Version 2 Operations Handbook                             | 60459310                      |

## Ordering Manuals

Control Data manuals are available through Control Data Sales Offices or from:

Control Data  
Literature and Distribution Services ARHLDS  
4201 Lexington Avenue N.  
St. Paul, MN 55126-6198

You can also call (612)482-3800 or (612)482-3801, or FAX your enquiry to (612)482-3813. (If you are a Control Data employee, use the Controlnet number 235-3800, 235-3801, or 235-3813.)

## Submitting Comments

Control Data welcomes your comments about this manual. Your comments may include your opinion of the usefulness of this manual, your suggestions for specific improvements, and the reporting of any errors you have found.

You can submit your comments on the comment sheet on the last page of this manual. If the comment sheet has already been used, you can mail your comments to:

Control Data  
Technical Publications ARH219  
4201 Lexington Avenue N.  
St. Paul, MN 55126-6198

You can also submit your comments through SOLVER, an on-line facility for reporting problems. To submit a documentation comment through SOLVER, do the following:

1. Select Report a new problem or change in existing PSR from the main SOLVER menu.
2. Respond to the prompts for site-specific information.
3. Select Write a comment about a manual from the new menu.
4. Respond to the prompts.

Please indicate whether or not you would like a written response.

## Central Software Support Hotline

Control Data's Central Software Support maintains a hotline to assist you if you have trouble using our products. If you need help not provided in the documentation, or find the product does not perform as described, call us at one of the following numbers. A support analyst will work with you.

From the USA and Canada: (800) 345-6628

From other countries: (612) 482-3434

# Introduction to Network Operations and Analysis

1

|  |       |
|--|-------|
| Network Operations Concepts .....                                    | 1-2   |
| Operating Environment .....  | 1-2   |
| Host Computer .....  | 1-2   |
| Device Interface .....   | 1-2.1 |
| Lines, Trunks, and Network Solutions .....                           | 1-2.1 |
| Communication Line .....   | 1-2.1 |
| Trunks .....   | 1-2.1 |
| Network Solution .....   | 1-3   |
| Catenet .....  | 1-3   |
| Terminal Interface Programs (TIPs) .....                             | 1-3   |
| Logging Group .....  | 1-4   |
| Operations Station .....   | 1-4   |
| Network Operations Activities .....                                  | 1-4   |
| Gateways .....   | 1-4   |
| Network Products Gateways (NOS Only) .....                           | 1-5   |
| X.25 Gateway .....   | 1-5   |
| TCP/IP Gateway .....   | 1-5   |
| Outcall Gateway .....  | 1-6   |
| Terminal Passthrough .....   | 1-6   |
| Device Outcall .....   | 1-6   |
| Sending Network Commands .....                                       | 1-7   |
| Command Responses and Alarms .....                                   | 1-7   |
| Physical and Logical Names .....                                     | 1-7   |
| Physical Names .....   | 1-8   |
| Logical Names .....  | 1-11  |
| Addresses and Titles .....   | 1-12  |
| Network Configuration .....  | 1-12  |
| Physical Configuration .....   | 1-12  |
| Logical Configuration .....  | 1-13  |
| Network Validation .....   | 1-13  |
| NTF Remote System Configuration .....                                | 1-14  |
| Network Operator Utility (NETOU) .....                               | 1-14  |
| Session Control .....  | 1-14  |
| Network Control .....  | 1-14  |
| Network Delay Measurement .....                                      | 1-14  |
| Network Performance Analyzer .....                                   | 1-15  |
| NPA Reports and Report Formats .....                                 | 1-15  |
| How To Create Customized NPA Reports Using IPF2 Database Files ..... | 1-15  |
| Device Interface Dump Analyzer .....                                 | 1-16  |
| Network Analysis .....   | 1-16  |
| Remote Line Monitor .....  | 1-16  |





# Introduction to Network Operations and Analysis

---

1

This chapter explains CDCNET concepts you should know before performing network operations. It also provides an overview of the CDCNET network operations processes. The following main topics are included in this chapter.

- Network Operations Concepts
- Network Operator Utility (NETOU)
- Session Control
- Network Control
- Network Performance Analyzer (NPA)
- NPA Reports and Report Formats
- How To Create Customized NPA Reports Using IPF2 Database Files
- Dump Analyzer
- Network Analysis
- Remote Line Monitor

It is important that you read this chapter before logging into CDCNET for network operations. For more information about CDCNET software and hardware concepts and terminology, review the CDCNET Conceptual Overview and the Product Descriptions manuals.

## NOTE

---

If you are doing operations on a CDCNET Network Management Station, refer to the CDCNET Network Management Station manual. The CDCNET Network Management Station has utilities similar to NETOU and NPA. The CDCNET Network Management Station does not have a Dump Analyzer. Because of this, the chapters describing NETOU, Dump Analyzer, and NPA in this manual do not apply to CDCNET Network Management Station.

---

## Network Operations Concepts

CDCNET is a distributed data communications network and a collection of data communications equipment interconnected by communications channels. CDCNET distributes its automated communications control and network management functions throughout the network, using a collection of device interfaces (DIs). DIs are connected to mainframes, terminals and printers, batch input and output equipment, and other networks. DIs may be connected to communications media that carry information formatted for CDCNET from one DI to another.

CDCNET may have a variety of configurations, depending upon the size of the network, number of terminals the network supports, and the amount of communications traffic the network generates.

The following are concepts you should read and understand before performing network operations.

### Operating Environment

For CDCNET to operate, it must have:

- At least one host computer.
- For CYBER systems, one mainframe device interface (MDI) or one integrated communications adapter (ICA) is required. For CDCNET Network Management stations, an MDI or an ICA is not required.
- One terminal device interface (TDI) or mainframe terminal interface (MTI).

### Host Computer

A host computer consists of a mainframe computer and its operating system. Together, they provide applications and services to the computer network.

The host computer can be:

- A Control Data Network Operating System/Virtual Environment (NOS/VE) mainframe
- A Control Data Network Operating System (NOS) mainframe
- A CDCNET Network Management Station (CNMS) on a UNIX system

The host computer is the network host. As a host, it can download software to DIs; provide programs to configure the network; and run other utilities needed by CDCNET, such as the utility that analyzes the CDCNET log file.

## Device Interface

A DI is the main hardware device used to implement CDCNET. The DI controls access to the network and controls data communications through the network. Both DI hardware and software are modular. The type of hardware and software housed in a DI depends on the DI's specific function as a network communications controller. For more information about DI hardware and software, see the CDCNET Conceptual Overview and Product Descriptions manuals.

## Lines, Trunks, and Network Solutions

You control several types of network communications media in CDCNET network operations; they are described in the following section.

### Communication Line

A communication line connects data terminating equipment (DTE), such as a terminal or printer, to a DI. Data carried on this line from a DI is meant specifically for the terminal device, or is sent from the terminal device to the DI to which it is connected. Unlike a network solution, a line does not receive data meant for other areas of the network.

The DI hardware controlling communication lines includes the Communications Interface Module (CIM), Line Interface Modules (LIMs), and Unit Record Interface (URI) LIMs. The DI software that controls communication lines and the input to, and output from terminal devices, is called a terminal interface program (TIP).

### Trunks

A trunk carries data for many devices connected to the network that may or may not be attached to the trunk. A trunk may be the underlying medium for a network solution. A trunk may also be the medium used to connect to a Public Data Network (PDN) through a gateway that acts as a translator between different protocols. The physical device for a trunk may be an Ethernet coaxial cable, a NOS/VE or NOS host's mainframe channel, a high-level data link control (HDLC) line, or an X.25 communication line.



## Network Solution

Network solutions interconnect two or more CDCNET DIs or CYBER 93x hosts, using CDCNET protocols. A network solution is a trunk configured to carry both user data and CDCNET network management traffic.

A network solution is the main structural element of a CDCNET-type network. It can carry data from any point in the CDCNET network to any other point in the network. Unlike trunks and lines, it can also carry CDCNET network management services (such as log messages and alarms) and other services provided by the network (such as connections to host services).

## Catenet

A catenet is a set of one or more types of interconnected network communication media that use CDCNET protocols. The media that can be used to connect equipment together into a single catenet include the following: Ethernet local area networks (LANs), HDLC trunks, and X.25 network solutions. This term is often used in commands and text when referring to all the DIs and network solutions in a site's network.

## Terminal Interface Programs (TIPs)

A TIP is a program that acts as a protocol translator between a terminal and CDCNET. CDCNET provides TIPs to support different terminal protocols. The following TIPs are provided by CDCNET in this release:

- Asynchronous TIP
- Telnet TIP
- Houston Automatic Spooling Protocol (HASP) TIP
- Unit Record Interface (URI) TIP
- 3270 Bisynchronous (BSC3270) TIP
- 3270 SNA Communications Protocol
- X.25 Asynchronous TIP
- X.PC TIP
- Mode 4 TIP
- Network Job Entry (NJEF) TIP
- Network Transfer Facility (NTF) TIP

These TIPs are defined by commands in DI system configuration procedures.

## Logging Group

A logging group is a subset of DIs, within a catenet, that send their messages to a common log file. A logging group is established at configuration time. Each DI belongs to only one logging group. At configuration time, you can assign each DI the name of the logging group to which the DI belongs. The default logging group name on the configuration commands is CATENET. You can also configure each DI with the list of message numbers identifying the log messages it sends to the log file. Enable the default set of log messages by entering the `DEFINE_SOURCE_LOG_GROUP` command without the message parameter.

## Operations Station

This manual uses the term operations station to refer to the remote terminal or host console from which operations activities are performed through NETOU.

## Network Operations Activities

As a network operator, you control the network by managing the network's DIs and other network components, such as network solutions, communication lines, gateways, and by monitoring and responding to alarms and other messages generated by the network. These activities are performed by sending commands to DIs and observing the command responses.

You can monitor, control, and occasionally change the logical configuration of CDCNET either from an interactive terminal, or from a host computer console. Network operations commands are equivalent whether you perform network operations from an interactive terminal or host console.

The network activities you perform may vary depending on your site's configuration and communication needs. You may perform some activities more often than others, again depending on your site.

## Gateways

A gateway is a program which connects two networks that use different protocols. CDCNET provides gateways to support translation between CDCNET and NOS protocols, CDCNET and X.25 network protocols, and CDCNET and Transmission Control Protocol/Internet Protocol (TCP/IP).



## Network Products Gateways (NOS Only)

NOS supports a network based on 2550 Network Processing Units. This network has been known by various names, including Network Products and Network Host Products. The Network Products gateways allow information to be transferred between CDCNET and a non-CDNA NOS host. The Network Products protocol is different from the CDNA protocol; a gateway is necessary for CDCNET to access the NOS host.

Each NOS host uses an MDI or MTI to interface to CDCNET. An MDI or MTI provides the Network Products gateway function. Network Products connections exist between the gateway function in each MDI or MTI and its associated host. MDIs and MTIs containing Network Products gateways are members of both networks and understand both CDCNET and Network Products protocols. To CDCNET, a gateway is seen as the end of the connection, although a host mainframe is beyond the gateway.

There are two kinds of Network Products gateways: The terminal-to-application (T-to-A) gateway and application-to-application (A-to-A) gateway. The T-to-A gateway is called the Network Products terminal gateway (abbreviated as NP\_TERMINAL\_GW in network commands). The NP terminal gateway allows both interactive and remote batch terminal users to connect to the NOS host through CDCNET. There are two parts to the NP terminal gateway: The Interactive Virtual Terminal gateway (IVT gateway) and the Remote Batch Facility gateway (RBF gateway). The batch gateway depends on the interactive gateway. The NP terminal gateway software resides in a MDI or MTI. This gateway is an important portion of DI software. If the gateway is logically deleted or if the gateway software is removed from a DI, terminal users cannot connect to a NOS system.

The NP A-to-A gateway (abbreviated as NP\_GW in network commands) is a gateway that allows applications on another NOS/VE, NOS, or foreign system to access the NOS system. The NP A-to-A gateway also allows applications on the NOS system to access applications on other NOS/VE, NOS, or foreign systems. File transfer (PTF) and job transfer (QTF) are the primary users of the NP A-to-A gateway.

## X.25 Gateway

X.25 circuits allow CDCNET to access public data networks. An X.25 gateway is used to transfer data from a host connected to CDCNET, to a host in another network at the other end of the X.25 circuit. The X.25 gateway allows A-to-A connections to take place over an X.25 circuit. Some network commands control an X.25 gateway and can be used to start and stop access to X.25 services.

## TCP/IP Gateway

The TCP/IP gateway supports CDCNET access to Department of Defense (DOD) networks and provides A-to-A services such as FTP. The gateway supports CDCNET access to Defense Data Networks (DDN) or workstations using TCP/IP protocols that support the Advanced Research Project's Agency Network (ARPANET) community. The gateway also supports the Excelan PC and equivalent products. There are network commands to control a TCP/IP gateway and to stop and start TCP/IP services.

## **Outcall Gateway**

The CDCNET outcall gateway provides both terminal passthrough and device outcall services. This gateway must be present in the device interface before either service can be made available.

### ***Terminal Passthrough***

Terminal passthrough allows an asynchronous interactive terminal user on one line to establish a connection to an asynchronous device on another line. The device on the other line could be a terminal, modem, microcomputer, or non-CDCNET host such as NOS/BE, VAX, or IBM. With terminal passthrough, terminal traffic passes through the CDCNET network transparently and the two devices interface to each other as if they were directly connected. Terminal passthrough also supports connections to a modem with dial-out capability. See the Configuration Guide for detailed information on terminal passthrough.

### ***Device Outcall***

Device outcall allows host applications to initiate connections to asynchronous terminal devices. Once a connection is established, communications proceed as though the terminal had initiated the connection. Desktop/VE is the only NOS/VE application currently using device outcall. See the Configuration Guide for detailed information on device outcall.

## **Sending Network Commands**

The following section describes concepts used to send commands to the appropriate destination in CDCNET.

Network commands must be sent to the network's DIs, affecting DIs and their hardware and software components. For example, there are network commands which display the operational status of a DI's logic boards, control statistics collection, add or delete lines from a network's configuration, stop communications on a network component, or run diagnostics on DI boards and ports.

To send a CDCNET network operations command to a DI, insert the command within another command which acts in the manner of an addressed envelope. This command is called `SEND_COMMAND`. It sends the network command to a specific DI or list of DIs. Session control commands are not sent to DIs to control network equipment, therefore they do not have to be sent within a `SEND_COMMAND`.

## **Command Responses and Alarms**

In CDCNET, once a network command arrives at the proper destination, it is processed, and a response to the command is sent back to you.

Some messages are sent to you unsolicited, that is, without sending a command. These unsolicited messages are called alarms. Alarms are messages generated by network software for various events worthy of operator notification which the software detects, or for actions the software takes.

## **Physical and Logical Names**

When sending network operations commands to ICAs or DIs, you can address DI components (boards, lines, trunks, network solutions, terminal devices) by name. The following naming conventions are allowed.

- Its physical name is derived from the physical addressing of a hardware component.
- Its logical name is derived from the value provided in the logical configuration of a DI. You can assign the logical name, which is the name by which the network's components and services are referenced.

## Physical Names

Physical names are assigned to a DI's hardware devices, such as boards, ports, memory banks, terminal devices, communication lines, network solutions, and the DI itself. With the exception of boards, physical names are used as the default logical names for many DI components with logical names. Logical names are defined by CDCNET configuration commands. Once defined, the logical names are used in place of, and not in addition to, physical names. Some network operations commands, such as the online diagnostics commands, require that you specify physical names of devices.

Physical names begin with a \$ character.

The physical name for a DI or ICA system is in the form

**\$DI\_system\_id**

**or**

**\$ICA\_system\_id**

where system\_id represents the unique 12-character system ID assigned to the DI. An example of a DI physical name is \$DI\_0800253000A1.

For DI boards, the physical name is in the form

**\$devicen**

The device portion of the name refers to board type, which may be one of the following values.

|                                     |                                   |
|-------------------------------------|-----------------------------------|
| MPB                                 | Main processor board              |
| SMM                                 | System main memory                |
| PMM                                 | Private memory module             |
| CIM                                 | Communications interface module   |
| ESCI                                | Ethernet serial channel interface |
| ICA                                 | Integrated Communications Adapter |
| MCI                                 | Mainframe channel interface       |
| LIM                                 | Line interface module             |
| URI                                 | Unit record interface             |
| SMM bank number (specified as BANK) |                                   |
| LIM port number (specified as PORT) |                                   |
| URI port number (specified as PORT) |                                   |

The n portion of the name is a number that may have one of the following values.

- Board slot number (0 through 7). Refers to the board slot number of the hardware device in the DI. A DI contains two sizes of boards, large boards (MPB, PMM, SMM, CIM, ESCI, and MCI), and small boards (LIM/URI).
- System Main Memory (SMM) bank number (0 through 1).
- LIM port number (depending on the LIM model, either 0 or 1, 0 through 3, or 0 through 7). Port 0 is the top port on the LIM.
- URI port number (0 through 1). Note that only URI port 0 (the top port) is currently supported.

The following are examples of physical names for DI boards.

\$CIM3      Physical name for CIM board in board slot 3

\$ESCI4      Physical name for ESCI board in board slot 4

When a component is a subassembly of a device, such as a port on a LIM, the physical name of the subassembly is a concatenation of the main device name and the subassembly's name, joined by an underscore. For example, \$LIM5\_PORT2 is the physical name for the second port on a LIM board in LIM board slot 5, \$SMM2\_BANK0 is the physical name for bank 0 on a SMM board in board slot 2, and \$URI7\_PORT0 is the physical name for port 0 of a URI board in slot 7.

Figure 1-1 shows how physical names are assigned in a DI and shows an example of how boards may be installed in a DI. NN




Figure 1-1. Example of Physical Names

Based on the configuration of boards shown in figure 1-1, the following physical names are assigned.

| Large Board<br>Physical Names | LIM<br>Physical Names | Port<br>Physical Names       |
|-------------------------------|-----------------------|------------------------------|
| \$MPB0                        | \$LIM0                | \$LIM0_PORT0 to \$LIM0_PORT3 |
| \$PMM1                        | \$LIM1                | \$LIM1_PORT0 to \$LIM1_PORT3 |
| \$SMM2                        | \$LIM2                | \$LIM2_PORT0 to \$LIM2_PORT3 |
| \$SMM3                        | \$LIM3                | \$LIM3_PORT0 to \$LIM3_PORT3 |
| \$CIM5                        | \$LIM4                | \$LIM4_PORT0 to \$LIM4_PORT3 |
| \$ESCI6                       | \$LIM5                | \$LIM5_PORT0 to \$LIM5_PORT3 |
| \$MCI7                        | \$LIM6                | \$LIM6_PORT0 to \$LIM6_PORT3 |
|                               | \$LIM7                | \$LIM7_PORT0 to \$LIM7_PORT3 |

Large board slot 4 is empty, therefore no physical name is assigned for slot 4.

A port's physical name is used as the default logical name for a communication line. For example, the default logical name for a line connected to LIM 0, port 0 on a DI is \$LIM0\_PORT0.

The physical name for a terminal device is made up of:

- \$
- The type of terminal device.
- The last six digits of the 12-digit hexadecimal system ID to which the terminal is connected.
- The LIM number to which the terminal is connected.
- The port number which is connected to the communication line leading to the terminal device.
- The cluster address for the terminal device.
- The device address for the terminal device.

For example, given a terminal device configuration with the values:

```

System ID:      08002510003C
LIM number:     4
Port number:    2
Device type:    console
Cluster address: 00
Device address: 01

```

the terminal device would have the following physical name, which is the default logical name,

```
$CONSOLE_10003C_4200010000
```

## Logical Names

Logical names allow you to give descriptive names other than physical names to network components, names which may be more immediately meaningful to your site than the physical names. For example, your site may choose to develop a descriptive naming scheme for communication lines. Defining short, descriptive logical names for DIs makes it easier for you to specify the system name when sending commands to DIs, rather than specifying the entire physical name. If logical names are not defined for components on configuration commands, the default logical name is the component's physical name. For example, if you do not define a logical name for a line, the line assumes a default name which is the physical name of the LIM and port to which the line is connected. If the line is connected to port 3 on LIM 1, then the default logical name for the line is the port's physical name: \$LIM1\_PORT3.

The CDCNET Configuration Guide contains conventions for creating logical names, and a table that shows the construction of logical names. The default logical names for network components are shown in the DEFINE command descriptions in the CDCNET Commands Reference manual.

A NETOU command, DISPLAY\_LOGICAL\_NAMES, displays the logical names defined for a DI, such as logical names for trunks, network solutions, and communication lines. See the command description in the CDCNET Commands Reference manual.

Example logical names:

Device interface names

North\_Bldg\_TDI\_1

MDI\_3C (for a DI with a system ID of 0800251003C)

TDI\_134 (for a DI with a serial number of 134)

Trunk names

ESCI3

MCI2

Network names

Network\_1

ESCI\_Network

Line names

Engineering\_Port\_1

Line12 (for a line on \$Lim1, Port 2)

Compsci\_02



## Addresses and Titles

Each DI has a unique address and title that identifies its location in the network. DI addresses are assigned during hardware installation. DI titles are assigned during software configuration. A configuration command (`DEFINE_SYSTEM`) may be used to define a logical name for the DI. The logical name maps to the DI's title and address. The system title is created from this logical name and from the default logical name. The difference between a title and other logical names known by a DI system is that titles are registered with a service called Directory Management Entity (ME) and may be known throughout the catenet; other logical names such as line names are local to the individual DI system. System titles are known throughout the catenet.

For example, suppose a DI is installed with the system ID of 0800252A1FF2 hexadecimal. This system ID is a part of its system address. During software configuration, the DI is defined as a TDI with the logical name `First_Floor_TDI`. The system title is then `$SYSTEM_FIRST_FLOOR_TDI`. You, as the system operator at configuration time, do not actually enter the portion of the system title represented by `$SYSTEM_`. The portion of the system title represented by `$SYSTEM_` is the common prefix for all system titles assigned by convention. The NETOU generates this common prefix automatically. When operations commands are sent to this TDI, the logical name can be specified as the destination of the command and is interpreted as corresponding to the DI's system address and title, with the command received at the correct destination.

Network operations commands can also be sent to DIs by specifying their default logical names, which are described in the Physical Names section of this chapter.

It is important to keep track of titles, addresses and logical names. For suggestions on maintaining complete and accurate records of titles, addresses, and other network information, see the Recordkeeping section in chapter 4.

## Network Configuration

The material in this section is intended to provide background information on the logical and physical configuration processes that ready CDCNET for operations. You do not have to understand the logical configuration process completely in order to perform the tasks described in this manual. Both the logical and physical configuration process should be completed by other site personnel by the time you begin CDCNET network operations. Defining and maintaining your site's initial logical configuration is the responsibility of the site administrator (the site administrator's responsibilities are documented in the CDCNET Configuration Guide).

CDCNET configuration involves planning and installing the network's hardware (physical configuration) and preparing the software used to run the network (logical configuration). Both physical and logical configuration must be completed before CDCNET can be operational.

### Physical Configuration

The CDCNET Hardware Installation and Troubleshooting manual explains how device interfaces (DIs) and other network hardware components, including LAN cables and components (transceivers, repeaters, and multiplexers), are installed. This phase of configuration involves planning the physical layout, installing cables and lines, installing boards in the DIs, connecting the DIs to the network communications media, and ensuring that all the required hardware is present.

## Logical Configuration

Logical configuration involves planning and preparing the software which runs in the DIs. The logical configuration is a description of functions of the DI and components connected to it. This description is in the form of configuration commands that define characteristics for the software which runs in the DIs. For example, configuration commands can be used to define the logical names of DIs and trunks and network solutions, to declare the line speeds for communication lines, and to define characteristics of batch devices such as printers and card readers. Configuration commands can also be used to define logical names for network components, such as DIs, trunks, network solutions, communication lines and terminal devices.

Logical configuration is necessary because DIs cannot function if they do not contain the software necessary to perform network tasks and operations.

The CDCNET Configuration Guide describes logical configuration. Logical configuration is the responsibility of a CDCNET site administrator, and should be accomplished prior to your beginning network operations. Occasionally during network operations, you may be directed to change the logical configuration while the network is running. For more information, see Changing Network Logical Configurations in the CDCNET Configuration Guide.

## Network Validation

Network Validation is a feature that provides system security by requiring users to enter a valid username and password to use CDCNET. This username and password is in addition to login requirements for NOS/VE or other hosts. Network Validation is configured on a DI-by-DI basis and you can add it to any line serviced by the Asynchronous TIP, X.25 Asynchronous TIP, or Telnet TIP.

On a line configured for Network Validation, the DI prompts for a username and password before processing any user commands or executing any terminal user procedures. Terminal support software in the DI compares the entered and encrypted password with the one stored for the username. If the two passwords match, the user is accepted and normal processing continues. If the passwords do not match or the user does not have a password, the DI returns an error response and prompts the user to try again. This cycle repeats until either the proper password is entered, the retry limit is reached, or the connection times out.

The DI obtains the valid encrypted password for a username from the network validation database. This database is kept by the NOS/VE host providing file service to the DI. A site can use the `LOAD_FILE` command to load a DI with the validation files for users expected for that DI. However, each time the database changes the DI must be reloaded with the updated version. The network validation database is created and maintained with the Administer Network Validations utility. See the NOS/VE Network Management manual for more information.

The Network Validation feature also stores information on how network resources are being used. A network administrator can obtain this information from log messages and NPA reports. See the Configuration Guide for information on configuring Network Validation in a DI.

## NTF Remote System Configuration

The Network Transfer Facility (NTF) is an application providing a fully symmetric queued file transport facility between a NOS/VE host and another host in a geographically dispersed network. Support for NTF is similar to batch device support for NOS/VE and CDCNET. NTF support on NOS/VE is similar to NJEF on NOS.

NTF supports IBM's Network Job Entry (NJE) protocol and HASP multileaving protocol for communication between hosts. The NTF network can include any of the following hosts:

- Multiple CYBERs running NOS/VE with NTF
- Multiple CYBERs running NOS with RBF or Network Job Entry Facility (NJEF)
- Multiple CYBERs running NOS/BE with INTERCOM5
- Multiple IBM, VAX, or other vendors' systems which support NJE and/or HASP

See the Configuration Guide for detailed information on NTF.

## Network Operator Utility (NETOU)

The Network Operator Utility (NETOU) supports the set of commands and features used to monitor, control, and logically reconfigure CDCNET. NETOU supports commands to control the network from your operations station. Operations commands can be divided into the following types:

- Session control
- Network control

### Session Control

Session control involves setting up and controlling your operations session. Examples of session control include controlling which DIs send alarm messages to your operations station, and routing NETOU command responses to a file that serves as a record of the responses. These activities do not actually control or change the network. See the CDCNET Commands Reference manual for descriptions of the commands used for session control.

### Network Control

Network control activities include monitoring, controlling, and dynamically changing the logical definition of network equipment. See the CDCNET Commands Reference manual for descriptions of the commands used for network control.

### Network Delay Measurement

Network delay measurement measures the average network delay time against a user-specified delay-time threshold. This allows you to evaluate the performance against a response threshold and report an error condition. See chapter 4 of this manual for detailed information on network delay measurement.

## Network Performance Analyzer

The CDCNET Network Performance Analyzer (NPA) is a network analysis tool made up of flexible modular software components resident in a Control Data host computer. NPA helps you analyze the performance of your network by producing a variety of reports. These reports allow you to:

- Identify the configuration of your network
- Identify actual and potential hardware and software failures
- Identify potential congestion on communication lines
- Determine if your network is performing correctly
- Evaluate network use

## NPA Reports and Report Formats

You may generate NPA reports individually to reflect a specific aspect of the network's performance, or you may generate a group of reports that reflect an overall picture of the network. Use NOS or NOS/VE commands to choose which report or set of reports NPA produces and the time period that your reports cover.

## How To Create Customized NPA Reports Using IPF2 Database Files

You may also create NPA reports that are tailor-made for your specific needs. The IPF2 database files provide a process to change standard NPA reports. See chapter 7 for specific information on how to create customized NPA reports.

## Device Interface Dump Analyzer

The DI Dump Analyzer program resides on a Control Data host computer and runs under NOS/VE or NOS. It processes subcommands that extract and format the information collected when DI memory is written to a dump file. The Dump Analyzer helps troubleshoot CDCNET by identifying events that have caused its DIs to reset.

Dump Analyzer subcommands let you display information about the conditions that existed at the time of the reset, including:

- **Important data structures**
- **Contiguous memory**
- **Program call chains**
- **Task control information**

## Network Analysis

Analyzing the network requires a thorough understanding of the network, its configuration, and the CDCNET software that runs in DIs and on the host computer. Some advanced activities use several different programs that are not a part of NETOU. Other advanced activities can have a major effect on the network's performance, such as shutting off a DI or changing the network's logical configuration. Because advanced operations activities can affect the network's performance, your site may choose to have an analyst perform them, or to have you perform the activities under an analyst's supervision. Advanced operations activities include starting and stopping a gateway, stopping a DI, making online network configuration changes, and loading and unloading CDCNET software.

When problems occur in the network (such as users being unexpectedly disconnected from host services), CDCNET network commands can be used as a first step in troubleshooting. Network commands can be used to gather information about a problem and to isolate failures. Depending on the situation, you may be able to fix the problem yourself, using the available operations commands, or you may have to refer the problem to an analyst or customer engineer (CE). See the CDCNET Hardware Installation and Troubleshooting manual for more information on troubleshooting procedures.

## Remote Line Monitor

The NOS/VE Remote Line Monitor monitors all received and transmitted characters on a given LIM and port. The given LIM and port must be supported by standard CDCNET CIM Firmware. See chapter 10 of this manual for detailed information on the Remote Line Monitor.

# Network Operator Utility (NETOU)

2

|  |      |
|--|------|
| Common Network Operations Features .....               | 2-1  |
| Command Syntax .....                                   | 2-1  |
| Command Format .....                                   | 2-1  |
| Command Abbreviations .....                            | 2-2  |
| Parameter Abbreviations .....                          | 2-2  |
| Parameters and Parameter Values .....                  | 2-2  |
| Default Parameter Values .....                         | 2-3  |
| Command Entry .....                                    | 2-3  |
| Command Verbs .....                                    | 2-3  |
| Add .....  | 2-4  |
| Cancel .....   | 2-4  |
| Change .....   | 2-4  |
| Define .....   | 2-4  |
| Delete .....   | 2-4  |
| Display .....  | 2-5  |
| Start .....  | 2-5  |
| Stop .....   | 2-5  |
| Order of Command Execution .....                       | 2-5  |
| Command Responses .....                                | 2-6  |
| Command Response Format .....                          | 2-6  |
| Common Responses .....                                 | 2-8  |
| Loss of Commands and Responses .....                   | 2-9  |
| Break Processing (Response Suppression) .....          | 2-9  |
| Response Suppression on NOS/VE .....                   | 2-9  |
| Response Suppression on NOS .....                      | 2-10 |
| Alarms .....   | 2-10 |
| Alarm Format .....                                     | 2-11 |
| Alarm Output .....                                     | 2-11 |
| Severity Levels for Command Responses and Alarms ..... | 2-11 |
| Informative .....                                      | 2-12 |
| Warning .....  | 2-12 |
| Error .....  | 2-12 |
| Fatal .....  | 2-12 |
| Operations in a NOS/VE Environment .....               | 2-13 |
| Accessing NETOU .....                                  | 2-13 |
| Prompts for NETOU .....                                | 2-15 |
| Paging .....   | 2-15 |
| NETOU Terminal Display Format .....                    | 2-15 |
| Exiting NETOU .....                                    | 2-15 |
| Entering Network Commands .....                        | 2-16 |
| SEND_COMMAND (NOS/VE Version) .....                    | 2-16 |
| SEND_COMMAND Example .....                             | 2-16 |
| Operations in a NOS Environment .....                  | 2-17 |
| Network Operations from an Interactive Terminal .....  | 2-19 |
| NETOU Terminal Display Format .....                    | 2-19 |
| Login .....  | 2-19 |
| Selecting an MDI or MTI .....                          | 2-20 |
| Creating a Prolog .....                                | 2-21 |
| Prompts .....  | 2-21 |
| Paging .....   | 2-22 |
| Displaying Job Status Information .....                | 2-22 |

|   |      |
|---|------|
| Logout .....  | 2-22 |
| Network Operations from a NOS Host Console .....              | 2-23 |
| NETOU K-Display Format .....                                  | 2-23 |
| Login .....   | 2-24 |
| Logout .....  | 2-25 |
| Exiting and Resuming NETOU Sessions .....                     | 2-25 |
| Prompts .....   | 2-26 |
| Paging .....  | 2-27 |
| K-Display Console Entry Restrictions .....                    | 2-27 |
| Entering Characters Not Supported at a NOS Host Console ..... | 2-28 |
| Continuing Commands .....                                     | 2-30 |
| Command Syntax for NOS NETOU .....                            | 2-30 |
| Entering NETOU Commands on NOS .....                          | 2-31 |
| SEND_COMMAND (NOS Version) .....                              | 2-31 |
| NOS SEND_COMMAND Examples .....                               | 2-31 |

This chapter describes the Network Operator Utility (NETOU), as used in NOS/VE and NOS environments. NETOU allows you to access CDCNET and perform network operations activities from a remote terminal or from a host console.

The command syntax is the same whether you are at an interactive terminal or host console. However, some aspects of terminal and console command entry, display and screen control are different. This chapter explains those differences.

Since NETOU has some different features on NOS/VE and NOS, the chapter is divided into three sections:

- Common Network Operations Features
- Operations in a NOS/VE Environment
- Operations in a NOS Environment

## NOTE

If you are doing operations on a CDCNET Network Management Station, refer to the CDCNET Network Management Station manual. The CDCNET Network Management Station has a utility similar to NETOU.

## Common Network Operations Features

This section describes features of NETOU that are common to both NOS/VE and NOS operations environments. The following features are described: Command syntax rules, descriptions of common command verbs, order of command execution, command responses, alarms, and severity levels for responses and alarms.

### Command Syntax

This section outlines the syntax rules for the CDCNET commands described in this manual. All commands follow a subset of the NOS/VE SCL syntax. This section is provided to give you sufficient information to understand the commands used in this manual. For more information on SCL command syntax, see the NOS/VE Commands and Functions manual. Commands used in a NOS environment have additional properties (see Command Syntax for NOS NETOU later in this chapter).

### Command Format

A command is in the following form.

```
command_name parameter_1=value_1,parameter_2=value_2,...
```

Example:

```
DISPLAY_HARDWARE_STATUS DEVICE_NAME=$LIMO_PORT0,DISPLAY_OPTION=EXPANDED
```



Either a blank or a comma can be used as a separator. The underscore character cannot be omitted. Command strings may be up to 256 characters long. The maximum size of a SEND\_COMMAND command (SEND\_COMMAND plus command to be sent) is 512 characters on NOS and 65K on NOS/VE. You may continue entering a command on another entry line using the ellipsis (..), as shown in the following example.

```
senc c='start_process_metrics p=commands,...
g=(summary,expanded)',s=mdi_3
```

### Command Abbreviations

Command names are abbreviated by taking the first three characters from the verb portion of the command name and combining them with the first character from the remaining words in the command. The abbreviated form of a command name having a plural form is the same as the abbreviation for the singular form.

For example, DISPLAY\_HARDWARE\_STATUS is abbreviated by taking DIS from DISPLAY and combining it with the H from HARDWARE and the S from STATUS to form.

DISHS

### Parameter Abbreviations

Parameter names are abbreviated by taking the first character from each word in the parameter name. For example, the parameter LINE\_NAME has the abbreviated form LN.

### Parameters and Parameter Values

Parameters consist of a parameter name followed by an equal sign and a parameter value. A parameter value may be a list of values, as in:

```
parameter=(value_1,value_2,...)
```

or a list of lists, as in:

```
parameter=((value_1,value_2),value_3,(value_4,value_5...)...)
```

The following types of parameter values are allowed: string, name, integer, boolean, and keyword value.

A string is any sequence of ASCII characters enclosed by apostrophes ('). Most of the network operations commands must be entered as a string value within SEND\_COMMAND. The enclosed command string must be surrounded by apostrophes. If you include an apostrophe within a string value, you must use two consecutive apostrophes for the embedded apostrophe character to be recognized, as in the following example.

```
send_command c='write_terminal_message,...
m=(''New communications configuration tomorrow'', ''Network down ..
until 10:00.'')',s=td11
```

An SCL name is a combination of from 1 through 31 alphabetic characters (ASCII characters A through Z and a through z), digits (ASCII characters 0 through 9), and/or special characters (underline [\_], dollar sign [\$], number sign [#] and commercial at [@]). Lowercase is folded to uppercase in a name. The first character cannot be a digit.

An integer parameter value represents a binary, octal, decimal, or hexadecimal integer value. Integer values may be expressed as a combination of digits or for hexadecimal integers, A through F (uppercase or lowercase). A hexadecimal integer must begin with a digit. SCL makes no distinction between uppercase and lowercase characters in hexadecimal integer constants.



Integer parameter values may be expressed as: integer (radix), or a range of integer values. If you do not specify a radix, the decimal system (base 10) is assumed. Any radix between 2 and 16 is accepted. A radix must be surrounded by opening and closing parentheses, as in 1FFFF(16) and 101(8).

In command descriptions, when two integers are separated by an ellipsis (..), a range of integer values is possible. The allowed value may be the first value through the second value. For example, the parameter value BUFFER\_SIZE = 64..4096 indicates that any value from 64 through 4096 is possible for the BUFFER\_SIZE parameter.

A boolean parameter value represents a condition of either TRUE or FALSE. In NOS/VE systems, there are three possible words used for both TRUE and FALSE conditions. For a TRUE condition, you may specify TRUE, YES, or ON. For a FALSE condition, you may specify FALSE, NO, or OFF. In NOS systems, NETOU only supports YES and NO.

A keyword value is a parameter value that has a special meaning in the context of a particular parameter. For example, the command DEFINE\_LINE has a parameter LINE\_TYPE, where two types of lines, switched and dedicated, are allowed. Two keyword values are allowed for this parameter: SWITCHED and DEDICATED. You specify one or the other by providing the appropriate keyword value for the parameter. The keyword value ALL is frequently used in commands to select all available options for a parameter value.

### Default Parameter Values

Not all parameters require you to provide values. In the command descriptions, required and optional parameters are designated. Most parameters have a value called a default parameter value that is provided if you do not specify the parameter with the command. Default parameter values are specified in command descriptions.

### Command Entry

You can enter the parameters in this manual in two ways.

- Position-dependent
- Position-independent

In position-dependent format, you supply values for parameters in the order specified in the command format, without entering parameter names or equal signs. Separate parameter values with commas. If you omit any parameters, you must supply a comma for the missing parameter.

In position-independent format, you supply the values for the parameters by specifying the parameter name and the equal sign before the value for each parameter. You can enter the parameters in any order.

### Command Verbs

This section explains the verbs used in several common network operations command types. Commands beginning with these words comprise the majority of network operations commands.

## **Add**

Add commands add to the logical configuration of an element you specify. Add commands are a part of the set of configuration commands, and are used in DI configuration files.

## **Cancel**

Cancel commands delete the logical configuration of the element you specify. For example, you may cancel the logical configuration of an Ethernet network solution using the `CANCEL_ETHER_NET` command. The network solution's logical configuration is deleted. If you want the network solution to support data transfer again, you must redefine the network using a `DEFINE` command type (see following descriptions).

## **Change**

Change commands change the current logical configuration of a hardware component, the values of certain aspects of a DI's operating system such as buffer size and memory management, or the set-up of the network's system for reporting alarms.

## **Define**

Define commands create a logical configuration of the element you specify in the network. Define commands are a part of the set of configuration commands, and are used in DI configuration files. These commands are also used if you cancel a component's logical configuration and want to redefine it.

## **Delete**

Delete commands delete from the logical configuration of an element you specify. For example, you may delete an X.25 gateway outcall title, which was previously added by an `ADD` command, from the logical configuration of the X.25 gateway.

## Display

Display commands return information you request to your operations terminal or console screen. There are display commands to display the following information.

- Status for hardware and software elements of a DI.
- Configuration parameters for network elements.
- The list of log messages and alarms to be transmitted from a DI.
- The current date and time registered at a specific DI.
- Diagnostic test results.

For commands that display several parameters, you can select which parameters you want displayed. These commands have a parameter called `DISPLAY_OPTION` (DO), which allows you to specify only parameters that are of interest to you. You may choose one, several, or all of the options that a `DISPLAY_OPTION` parameter allows.

For example, the `DISPLAY_SYSTEM_OPTIONS` (DISSO) command, which displays the current value of DI system program attributes, has a `DISPLAY_OPTION` parameter. `DISPLAY_OPTION` allows you to choose from among several configuration attributes you want displayed, by specifying keyword values such as `DATA_BUFFER_SIZE`, `BUFFER_PERCENTAGE`, `MEMORY_MANAGER_PERIOD`, and `CLOCKING_SYSTEM`.

## Start

Start commands begin the specified action, or enable the specified component to begin data communications. Some start commands make an element you specify operational, or ready for data transfer. For example, you may start communications traffic on a communication line from a LIM to a terminal using the command `START_LINE`. Other start commands begin online diagnostic tests (such as `START_CIM_TEST` and `START_ESCI_TEST`), and statistics collection (such as `START_LINE_METRICS` and `START_NETWORK_METRICS`).

## Stop

Stop commands end the specified action, or disable the specified component from performing data communications. Some stop commands stop the support of data transfer on the network element you specify, such as `STOP_LINE` and `STOP_NETWORK`. Other stop commands stop diagnostics, and statistics collection.

## Order of Command Execution

Commands you send to a DI are executed in the order received. Commands from operators at different stations that affect overlapping sets of DIs may be received in a different order at each DI. If there is more than one CDCNET network operator currently logged in and sending commands, there is no guarantee that commands sent from one network operator to network components are performed in sequence before those sent from another network operator.

## Command Responses

All commands entered generate a response. This section describes command responses.

## Command Response Format

CDCNET command responses have the following format (brackets indicate optional portions of the response).

[illegible]

```

tttttttttt... Logical or physical name of system sending response.

```

cccc Numerical identifier for the command response. NOS/VE does not display this identifier for informative command responses; NOS does. Using the message number, you can reference the command response's description in the online CDCNET Diagnostic Messages manual.

ssssssssss Severity level of command response (see Severity Levels for Command Responses and Alarms, later in this chapter) This severity level is not displayed for every response. If no severity level is displayed, the response is informative and the command has completed successfully.

**response text**      The response text may either directly follow the severity level or begin on the next line.

For NOS/VE environments, a normal CDCNET command response is written to the output file when it includes response text. An abnormal CDCNET command response is always written to the standard file \$RESPONSE.

The following is an example command entry and command response (NOS host). It shows a command called `DISPLAY_HARDWARE_STATUS` (DISHS) being sent to a DI, and the response sent back to the network operator.

Command:

```
senc s=mdi_1,c='display_hardware_status'
```

Command response:

```
FROM MDI_1                                33021
Hardware Status
device name    status    state    version    lim/bank/port    type
$MPB0          on        active   0000
$PMM1          on        active   0008
$SMM2          on        active   0001        2
3             off
$CIM4          on        configured 0001        0,1,2,3
$CIM5          down      not config. 0001
$ESCI6         on        active   0000
$MCI7          on        active   0000
$LIM0          on        not config.    4          RS232
$LIM1          down      configured    4          RS232
$LIM2          on        configured    2          RS449
$LIM3          on        not config.    2          RS449
```

The following is an example command entry and command response (NOS/VE host). It shows a command called `DISPLAY_HARDWARE_STATUS` (DISHS) being sent to a DI, and the response sent back to the network operator.

Command:

```
senc s=mdi_1,c='display_hardware_status'
```

Command response:

```
FROM MDI_1
Hardware Status
device name    status    state    version    lim/bank/port    type
$MPB0          on        active   0000
$PMM1          on        active   0008
$SMM2          on        active   0001        2
3             off
$CIM4          on        configured 0001        0,1,2,3
$CIM5          down      not config. 0001
$ESCI6         on        active   0000
$MCI7          on        active   0000
$LIM0          on        not config.    4          RS232
$LIM1          down      configured    4          RS232
$LIM2          on        configured    2          RS449
$LIM3          on        not config.    2          RS449
```



Other examples (NOS host):

```
send_command c='display_date_and_time',s=di_sn093
```

```
FROM DI_SN093                                33525
System date and time
31/01/85 23:20:24
```

Other examples (NOS/VE host):

```
send_command c='display_date_and_time',s=di_sn093
```

```
FROM DI_SN093
System date and time
31/01/85 23:20:24
```

## Common Responses

The following command responses are common to all network commands.

- Responses indicating that the DI or component cannot be located or is unavailable may occur for any command sent to a DI.
- Error responses indicating unknown commands, invalid parameters, and incorrect parameter values (command parser errors which abort execution of commands).

These common responses are not documented with the commands responses. Only responses that are uniquely defined for the command are documented. All command responses are documented in the online CDCNET Diagnostic Messages manual.

## Loss of Commands and Responses

Network commands to specific DIs are sent by transport connections that ensure commands are delivered to the correct DI and that loss of commands in transmission cannot occur. However, a destination DI could fail while the command is executing, or the command processor in the DI could stop abnormally. To allow for such events, NETOU times the response for any command and declares a command failed if no response is received from the CDCNET system within 120 seconds after the command is sent. For commands that do not send a response within 120 seconds, the following response is sent.

NOS example:

```
--ERROR-- No response received from system <name> for the CDCNET command
<command_name>.
```

NOS/VE example:

```
--ERROR--No response received from system <name> for the last CDCNET command
```

## Break Processing (Response Suppression)

With break processing, you may suppress responses to network commands in progress (keep any output from commands from being displayed on your screen). Commands with suppressed responses complete, but no response for the commands are delivered to your operations station.

Command response suppression does not abort command processing. You cannot abort commands that are being processed at the destination DIs. Once received at a DI, commands complete regardless of what you enter from your terminal or the host console. When you suppress responses, the next command entry prompt (nou/ on NOS/VE and NOU/ on NOS) indicates the end of response suppression. Commands entered after you receive that prompt execute normally and return responses.

## Response Suppression on NOS/VE

On NOS/VE, you initiate response suppression by entering the user\_break\_2 at an interactive terminal. If an included file is executing when response suppression is initiated (see Building Command Files, in chapter 3 of this manual) response suppression both suppresses responses for commands in progress and terminates NETOU processing of the file.

When a user break sequence is entered, NETOU responds with the Terminal Manager response to a user break. The response to the user break also identifies commands for which responses have not been received and commands that have unknown destinations. The following messages are used to indicate these conditions.

```
No response received from system <string> for the last CDCNET command.
```

```
System <string> is unknown.
```

```
No response received to connect request to system <string>.
```

## Response Suppression on NOS

On NOS, when a break command is issued, some commands sent to a DI may still be processed, and others may have the output discarded. You initiate response suppression using one of the following methods.

- At an interactive terminal, enter the `user_break_1` or `user_break_2` sequence. NETOU responds with the following message.

Pending responses suppressed

- At a host console, enter `K./`

You can enter a command response suppression command while a file of network operations commands is being executed (see *Building Command Files* in chapter 3 of this manual). Command response suppression both suppresses responses and terminates NETOU processing of the command file.

## Alarms

Alarms may be sent from DIs to your operations station during an operations session. These alarms are unsolicited; they are not responses to commands, and you may receive them at any time during an active NETOU session.

On NOS, alarms are always activated. You do not have to enter a command to activate their transmittal to your operations station. In NOS/VE environments, alarms are not initially activated. You must explicitly activate alarms by entering the `ACTIVATE_ALARMS` command before you can receive alarms. Rather than manually activating alarms every time you begin an active NETOU session on NOS/VE, you can automatically activate alarms through your NETOU prolog by placing the appropriate commands in your prolog. See *Session Control on NOS/VE* in chapter 3 of this manual.

Alarms alert you to a wide range of conditions that occur in a network, from the completion of a diagnostic test to the failure of a hardware component. In addition, any messages sent to you from the network's terminal users appear as alarms at your display.

When a DI completes being loaded and logically configured, alarms generated during the logical configuration are sent to your operations station.

Much of your network operations work involves responding to CDCNET alarms.

## Alarm Format

CDCNET alarms have the following format (brackets indicate optional portions of the response).

```
***** ALARM FROM tttttttttttttttttttttttt date/time ccccc
[--ssssssssssssssss-- ]alarm text
```

|               |   |
|---------------|---|
| tttttttttt... | Logical or physical name of system sending alarm. An alarm generated by NETOU itself, such as an alarm issued when an MDI connection is broken, displays NETWORK_OPERATOR_UTILITY in this field.  |
| cccccc        | The numerical identifier for the alarm message. This identifier is displayed for all alarms and is intended to help you index into the online CDCNET Diagnostic Messages manual for a description of the message.   |
| ssssssssssss  | Severity level of the alarm (see Severity Levels for Command Responses and Alarms, later in this chapter). This field is suppressed for informative alarms; if no severity level is displayed, the alarm is informative. Informative alarms may indicate the completion of an operation (such as a diagnostic), the recording of information (such as statistics), or convey a message from a terminal user. Informative alarms are not the result of incorrect or incomplete CDCNET operation. |

The following is an example of an alarm:

```
***** ALARM FROM DI_SN093                85/01/31  23.24.31  458
New maximum recovery rate
Failure ID = 0013
Threshold count = 1
Period in seconds = 2
```

## Alarm Output

When alarms are sent to you, they are immediately displayed at your screen unless you specifically route alarms to a file only, using the ROUTE\_ALARM command on NOS, or connect the alarm output to a file on NOS/VE.

Alarms appear in the order received. At an interactive terminal, alarms are not displayed while you are entering input. Should an alarm be delivered to your terminal, an alarm bell rings only at interactive terminals, and only on NOS NETOU. At an interactive terminal or host console, alarms may be interspersed within the responses to commands.

## Severity Levels for Command Responses and Alarms

The command responses and alarms you receive are grouped into the following severity levels: Informative, Warning, Error, and Fatal.

Informative and Warning command responses indicate a command completed successfully. Error and Fatal are both error responses alerting you to command errors. The following paragraphs are descriptions of these severity levels.

## **Informative**

An Informative command response indicates successful command completion. Informative alarms are not the result of incorrect or incomplete CDCNET operation. The severity level for informative responses and alarms is not displayed. If you receive a response or alarm without a severity level displayed, the response or alarm is informative.

## **Warning**

A Warning command response indicates that a command completed successfully, but that the command may have unintended effects. For example, some of the definition parameters for a communications trunk may be changed while the trunk is active. Changing those parameters, however, could disrupt communications over the trunk, unless changes at both ends of the trunk are coordinated. Warning responses are sent for redundant commands.

Warning alarms alert you to potential network problems. They indicate that a DI or network is approaching an error or fatal condition, such as a lack of system buffers. However, no operation is yet incorrect or incomplete due to the condition. Check the alarm's text to determine what you can do to avoid errors in the network.

## **Error**

An Error command response indicates that a command failed due to operator error. An error response may indicate, for example, errors detected in command processing, errors in parameters, such as unknown names, and attempts to execute a command which is not allowed. Error responses may also indicate that a connection could not be established to deliver a command to its destination system.

Error level alarms indicate the following: the failure of an operation to complete correctly, with the possibility of being recovered by the DI's software; and the failure of a device connected to the DI, such as the loss of a modem signal or communication line.

## **Fatal**

A Fatal command response indicates that a command failed due to device failures or lack of resources to complete the command. For example, if there is not enough memory available on a DI hardware device to execute a command, a Fatal-severity level response would be returned.

Fatal alarms indicate the following: the failure of an operation to complete correctly, without the possibility of being recovered (such as the failure of DI system software); and the failure of tasks in the DI system software.

## **NOTE**

---

When you receive fatal alarms, it is important to intervene when possible to prevent a system failure.

---

## Operations in a NOS/VE Environment

Figure 2-1, NETOU Operating Environment for NOS/VE, shows the major software and hardware components that provide the operations environment on NOS/VE. For NOS/VE environments, NETOU consists of the CYBER-resident NETOU application, and the Dependent Command Management Entity resident in each DI. On NOS/VE, you log into a NOS/VE service title, and enter a command to invoke NETOU. Selecting NETOU allows you to add the subset of NETOU session and network control commands to the NOS/VE commands you are currently allowed to enter. You may continue to enter other NOS/VE commands during any active session with NETOU.

### Accessing NETOU

Before accessing NETOU, you must connect to a service on the host system to begin an interactive terminal session. Use the `CREATE_CONNECTION` (CREC) and the service title defined at your site through the `Manage_Network_Applications` Host Utility. The following is an example of a connection to a service on NOS/VE entitled, NVE.

```
create_connection nve
```

If you need to review how to use the `CREATE_CONNECTION` command, see the Terminal Interface manual.

To access NETOU, first log in to NOS/VE using the standard NOS/VE login process.

You must be validated to use NETOU. Access to NETOU is controlled by the NOS/VE operating system. Your site's family administrator, through the Administer Validation Utility, controls the NETOU privileges available to you. Check with your site's administrator if you are not validated to use NETOU.

To use NETOU, enter the following NOS/VE command after you have logged in.

#### **NETWORK\_OPERATOR\_UTILITY (NETOU or NOU)**

*PROLOG = file reference*

*STATUS = status variable*

Both parameters are optional. The `PROLOG` parameter specifies a file containing commands to be executed once NETOU is invoked. Any NOS/VE or NETOU command can be in the prolog. The default file reference for the `PROLOG` parameter is `$USER.NETWORK_OPERATOR_PROLOG`. If you do not specify this parameter and the default prolog file does not exist, no prolog file processing occurs. For more information on prologs, see *Creating a Prolog* in chapter 3 of this manual. For information on the `STATUS` parameter, see the basic status concept for NOS/VE SCL in the NOS/VE System Usage manual.

You may add the NETOU command to your NOS/VE prolog (see the System Access chapter of the SCL for NOS/VE Commands and Functions manual), so that NETOU is automatically invoked each time you log in.




Figure 2-1. NETOU Operating Environment for NOS/VE

## Prompts for NETOU

The prompt for NETOU is:

```
nou/
```

This prompt indicates that you have selected NETOU and can begin entering NETOU commands. You may also enter other NOS/VE commands.

You may also receive the following prompt for NETOU.

```
nou../
```

This prompt indicates that the previous line you entered was continued to another line.

## Paging

Paging allows you to move forward within a display on the terminal screen. You may enable or disable paging using the CDCNET terminal command `CHANGE_TERMINAL_ATTRIBUTES (CHATA)`. To do this, enter the network command character (NCC) (shown here as a percent sign [%], but the actual NCC may differ for your terminal), and the `CHANGE_TERMINAL_ATTRIBUTES` command, as in the example that follows. You may also enter the `CHANGE_TERMINAL_ATTRIBUTES` command without a preceding network command character to cause the host version of the command to execute.

```
%CHANGE_TERMINAL_ATTRIBUTES HOLD_PAGE=ON or OFF
```

ON enables paging; OFF disables paging. The default is for paging to be OFF. When paging is on, to scroll to the next page of text, enter a carriage return or a control character. For more information about the `CHANGE_TERMINAL_ATTRIBUTES` command and the network command character, see the Terminal Interface manual.

## NETOU Terminal Display Format

NETOU at a terminal uses virtual line mode format (as opposed to full screen mode) for display output. Commands are entered and responses are returned line by line. You use some utilities to perform network operations tasks that use full screen mode. These utilities run outside of NETOU, and include the Network Performance Analyzer (NPA), and the Manage CDCNET Configuration Utility (MANCC).

## Exiting NETOU

To exit NETOU, enter the QUIT command.

```
quit
```

When you enter QUIT, you can exit NETOU and still remain logged in to the service. QUIT removes the NETOU commands from the set of commands you are allowed to enter. The LOGOUT command both terminates NETOU and logs you out of Timesharing.



## Entering Network Commands

NETOU commands are valid only within a NETOU session. The session begins when you enter the NETOU command to invoke NETOU. The session ends when you enter the QUIT command. You use SEND\_COMMAND to send network commands to the appropriate destination.

### SEND\_COMMAND (NOS/VE Version)

A network command is embedded within SEND\_COMMAND as a string value, and another parameter sets the destination for the network command. SEND\_COMMAND has the following format on NOS/VE.

```
SEND_COMMAND
  COMMAND = string
  SYSTEM = list of name
  OUTPUT = file name
  STATUS = status_variable
```

There are two required parameters: COMMAND and SYSTEM. COMMAND is the CDCNET operations command to be sent to the specified DI. The command is entered as a string value enclosed by apostrophes (').

### NOTE

---

If the command you are sending contains any apostrophes, you must use two consecutive apostrophes for the embedded apostrophe character to be recognized. Otherwise, NETOU assumes the embedded apostrophe signals the end of the NETOU command, and errors could result.

For example, the following command contains an embedded apostrophe in the message being transmitted to all terminals connected to TDI1.

```
send_command c='write_terminal_message,...
m=''ENGINEERING''''s network down until 10:00''',...
s=tdi1
```

---

SYSTEM is the logical or physical DI name or list of DI names to which the command is to be sent. If a CDCNET command is sent to more than one CDCNET system, a response must be received from each system for the command to complete. The other parameters are optional.

### SEND\_COMMAND Example

The following command sequence would be entered to stop traffic on a communications line connected to a DI named TDI\_3.

```
send_command command='stop_line line_name=line3',system=tdi_3
```

The actual command to stop communications traffic is enclosed within a SEND\_COMMAND command that specifies the DI (TDI\_3) to which the line is connected.

## Operations in a NOS Environment

Figure 2-2 shows the major software and hardware components that provide the operations environment on NOS. On NOS, NETOU is an application that you select as you would other NOS applications, such as Interactive Facility (IAF). For the NOS environment, NETOU consists of the CYBER-resident NETOU application; the Operator Support Application (also known as the Independent Command ME) which resides in MDIs/MTIs that have been chosen, during logical configuration, to provide operator support; and the Dependent Command ME which is resident in each DI in the network. When you select NETOU, your job is dedicated to NETOU until you exit that application. Commands other than NETOU session and network control commands are not accepted.

On NOS, NETOU can be used either at a remote terminal or a NOS host console. On the NOS host console, NETOU runs through the NAM K display. The K display has special character and command entry restrictions that are described in the section titled Network Operations from a NOS Host Console later in this chapter.




Figure 2-2. NETOU Operating Environment for NOS

## Network Operations from an Interactive Terminal

At an interactive terminal, you communicate to CDCNET via NETOU through a normal interactive terminal connection.

### NETOU Terminal Display Format

At a terminal, NETOU uses virtual line mode (as opposed to full screen mode) for display output. Commands are entered and responses are returned line by line. You use some utilities to perform network operations tasks that use full screen mode. These utilities run outside of NETOU, and include NPA, Network Logfile Termination Utility (NLTERM), and MANCC.

### Login

Use the following procedure to log in to NOS and select NETOU from a host console.

1. Create a connection to the host system using the `CREATE_CONNECTION` (CREC) terminal user command, as in the following example in which the user creates a connection with the host system by specifying the title NOS100.

If you need to review how to use the `CREATE_CONNECTION` command, see the Terminal Interface manual.

```
create_connection,nos100
```

2. To enter NETOU, log into NOS and select the NETOU application. Enter your family, user name, password, and NETOU, separating each by commas (if you use the default family name, log in beginning with a comma).

```
family,user name,password,netou
```

3. If you are validated to access NETOU, you are connected to NETOU and see the following message.

```
WELCOME TO NETWORK OPERATOR UTILITY
CDCNET - COPYRIGHT CONTROL DATA CORP, 1985, 1989.
```

4. If you are not validated to access the NETOU application, you receive the following response.

```
INVALID APPLICATION, TRY AGAIN
```

If you get this message, ask the network administrator at your site if you have been validated to use NETOU.

You may optionally want to create a file containing commands to be executed every time you log in. This NOS indirect access file `NETOPRP` resides in the operator's catalog. Typically, this file defines your command environment. For more information on prologs, see *Creating a Prolog* in chapter 3 of this manual.

*Selecting an MDI or MTI***NOTE**


---

This section is provided for site configurations that have more than one MDI connected to a host. Two MDIs that share only a single NOS host are considered separate catenets.

---

When you log in to NETOU, your job's connection is switched to NETOU. NETOU responds by connecting your operations station to the default MDI or MTI to receive your network commands and route them through the network. If there is more than one MDI or MTI available for you to select for an operations session, NETOU responds in one of two ways.

- NETOU automatically selects an MDI/MTI for you.
- NETOU prompts you to select an MDI or MTI.

You must also select an MDI if the currently selected MDI breaks its connection with NETOU.

Until an MDI becomes available and you select one, you may only enter the following commands.

```

DISPLAY_CONNECTED_MDI
DISPLAY_ALARM_HISTORY
ROUTE_ALARM
ROUTE_COMMAND_RESPONSE
SET_COMMAND_MDI
DISPLAY_COMMAND_LIST
DISPLAY_COMMAND_LIST_ENTRY
HELP
DISPLAY_COMMAND_INFORMATION
QUIT
LOGOUT
BYE
GOODBYE
HELLO
LOGIN

```

All other commands are ignored.

If more than one MDI or MTI is connected to NETOU, you receive a message listing all the MDIs which you can select to connect with the network. The display you receive depends on the number of MDIs and/or MTIs defined at your site. The following is an example of such a message:

```

STATUS OF CONNECTED MDIs
NODE    CURRENT    SYSTEM
NUMBER  STATE        TITLE

043     AVAILABLE    MDI_8A
044     AVAILABLE    MDI_85

```

If more than one MDI has established a connection with NETOU, as in the previous example, you also receive the following message.

```
More than one MDI available.
Please select an MDI by the following command:
  To select an MDI, type SETCM MDI=MDINAME
  MDINAME is optional, if not specified,
  default is <system title>
```

The command you enter is called SET\_COMMAND\_MDI (SETCM). The value of <system title> is the MDI to which you are connected if you do not specify an MDI. If you specify no parameter, the first available MDI in the list in the AVAILABLE state, is selected.

A default MDI can be defined in the job statement for NETOU in a host file named NAMSTRT. If the connection with this default MDI is broken, NETOU reselects the default MDI. Unless there is more than one MDI at your site, or if you plan to switch between MDIs, you can use the default MDI. For more information on how to select a default MDI see the NOS Version 2 Installation handbook.

Once you have selected an MDI for communication with the network, you receive that MDI's title in a message sent from that MDI. If you need to check which MDI or MTI you have currently selected, enter the DISPLAY\_CONNECTED\_MDI (DISCM) command.

---

#### NOTE

You receive alarms that are sent through the selected MDI or MTI. If alarms from another catenet are desired, you must select a different MDI using the SETCM commands.

---

### Creating a Prolog

See Creating a Prolog in chapter 3 of this manual if you wish to create a file containing a series of commands that you execute every time you establish a connection.

### Prompts

You immediately get the following prompt after logging in to NETOU.

```
NOU/
```

This prompt indicates that you are logged in to NETOU and can begin entering NETOU commands. NOU/ is displayed as a prompt until you select another application, such as IAF.

You immediately get the following prompt after entering the SENCs command.

```
SENCs/
```

This prompt indicates that you are in the SEND\_COMMAND\_SEQUENCE mode. SENCs mode allows you to send one or more commands to the same system(s) without enclosing the command within a SENC command. The commands you enter following this prompt are sent only to the systems listed in the system parameter of the SEND\_COMMAND\_SEQUENCE command. SENCs displays as a prompt until you enter \*\* to exit the SENCs mode.

## Paging

Paging allows you to move forward within a display on the terminal screen. You may enable or disable paging using the CDCNET terminal command called `CHANGE_TERMINAL_ATTRIBUTES` (CHATA). To do this, enter the network command character (NCC) (shown here as a percent sign [%], but the actual NCC may differ for your terminal), and the `CHANGE_TERMINAL_ATTRIBUTES` command, as in the following example.

```
%CHANGE_TERMINAL_ATTRIBUTES HOLD_PAGE=ON or OFF
```

ON enables paging; OFF disables paging. The default is for paging to be OFF. When paging is ON, to scroll to the next page of text, enter a carriage return or a control character. For more information about the `CHANGE_TERMINAL_ATTRIBUTES` command and the network command character, see the CDCNET Terminal Interface manual. Instructions for paging at the K display console are provided later in this section.

## Displaying Job Status Information

Displaying job status allows you to monitor the progress of your job through the CDCNET network. To do this, enter the network command character (NCC) shown here as a percent sign (%) followed by an e. The actual NCC may differ at your site. The first two lines tell you the current routing of the command responses and alarms. The third line tells you that you are in SENCS mode; that is, if you are in the SENCS mode. A list of the DIs to which the commands are being sent in SENCS mode follows. The last line tells you the current status of your job.

```
%e
```

```
Command responses routed to DISPLAY.
Alarms routed to DISPLAY.
You are currently in SEND_COMMAND_SEQUENCE mode
Commands sent to <list of DIs>
You may enter commands.
```

## Logout

When you want to log out from the NETOU application (and optionally log in to another application such as IAF), enter one of the following commands. NETOU terminates your current session and prompts you for a new session (if you use LOGIN).

```
HELLO,application
BYE
LOGOUT
LOGIN,application
GOODBYE
QUIT
QUI
```

## Examples:

The following example logs an operator out of the NETOU application and selects the IAF application.

```
hello,iaf
```

The following example logs an operator out of the current NETOU session and begins a new NETOU session.

```
hello,netou
```

## Network Operations from a NOS Host Console

At a NOS host computer console (a CC545 console or a 721 terminal), your interface to CDCNET is through the standard Network Access Method (NAM) host operator interface, the NAM K display. This section focuses on using the NAM K display to access and use NETOU. For background information on host console operations and K displays, see the NOS 2 Analysis handbook.

### NETOU K-Display Format

The K-display format used during the NETOU application is identical to the standard NAM K display used for NOS Operations. For further information about K displays, see the NOS Operations handbook. Figure 2-3 shows a typical K display used for CDCNET network operations.

```

K,NAM.
13:30:45 86.01.10
      MID=81   NOS43C/14R8117KD
.....

NETWORK_OPERATOR_UTILITY   86/11/10   13.30.45   1478
WELCOME TO NETWORK OPERATOR UTILITY
CDCNET - COPYRIGHT CONTROL DATA CORP, 1985, 1986.
      :
      (data area -- 31 display lines maximum)

READY..      (message line)

ALERTS (alert line -- a list of applications requesting your attention)

NETOU      SETCM,MDI_80

```

**Figure 2-3. NETOU K-Display Format**

The NETOU in the lower left corner of the operator entry line indicates that you are logged in to NETOU. To the right of NETOU you see the last command entered. This field contains 40 characters or less. Commands longer than 40 characters are not completely displayed. NETOU uses the K-display alert line and the operator entry line similarly to the standard NAM applications. NETOU does not use the host message line.

The K display has two data areas, left and right. The left data area displays commands, responses, network alarms, and operator prompts. You may display data on this side as a continuous scroll or view it page by page. See the discussion on paging of the K display, later in this chapter. The right data area is not used for NETOU operations in this release.



## Login

Use the following procedure to log in to NOS and select NETOU from a host console.

1. To access the NAM K display from the host console, enter the following.

```
K,NAM.
```

2. Select NETOU:

```
K.AP=NETOU
```

3. The NETOU application responds by clearing the left data area and sending the following prompt.

```
READY..
PLEASE ENTER *USERNAME,PASSWORD*,
ENTER VALUES IN ONE LINE, SEPARATED BY COMMAS.
READY..
```

Enter your user name and password.

```
user name,password
```

Your user name must be a member of the operating system's default family. For a valid login (a login that is known to the operating system and authorized for CDCNET control access), NETOU responds by sending the following message,

```
USER VALIDATION SUCCESSFUL,UN=<user_name>
```

and then connects your session to the default MDI or MTI to receive your network commands and route them through the network. If there is more than one MDI or MTI available for connecting to the network, you are prompted (if your site selected the prompting option) to select the MDI or MTI to be used for your operations session. If login is invalid, NETOU reissues the prompt for a valid login. See NOS Version 2 Installation handbook for more information on selecting the prompting option.

4. You receive the status of connected MDIs at your site, and a prompt to choose an MDI, if more than one MDI is available.

```
STATUS OF CONNECTED MDIs
NODE      CURRENT    SYSTEM
NUMBER    STATE      TITLE

043       AVAILABLE   MDI_8A
044       AVAILABLE   MDI_85
```

If more than one MDI has established a connection with NETOU, as in the previous example, you also receive the following message.

```
More than one MDI available.
Please select an MDI by the following command:
To select an MDI, type SETCM MDI=MDINAME
MDINAME is optional, if not specified,
default is <system title>
```

5. Enter SET\_COMMAND\_MDI (SETCM). The value of <system title> is the default MDI to which you are connected if you do not specifically select an MDI. The default MDI is the first MDI listed as AVAILABLE. If you enter only SETCM with no parameter, then the first DI in the list is selected.

You receive a message showing the current user name in effect when the K display is reassigned after you have logged in.

YOU ARE CURRENTLY LOGGED IN AS UN=user\_name

You may also see alarms that have been sent since a DISPLAY\_ALARM\_HISTORY command was issued, and a notification of the current operator state, such as command in progress.

You may wish to create a prolog, a file containing a series of commands that you execute every time you establish a connection. For information on how to create a prolog, see Creating a Prolog, in chapter 3 of this manual.

### Logout

To log out from NETOU, enter any of the following logout commands:

```
K.LOGIN
K.LOGOUT
K.GOODBYE
K.BYE
K.QUIT
K.QUI
K.HELLO
```

All the above logout commands perform two actions: terminate the current session and begin a new session.

After logout, a login prompt is displayed. You must type K.\* to return the K display to NAM control. Once you log out, alarms issued by the network are discarded. Any commands you sent prior to the logout may or may not complete, but you do not receive responses to these commands.

### Exiting and Resuming NETOU Sessions

At the host console, you may exit NETOU without logging out of NETOU completely. To do this, enter:

```
K.*
```

K.\* returns the K display to NAM control. NETOU remains active and retains your login. NETOU continues to monitor the network for alarms, even though you are not currently using the application. If new alarms occur during this time, the following message appears on the K display alert line.

```
NETOU
```

Any alarms received at your operations site can be displayed after you resume using NETOU.

To resume your operations session, enter:

```
K.AP=NETOU
```

NETOU returns the following message.

```
YOU ARE CURRENTLY LOGGED IN AS UN = <username>
```

Immediately following the above message, the most recent alarms are automatically displayed. Most recent alarms are those that have been sent since you last entered the DISPLAY\_ALARM\_HISTORY command. After alarms are displayed, you receive status information (see Displaying Job Status Information, in this chapter), followed by either the READY.. prompt or information that a command is in process. The NETOU prompt is cleared from the information alert line.

### Prompts

Common prompts at the K display include the following.

| Prompt           | Description  |
|------------------|--|
| READY..          | Command entry is allowed.  |
| MORE DATA..      | Page wait is on and more pages (screens) of data exist.<br>Enter K.+ to see the next page of data or K.- to turn page wait off and see the rest of the data. |
| REPEAT..         | You entered a command before the NETOU application was ready to receive it. Wait until you see the READY.. prompt, and reenter the command.                  |
| COMMAND TOO LONG | The command you are entering is too long for the K display (see Continuing Commands later in this chapter).  |
| LINE TOO LONG    | The line of data you are entering is too long for the K display (see Continuing Commands later in this chapter).   |

Most prompts are displayed at the bottom left corner of the K display's left data area. The REPEAT.. prompt is displayed at the right margin of the operator entry line.

## Paging

Some command responses fill more than one screen of the K display. When page wait is on, the MORE DATA.. prompt indicates this. You may view additional screens of data (also known as paging) and control paging of the data areas by entering the following commands. You may enter commands to turn paging on and off for the left data area. By default, paging is off at the K display.

| Command | Description   |
|---------|---|
| K.+     | Turns paging on for left data area. When you first enter NETOU mode, paging for the left data area is off. Once paging is on, NETOU only displays one page at a time of a multipage response. Multipage responses are indicated by the MORE DATA.. prompt. You may scroll to the next page by again entering K.+. |
| K.-     | Turns paging off for the left data area. If you enter K.- instead of K.+ when the MORE DATA.. prompt appears, paging is shut off. The screen immediately displays all responses, and MORE DATA.. is not displayed again.  |

If you change page wait from off to on or on to off, the success response is as follows:

PAGE ACCEPTED.

## K-Display Console Entry Restrictions

All commands at the K display are entered as follows:

K.command

The K. prefix is required. The syntax used for the command portion is the same as that used at an interactive terminal. See Common Network Operations Features in this chapter for more information on command syntax.

Normally, once the K display is active, the K. is automatically generated each time you enter a command. If you cancel the automatic feature by pressing the erase (left blank) key on the system console, you can restart the automatic process again by reentering the K. before the next command. Enter a carriage return to indicate the end of a command.

## Entering Characters Not Supported at a NOS Host Console

NETOU commands use a subset of the syntax for NOS/VE SCL commands. SCL uses the ASCII character set, which has characters the NOS host console (CC545 and 721) does not support. On the NOS host console, you must type two characters, or an escape sequence, to designate the ASCII characters not supported on the console.

On the NOS host console screen, unsupported ASCII characters are designated by other characters. For a character which represents more than one ASCII character when displayed, such as the asterisk (\*), the only way to know which ASCII character it represents is by the display's context. Table 2-1 shows escape sequences for unsupported ASCII characters and how these characters are represented on the console screen.

The following example compares command entries made at a terminal that supports the full ASCII character set with the same entries made at a NOS host console using the escape sequences. In this example, the hyphen is used rather than the /0 sequence to represent the underscore character.

ASCII terminal entry:

```
send_command command='display_hardware_status',system=north_tdi_1
```

System display console entry:

```
SEND-COMMAND COMMAND=/*DISPLAY-HARDWARE-STATUS/*,SYSTEM=NORTH-TDI-1
```

**Table 2-1. NOS Host Console Escape Sequences and Displays**

| Character | Name              | Escape Sequence On Keyboard | Displayed On Screen As: |
|-----------|-------------------|-----------------------------|-------------------------|
| ^         | Circumflex        | /1                          | /1                      |
| "         | Quotation Marks   | /2                          | /2                      |
| #         | Number Sign       | /3                          | /3                      |
| \$        | Dollar Sign       | /4                          | /4                      |
| @         | Commercial At     | /5                          | /5                      |
| ;         | Semicolon         | /6                          | /6                      |
| ?         | Question Mark     | /7                          | /7                      |
| {         | Opening Brace     | /8                          | /8                      |
| }         | Closing Brace     | /9                          | /9                      |
| _         | Underline         | Hyphen (-) or /0            | -                       |
| [         | Opening Bracket   | / (                         | / (                     |
| ]         | Closing Bracket   | / )                         | / )                     |
| >         | Greater Than      | / +                         | / +                     |
| <         | Less Than         | / =                         | / =                     |
| '         | Aposotrophe       | / *                         | / *                     |
| /         | Slant             | //                          | /                       |
| !         | Exclamation Point | None                        | .                       |
| %         | Percent Sign      | None                        | *                       |
| &         | Ampersand         | None                        | +                       |
| \         | Reverse Slant     | None                        | *                       |
| `         | Grave Accent      | None                        | *                       |
|           | Vertical Line     | None                        | *                       |
| ~         | Tilde             | None                        | *                       |
| :         | Colon             | /,                          | .                       |
| -         | Minus, Hyphen     | /-                          | -                       |
| a..z      | Lowercase         | /A../Z                      | A..Z                    |

## Continuing Commands

The K display does not accept input of more than 50 characters after the K. If you enter a command that goes over this limit, you receive one of the following prompts in the lower left corner of the console screen.

```
LINE TOO LONG
```

```
COMMAND TOO LONG
```

When this happens, the command entry is not processed. You may not enter anything else until you clear the entry by one of the following methods.

- Press the backspace key repeatedly, until you have fewer than 50 characters.
- Erase the entry by using the left blank (erase) key on the system console keyboard. Then reenter the command starting with the K.

To enter command strings that are longer than 50 characters, use the continuation symbol, the ellipsis (.), before you enter the 48th character, and enter a carriage return. Continue the command on the next line. The following examples show how to enter a multiple-line command from a system console. Assume that the hyphen represents the underscore character and that each line ends with a carriage return.

```
K.SEND-COMMAND ..
K.C=/*DISPLAY-LINE-STATUS LINE-NAME=(COMPSCI-02 ..
K.ENGINEERING-PORT-1 ENGINEERING-PORT-2 ..
K.ENGINEERING-PORT-3)/* SYSTEM=NORTH-TDI-2
```

## Command Syntax for NOS NETOU

This section describes the special syntax rules and the process used for sending CDCNET network operations commands from your operations station to the network in a NOS-based operations environment.

In a NOS environment, NETOU has the following types of commands.

- Commands executed on the host (session control commands).
- Commands executed in the MDI through which you are communicating with the network (session control commands).
- Commands executed in DIs throughout the network (network commands).

All these commands follow a subset of the NOS/VE SCL syntax (see Command Syntax later in this chapter). All network operations commands share the following properties in a NOS environment.

- Lowercase letters are interpreted as uppercase letters, with the exception of lowercase strings enclosed within single quotation marks (').
- Entering more than one network operations command per entry line is prohibited.

Some commands require parameters, such as `FILE_NAME`, that are passed on to NOS. The values allowed for these parameters have the same syntax and limits as those used in the NOS command language.

## Entering NETOU Commands on NOS

NETOU commands are valid only within a NETOU session. The session begins when you select NETOU. The session ends when you log out of NETOU.

Network commands are embedded within SEND\_COMMAND, which is interpreted by the Operator Support Application (OSA) in the MDI through which you are communicating with the network.

### SEND\_COMMAND (NOS Version)

To send network commands through the network, use SEND\_COMMAND (SENC), transmitting the network commands to the DI you specify. Except for the session control commands described later in this manual, you must embed all network commands in a SEND\_COMMAND. To use this command, enter:

```
SEND_COMMAND COMMAND=string,SYSTEM=name
```

COMMAND (C) is the network command to be sent to the DI specified with the SYSTEM parameter. Enter the command as a string value enclosed by apostrophes (').

#### NOTE

If the network command you are sending contains any apostrophes, you must use two consecutive apostrophes for the embedded apostrophe character to be recognized. Otherwise, NETOU assumes the embedded apostrophe signals the end of the network command, and errors result.

SYSTEM is the logical or physical DI name or list of DI names to which you want to send the command. SYSTEM is an optional parameter. If you omit this parameter, the last DI to which you sent a command is used. If SYSTEM is omitted on the first SEND\_COMMAND you use after you log in to NETOU, the selected MDI is used as the value for the SYSTEM parameter. The SYSTEM parameter may specify a maximum of 15 systems to which you want to send a network command with a single SENC command. If a network command is sent to more than one DI, a response from each DI must be received for the command to complete. The SYSTEM parameter is optional for SEND\_COMMAND in NOS environments, but required for SEND\_COMMAND in NOS/VE environments.

### NOS SEND\_COMMAND Examples

1. Enter the following command sequence to stop traffic on a communications line connected to a DI named TDI\_3. The actual command to stop communications traffic is enclosed within a SEND\_COMMAND that specifies the DI (TDI\_3) to which the line is connected.

```
send_command command='stop_line line_name=line3',system=tdi_3
```

2. Use the following SEND\_COMMAND command to send a DISPLAY\_LINE\_STATUS command sent to the same DI as in example 1 (TDI\_3). In this example, the SYSTEM parameter can be omitted, since the previous SEND\_COMMAND specified TDI\_3.

```
send_command command='display_line_status'
```





|   |      |
|---|------|
| Session Control on NOS/VE .....             | 3-2  |
| SCL Functions for NETOU Sessions .....      | 3-2  |
| \$NORMAL_RESPONSE .....                     | 3-2  |
| \$RESPONSE_IDENTIFIER .....                 | 3-2  |
| \$MATCHING_NAMES .....                      | 3-3  |
| Wildcard Characters .....                   | 3-3  |
| SCL Procedures for NETOU Sessions .....     | 3-3  |
| Session Control Activities .....            | 3-4  |
| Creating a Prolog .....                     | 3-4  |
| Building Command Files .....                | 3-4  |
| Writing and Executing Command Files .....   | 3-5  |
| Using SCL Procedures .....                  | 3-7  |
| Activating and Deactivating Alarms .....    | 3-7  |
| Routing Command Responses and Alarms .....  | 3-7  |
| Routing Responses .....                     | 3-8  |
| Routing Alarms .....                        | 3-8  |
| Accessing Response and Alarm Files .....    | 3-8  |
| Responding to Alarms .....                  | 3-8  |
| Session Control on NOS .....                | 3-9  |
| Creating a Prolog .....                     | 3-9  |
| Building Command Files .....                | 3-10 |
| Writing and Executing Command Files .....   | 3-11 |
| Routing Command Responses and Alarms .....  | 3-13 |
| Accessing Routed Responses and Alarms ..... | 3-13 |
| Displaying Alarm Environment .....          | 3-14 |
| Changing Alarm Environment .....            | 3-14 |
| Restoring Alarm Environment .....           | 3-15 |
| Displaying Alarm History .....              | 3-15 |
| Responding to Alarms .....                  | 3-15 |



This chapter contains descriptions of NETOU session control procedures. Session control is a term used to describe the set of actions you take to define, change, and control the online environment for your CDCNET network operations sessions. Examples of session control include routing command responses and alarms to files, and executing files of CDCNET commands.

Session control commands differ from other network operations commands because they are not sent to DIs. They define your operations setup and are not enclosed within SEND\_COMMAND.

This chapter is divided into two sections: Session Control on NOS/VE (for NOS/VE-based operations) and Session Control on NOS (for NOS-based operations). Each section provides instructions for doing session control activities.

## NOTE

For a complete description of the commands in this chapter, see the CDCNET Commands Reference manual.

If you are doing operations on a CDCNET Network Management Station, refer to the CDCNET Network Management Station manual. The CDCNET Network Management Station has a utility similar to NETOU.

## Session Control on NOS/VE

This section describes how to use commands and functions to control your CDCNET network operations sessions in a NOS/VE environment. In a NOS/VE environment, most of the CDCNET operations session control is done through standard SCL functions, commands, and services on NOS/VE. If standard SCL functions, commands, or services are used to perform any activities, they are referred to in the text, but not described in detail. You are directed to the appropriate NOS/VE SCL manual for more information.

### SCL Functions for NETOU Sessions

NETOU provides the following SCL functions to help you perform iterative operations and to use NETOU commands in combination.

#### **\$NORMAL\_RESPONSE**

This function returns a value of TRUE if a normal response was received from the last CDCNET command sent by the SEND\_COMMAND command.

The command format is:

**\$NORMAL\_RESPONSE**(name)

where *name* is the name of the system for which the response is to be checked. This parameter is always optional. If the last CDCNET command was sent to more than one system and the *name* parameter is omitted, then a value of TRUE is returned only if all of the responses were normal.

#### **\$RESPONSE\_IDENTIFIER**

This function returns the command response identifier from the response to the last CDCNET command sent by the SEND\_COMMAND command. Response identifiers are integers in the range 33000..65535. The meaning of a specific value is described in the online CDCNET Diagnostics Messages manual.

The format for this function is:

**\$RESPONSE\_IDENTIFIER**(name)

where *name* is the name of the system for which the response is to be checked. This parameter is optional if a command is sent to only one CDCNET system. If the last CDCNET command was sent to more than one system, then the *name* parameter is required.

## \$MATCHING\_NAMES

This function returns a list of CDCNET system names matching a name pattern. The list of names is assigned to an SCL array variable that is then used as the value for the `SEND_COMMAND` parameter that sets the destination for a series of CDCNET commands. The name pattern may contain wildcard characters. For this release of CDCNET, wildcards are supported for the `$MATCHING_NAMES` function only. (See Wildcard Characters, next, for more information.)

The format of the function is:

```
$MATCHING_NAMES(string)
```

where `string` is a string representing the pattern to be matched. This is a required parameter. Enclose the string value within apostrophe characters.

Example:

```
$MATCHING_NAMES('$*')
```

## Wildcard Characters

Optional wildcard characters allow you to address a command to CDCNET systems using names that match a specific name, as modified by a wildcard character. Names used as the destinations for network commands may be modified by the following wildcard characters.

| Character | Description   |
|-----------|---|
| ?         | Represents any single character.  |
| *         | Represents any string of characters.  |
| [ ]       | Represents any one of a set or range of characters collated in the ASCII character set. For example, [3ab4] represents any one of the character set 3, a, b, or 4. The abbreviation [3-6] represents any one of the characters 3, 4, 5, or 6. |

## SCL Procedures for NETOU Sessions

You can create and use SCL procedures that use the functions described in this section to enhance your NOS/VE NETOU environment. For example, you could create a procedure that uses the `$MATCHING_NAMES` function to send a command to a set of DIs that match a name modified by wildcard characters.

## Session Control Activities

This section contains instructions for using NOS/VE-based session control commands and functions to set up and control your operations sessions.

### Creating a Prolog

A prolog is a file containing a list of commands that are executed each time an activity is initiated. You can create a prolog specifically for your NETOU sessions that are executed every time you access NETOU. A prolog is not required for a successful invocation of NETOU. The commands you put in the prolog are up to you. Any NETOU or NOS/VE commands may appear in the file. For example, the `ACTIVATE _ALARMS` command must be entered any time you invoke NETOU if you want to enable alarm reporting at your operations station. Instead of entering this command every time, you could put it in your prolog to automatically enable alarm reporting whenever you invoke NETOU.

The default prolog file name is `$USER.NETWORK_OPERATOR_PROLOG`. However, you may define alternate prologs and put them in any catalog you can access through a normal NOS/VE file reference. When you invoke NETOU with the `NETOU` command, use the `PROLOG` parameter to specify the file reference for your prolog.

During NETOU sessions, other files called command files can be used to simplify command entry. The next section provides information on command files.

### Building Command Files

Command files contain CDCNET network operations commands (both session and network control commands) as well as any other NOS/VE commands. You can use the NOS/VE command `INCLUDE_FILE` to process a command file. The `INCLUDE_FILE` command causes the text of a file to logically replace the occurrence of the `INCLUDE_FILE` command. The commands in the specified file are then processed. Each line of the command file is executed as if it were an individual command you typed in at your operations site. For more information on the `INCLUDE_FILE` command, see the NOS/VE Commands and Functions manual. You may build command files to perform session and network control activities. A break sequence terminates command file processing.

Command files can be an efficient way to send commands and save keyboard entry, since you can group several commands that perform a single activity together in a file. Once a command file is created and saved, when you need to perform an activity such as redefining a line, you specify the file with the `INCLUDE_FILE` command rather than entering all the commands individually. Chapter 4 describes network operations activities and the commands that perform the activities. You can build command files to perform the activities described there.

You can also use command files to send a command to several DIs. The command file would have the same command on every line, but the DI name specified on the `SEND_COMMAND` would differ for each line.

### *Writing and Executing Command Files*

The following procedure makes use of the concepts for managing NOS/VE files. For more information, see the NOS/VE System Usage manual. This procedure also assumes you can use the full screen editor for NOS/VE.

1. After logging in to NOS/VE, enter NETOU by typing in the following:

```
/netou
```

2. Create and edit a file using the full screen editor by entering the EDIT\_FILE command. When creating the file, you must specify the FILE\_CONTENT and FILE\_PROCESSOR parameters. The FILE\_CONTENT = LEGIBLE parameter permits the file to contain character data. The FILE\_PROCESSOR = SCL specifies that SCL processes the data.

```
edit_file file=di_status
```

3. You may put any NOS/VE session control commands and CDCNET network control commands in the file. For network control commands, be sure to enclose the commands within the SEND\_COMMAND command. You can also enter other NOS/VE commands in the file.

```
"File DI_STATUS contains the DISPLAY_DI_SYSTEM_STATUS command."
"When the file is executed, the status command will be sent to"
"the three DIs specified in the file by the SEND_COMMAND."
```

```
senc c='disdss',s=mdi1
senc c='disdss',s=tdi1
senc c='disdss',s=tdi2
```

---

#### **NOTE**

Always note the command file's purpose, either in the file itself (as a comment) or in your records. This is important if you have many command files or several versions of a command file.

---

4. To execute the command file, use the INCLUDE\_FILE command and the file name parameter. For descriptions of the other parameters, see the INCLUDE\_FILE description in the NOS/VE System Usage manual.

```
include_file file=di_status
```

The commands in the DI\_STATUS file are sent to the appropriate DIs, where they are executed.



In this example, the command file `DEFINE_ETHERNET` is a standard set of commands used to redefine an Ethernet network solution. Parameter values are left blank so the file can be copied and parameter values can be specified.

"File `DEFINE_ETHERNET`"

"This file is a template file of network operations commands"

"that can be copied and used to define an Ethernet network solution."

"Insert the appropriate parameter values where indicated."

"Not all optional parameters are shown. If other parameters are added"

"to the command being sent, they must be placed within the final"

"apostrophe character."

Send\_command Command='Stop\_network Network\_name=       ',System=

Send\_command Command='Cancel\_ether\_net Network\_name=   ',System=

Send\_command Command='Define\_ether\_trunk Slot=   ,Trunk\_name=',System=

Send\_command Command='Define\_ether\_net,...

Trunk\_name=       ,Network\_ID=       Network\_name=       ',System=

Send\_command Command='Start\_Network Network\_name=       ',System=

A command file is useful in this situation because defining and starting a network solution involves defining and starting the network at two places. Once you have created a file of commands to define and start a network solution, you can duplicate and use the file to define and start the network solution on each DI affected by the definition change. This command file includes comments that describe the file's use.

## Using SCL Procedures

An SCL procedure is a series of SCL statements that perform a specific task. Because SCL allows parameter substitution, SCL procedures are easier to use to perform routine network management activities. You can develop your own SCL procedures for your particular site.

## Activating and Deactivating Alarms

Every DI generates alarms ranging from informative messages to indications of software failures. By default, these alarms are not sent to your operations station unless you explicitly activate them. To activate alarms so that they are displayed at your operations station, you must activate transmittal from the host to your station any time you invoke NETOU, by entering the `ACTIVATE_ALARMS` command. To ensure that this command is entered every time you invoke NETOU, include `ACTIVATE_ALARMS` in your user prolog (see *Creating a Prolog* in this section). Then, when you enter the NETOU command to invoke NETOU, alarms are activated.

Deactivate alarms by shutting off the transmittal of alarms from the host to your operations station. To do this, enter the `DEACTIVATE_ALARMS` command.

For NOS/VE CDCNET operator environments, all alarms received at the operations station are displayed when alarms are activated. Either all DIs in the network send alarms to you, or no DIs send alarms. There is no way to selectively deactivate an individual DI's alarms using session control commands. Instead, you must send the network control command `CANCEL_SOURCE_ALARM_MESSAGE` to the DI and specify the appropriate alarm message numbers. This command turns alarm messages off for all operators, because it directs the DI not to send the alarm.

## Routing Command Responses and Alarms

You can route command responses and alarms to files other than your display screen using standard NOS/VE files and commands. Routing responses and alarms to files can help you keep a record of responses and alarms. You can review the files and print them, if necessary. Routing is helpful with lengthy responses, such as the responses to the display status and configuration network control commands, which may return several screens of data.

To route responses and alarms to files, use the SCL command `CREATE_FILE_CONNECTION`. See the NOS/VE Commands and Functions manual for a complete description of this command. `CREATE_FILE_CONNECTION` establishes a connection between one of the standard NOS/VE files and one or more files. Any data written to the standard file is also written to the file you specify. The allowed standard file names include the following.

- `$ECHO`
- `$ERRORS`
- `$INPUT`
- `$LIST`
- `$OUTPUT`
- `$RESPONSE`

### *Routing Responses*

Normal command responses are written to the file specified on SEND\_COMMAND. The default output file is the standard NOS/VE file \$OUTPUT. Error responses are written to standard NOS/VE file \$RESPONSE. Use the CREATE\_FILE\_CONNECTION command to connect a file to these standard files. If you only want a file of error messages, specify \$RESPONSE.

NETOU commands and any NOS/VE commands you enter are written to standard file \$ECHO. For a complete record of your operations sessions which include both commands and responses, use the CREATE\_FILE\_CONNECTION command to connect a file to \$OUTPUT, \$RESPONSE and \$ECHO. You can use the standard job log file (\$JOB\_LOG) to serve as the file to which all commands and responses are written. The job log adds a date and time stamp to the commands and responses. By default, \$RESPONSE is connected to \$JOB\_LOG.

### *Routing Alarms*

All alarms are written to the file specified on ACTIVATE\_ALARMS. The default output file is the standard file \$OUTPUT. For an alarm history file, use the CREATE\_FILE\_CONNECTION command to connect another file to \$OUTPUT, or to any other file you specify as the one to receive alarm output on. You can write the alarms to the same file to which responses are written.

### *Accessing Response and Alarm Files*

Use the standard NOS/VE commands for accessing and displaying the files to which responses and alarms are written. If you write responses and alarms to \$JOB\_LOG, use the DISPLAY\_LOG command to display the job log.

### **Responding to Alarms**

Check the online CDCNET Diagnostic Messages manual for the description of the alarm you have received and the suggested actions for each message.

Alarms may also be messages to you from a terminal user. Respond to a message from a terminal user by the same line name listed in the alarm, using the WRITE\_TERMINAL\_MESSAGE command.

## Session Control on NOS

This section describes how to use commands to control your CDCNET network operations sessions in a NOS environment.

You must be validated on the family in which the NETOU application executes. If you are not validated on that family, you cannot read the prolog and command files, and you cannot write routing files.

### Creating a Prolog

A prolog is a file containing a list of commands that are executed each time an activity is initiated. You can create a prolog for your NETOU sessions that is executed each time you access NETOU. A path to CDCNET must be available at the time you access NETOU. You can put any NETOU command in your prolog file. Typically, your prolog contains the CDCNET commands to establish your command environment. Rather than entering these commands every time you access NETOU, put the commands in your prolog to establish your command environment whenever you invoke NETOU. You could also include a SEND\_COMMAND\_SEQUENCE (SENC) command in your prolog. This eliminates typing because you need not enclose each command within the SENC command.

The default prolog file, NETOPRP, is a NOS indirect access file which resides on your operator's catalog. However, you can specify a different prolog file name on the APPSW command when you log in to NETOU. The file name on the APPSW command is then used as your prolog file.

The APPSW command has the following format.

```
APPSW,AP=NETOU,Z.PROLOG=<name>,MDI=<name>
```

AP

The application to which you want to connect (in this case, NETOU).

Z

Indicates additional data follows the period. The data is saved and passed to the application you specified with the AP parameter.

PROLOG (P)

Specifies the name of the permanent file to be used as your user prolog file. Follow the NOS file naming conventions when naming your prolog file. If this optional parameter is omitted, the default file, NETOPRP is used as the prolog file.

**MDI (M)**

Specifies the system title of the MDI to which the operator's session is to be switched. Using this parameter is equivalent to logging into NETOU and entering the SET\_COMMAND\_MDI (SETCM) command. However, using this optional parameter causes suppression of the copyright banner and MDI selection message you would otherwise receive after logging in to NETOU. If you specify an MDI on the APPSW command and that MDI subsequently fails, NETOU logs you out and returns the connection to IAF.

The PROLOG and MDI parameters are positional parameters. If you do not use the keywords, specify the prolog file name followed by the MDI name. If you do not use the keywords and if you do not specify the prolog file name, substitute a comma for the prolog file name, followed by the MDI name.

During NETOU sessions, you can use other files, called command files, to simplify command entry. The next section provides information on command files.

**Building Command Files**

Command files are files containing CDCNET network operations commands (both Session Control commands and the commands that monitor, control, and configure DIs). You can build command files to perform session and network control activities. Each command in the file is executed as if it were an individual command you typed in at your operations site. A break sequence terminates command file processing.

Command files can be an efficient way to send commands and save keyboard entry, since several commands that perform a single activity can be grouped together in a file. Once a command file is created and saved, when you need to perform an activity for which the command file was created, you can call the command file and execute it using the EXECUTE\_COMMAND\_FILE command, rather than entering all the commands individually. Network operations activities and commands that perform the activities are described in chapter 4. You can build command files to perform the activities described there.

**NOTE**


---

Some commands and procedures used to perform network operations activities are not a part of NETOU, but run under another application. You may not include commands and procedures that are not CDCNET network operations commands in command files. Commands and procedures that are described in this manual but are not allowed in CDCNET network operations command files include:

- Network\_Logfile\_Termination Utility (NLTERM).
  - Network\_Logfile\_List (NLLIST).
  - All Network Performance Analyzer (NPA) commands and procedures used to obtain network statistics.
-

*Writing and Executing Command Files*

The following procedure assumes that you have access to an editing program, such as NOS Full Screen Editor (FSE). Command files can be created at either a host console or an interactive terminal. However, because interactive terminals with full screen interface are better suited to file editing, this procedure is geared toward an interactive terminal using FSE.

1. CDCNET command files must be written in the NOS 6/12 ASCII character set. To ensure this, enter the NOS ASCII command prior to accessing FSE.

```
ascii
```

2. Create a NOS local file by entering FSE and the name of the new file.

```
fse,newfile
```

3. Using FSE, enter the appropriate session and network commands in the file.

**NOTE**


---

The commands EXECUTE\_COMMAND\_FILE, INCLUDE\_FILE, and SET\_COMMAND\_MDI cannot be used in command files. To put comments in the command file, enclose the comment text in quotation marks.

---

4. Make the command file an indirect access permanent file using the SAVE command.

```
save,newfile
```

**NOTE**


---

You should make a note of the command file's purpose, either in the file itself or in your records. This is important if you have many command files or several modified versions of a command file.

---

5. Exit the NOS Interactive Facility (IAF) and enter NETOU by entering the following:

```
/bye,netou
```

6. Test the file by executing it using the EXECUTE\_COMMAND\_FILE command.

```
execute_command_file file=newfile,user_name=name
```

Provide the name of the command file you want to execute. USER\_NAME is optional. Use it if the command file is not in your permanent file catalog, but under another user name. In that case, the file must be public or semiprivate, as you must have permission to access the file.

The following command file sends a set of display status commands to a list of three DIs, MDI1, TDI1, and TDI2.

```
"File STATUS displays status of DI hardware and software."
sencs s=(mdi1, tdi1, tdi2)
display_di_system_status,
display_hardware_status,
display_line_status,
display_network_status,
display_software_load_status,
display_directory_status,
**
```

The following command file, DEFETH, is a standard set of commands used to logically reconfigure an Ethernet network solution. Parameter values are left blank so the file can be copied and parameter values can be specified. A command file is useful in this situation because defining and starting a network solution involves defining and starting the network at two places. Once you create a file of commands to define and start a network solution, you can duplicate and use it to define and start the network solution on each DI affected by the definition change. This command file includes comments that describe the file's use.

```
"File DEFETH"
"This file is a template file of network operations commands"
"that can be copied and used to define an Ethernet network solution."
"Insert the appropriate parameter values where indicated."
"Not all optional parameters are shown. If other parameters are added"
"to the command being sent, they must be placed within the final"
"apostrophe character."

Send_command Command='Stop_network Network_name=      'System=

Send_command Command='Cancel_ether_net Network_name=    ',System=

Send_command Command='Define_ether_trunk Slot=      ,Trunk_name=',System=

Send_command Command='Define_ether_net,...
    Trunk_name=      ,Network_ID=      Network_name=      ',System=

Send_command Command='Start_Network Network_name=      ',System=
```

The following EXECUTE\_COMMAND\_FILE example executes a file called TRMSTAT, that starts collection and reporting of line statistics. The file TRMSTAT is under another user name, so an alternate user name is specified with the command.

```
EXECUTE_COMMAND_FILE FILE=TRMSTAT,UN=ZELDA
```

## Routing Command Responses and Alarms

You can route command responses and alarms to a file using the `ROUTE_COMMAND_RESPONSE` and `ROUTE_ALARM` commands. Routing of responses and alarms allows you to review responses, retain them in a NOS permanent file, and print the file to more thoroughly review the responses. Routing is helpful with lengthy responses, such as status and configuration displays, which may return several pages of data.

To route responses, enter:

```
ROUTE_COMMAND_RESPONSE FILE = (file_name,DISPLAY) or DISPLAY or file_name
```

To route alarms, enter:

```
ROUTE_ALARM FILE = (file_name,DISPLAY) or DISPLAY or file_name
```

Specify a file name as the file to receive the responses or alarms. This file must be a NOS direct access permanent file. If the file does not exist when the command is executed, a new file is defined. If the file does exist, responses or alarms are appended to the end of the file. If you enter `DISPLAY`, command responses or alarms are routed to your operations station. If you enter `DISPLAY` without any parameters, command responses or alarms are routed to your operations terminal (`DISPLAY` is assumed). If you specify a file name but do not enter `DISPLAY`, command responses or alarms are not routed to your operations station. At the start of your session, routing of responses to your operations station (`DISPLAY`) is assumed.

You may simultaneously route command responses or alarms to your display and to a file by specifying both `DISPLAY` and another file name as a list with the command. You may also route command responses and CDCNET alarms to the same file.

When requesting the status of several DIs and lines, you could create a file called `NSTATUS` to receive the status responses, and route the responses to `NSTATUS` by entering:

```
route_command_response file=nstatus
```

The following command example directs all alarms to a file named `OPALARM` and to the operations station.

```
route_alarm file=(opalarm,display)
```

### *Accessing Routed Responses and Alarms*

To access files containing CDCNET command responses and alarms, log into IAF or switch to your IAF connection by the `CHANGE_WORKING_CONNECTION` terminal user command, if you have established multiple connections at your operations station. Use the NOS command `ATTACH` to attach the file, and the Full Screen Editor to view the file. You may also route the file to a printer using the NOS command `ROUTE`. See the NOS Reference Set, Volume 3 for the format of the `ROUTE` command.



## Displaying Alarm Environment

The `DISPLAY_ALARM_ENVIRONMENT` command shows the current alarm reporting setup for your operations station.

```
display_alarm_environment
```

```
Alarm Environment
```

```
Community      Alarm Status
CATENET        Enabled
```

```
Disabled Systems
```

```
-None-
```

## Changing Alarm Environment

To change the alarm reporting setup for an operations station, enter the `CHANGE_ALARM_ENVIRONMENT` (CHAAE) command. This command changes the list of DIs that send alarms to you. The `CHANGE_ALARM_ENVIRONMENT` command also enables alarms.

To shut off alarms from a DI, enter:

```
CHANGE_ALARM_ENVIRONMENT DISABLE_SYSTEM= DI name or names
```

To turn alarms from a DI back on, enter:

```
CHANGE_ALARM_ENVIRONMENT ENABLE_SYSTEM=DI name or names
```

## NOTE

---

The `CHANGE_ALARM_ENVIRONMENT` command is effective only for the operator who enters the command. If there is more than one network operations station active at your site, the alarms still go to the other operators. If you want to turn off alarms for all operators, cancel the source alarm messages at the individual DIs using the `CANCEL_SOURCE_ALARM_MESSAGE` command.

---

There are two other commands that can be used to activate and deactivate receipt of all alarms from *all* DIs at an operations station: `ACTIVATE_ALARMS` and `DEACTIVATE_ALARMS`. You cannot selectively enable or disable alarms with these two commands; use `CHANGE_ALARM_ENVIRONMENT` and specify the DIs for which you want to activate alarms.

The `ACTIVATE_ALARMS` command activates receipt of alarms from *all* DIs in the catenet at an operations station. The effect of `ACTIVATE_ALARMS` is the same as using the `CHANGE_ALARM_ENVIRONMENT` command to enable all alarms in the CATENET community of DIs. On NOS, alarms are activated by default. You do not need to use an `ACTIVATE_ALARMS` command to enable alarm reporting at your operations station at the beginning of your NETOU session.

The `DEACTIVATE_ALARMS` command deactivates receipt of alarms from *all* DIs in the catenet. The effect of `DEACTIVATE_ALARMS` is equivalent to using `CHANGE_ALARM_ENVIRONMENT` to disable all alarms in the CATENET community of DIs.

## Restoring Alarm Environment

Use the `CHANGE_ALARM_ENVIRONMENT` command to add DIs back to the list of DIs that report alarms to you, or use the `RESTORE_ALARM_ENVIRONMENT` command. The `RESAE` command restores all DIs to the list of DIs reporting alarms to you. This list of DIs was originally defined at the beginning of your operations session.

## Displaying Alarm History

The `DISPLAY_ALARM_HISTORY` command displays the alarms received at your operations station since the start of your `NETOU` session.

```
DISPLAY_ALARM_HISTORY DISPLAY_OPTION=option
```

The options for this command are `LAST`, `PAGE`, and `ALL`. `LAST` displays all alarms received since the last `DISAH` command was entered. `PAGE` displays the last page of alarms received. `ALL` displays all alarms received in the alarm history buffer, which is limited by buffer size to 50 lines of display. If the buffer receives more than 50 lines of display, new lines of display are written over the oldest alarms in the file. Because there is a blank line between each alarm, you may see only 34 nonblank lines of text.

For example,

```
display_alarm_history
```

returns this display.

### ALARM HISTORY REPORT

```
***** ALARM FROM MTI_83          85/10/10  13.38.51      619
--ERROR--   Line: LINE31 down, connection timer expired

***** ALARM FROM MTI_83          85/10/10  13.38.55      202
--ERROR--   Line: LINE23 down, auto-recognition failed

***** ALARM FROM MTI_83          85/10/10  13.40.28      202
--ERROR--   Line: LINE23 down, auto-recognition failed
```

## Responding to Alarms

Check the online CDCNET Diagnostic Messages manual<sup>®</sup> for the description of the alarm you have received online and the suggested actions for each message. Alarms may also be messages to you from a terminal user. If the alarm is a message from a terminal user, send a message back to the terminal user by the same line name listed in the alarm using the `WRITE_TERMINAL_MESSAGE` command.



# NETOU Network Control Procedures

4

|  |      |
|--|------|
| Recordkeeping .....  | 4-1  |
| Network Operation Commands .....                                       | 4-3  |
| Display Status Commands .....  | 4-4  |
| Displaying Network Components Status .....                             | 4-4  |
| Communications Control Commands .....                                  | 4-5  |
| Starting a Line .....  | 4-5  |
| Stopping a Line .....  | 4-5  |
| Starting a Network Solution .....                                      | 4-6  |
| Stopping a Network Solution .....                                      | 4-6  |
| Starting Communications Trunks .....                                   | 4-7  |
| Stopping Communications Trunks .....                                   | 4-7  |
| Operator Messages Commands .....                                       | 4-8  |
| Sending Messages to Terminal Users .....                               | 4-8  |
| Receiving Messages from Terminal Users .....                           | 4-9  |
| Clock Management Commands .....  | 4-10 |
| Resetting the Master Clock (NOS Only) .....                            | 4-11 |
| Synchronizing Time Clocks in All DIs .....                             | 4-11 |
| Displaying Date and Time Set at a DI .....                             | 4-11 |
| Display Configuration Commands .....                                   | 4-12 |
| Display Ethernet Trunk Configuration .....                             | 4-12 |
| Statistics Control Commands .....                                      | 4-13 |
| Start Network Statistics .....   | 4-13 |
| Stop Network Statistics .....  | 4-13 |
| Network Management Entities Control Commands .....                     | 4-14 |
| Cancel Operator Support Application .....                              | 4-14 |
| Diagnostic Control Commands .....                                      | 4-14 |
| Starting a Port Test .....   | 4-14 |
| Change Network Configuration Commands .....                            | 4-15 |
| Changing the Outcall Gateway .....                                     | 4-15 |
| Advanced Activities .....  | 4-16 |
| Controlling the Network Services Access .....                          | 4-16 |
| Changing the Network's Logical Configuration .....                     | 4-17 |
| Adding a Line .....  | 4-18 |
| Deleting a Line .....  | 4-18 |
| Redefining a Communication Line .....                                  | 4-19 |
| Adding a Network Solution .....  | 4-19 |
| Deleting a Network Solution .....                                      | 4-22 |
| Redefining a Network Solution .....                                    | 4-24 |
| Adding Terminal Devices .....  | 4-25 |
| Adding Batch Devices, I/O Stations, and NTF Remote Systems .....       | 4-25 |
| Controlling Gateways .....   | 4-26 |
| Network Products Gateways .....  | 4-26 |
| X.25 Gateways .....  | 4-27 |
| TCP/IP Gateways .....  | 4-28 |
| IP Host .....  | 4-29 |
| Logging and Alarm Control .....  | 4-29 |
| Defining Log Messages To Be Generated by a DI .....                    | 4-30 |
| Adding Log Messages to the Currently Defined List for Source DIs ..... | 4-31 |
| Cancelling and Redefining Log Messages .....                           | 4-31 |
| Changing the Logging Recorder DI (NOS Only) .....                      | 4-31 |
| Alarm Control .....  | 4-32 |

|   |      |
|---|------|
| Defining Alarm Messages To Be Generated by a DI ..... | 4-33 |
| Controlling Alarm Environment .....                   | 4-33 |
| Terminating Network Log Files on NOS/VE .....         | 4-34 |
| Terminating Network Log Files on NOS .....            | 4-35 |
| Archiving Network Log Files .....                     | 4-35 |
| Measuring Network Delay .....                         | 4-35 |
| Starting Network Delay Measurement .....              | 4-35 |
| Stopping Network Delay Measurement .....              | 4-35 |
| Displaying Network Delay Measurement Results .....    | 4-36 |

This chapter contains information on how to monitor and control a network. This includes the following:

- Recordkeeping
- Network Operation Commands
- Advanced Activities

## Recordkeeping

Keeping track of the network's components, their locations, and their maintenance schedule is an important part of network operations.

Your recordkeeping system should include:

- A diagram of the network's physical layout. The diagram should note the location of all equipment at your site (mainframes, DIs, Ethernet cables, communication lines, hardwired [dedicated] terminals, dial-up [switched] lines, and other network equipment).
- A current list of the logical names assigned to network components. The names for physical components (DIs, network solutions, communication lines) should be shown on the network diagram. When configuration changes or replacements are made, be sure to update this list. You can use the following commands to generate lists of the current logical names and titles defined for the network: `DISPLAY_LOGICAL_NAMES`, the `$MATCHING_NAMES` function on NOS/VE, and `DISPLAY_CATENET_TITLES` on NOS.
- The channel number and mainframe ID for the mainframe connected to an MDI or MTI.
- A list of the serial numbers assigned to DIs. These should also be included on the network diagram.
- Dial-up connections and their baud rates.
- A list of all ports for each DI and each line connected to the DI.
- Maintenance records for all DIs including diagnostic results, repairs, and replacements; problems reported to operator; and records of maintenance personnel visits.
- Network Performance Analyzer (NPA) reports.
- A diagram of Service Access Control restrictions (see the CDCNET Configuration Guide for more detailed information).

### NOTE

If network management Service Access Control is not permitted on a network solution, you may not be able to send commands to certain DIs. Ask the network analyst which network management is permitted.

- The DI, for DIs supported by NOS hosts, that contains the catenet's master clock (from which all other DIs set their clocks). The location of the master clock is determined during configuration when the functions for each DI are defined in the DI's configuration file. A DI that contains the master clock is known as a clocking system. For DIs supported by NOS/VE systems, the master clock is configured in a NOS/VE host.

#### **NOTE**

---

If you do not have a record of which DI contains the master clock, send a `DISPLAY_SYSTEM_OPTIONS (DISSO)` command to each DI in the network. Specify with the `DISPLAY_OPTION (DO)` parameter that you want the DI to return a display of whether or not it is a clocking system.

```
SEND_COMMAND COMMAND='DISSO DO=CLOCKING_SYSTEM',SYSTEM=di_name
```

The DI that contains the master clock for the network returns

```
Clocking system=yes.
```

Mark the location of the master clock in your records and on the network diagram.

---

You may find it helpful to attach tags to your DI's listing:

- Mainframe (where applicable, as in MDIs and MTIs).
- Mainframe channel number (where applicable).
- Ethernet trunk (where applicable, as in MDIs and TDIs).
- DI type (MDI, MTI, TDI, NDI, RTI) or gateway DI.
- DI serial number.
- DI system ID.

Such information is helpful for people at your site who are unfamiliar with CDCNET hardware, and for you when dealing with CDCNET network problems over the phone.

You can develop an online recordkeeping database of information about network components such as DIs, circuits, lines, ports, locations, and logical names, by using the configuration files for the DIs. Include the previously listed information as comments in the configuration files for your DIs. You can also include comments such as the system ID, the DI's location, and the original date of installation and of subsequent configuration changes. Print copies of the configuration files regularly and arrange them in a binder.

It is important to update the map and the database regularly, particularly when configuration changes, problems, and repairs occur. If you are one of several network operators at your site, be sure to keep each other informed about changes to the records.

## Network Operation Commands

To perform basic network activities, you must know how to execute the various types of network operation commands. The command types are shown in the following list and are further explained in this chapter.

### **NOTE**

---

For a complete description of the commands used in the following procedures, see the CDCNET Commands Reference manual.

---

- Display status commands
- Communications control commands
- Operator messages commands
- Clock management commands
- Display configuration commands
- Statistics control commands
- Network management entities control commands
- Diagnostic control commands
- Change Network configuration commands

For many of these activities, you can use command files to simplify command entry. See chapter 3 for more information on command files.



## Display Status Commands

Display status commands display the operational status of the hardware devices, communications lines, network solutions, and software configured for a DI or an ICA system.

A status display is similar to a snapshot in that it gives a picture of how the network is running at the time that the status command is processed. You can request and receive status displays anytime the network is running. They show you how the network component is performing at the time you request the status.

This snapshot effect is important when you are investigating user complaints or problems with the network. In such situations, you need to isolate the problem and return the user to network services as quickly as possible. Checking network component status is a first step in this process.

### Displaying Network Components Status

In this activity, you request and obtain the current operational status of network components, such as hardware boards in a DI. You may route the displays to a file using SCL commands on NOS/VE or by the ROUTE\_COMMAND\_RESPONSE session control command on NOS.

To display the hardware status in your network with a logical system name of TDI\_1, enter:

```
send_command command='display_hardware_status',s=tdi_1
```

You receive a response similar to the following:

#### Hardware Status

| device name | state | status      | version  | lim/bank/port | type  | boot enab | ROM level |
|-------------|-------|-------------|----------|---------------|-------|-----------|-----------|
| \$MPB0      | on    | active      | 0000(16) |               |       | n/a       | 160A      |
| \$PMM1      | on    | active      | 0008(16) |               |       | n/a       | 160A      |
| \$SMM2      | on    | active      | 0001(16) | 2             |       | n/a       | 0000      |
| \$CIM4      | on    | configured  | 0001(16) | 0,1,2,3       |       | no        | 2702      |
| \$CIM5      | down  | not config. | 0000(16) |               |       | yes       | 2702      |
| \$ESC16     | on    | active      | 0000(16) |               |       | no        | 0806      |
| \$LIM0      | on    | configured  | 0008(16) | 4             | RS232 |           |           |
| \$LIM1      | down  | configured  | 0009(16) | 4             | RS232 |           |           |
| \$LIM2      | on    | not config. | 0000(16) | 2             | RS449 |           |           |
| \$LIM3      | on    | not config. | 0000(16) | 2             | RS449 |           |           |
| \$URI4      | on    | configured  |          |               |       |           |           |

## Communications Control Commands

Communications control commands start or stop communications on communications trunks; networks; and asynchronous, synchronous, or URI lines. The communications control commands address trunks, networks, and lines by the logical names assigned by define commands. These activities involve controlling the communications traffic on each specific communication line. Before performing these activities, make sure you know the network's physical configuration and the logical names assigned to the network's communication lines.

Starting and stopping lines may be done for several reasons, such as replacing a communication line and changing a line's logical configuration. Stopping a communication line cuts off a terminal user from the rest of the network. If you have to stop a line connected to a terminal, inform the terminal user well in advance that the line will be stopped by sending a `WRITE_TERMINAL_MESSAGE` command to the terminal user.

### Starting a Line

To start an individual line, you must know the line and the logical names of the DI supporting the line. You may use the `DISPLAY_LOGICAL_NAMES` command to determine the logical names for DIs and lines.

Requirements:

- The line must be defined in the network's configuration by the `DEFINE_LINE` (`DEFL`) command. (A configured line is a line that has been assigned to a specific terminal interface program (TIP) that services the line when the line is started. If the line is not configured, a TIP has not been assigned to start and service the line.) If you're not sure the line is configured, check the DI's configuration file or enter the `DISPLAY_LINE_STATUS` command. Configured lines are indicated by configured in the command response.
- The terminal interface program (TIP) supporting this line must be configured by the `DEFINE_TIP` (`DEFT`) command. Check the DI's configuration file for this command. To start a line, enter the `START_LINE` command as shown in the following example.

```
send_command command='start_line line_name=group_1',system=first_floor_tdi
```

### Stopping a Line

To stop an individual line, you must know the logical name of the line. You can use the `DISPLAY_LOGICAL_NAMES` command to determine the logical names for DIs and lines. Use the following procedure.

1. Notify the line's user that the line will be stopped using the `WRITE_TERMINAL_MESSAGE` command. Tell user to log off.

```
send_command command='write_terminal_message,ln=line23,...  
m=('Line 23 going down please log off')',s=tdi
```

2. Enter the `STOP_LINE` command as shown in the following example.

```
send_command command='stop_line line_name=line23',system=tdi
```

## Starting a Network Solution

Starting the network solution also starts the underlying trunk, if not already started.

Requirements:

- The network solution must be defined by the appropriate network definition commands. See Adding a Network Solution and Deleting a Network Solution later in this chapter.
- Know the network solution's logical name as it is defined for the DI to which you are sending the commands. Use the `DISPLAY_LOGICAL_NAMES` command to determine the logical names for DIs and lines.

Enter the `START_NETWORK` command as shown in the following example.

```
send_command command='start_network network_name=net_1',system=tdi04
```

## Stopping a Network Solution

This activity affects a larger part of the CDCNET network than starting and stopping communication lines. Stopping a network solution logically removes a portion of the CDCNET network over which data can travel.

Do not stop the network solution that connects the operations station to the network host computer. Stopping the network solution which connects to the TDI that supports the operations station leaves the TDI (and you) logically disconnected from the network.

For example, if a TDI is connected to a CDCNET over a single Ethernet network solution, you should not stop communications on that network solution, because it is required to carry operations commands and other data to the TDI. You cannot start the network solution again unless you manually reset the TDI.

Requirements:

- Check the network's physical and logical configuration to determine the connections between DIs and network solutions. Do not stop a network solution if it is the only network solution over which your commands can be sent to a DI.
- Know the network solution's logical name. You may use the `DISPLAY_LOGICAL_NAMES` command to determine the logical names for DIs and lines.

Enter the `STOP_NETWORK` command as shown in the following example. The `STOP_NETWORK` command stops the underlying trunk if the network solution is the only traffic being carried by the trunk.

```
send_command command='stop_network network_name=net_1',system=tdi04
```

**Starting Communications Trunks**

To start the trunk, execute the `START_TRUNK (STAT)` command as shown in the following example.

```
senc c='start_trunk trunk_name = menlo_trunk_1' s=tdi2
```

**Stopping Communications Trunks**

To stop the communications trunk, execute the `STOP_TRUNK (STOT)` command as shown in the following example.

```
senc c='stop_trunk trunk_name = menlo_trunk_1' s=tdi2
```

## Operator Messages Commands

Operator messages commands let you communicate with other operators on a communication path.

### Sending Messages to Terminal Users

Sending the `WRITE_TERMINAL_MESSAGE` command through NETOU allows you to send messages to all users connected to a particular service, or to a particular line. You enclose the message within quotation marks. The optional parameters `LINE_NAME`, `DEVICE_NAME`, and `SERVICE_NAME` allow you to specify where you want the message to go.

You may send a message to a specific line or group of lines, to a particular terminal device or group of devices, or to the users of a specific gateway service. For example, if you send a message specifying a particular NOS/VE or NOS service name with the `SERVICE_NAME` parameter, all terminal users currently connected to the service name specified receives the message. Only terminals that match the parameters you specify receive this message. If you do not specify the optional parameters, the message is sent to all terminal users.

The message you specify with the message parameter must be entered as a string value enclosed by two consecutive apostrophes. If you want the message to have several lines of text, you must enter each line to be output at the terminal as a string value within parentheses, as in the following example.

The following command sends a message to a terminal user connected to TDI1 and on a line called LINE15:

```
send_command c='write_terminal_message,..
message=(''New communications configuration tomorrow'', ''Network down ..
untill 10:00.''),line_name=line15',system=tdi1
```

## Receiving Messages from Terminal Users

Messages from terminal users are sent to the network operator by a terminal user command called REQUEST\_NETWORK\_OPERATOR (REQNO). These messages show up at your operations station as alarms. On NOS, a warning bell rings at an interactive terminal, and NETOU is displayed on the operator attention line at the host console.

The alarm message from a terminal user gives the line name, terminal device name, gateway service through which the message was sent, and the text of the message. You can route terminal user messages to a file using standard SCL commands on NOS/VE or the ROUTE\_ALARM command on NOS.

Send a message back to the user using the WRITE\_TERMINAL\_MESSAGE command to acknowledge that you have received the message.

Example:

```
***** ALARM FROM riverside_tdi_1           85/06/13 11.15.45 168
Terminal User Request
line_name = mech_eng_2
Device name = mech_eng_term_2
Message: Will be moving office next week.  Need configuration change form.
```

---

### NOTE

The REQNO command does not execute successfully (a terminal user cannot contact the network operator using this command) unless CDCNET log message number 168 is enabled as an alarm by the DEFINE\_SOURCE\_ALARM\_MESSAGE (DEFSAM) configuration command on the DI. Message number 168 is not enabled as an alarm by default.

---

## Clock Management Commands

Each CDCNET system reports date and time in command responses, logs, and alarms. So that the responses, logs, and alarms from different systems can be correlated, CDCNET provides clock management functions to ensure that all systems in a catenet report the same date and time (within 1 second) at the same instant. These functions are provided by the Independent and Dependent Clock MEs.

The Independent Clock ME resides in one system in a catenet and maintains the master clock for the catenet. A Dependent Clock ME resides in every system in a catenet. Each Dependent Clock ME is responsible for obtaining the master catenet clock from the Independent Clock ME and for setting the system's clock to the master clock.

If the Independent Clock ME resides in a CYBER 170 NOS MDI, you may reset the master clock through the SET\_DATE\_AND\_TIME command. Through the SYNCHRONIZE\_CLOCK command, which should be broadcast to each system in the catenet whenever the master clock is changed, you may reset each system's clock to the master clock.

There are three parts to the clock management function.

- Resetting the master clock, using the SET\_DATE\_AND\_TIME command (NOS only).
- Synchronizing time clocks in all DIs, using the SYNCHRONIZE\_CLOCK command.
- Displaying date and time set at a DI, using the DISPLAY\_DATE\_AND\_TIME command.

---

### NOTE

For CDCNET networks supported by a NOS/VE host, the master clock is configured in the NOS/VE host. For CDCNET networks supported by a NOS host, the master clock is configured in a DI in the network. This DI is called the clocking system DI.

---

**Resetting the Master Clock (NOS Only)**

1. Determine which DI contains the master clock by one of the following methods.

- Check your site's records and network map (if available) for the DI marked as containing the master clock.
- Send a `DISPLAY_SYSTEM_OPTIONS` (DISO) command to each DI, specifying `CLOCKING_SYSTEM` with the `DISPLAY_OPTION` parameter.

```
senc c='disso do=clocking_system',system=mdi_1
```

The DI that contains the master clock sends the following response.

```
clocking system = yes
```

2. Once you have located the DI containing the master clock, reset the master clock by sending a `SET_DATE_AND_TIME` command to that DI. Provide the current date and time for the `DATE` and `TIME` parameters. Both the date and time must be entered as string values enclosed by two consecutive apostrophes.

In the following example, the master clock for a network is located in a DI called TDI2. To reset the master clock, the operator sends a `SET_DATE_AND_TIME` command to TDI2.

```
senc c='setdat d='11/24/85'',t='08:25:49'',s=tdi2
```

After the master clock has been reset, synchronize all the DI clocks using the `SYNCHRONIZE_CLOCK` command, described next.

**Synchronizing Time Clocks in All DIs**

Clock synchronization automatically occurs when a DI is configured. Once a day, all DI clocks are resynchronized. Over one day's time, for example, clocks could be running 1 to 2 seconds out of synchronization with each other. The `SYNCHRONIZE_CLOCK` (SYNC) command synchronizes a DI's clock to the date and time set at the master clock.

If you want to synchronize the DI clocks, send the `SYNCHRONIZE_CLOCK` command to every DI in the network, or write and execute a command file that sends `SYNCHRONIZE_CLOCK` to every DI in the network (see chapter 3 for directions on writing a command file).

**Displaying Date and Time Set at a DI**

If, at any time, you want to see the date and time set at a DI, send the DI a `DISPLAY_DATE_AND_TIME` command as shown in the following example.

```
senc c='display_date_and_time',s=north_tdi_1
```

```
System date and time
11/24/86 08:25:49
```



## Display Configuration Commands

A display configuration command is provided for each network definition command. The display configuration commands display the current values of DI configuration parameters defined through network definition commands. These configuration parameters include the configuration of DI system software, hardware devices, communications lines, URI lines, network solutions, and interfaces.

### Display Ethernet Trunk Configuration

One of the display configuration commands allows you to display the configuration of Ethernet trunks. The following example displays the configuration of the Ethernet trunk named ethernet\_cim02.

To display the configuration of the selected Ethernet trunk, enter the following command.

```
senc c='display_ether_trunk_options tn=ethernet_cim02' s=tdi1
```

If the command executes successfully, you receive a response similar to the following:

```
ETHERNET trunk options
slot = 4
trunk_name = ETHERNET_cim02
max_frame_size = 1500
interframe_spacing = 96
```

## Statistics Control Commands

Statistics control commands start and stop the collection of statistics for communications networks, lines, communications software, and trunks. In addition, the collection of statistics can be synchronized so that the statistic data reported by a system for different networks, lines, communications software, or trunks can be correlated.

The CDCNET statistics are counts of data traffic and various events detected by the communications software. The communications software gathers these statistics over a collection period called the report interval. The report interval is set through the start statistics commands and may differ between statistics. At the end of a report interval, the communications software reports the statistics via a log message, clears the collection counts and starts another report interval.

The three levels of statistics are summary, expanded, and debug. Summary level statistics provide an overview of the operation of a line, network solution, process, or trunk. The expanded and debug statistics provide further refinement of the statistics with the debug statistics the most detailed (some statistics do not support the expanded and debug levels).

### Start Network Statistics

The following example starts statistics collection for a network named bld\_3\_net.

To start statistics collection, enter the following command:

```
senc c='start_network_metrics nn = bld_3_net' s=tdi3
```

If the command executes successfully, you receive a response similar to the following:

```
Network bld_3_net summary metrics started
```

### Stop Network Statistics

To stop the collection of network statistics for one or more network solutions, enter the following command:

```
senc c='stop_network_metrics nn = bld_3_net,g = summary' s=tdi1
```

If the command executes successfully, you receive a response similar to the following:

```
Network BLD_3_NET summary stopped.
```

## Network Management Entities Control Commands

These commands control the services provided by the following network management entities installed on CYBER 170 NOS MDI/MTI's.

- Operator Support Application
- Independent File Access ME
- Initialization ME

### Cancel Operator Support Application

To cancel Operator Support Application for a NOS host, execute the CANCEL\_OPERATOR\_SUPPORT command as shown in the following example.

```
senc c='cancel_operator_support trunk_name = c170_trunk1' s=tdi4
```

If the command executes successfully, you receive a response similar to the following:

```
Operator Support is cancelled for trunk c170_trunk1
```

## Diagnostic Control Commands

Diagnostic control commands place physical devices under diagnostic control and start and stop diagnostics on these devices. For detailed descriptions of the diagnostic commands, see the CDCNET Installation and Troubleshooting Guide.

### Starting a Port Test

To start a diagnostic test on a given port, enter the following command:

```
senc c='start_port_test device_name = $lim_port1' s=tdi2
```

If the command executes successfully, you receive a response similar to the following:

```
PORT test started version 10
CIM slot number= 5
LIM slot number= 3
PORT number= 1
```

## Change Network Configuration Commands

These commands change the configuration of communications trunks, networks, and lines.

### Changing the Outcall Gateway

To change the outcall gateway default inactivity timer value, enter the following command:

```
senc c='change_outcall_gateway it = 30' s=td12
```

If the command executes successfully, you receive a response similar to the following:

```
Change of Outcall Gateway is accepted.
```

## Advanced Activities

You need a deeper understanding of the network, its configuration, and software that runs in DIs and on host computers to perform the following advanced activities. Advanced activities include procedures that may affect the performance of the network, such as cancelling the logical configuration of a communication line. Such activities are usually performed by an analyst or by an operator under an analyst's supervision.

- Controlling the network services access.
- Changing the network's logical configuration.
- Controlling gateways.
- Logging and alarm control.
- Terminating network log files on NOS/VE.
- Terminating network log files on NOS.
- Archiving network log files.
- Loading and unloading software.
- Controlling the network delay measurement.

For many of these activities, you can use command files to simplify command entry. See chapter 3 for more information on command files.

### Controlling the Network Services Access

CDCNET provides a Service Access Control feature to control network services that can be accessed across specific network solutions and DIs. Service Access Control operates by restricting access to service titles in the network directory. Users normally find services by requesting them by title. The title is translated to a network address by the directory management entity and a connection is established. Preventing a user from accessing a title also prevents that user from establishing a connection to the service.

Service Access Control features and procedures are further defined in the CDCNET Configuration Guide. The Service Access Control commands are defined in the CDCNET Commands manual.

## Changing the Network's Logical Configuration

The activities in this subsection alter the logical configuration of the network using network operations commands to logically add, delete, and redefine communication lines, network solutions, gateways, log messages, and alarm messages.

There are several types of configuration changes. Some changes, such as the addition of new DIs and network solutions, can affect the entire network and its physical appearance. Other configuration changes are less visible, but are still physical changes, such as adding more lines to a DI.

Logical configuration changes are changes in the network's software, such as removing a network solution's definition from a DI's logical configuration, or changing the line speed and other attributes for a communication line. These changes are not as visible, but are no less important in affecting how the network operates.

Deleting an element from a network's logical configuration is as major a change as physically removing the element. A logically cancelled element can no longer be used to send, receive, or relay data. As a network operator, you may be called upon to change a DI's logical configuration. There are two ways to change a DI's logical configuration.

- Entering configuration commands through NETOU while the network is running.

The same commands that are in a DI's configuration procedure (except the `DEFINE_SYSTEM` command) may be entered during operations. These commands change the logical configuration of the DI to which you send the command. This section assumes you are making configuration changes while the network is running.

This type of configuration change made by entering commands through NETOU is not permanent. The configuration change at a DI stays in effect until that DI is reloaded. The configuration procedures on the host remain unchanged. When the DI is reloaded, the original configuration procedures are loaded. If you want to make permanent changes to a DI's logical configuration, you must access the DI's configuration procedures and make the changes to the procedures. You can use the `MANAGE_CDCNET_CONFIGURATION` (MANCC) Utility to edit configuration procedures.

- Changing the configuration by changing the configuration procedures.

This type of change is more permanent because it stays in effect even if DIs are reloaded. However, these changes are permanent only if the system is reloaded. See the CDCNET Configuration Guide for information on MANCC.

Additional information on more advanced configuration changes such as changing terminal configuration parameters and reconfiguring a DI's base system software can be found in the CDCNET Configuration Guide.

## Adding a Line

When a communication line is added to the network, it must be logically defined in addition to being physically installed. This definition consists of the line's logical name and characteristics of the line.

1. If a terminal interface program (TIP) has not been defined for the TDI or MTI supporting this line, define the TIP by the `DEFINE_TIP` command.

```
send_command command='define_tip tip_type=asynctip',system=south_tdi_2
```

2. Define the line's configuration using the `DEFINE_LINE` command.

```
send_command command='define_line lim=1,port=0,...  
tip_name=async,line_name=110',system=south_tdi_2
```

3. The line should start after the `DEFINE_LINE` command completes, unless the optional `START` parameter was set to `NO`. If the line does not start communications, start the line (see *Starting and Stopping Communication Lines* in this chapter).

## Deleting a Line

When communication lines are removed from the network, their definition must also be removed from the network's logical definition. To do this, enter a `CANCEL_LINE` command.

1. Notify user or users that the line or lines will be stopped using the `WRITE_TERMINAL_MESSAGE` command.

```
send c='write_terminal_message,ln=engin_line_31,...  
m=(''Line engin_line_31 being deleted'')',s=engin_tdi
```

2. Stop communications traffic on the line using the `STOP_LINE` command.

```
send c='stop_line line_name=engin_line_31',s=engin_tdi
```

3. Cancel the line's logical definition using the `CANCEL_LINE` command.

```
send c='cancel_line line_name=engin_line_31',s=engin_tdi
```

## Redefining a Communication Line

To redefine a communication line, first cancel its current logical definition. Once the definition is cancelled, you can redefine the line using the `DEFINE_LINE` command. If the `DEFINE_LINE` command included the `START=NO` parameter, you must use the `START_LINE` command. Otherwise, the `START_LINE` command is unnecessary.

Enter the commands to redefine a line in the following sequence.

```
STOP_LINE
CANCEL_LINE
DEFINE_LINE
START_LINE
```

When network solutions are added to the network, they must be logically defined by configuration commands for the DIs using the network solutions. The configuration commands may be entered during operations, but changes remain in effect only until the DI is reloaded. To make permanent changes, the commands must be changed in the DI's configuration procedure (see the CDCNET Configuration Guide).

---

### NOTE

Deleting the network solution over which you load the DI is not recommended.

---

## Adding a Network Solution

When network solutions are added to the network, they must be logically defined by configuration commands for the DIs using the network solutions. The configuration commands may be entered during operations, but changes remain in effect only until the DI is reloaded. To make permanent changes, the commands must be changed in the DI's configuration procedure (see the CDCNET Configuration Guide).

Adding a network solution to a network's logical configuration involves defining the trunk which supports the network solution, then defining the network solution. The commands used for this depend on what type of network solution you are defining.

---

### NOTE

When adding or changing a network solution, be sure to define the Service Access Control restrictions. See the CDCNET Configuration Guide for these procedures. The commands used to define or change Service Access Control are described in the CDCNET Commands manual.

---

- **Ethernet Network Solutions**

For DIs loaded across an Ethernet medium (such as a TDI), the commands used to define an Ethernet trunk and network solution, `DEFINE_ETHER_TRUNK` and `DEFINE_ETHER_NET`, are performed implicitly by each DI's load process, and default names are assigned to the trunk and network solution. Once a DI is loaded and configured, you do not have to enter these commands through NETOU to define the Ethernet trunk and network solution. A `DEFINE_ETHER_TRUNK` or `DEFINE_ETHER_NET` command sent to such a DI fails if the trunk or network is already defined.



1. Enter the `DEFINE_ETHER_TRUNK` command. Provide the number of the slot in the DI which houses the ESCI board that supports the Ethernet trunk. If the DI has only one ESCI board, the slot number for the Ethernet trunk is optional. The `TRUNK_NAME` parameter is optional and specifies a logical name for the trunk being defined. If you do not specify a trunk name, a default trunk name is created from the `SLOT` parameter, as in `$ESCI4` (ESCI board in board slot 4).

```
senc c='define_ether_trunk trunk_name=ether1,slot=4',s=mdi_2
```

2. Enter the `DEFINE_ETHER_NET` command. Provide the logical names of the network solution and trunk, and the ID number assigned to the network solution. The trunk name must be the same as the trunk name specified in the `DEFINE_ETHER_TRUNK` command for the trunk to be used as a network solution.

```
senc c='define_ether_net network_name=ARHNET,trunk_name=ether1,...
network_id=0afbb1(16)',s=mdi_2
```

3. Enter the `START_NETWORK` command. Provide the logical name of the network assigned to the network by a define command.

---

#### NOTE

The `START_NETWORK` command is required only if you do not want the network solution to automatically start once the network solution is configured. The network solution automatically starts after configuration unless you include the parameter `START=FALSE` on the `DEFINE_ETHER_NET` command.

---

#### ● HDLC Network Solutions

1. Enter the `DEFINE_HDLC_TRUNK` command. Provide the numbers of the LIM and port to which the HDLC line is connected and which support the HDLC trunk. Provide the address of the local HDLC station and the address of the remote HDLC station. Both addresses are specified in digits from 0 through 9. The `TRUNK_NAME` parameter is optional and specifies a logical name for the trunk being defined. If you do not specify a trunk name, a default trunk name is created from the `LIM` and `PORT` parameters, as in `$LIM1_PORT3`.

```
senc c='define_hdlc_trunk lim=1 port=1 local_address=3075551212,...
remote_address=5006221313 trunk_name=TYMN1' s=ndi_1
```

2. Enter the `DEFINE_HDLC_NET` command. Provide the trunk name, which must be the same as that specified on the `DEFINE_HDLC_TRUNK` command. Provide the network ID, which is the CDCNET network identifier of the HDLC network solution.

```
senc c='define_hdlc_network trunk_name=TYMN1,...
network_id=1234'..s=ndi_1
```

---

#### NOTE

The `START_NETWORK` command is required only if you do not want the network solution to automatically start once the network solution is configured. The network solution automatically starts after configuration unless you include the parameter `START=FALSE` on the `DEFINE_HDLC_NET` command.

---

- X.25 Network Solutions

1. Enter the `DEFINE_X25_TRUNK` command. Provide the numbers of the LIM and port to which the X.25 line is connected, and which supports the X.25 trunk. The `TRUNK_NAME` parameter is optional and specifies a logical name for the trunk being defined. If you do not specify a trunk name, a default trunk name is created from the LIM and PORT parameters, as in `$LIM3_PORT1`.

```
senc c='define_x25_trunk lim=1 port=1 trunk_name=TYMN1' s=ndi_1
```

2. Enter the `DEFINE_X25_INTERFACE` command. The trunk name must be the same as that specified on the `DEFINE_X25_TRUNK` command. The `INONLY_RANGE`, `TWOWAY_RANGE`, and `OUTONLY_RANGE` parameters specify ranges of channel numbers allotted for incoming calls and outgoing calls. At least one of these parameters must be specified. If you specify more than one range, the ranges must be ascending with no overlapping value ranges.

```
senc c='define_x25_interface trunk_name=TYMN1 public_data_network=TYMNET,...
twoway_range=0..32' s=ndi_1
```

3. Enter the `DEFINE_X25_NET` command. The trunk name is the name of the X.25 trunk that supports the network solution. The remote DTE address is the remote data terminating equipment address for this X.25 network solution. This is typically a telephone number for the other end of the network, assigned by the network provider (such as or Tymnet) when a site subscribes to the public data network. The address is specified as a string of digits from 0 through 9. The network ID is the CDCNET network identifier of the X.25 network solution.

```
senc c='define_x25_network trunk_name=TYMN1,...
remote_dte_address=''3075551212'' network_name=TYMNET_NET1,...
network_id=1234' s=ndi_1
```

4. If the X.25 network solution connects to foreign hosts, you must enter a `DEFINE_X25_GW` command to define the gateway between CDCNET and the foreign host.

#### NOTE

The `START_NETWORK` command is required only if you do not want the network solution to automatically start once the network solution is configured. The network solution automatically starts after configuration unless you include the parameter `START=FALSE` on the `DEFINE_X25_NET` command.

## Deleting a Network Solution

A network solution can be logically deleted. However, the network solution should not be deleted if it is the only link between a DI and the rest of the network. For example, if you logically delete the Ethernet network solution which is the only path from a TDI to the rest of the network, you cut off that TDI from the rest of the network. You cannot access the TDI by NETOU to reenable the network solution; the only way to redefine the network solution is to manually reset the TDI.

### • Ethernet Network Solutions

To delete an Ethernet network solution, follow this procedure.

1. Stop traffic on the network solution by entering the `STOP_NETWORK` command.

```
send_command c='stop_network network_name=engin_bldg_net',s=engin_tdi_1
```

2. Cancel the network solution's definition by entering the `CANCEL_ETHER_NET` command. This command also cancels the underlying Ethernet trunk, so a separate `CANCEL_ETHER_TRUNK` command is not needed. However, when redefining an Ethernet network solution, you must define the Ethernet trunk because it was cancelled (see Redefining a Network Solution in this chapter). Provide the logical name of the network solution for the `NETWORK_NAME` parameter.

```
send_command c='cancel_ether_net network_name=engin_bldg_net',s=engin_tdi_1
```

### • NP Interface (NOS Only)

To logically delete an NP interface on NOS, follow this procedure.

1. Stop traffic to a NOS Network Products host by entering the `STOP_NP_INTERFACE` command. This command identifies the NOS Network Products interface to the NOS host. Provide the logical name of the interface assigned by the `DEFINE_NP_INTERFACE` configuration command for the `INTERFACE_NAME` parameter.

```
senc c='stop_np_interface in=cyber_109', s=mdi1
```

2. Cancel the configuration of the NP interface with a `CANCEL_NP_INTERFACE` command. Provide the logical name of the interface assigned by the configuration command, `DEFINE_NP_INTERFACE` for the `INTERFACE_NAME` parameter.

```
senc c='cancel_np_interface in=cyber_109', s=mdi1
```

3. Cancel the configuration of the channel trunk with a `CANCEL_CHANNEL_TRUNK` command. Provide the logical name of the trunk assigned by the configuration command, `DEFINE_CHANNEL_TRUNK` for the `TRUNK_NAME` parameter.

```
senc c='cancel_channel_trunk tn=cyber_101_alt'
```

- HDLC Network Solutions

To logically delete an HDLC network solution, follow this procedure.

1. Stop traffic on the network solution by entering the `STOP_NETWORK` command. Provide the logical name of the network solution for the `NETWORK_NAME` parameter.

```
send_command c='stop_network network_name=tymnet_net_1',s=ndi_1
```

2. Cancel the HDLC network solution by cancelling the logical definition of the HDLC network and the HDLC trunk by entering the `CANCEL_HDLC_NET` command. This also cancels the underlying trunk definition. Provide the logical name of the HDLC network for the `NETWORK_NAME` parameter.

```
send_command c='cancel_hdlc_net network_name=tymnet_net_1',s=ndi_1
```

- X.25 Network Solutions

To logically delete an X.25 network solution, follow this procedure.

1. Stop traffic on the network solution by entering the `STOP_NETWORK` command. Provide the logical name of the network solution for the `NETWORK_NAME` parameter.

```
send_command c='stop_network network_name=tymnet_net_1',s=ndi_1
```

2. Cancel the network solution's definition by entering the `CANCEL_X25_NET` command. Provide the logical name of the network solution for the `NETWORK_NAME` parameter.

```
send_command c='cancel_x25_net network_name=tymnet_net_1',s=ndi_1
```

3. Stop the X.25 Packet Level interface by entering the `STOP_X25_INTERFACE` command. Provide the logical name of the X.25 interface for the `INTERFACE_NAME` parameter.

```
send_command c='stop_x25_interface network_name=tymnet_net_1',s=ndi_1
```

4. If the X.25 interface that supports the network solution is also to be cancelled, enter the `CANCEL_X25_INTERFACE` command. If the X.25 interface has other active users, such as an X.25 gateway, do not cancel the X.25 interface. Provide the logical name of the interface assigned by a `DEFINE_X25_INTERFACE` configuration command for the `INTERFACE_NAME` parameter.

```
send_command c='cancel_x25_interface interface_name=tymnet_1',s=ndi_1
```

5. If the logical definition of the trunk that supports the network solution is also to be cancelled, enter the `CANCEL_X25_TRUNK` command. Provide the logical name of the trunk for the `TRUNK_NAME` parameter.

If the X.25 interface remains, do not cancel the trunk.

```
send_command c='cancel_x25_trunk trunk_name=tymnet_trunk_1',s=ndi_1
```

## Redefining a Network Solution

To redefine a network solution's logical definition, first cancel the current definition, then provide the values for the new definition. This subsection presents the sequence of commands required to redefine Ethernet, channel, X.25, and HDLC network solutions.

- Ethernet

The CANCEL\_ETHER\_NET also cancels the underlying Ethernet trunk, so a separate CANCEL\_ETHER\_TRUNK command is not needed. However, when redefining an Ethernet network solution, you have to define the Ethernet trunk, since it was cancelled.

```
STOP_NETWORK
CANCEL_ETHER_NET
DEFINE_ETHER_TRUNK
DEFINE_ETHER_NET
START_NETWORK
```

- Channel (NOS Only)

```
STOP_NP_INTERFACE
CANCEL_NP_INTERFACE
CANCEL_CHANNEL_TRUNK
DEFINE_CHANNEL_TRUNK
DEFINE_NP_INTERFACE
```

- X.25

```
STOP_NETWORK
CANCEL_X25_NET
STOP_X25_INTERFACE
CANCEL_X25_INTERFACE
CANCEL_X25_GW (if applicable)
CANCEL_X25_TRUNK
DEFINE_X25_TRUNK
DEFINE_X25_INTERFACE
DEFINE_X25_NET
DEFINE_X25_GW (if applicable)
START_NETWORK
```

If you only want to redefine the network solution, enter the following commands.

```
STOP_NETWORK
CANCEL_X25_NET
DEFINE_X25_NET
START_NETWORK
```

- HDLC

```
STOP_NETWORK
CANCEL_HDLC_TRUNK
DEFINE_HDLC_TRUNK
DEFINE_HDLC_NET
START_NETWORK
```

**NOTE**

The `START_NETWORK` command is required only if you do not want the network solution to automatically start once it is configured. (By default, it is started.) This is set by the `START` parameter on the `DEFINE_ETHER_NET`, `DEFINE_X25_NET`, and `DEFINE_HDLC_NET` commands.

**Adding Terminal Devices**

To add a terminal device to a DI's logical configuration, create a terminal definition procedure (TDP) that contains the `DEFINE_TERMINAL_DEVICE` command. See the CDCNET Configuration Guide for information about creating TDPs.

**Adding Batch Devices, I/O Stations, and NTF Remote Systems**

Logical configuration of batch devices, I/O stations, and NTF remote systems is covered in the CDCNET Configuration Guide. Operation of batch devices is covered in the CDCNET Batch Device User Guide and the NOS Remote Batch Facility (RBF) Reference manual. See these manuals for detailed information on configuring and operating batch devices.

To configure batch I/O stations and individual devices, use TDPs. TDPs contain commands to define the logical group of batch devices called an I/O station, to define parameters that apply to all the devices in the I/O station, and to define parameters that apply to the individual batch devices such as printers in the I/O station. The following commands are used in TDPs for I/O stations.

```
DEFINE_BATCH_DEVICE
DEFINE_I_O_STATION
DEFINE_NP_BATCH_STATION
DEFINE_TERMINAL_DEVICE
DEFINE_USER_I_O_STATION
```

Network Transfer Facility (NTF) Remote Systems are configured using TDPs. The following commands are used in TDPs for NTF Remote Systems:

```
DEFINE _ACCESSIBLE_REMOTE_SYSTEM
DEFINE _BATCH_STREAM
DEFINE _REMOTE_SYSTEM
```

TDPs are created during network configuration, but they can be modified and new ones can be created. See the CDCNET Configuration Guide for more information on creating and modifying TDPs and configuring I/O stations and NTF remote systems. TDPs are either executed automatically when the line connected to the I/O or remote system station becomes active, or when a station operator executes the TDP using the DO command. For example, the following command executes a TDP named STATION1. PROCEDURE\_TYPE=TDP is required.

```
DO,STATION1 PT=TDP
```

If you are already connected to a host service, use the network command character with the DO command, as shown in the following example.

```
%DO,STATION1 PT=TDP
```

Once batch I/O stations and their devices are active, you can perform operations such as starting and stopping devices as described in the CDCNET Batch Device User Guide and the NOS RBF Reference manual.

## Controlling Gateways

This section describes how to control gateways.

### Network Products Gateways

Activities are usually done by including the commands in the DI configuration files. The DEFINE\_NP\_GW command automatically starts the gateway when the command executes, so a start command is not currently supported. There are commands to start and cancel the Network Products interface (START\_NP\_INTERFACE and CANCEL\_NP\_INTERFACE).

The ADD\_NP\_GW\_OUTCALL is used when a remote system must access applications residing on a NOS host. The outcall is from the perspective of the CDCNET network; the call is going out of the CDCNET network. The add command provides the name (title) of the application through which remote systems can access applications residing on a NOS host. The name (title) is registered and maintained on a directory by the Directory Management Entity.

## X.25 Gateways

The following commands are used to control access to foreign hosts connected to X.25 networks:

```
START_X25_INTERFACE
STOP_X25_INTERFACE
CANCEL_X25_INTERFACE
DEFINE_X25_INTERFACE
START_X25_GW
STOP_X25_GW
CANCEL_X25_GW
DEFINE_X25_GW
ADD_X25_GW_OUTCALL
DELETE_X25_GW_OUTCALL
DEFINE_X25_TERMINAL_GW
START_X25_TERMINAL_GW
STOP_X25_TERMINAL_GW
CANCEL_X25_TERMINAL_GW
```

The start, stop, cancel, and define commands control the X.25 interface. The start, stop, cancel, and define X.25 gateway (GW) commands control the X.25 gateway that provides access for NOS applications-to-applications on foreign systems connected to CDCNET by an X.25 public data network. The add and delete commands control the registration of the name (title) of the X.25 gateway in the Directory ME. The X.25 interface supports the X.25 gateway. When starting the X.25 gateway, first start the interface. When stopping the interface, you must first stop the X.25 gateway, and if an X.25 network solution is defined, the X.25 network solution. Stopping the X.25 interface also stops the trunk that supports the interface.

Figure 4-1 shows how the X.25 control commands are used to start and stop X.25 gateway services.




Figure 4-1. X.25 Gateway Example



Figure 4-1 also shows an NDI connecting a CDCNET network with TELENET, a public data network, over an X.25 link. The X.25 interface to TELENET was defined during configuration in the NDI by the `DEFINE_X25_INTERFACE`, `ADD_X25_GATEWAY_OUTCALL`, and `DEFINE_X25_GW` commands. The logical name for the X.25 interface is `TELENET_1`. The logical name for the X.25 gateway is `TELENET_GW`. CDCNET terminal users can access TELENET by starting and stopping X.25 gateway, `TELENET_GW`.

To start X.25 gateway services, the following commands are sent to the NDI.

```
senc c='start_x25_interface interface_name=telenet_1' s=ndi_1

senc c='start_x25_gateway gateway_name=telenet_gw' s=ndi_1

senc c='add_x25_gateway_outcall gateway_name=telenet_gw title=PTFS$' s=ndi_1
```

To stop X.25 gateway services, the following commands are sent to the NDI. The stop commands are sent in the opposite order of the start commands.

```
senc c='delete_x25_gateway_outcall gateway_name=telenet_gw title=PTFS$' s=ndi_1

senc c='stop_x25_gateway gateway_name=telenet_gw' s=ndi_1

senc c='stop_x25_interface interface_name=telenet_1' s=ndi_1
```

## TCP/IP Gateways

Commands can define and start TCP/IP gateways, but these activities are usually done by including the commands in the DI configuration files. The `DEFINE_USER_TELNET_GW` command automatically starts the user gateway when the command executes. The `DEFINE_SERVER_TELNET_GW` command automatically starts the server gateway when the command executes. Include a `DEFINE_IP_HOST` command for the CYBER host.

The following examples illustrate how to cancel and redefine `USER_TELNET` and `SERVER_TELNET` gateways. In the first example, the `IP_ADDRESS` parameter of the `DEFINE_USER_TELNET_GW` command is the `IP_ADDRESS` of a non-CYBER host providing interactive services on the TCP/IP network.

In the second example, the IP\_ADDRESS parameter of the DEFINE\_SERVER\_TELNET\_GW command must match the IP\_ADDRESS of the DEFINE\_IP\_HOST command that configured the CYBER host providing the interactive services on the TCP/IP network.

```
senc c='stop_user_telnet_gw gateway_name=gw_to_vax',s=ndi_1
senc c='cancel_user_telnet_gw gateway_name=gw_to_vax',s=ndi_1
senc c='define_user_telnet_gw gateway_name=gw_to_vax,...
ip_address=(128,5,0,3),...
title=vax_86',s=ndi_1

senc c='stop_server_telnet_gw gateway_name=gw_to_cyber',s=ndi_3
senc c='cancel_server_telnet_gw gateway_name=gw_to_cyber',s=ndi_3
senc c='define_server_telnet_gw gateway_name=gw_to_cyber,...
ip_address=(128,5,0,2),...
title=VE_990',s=ndi_3
```

## IP Host

Commands can cancel and redefine an IP host. The host must have been previously defined with the DEFINE\_IP\_HOST command.

The following example shows how to cancel and redefine the IP host.

```
senc c='cancel_ip_host ip_address=(128,5,0,3)'
senc c='define_ip_host ip_address=(128,5,0,3),...
host_type= ip_host,...
system_id=(070701(16),009ECB(16))'
```

## Logging and Alarm Control

This section describes activities for configuring and managing the CDCNET log and alarm message features. Network logging allows you to have a record of network activity in the form of log messages routed to a file on the host computer. Alarms are messages sent to your operations station that alert you to events in the network.

This section also refers to the utility that terminates the network log file on a NOS host, the Network Logfile Termination (NLTERM) Utility. If you are running CDCNET with a NOS host, you have to use NLTERM periodically to close the current network log file and write the log messages to another permanent file.

## Defining Log Messages To Be Generated by a DI

The CDCNET logging structure consists of log message sources and log message recorders. Each DI is a log message source. The source provides log messages that describe the DI's activities. Each log message has a unique log message identifier. The complete list of these log messages and their identifiers is in the online Diagnostic Messages manual.

In CDCNET networks connected to a NOS host, at least one DI in the network serves as a log message recorder. The recorder has access to permanent storage. Aided by a NOS CDCNET host application called the Network Log Server (NETLS), the recorder DI records the log messages from the source DIs into a host file known as the network log file. The network log file on NOS resides on family SYSTEMX. The log file name has the following format:

| Value | Description   |
|-------|---|
| a     | Character incremented for each new log file, as in A,B,C. |
| mmdd  | Date file was created.                                    |

In CDCNET networks connected to a NOS/VE host, the log message recording function is configured in the NOS/VE host. A log message recorder DI cannot be defined in NOS/VE environments. Commands in the NOS/VE host \$SYSTEM.PROLOGS\_AND\_EPILOGS.NETWORK\_ACTIVATION\_EPILOG file activate and deactivate the network logging function: `ACTIVATE_NETWORK_LOG` and `DEACTIVATE_NETWORK_LOG`. For more information on these commands, see the NOS/VE System Analyst Reference set, Network Management.

There are network operations commands to configure and reconfigure the logging structure of your network. At each DI, there are lists maintained of what messages should be logged. The commands that affect logging sources allow you to define, change, and cancel one or more log messages at each DI.

If you have logging sources defined in your network, you should have a logging recorder defined for the network, or a portion of the memory in the network's DIs are used up by queued log messages generated by the DIs.

During network configuration, a default set of log message numbers are defined for each DI in the network with the `DEFINE_SOURCE_LOG_GROUP` command. These default messages are defined by commands in the DI configuration files created by the site administrator. Information on this activity is provided in the CDCNET Configuration Guide. You may add messages to this default set, but it is not recommended that you delete messages from the default set.

You can use the Network Performance Analyzer (NPA) Utility to look at log messages (see chapter 5 for NPA information).

## Adding Log Messages to the Currently Defined List for Source DIs

1. Display the log messages that are currently logged at the source DIs using the `DISPLAY_SOURCE_LOG_GROUP` command.
2. Add or delete the messages you want to enable or disable using the `CHANGE_SOURCE_LOG_GROUP` command. See the online CDCNET Diagnostic Messages manual for message numbers.

## Cancelling and Redefining Log Messages

You can also cancel and redefine the list of log messages to be generated at a DI by using the `CANCEL_SOURCE_LOG_GROUP` and `DEFINE_SOURCE_LOG_GROUP` commands.

### CAUTION

---

It is recommended that you limit the number of log messages generated by a DI, since the messages are logged on the host disk space. If a large number of messages, particularly the entire set of log messages, are enabled for a DI, a significant amount of network traffic is dedicated to transmitting log messages to the host. The log message feature may be useful for tracking problems or events in the network. However, enabling too many log messages can put constraints on DI and host memory.

---

## Changing the Logging Recorder DI (NOS Only)

In this activity, you control which host is to record log messages. This procedure is performed only in CDCNET networks that are supported by NOS hosts. Address the commands only to MDIs/MTIs that provide for log recording.

To cancel and redefine the recorder log group, follow this procedure:

1. Cancel the current log group to be recorded using the `CANCEL_RECORDER_LOG_GROUP` command.
2. Redefine the log group to be recorded using the `DEFINE_RECORDER_LOG_GROUP` command.

### NOTE

---

If you cancel the recorder log group, you cancel the recording function for the entire catenet unless the log recording function is defined on multiple MDIs in the catenet. Cancelling and redefining a log recording function should be done only if you move the log message recording function from one DI to another.

---

## Alarm Control

During network configuration, a default set of alarm message numbers are defined for each DI in the network by the `DEFINE_SOURCE_ALARM_MESSAGE` command. These alarms are sent to an alarm recorder. For NOS/VE operating systems, this is a network operator that executes the `ACTIVATE_ALARMS` command. Information on this activity is provided in the CDCNET Configuration Guide. You may add messages to this default set, but it is not recommended that you delete messages from the default set.

The initial set of DIs that report alarm messages to your operations terminal or console is all the DIs in the catenet. NOS/VE requires you to enter the `ACTIVATE_ALARMS` command within NETOU in order to receive alarms from the DIs. NOS has no such requirement; the alarms activate by default on NOS.

Occasionally, you may choose to redefine the list of alarm messages and/or the set of DIs that report alarms to you. For example, if a DI is undergoing tests and generating many alarms, and the DI is being monitored by test personnel, you can shut off receipt of the alarms from that DI.

There are two main activities involved in alarm control.

- Defining alarm messages to be delivered from a DI.  
This activity allows you to add and delete alarm messages from the list of alarms which are to be reported to all operators in the network from a particular DI.
- Controlling your alarm environment (NOS Only)  
This activity allows you to control which DIs report alarms to you. You may temporarily shut off receipt of alarms from a DI at your operations terminal/console. See chapter 3 for commands which control your operations alarm environment.

## Defining Alarm Messages To Be Generated by a DI

To initially define the set of alarm messages to be delivered from the source DI, use the `DEFINE_SOURCE_ALARM_MESSAGE` command. See the online CDCNET Diagnostic Messages manual for the message numbers.

### CAUTION

---

It is recommended that you limit the number of alarm messages defined for a DI. If a large number of alarms are enabled, the amount of network traffic devoted to alarm message transmission is increased. In addition, your operations station is constantly receiving alarms. The alarm message feature may be useful for tracking problems or events in the network. However, enabling too many alarms can put constraints on available DI memory.

---

## Controlling Alarm Environment

To redefine the set of messages to be delivered from the source DI as alarms, enter the following commands.

1. `DISPLAY_SOURCE_ALARMS` (to display alarm messages enabled).
2. `CANCEL_SOURCE_ALARM_MESSAGE` (to delete messages).
3. `DEFINE_SOURCE_ALARM_MESSAGE` (to add messages).

Provide the identification numbers for the messages you want the DI to send as alarms, surrounded by parentheses. See the online Diagnostic Messages manual for the message numbers. To add alarm messages to the existing set, you can enter a `DEFINE_SOURCE_ALARM_MESSAGE` without having to cancel the existing set of messages.

### NOTE

---

In order for the `REQUEST_NETWORK_OPERATOR (REQNO)` terminal user command to work, message number 168 must be enabled as an alarm.

---

## Terminating Network Log Files on NOS/VE

Control Data host computers provide logging capabilities to the network. Hosts maintain a network log file that receives log messages sent from DIs. Periodically, the current network log file must be terminated, and a new file to which new log messages are written must be defined.

On NOS/VE, the network log file resides on file LOG in the \$SYSTEM.CDCNET catalog. Individual sites can define the log file size limit, maximum number of log file cycles, and the interval at which a log file is terminated and analyzed, by specifying these values as parameters on the ACTIVATE\_NETWORK\_LOG command. This command can be entered by a system operator or be included in the NOS/VE host's \$SYSTEM.PROLOGS\_AND\_EPILOGS.NETWORK\_ACTIVATION\_EPILOG file. This file is executed when NAM/VE is started. For more information on the ACTIVATE\_NETWORK\_LOG command, see the NOS/VE System Analyst Reference Set, Network Management.

Parameters used to define log file termination and processing on the ACTIVATE\_NETWORK\_LOG command include MAXIMUM\_LOG\_CYCLES, MAXIMUM\_LOG\_SIZE, and INTERVAL. A site-managed job is used to process the log file.

MAXIMUM\_LOG\_CYCLES specifies the maximum number of log file cycles allowed. When this limit is reached, logging is suspended until one or more log file cycles are deleted. The default value is 999 cycles.

MAXIMUM\_LOG\_SIZE specifies the maximum size (in bytes) of the log file. When this file size is reached, the log file is terminated, a file called PROCESS\_LOG\_JOB is submitted as a batch job (see the following description of PROCESS\_LOG\_JOB), and a new log file cycle is started. The default maximum file size for log files is the NOS/VE maximum file size as configured for your site. If the keyword value NONE is specified for this parameter, the NOS/VE maximum file size is used.

INTERVAL establishes the time interval (in minutes) at which the log file is to be terminated and processed and a new log file created. The default for this parameter is for no periodic processing; a log file is terminated when it reaches a certain file size, rather than when a time period elapses.

The PROCESS\_LOG\_JOB is a batch job that is automatically run each time a network log file is terminated. The PROCESS\_LOG\_JOB resides in the file \$SYSTEM.CDCNET.SITE\_CONTROLLED.PROCESS\_LOG\_JOB. The sample job consists of three separate nested batch jobs. The three jobs execute NPA commands that reformat inactive cycles of the CDCNET log file, create and print NPA reports, and back up copies of processed log files, and archive old data in the NPA data bases. Control Data provides functioning versions of these jobs, which are written in System Command Language and are self-documenting. Examine the jobs and change them to meet the needs of your job site. The sample jobs may be found on file \$SYSTEM.CDCNET.VERSION\_INDEPENDENT.PROCESS\_LOG\_JOB.

## Terminating Network Log Files on NOS

On NOS, the network log file is a NOS direct access permanent file under user name SYSTEMX. The network log file is not automatically terminated. You must use the Network Log File Termination Utility (NLTERM) to terminate log files. The Network Logfile List Utility (NLLIST) provides a list of all terminated network log files that have not been purged. The function of NLLIST is also performed by an NLTERM subcommand called LIST.

NLTERM can be run as part of a daily system closedown process submitted as a batch job.

## Archiving Network Log Files

Archiving log files that have been terminated is an additional log file management step which may be appropriate for your site, depending on your site's network configuration, how much log traffic is generated, and how large your log files are. See chapter 5 for more information on archiving log files.

## Measuring Network Delay

Network delay time can be measured against a user-specified delay-time threshold by sending messages one at a time and waiting for the message to return. The delay time is compared against the specified delay time to determine if the message exceeds the threshold.

At the completion of the measurement period, a log message is issued indicating the average delay time for all messages during the transmission period. If the error threshold is exceeded, a network alarm message is issued. You may optionally define or cancel any log messages and network alarms by using CDCNET network commands.

### Starting Network Delay Measurement

To initiate the network delay measurement feature, execute the START\_NET\_DELAY\_MEASUREMENT (STANDM) command. The STANDM command validates the input parameters, loads and starts the measurement task, and issues a command response indicating the start status of the command. Enter the STANDM command as shown in the following example.

```
senc 'start_net_delay_measurement destination_system=ndi_d2..
delay_time_threshold=400' s=mdi_a1
```

### Stopping Network Delay Measurement

To stop the network delay measurement feature, enter the STOP\_NET\_DELAY\_MEASUREMENT (STONDM) command as shown in the following example.

```
senc 'stop_net_delay_measurement destination_system=ndi_1' s=mdi_a1
```



## Displaying Network Delay Measurement Results

To display the network delay measurement results of a running measurement, execute the `DISPLAY_NET_DELAY_MEASUREMENT` (DISNDM) command. This command displays the current measurement parameters and statistics as shown in the following example.

```
senc 'display_net_delay_measurement destination_system=ndi_d2..
      dtt=450 imi=15' s=ndi_a1
```

**FROM NDI\_A1**

**Network Delay Measures:**

**To NDI\_1**

```
Delay_time_threshold (msec.) = 450
Average_only = NO
Measurements = CONTINUOUS
Messages_per_measurement = 25
Measurement_priority = INTERACTIVE
Inter_measurement_interval (minutes) = 15
Error_threshold = 1
Message_timeout (seconds) = 120
```

```
Measurements completed = 12
Last delay time average (msec.) = 47
  at 13:43:22 on 01/16/90
```

# Network Performance Analyzer (NPA)

## Functional Overview

---

5

|  |      |
|--|------|
| NPA Features .....   | 5-1  |
| Data Reformat .....  | 5-2  |
| Report Generator .....   | 5-3  |
| File Maintenance Utilities .....                                 | 5-3  |
| Help File Utilities .....  | 5-4  |
| Change Expected Operating Limits .....                           | 5-4  |
| Periodic Utility (NOS Only) .....                                | 5-4  |
| Functional Overview .....  | 5-4  |
| Data Collection .....  | 5-5  |
| Data Logging .....   | 5-6  |
| Data Reformatting .....  | 5-6  |
| Data Reporting .....   | 5-7  |
| Accounting Database Restrictions .....                           | 5-8  |
| Statistics Control .....   | 5-8  |
| Statistics Groups .....  | 5-9  |
| Starting and Stopping Statistics .....                           | 5-10 |
| Obtaining Statistics Results .....                               | 5-11 |
| How To Initiate NPA Reports .....                                | 5-12 |
| NPA Report Generation Example .....                              | 5-14 |
| How To Enter NPA Commands in Screen Mode Format (NOS Only) ..... | 5-17 |
| ARCNDDB .....  | 5-17 |
| CHAEOL .....   | 5-19 |
| CRECAR .....   | 5-21 |
| EDICLM .....   | 5-23 |
| EXPCLM .....   | 5-25 |
| RELNDB .....   | 5-27 |
| How to Enter NPA Commands in Line Mode Format .....              | 5-28 |
| ARCNDDB .....  | 5-28 |
| CHAEOL .....   | 5-29 |
| CRECAR .....   | 5-30 |
| EDICLM .....   | 5-31 |
| EXPCLM .....   | 5-32 |
| REFCLF .....   | 5-33 |
| RELNDB .....   | 5-34 |
| How To Get Help on NPA Procedures .....                          | 5-35 |
| How To Get Help in Screen Mode (NOS Only) .....                  | 5-35 |
| How To Get Help in Line Mode (NOS Only) .....                    | 5-36 |
| How To Get Help in Line Mode (NOS/VE Only) .....                 | 5-36 |



# Network Performance Analyzer (NPA)

## Functional Overview

5

This chapter provides a functional overview of how NPA generates the reports used to monitor and troubleshoot a network. See chapter 6 for examples of all NPA reports. The following topics are included in this chapter.

### NOTE

For more detailed information on the commands discussed in this chapter, see the CDCNET Commands Reference manual.

- NPA Features
- Functional Overview
- How to Initiate NPA Reports
- How to Enter NPA Commands in Screen Mode Format (NOS Only)
- How to Enter NPA Commands in Line Mode Format
- How to Get Help on NPA Procedures

### NOTE

If you are doing operations on a CDCNET Network Management Station, refer to the CDCNET Network Management Station manual. The CDCNET Network Management Station has a utility similar to NPA.

## NPA Features

NPA consists of two major and four minor software components. The two major components are:

- Data Reformat
- Report Generator

The four minor components are:

- File Maintenance Utilities
- Help File Utilities
- Change Expected Operating Limits
- Periodic Utility (NOS only)

## Data Reformat

The reformat process should be initiated during the operating system startup and then periodically scheduled. The function of the reformat process is to:

- Acquire network log file(s) from the host system on which NPA runs, and map that information into the data file formats. CDCNET, at this time, only acquires log files from the host on which NPA is running.
- Collect the statistical information and the event information into the database files.
- Provide an indication of when a log file has been completely processed. The log file may then be dumped and purged.

The reformat process can automatically find log files under a catalog or acquire a log file specified by the user.

On NOS, if a log file is not specified as an input parameter, then the reformat process automatically searches a specified user catalog for all files that begin with the two letters NL and the current active log file, NETLfmid (up to a maximum of 30 files). These files are acquired if not already local to the job. If a user catalog is not specified, then the user catalog SYSTEMX is used. Access to all files is totally controlled via standard NOS file permissions (including log files in SYSTEMX).

On NOS/VE, if a log file is not specified as an input parameter, then the reformatter accesses and processes all cycles of the \$SYSTEM.CDCNET.LOG file, including the current (highest) cycle (up to a maximum of 30 cycles). Access to log files is controlled via standard NOS/VE file access permissions.

Network log files that have been previously processed by the reformatter may be reprocessed, but duplicate information remains in the database files. Report generation ignores these duplicate records. However, the cost to the user is extra file space and report generation time. Therefore, you should avoid the practice of reprocessing log files.

The reformatter processes each log message that has been acquired from the log files and maps it into the appropriate NPA database record. There are three types of NPA database records:

- Event records
- Statistics records
- Account records

Event records correspond one-to-one to a log message. The only difference is that they are reformatted from binary log format to readable text. An example of an event record is a software message record.

Statistics records correspond one-to-one to a log message. The only difference is that they are reformatted from binary log format into an internal fixed record NPA-defined format.

Account records are in log file format. Accounting log messages are copied as is to the accounting database. No reformatting occurs.

The date and time from the device interface (DI) clock are taken when the log record is reported to the Dependent Log Management Entity (Dependent Log ME). The time is universal network time, which can be either Greenwich Mean Time, if the network nodes span several time zones, or local time of the host for smaller localized networks.

It is necessary that a coordinated time base be used so that the time that hardware/software events occur in one DI corresponds to the time that other network events occur.

The reformat process writes the reformatted text output on a standard CYBER 170 or 180 sequential file(s).



## Report Generator

The function of the report generator is to generate standard, predefined reports or groups of reports upon request. You specify, by keywords, individual report names or the name of a report series, oriented toward a given target audience. The databases used are selected by the command parameters that you use.

NPA uses a Control Data product known as Information Processing Family Version 2 (IPF2) as part of its internal system. If you are a fully licensed IPF2 user, you can interactively manipulate the NPA database files to lay out customized report formats and to generate reports that meet your specific needs.

This capability can be used for developing reports that you can add to the set of NPA-supported reports. However, creating specialized reports requires additional host central-processor and central-memory resources beyond those required for normal NPA reporting. This capability also requires the use of the COBOL compiler. Therefore, an additional product license may be required if your site does not already have the COBOL product.

Chapter 7 provides an example of how to create a customized report using the IPF2 database files. If you need more information on the IPF2 files, refer to the IPF2 Reference manual listed in Additional Related Manuals.

## File Maintenance Utilities

These utilities consist of the following processes:

- Archiving databases
- Reloading databases

The archiving process is used to move older processed data to alternative storage media. This process allows you to release disk storage space. You determine how often and when to archive based on the amount of mass storage available at your site. The parameters for these procedures determine which data records are to be manipulated and the time interval during which the selected data was collected and recorded to the network log file.

The reloading process is used to reload records from an archive file and merge these records into the existing databases.



## Help File Utilities

The help file utilities consist of the following two interactive processes:

- Explain log messages
- Edit log messages

The `EXPLAIN_CDCNET_LOG_MESSAGES (EXPCLM)` command provides log message information on the selected log message number.

The `EDIT_CDCNET_LOG_MESSAGES (EDICLM)` command allows you to edit the help information for the selected log message.

## Change Expected Operating Limits

Some NPA reports contain the expected operating limits feature. This feature is a means of directing your attention to events that occur less frequently than or more often than expected for satisfactory network performance.

The `CHANGE_EXPECTED_OPERATING_LIMITS (CHAEOL)` command allows selection of a lower and an upper limit for columnar data within the report. When the number of times that an event occurs during a reporting period falls between the lower and upper CHAEOL limits, it is considered to be satisfactory. If an event occurs less frequently than expected, a less-than symbol (<) appears to the right of the reported statistic. If an event occurs more often than expected, a greater-than symbol (>) appears to the right of the reported statistic.

### NOTE

---

On NOS, the CHAEOL command is only applicable in full screen mode.

---

## Periodic Utility (NOS Only)

The NOS utility SUBBJP allows periodic submission of a job file to the input queue. SUBBJP determines if a file is ready to be submitted. After that file has been submitted, or if there is no file ready to be submitted, the utility rolls out until another file is submitted. A file is submitted if the difference between the last time it was scheduled and the current time exceeds the periodic interval specified. The last time executed is then updated. No provision is made for jobs that abnormally terminate.

## Functional Overview

NPA consists of the following four functions:

- Data collection
- Data logging
- Data reformatting
- Data reporting

## Data Collection

Software routines built into your DI units are responsible for the initial collection of appropriate network analysis data.

CDCNET is designed to collect data periodically. The normal report interval is 3600 seconds. This means that data is collected once every hour, giving you 24 sample measurements for each data field every day. Data is written to the appropriate log file as it is collected.

If you need sample measurements more often than hourly, you may reduce the report interval through the use of network operator commands defined in chapter 4. However, if you severely reduce the report interval, the amount of time your central processor unit (CPU) spends on statistics collection increases, and the amount of time and resources spent on processing work decreases. Therefore, a report interval of between 10 and 15 seconds is a practical lower limit.

Data collection software routines transform the collected data into log messages. There are four types of log messages collected:

|                           |   |
|---------------------------|---|
| Accounting information    | Information that helps to determine the distribution of costs to the user (see Accounting Database Restrictions later in this chapter).                     |
| Event information         | Information concerning hardware and software errors and other software events.  |
| Statistics information    | Information that is accumulated periodically on the operation of the network (see Statistics Control later in this chapter).                                |
| Configuration information | Each DI reports its current configuration to the log file once every hour. In addition, any configuration change is reported at the time of its occurrence. |

## Data Logging

The logging process consists of logging capabilities built into CDCNET software routines. A resident DI application task performs data logging at preset intervals. Statistics, configuration, and account data are formatted into log messages and forwarded to the network logging facilities for recording on the network log file. Failure information, configuration changes, and some accounting data (see Accounting Database Restrictions later in this chapter) are collected on an event occurring basis. NPA uses the data recorded on the network log file to produce reports about the network and its operation.

Components called Log Management Entities (Log MEs) provide the logging function. The Log MEs ensure that information is recorded on a mass storage log file on the appropriate host.

Each DI contains a Dependent Log Management Entity (Dependent Log ME), which receives log messages from the data collection software in the DI. The Dependent Log ME then tests to see whether or not a log message should be written to the network log file. Network configuration commands determine which log messages should be written to the network log file. If the answer to the Dependent Log ME test is yes, a log message is routed to the Independent Log Management Entity (Independent Log ME). If the answer is no, the log message is discarded.

The Independent Log ME receives log messages from one or more Dependent Log MEs. The Independent Log ME is responsible for writing log messages to the network log file.

Each log message is assigned an identifying number and can be selectively logged. The log message identification defines the type of information the log message contains and determines to which log file(s) the log message is written (currently only one log file).

## Data Reformatting

The organization of network log data is performed by the data reformatting utility `REFORMAT_CDCNET_LOG_FILE` (REFCLF) (figure 5-1). REFCLF accesses, reads, and organizes the data contained in the network log files on your local host. You must transfer network log files from other hosts (if you have more than one) in your network to the local host prior to using this utility. Use standard file transfer capabilities to accomplish file transfer.

---

### NOTE

The transfer of files can only be done on like hosts (for example, NOS to NOS).

---

When your system is initialized, the NPA database files are empty permanent files. At startup, your system generates statistics (see Statistics Information later in this chapter) and data that are logged into the network log file on your local host.

REFCLF reads your network log files, finds and extracts the appropriate log data, and then reformats and writes the appropriate log data to the data files. Collectively, these files are known as the NPA database.

The NPA database contains information for subsequent use by the network reporting functions.




Figure 5-1. Data Reformatting Process

## Data Reporting

The primary function of data reporting is to generate reports upon request. For the NPA report analysis tool, an existing commercial report generator is used so that more NPA development effort can be expended in the area of intelligent network analysis, rather than in duplicating yet another effort of report formatting.

Error prioritization is reported according to system impact consequence. Critical errors are reported first and informative errors last. The grouping of certain types of errors produces concise and relevant reports. This feature permits smaller sites with fixed or minimal maintenance resources to allocate them in a more cost-efficient manner.

The required capabilities of a flexible report writer combined with the desired data management facilities to sort data according to defined criteria are performed by the Information Processing Family Version 2 (IPF2). For more information on IPF2, see chapter 7 of this manual.

You use the NPA command `CREATE_CDCNET_ANALYSIS_REPORT (CRECAR)` to generate reports.

## Accounting Database Restrictions

NPA uniquely processes accounting data written as log messages to the network log file. REFCLF selects the accounting log messages to write to the accounting database NPBACNT, but does not reformat them in the same manner as other log messages. The accounting database basically reflects the raw accounting log messages. NPA does not provide additional services for processing accounting data (no reports are provided; accounting data cannot be archived or reloaded). The processing of the accounting database is left strictly up to the user.

### NOTE

---

Detailed information on the file structure is available through SOLVER, an online facility for reporting problems.

---

## Statistics Control

CDCNET statistics are numerical indicators of network performance. They include counts of data traffic and various events detected by the CDCNET communications software. Some examples of statistics include the number of messages or characters transmitted or received per line or DI and the number of errors encountered during a sampling period. You can use statistics to determine how the network is performing and to identify potential or real problems such as failing software processes or communication bottlenecks on lines and network solutions.

You may gather CDCNET statistics using statistics control commands. These commands start and stop the collection and reporting of statistics for the following network components: network solutions, communication lines, and software processes (such as the file access management function, log message recording, and gateways). There are start and stop commands for each of the three types of components for which you may gather statistics.

Statistics collection is started for the three types of statistics that may be collected (line, network, and process) by the start metrics commands. Once started, statistics are gathered over a collection period called a report interval. The report interval is set by a parameter on each start metrics command. This interval may differ between the components you are sampling. Collection of statistics is continuous; when one interval ends, another starts. At the end of a report interval, the statistics gathered during the report interval are reported by a log message, which is placed in the network log file, and a new report interval begins.

You may stop the collection and reporting of statistics by the stop metrics commands. These commands may be entered either before or after you obtain the statistics results (see Obtaining Statistics Results later in this chapter).

The appropriate log messages must be enabled for you to receive statistics information. The default set of log messages enabled by CDCNET includes the appropriate log messages providing statistical information.

## Statistics Groups

There are three levels of statistics that are collected: summary, expanded, and debug statistics.

Summary statistics provide an overview of the operation of a line, network solution, or software process. Examples include the number of messages received and characters transmitted. In most cases, summary statistics provide sufficient statistical information about a component's performance.

Expanded statistics are a refinement of summary statistics. Examples include response times for a terminal user, number of messages processed for each user, and distribution of size of messages transmitted and received by a software component. Expanded statistics are useful in cases where a service is being provided for an individual user through a connection, because they can give more specific information about the connection and how the service is performing using a particular connection. In contrast, summary statistics provide an overview of how the service is working for all users. Not every component supports expanded statistics.

Debug statistics are a further refinement of statistics and include information that can be used to debug software components. Examples include the amount of global memory used and memory addresses involved. Not every statistic type has expanded and debug levels; only process statistics have the debug statistics group.

Example statistics groups are in the statistics gathered for an HDLC interface. HDLC interface statistics report character, frames, and message information daily or hourly.

Statistics levels are not hierarchical. You can start collection of expanded or debug statistics without also starting summary statistics collection. The default group level for all start metrics commands is summary statistics. The default for all stop metrics commands is to stop all statistics groups. When you stop statistics collection and reporting by specifying groups, any statistics groups not specified in the command remain in effect. However, if you send a start metrics command and have all statistics groups reporting, and later stop statistics without specifying all groups, any groups not specified continue to be collected and reported.

## Starting and Stopping Statistics

1. Start the statistics using one or all of the following start metrics commands (send the commands within SEND\_COMMAND).

```
START_LINE_METRICS  
START_TRUNK_METRICS  
START_PROCESS_METRICS
```

```
senc c='start_line_metrics line_name=line31..  
report_interval=300',s=west_tdi
```

```
senc c='start_trunk_metrics network_name=ether1..  
report_interval=300',s=mdi1
```

```
senc c='start_process_metrics process=osi_transport..  
report_interval=300',s=tdi_3
```

2. Enter one or all of the following stop metrics commands either before or after obtaining the statistics results.

```
STOP_LINE_METRICS  
STOP_TRUNK_METRICS  
STOP_PROCESS_METRICS
```

```
senc c='stop_line_metrics line_name=line31',s=west_tdi
```

```
senc c='stop_trunk_metrics network_name=ether1',s=mdi1
```

```
senc c='stop_process_metrics process=osi_transport',s=tdi_3
```

## Obtaining Statistics Results

CDCNET statistics are reported by log messages, which are written to the CDCNET network log file on the host computer. You can display the statistics by defining the log messages as alarm messages, using the `DEFINE_SOURCE_ALARM_MESSAGE` command.

To obtain statistics, reformat the CDCNET log file containing the statistics messages by using the `REFORMAT_CDCNET_LOG_FILE` (`REFCLF`) command. `REFCLF` reorganizes the network log file (a chronological list of all log messages generated by the network's DIs), and builds files of various types of log messages called databases. NPA has standard database types and names. Each database contains a certain type of log message, such as log messages for a DI's CPU and memory use, or messages relating to terminal and connection performance. These databases are used to develop statistics reports.

Statistics reports are created from the NPA databases by using the `CREATE_CDCNET_ANALYSIS_REPORT` (`CRECAR`) command.

Log file reformatting and report generation (by the NPA commands `REFCLF` and `CRECAR`) may be done by running a routine batch job when the network and operating system are being shut down or started up.

While statistics are being reported, you can monitor statistics messages at your operations station by enabling the statistics messages as alarms. Use the `DEFINE_SOURCE_ALARM_MESSAGE` (`DEFSAM`) command to enable the messages as alarms. The message numbers to enable for line, network, and process metrics are shown in table 5-1.

**Table 5-1. Statistics Commands and Message Numbers**

| Command                            | Message Number   |
|------------------------------------|--|
| <code>START_LINE_METRICS</code>    | 166  |
| <code>START_PROCESS_METRICS</code> | 94, 291, 299, 405, 424, 446, 547, 737, 889, 890, 1357, 1453, 746, 1435, 1628, 1629, 1648, 1693, 1820, 1821, 1873 |
| <code>START_TRUNK_METRICS</code>   | 562, 665, 639  |



## How To Initiate NPA Reports

Use the following procedures to initiate NPA reports. An example of NPA report generation follows these procedure.

### NOTE

---

If you are using NOS/VE, you can use the Concurrent Maintenance Library for the Virtual Environment (CML/VE) to interactively generate some of the NPA reports. See the CML/VE Reference manual or the CDCNET Hardware Installation and Troubleshooting manual for information on CML/VE usage.

If you are using NOS, you can use the Common Maintenance Software Interface (CMSI) to interactively generate some of the NPA reports. See the CML Reference manual or the CDCNET Hardware Installation and Troubleshooting manual for information on CMSI usage.

If you want to generate customized NPA reports, see chapter 7, How To Create Customized NPA Reports Using IPF2 Database Files.

---

### NOS/VE Only

1. Log in to the host computer by entering your required user name and password. If you successfully log in, your terminal displays a slash.

/

2. You make NPA available to your job with the following SCL command.

```
CREATE_COMMAND_LIST_ENTRY $SYSTEM.CDCNET.VERSION_INDEPENDENT.COMMAND_LIBRARY
```

3. You then enter the NPA command. This command does all of the setup necessary to run NPA. The default attribute file NPAATTR is made local with this command along with the necessary library files needed for NPA command execution.

```
npa
```

4. When the following prompt appears, you are ready to enter NPA commands.

```
np/
```

5. Execute the REFORMAT\_CDCNET\_LOG\_FILE (REFCLF) command. REFCLF is used to execute the reformatting process. REFCLF converts network log file records into database records and transfers the converted records into appropriate data files. In this example, REFCLF processes up to 30 cycles of the \$SYSTEM.CDCNET.LOG file.

```
REFCLF,BD=850903,BT=120000,ED=, . .  
850907,DB=(ACNT,CONN,ETHR,SERR),O=REFREP,LFL=PURGLST
```

### NOTE

---

In order to execute the REFCLF command, you must have access to the network log file(s). If you do not have access to this file, have the network administrator execute the REFCLF command.

---

6. Execute the `CREATE_CDCNET_ANALYSIS_REPORT (CRECAR)` command. CRECAR is used to generate NPA reports.

```
CRECAR,RN=ETHRRP2,BD=850101,ED=850102
```

7. The generated report is stored in file CREOUT. To view this report at your terminal, enter:

```
EDIF,CREOUT
```

8. To exit the utility (this disables NPA commands, and the np/ prompt no longer appears), enter:

```
quit
```

### NOS Only

1. Log in to the host computer by entering your required user name and password. If you successfully log in, your terminal displays a slash.

```
/
```

2. You then enter NPA. This command does all of the setup necessary to run NPA. The default attribute file NPAATTR is made local with this command along with the necessary library files needed for NPA command execution.

```
npa
```

3. When a slash appears, you are ready to enter NPA commands.

```
/
```

4. Execute the `REFORMAT_CDCNET_LOG_FILE (REFCLF)` command. REFCLF is used to execute the reformatting process. REFCLF converts network log file records into database records and transfers the converted records into appropriate data files.

```
REFCLF.LF=(NLA0225,NLA0226),BD=850903,BT=120000,ED=,..  
850907,DB=(ACNT,CONN,ETHR,SERR),O=REFREP,LFL=PURGLST
```

### NOTE

In order to execute the REFCLF command, you must have access to the network log file(s). If you do not have access to this file, have the network administrator execute the REFCLF command.

REFCLF does not support full screen execution.

5. Execute the `CREATE_CDCNET_ANALYSIS_REPORT (CRECAR)` command. CRECAR is used to generate NPA reports.

```
CRECAR,RN=ETHRRP2,BD=850101,ED=850102,APPEND=yes
```

6. The generated report is stored in file CREOUT. To view this report at your terminal, enter:

```
FSE,CREOUT
```

## NPA Report Generation Example

This NOS example creates a hardware status report (HRDWRP1) similar to the one shown in figures 5-2 and 5-3. Figure 5-2 shows the report heading page. Figure 5-3 shows the actual report data page.

To create the report:

1. Log in to your terminal and access NPA by entering:

**NPA**

2. Convert the network log file records into database records by running the REFCLF command. You can only perform this step if you have access to the private network log file.

In this example, REFCLF processes up to 30 files beginning with NL or NETLF.

**REFCLF.DB=HERR,DBFUN=NETADMN**

3. Create the NPA hardware status report (HRDWRP1) using the line mode command entry procedure for CRECAR by entering:

**CRECAR,RN=HRDWRP1,DBFUN=NETADMN**

4. The hardware report HRDWRP1 is created and stored in file CREOUT. To view the report (figure 5-2 and figure 5-3) on your terminal, enter:

**FSE,CREOUT**

87/09/15

NETWORK PERFORMANCE ANALYZER  
VERSION 1.10/3403

CDCNET HARDWARE MESSAGES  
SORTED BY DATE AND TIME

HRDWRP1 REPORT

TIME PERIOD = 00/01/01 0000 - 99/12/31 2400

SYSTEM ID SELECTED = ALL

LOG IDS SELECTED = ALL

LOG IDS EXCLUDED = ALL

SEVERITY SELECTED = CATASTROPHIC  
FATAL  
ERROR  
WARNING  
INFORMATIVE

**Figure 5-2. HRDWRP1 Report Heading Page**

|   |             |              |        |             |  |
|---|-------------|--------------|--------|-------------|--|
| REPORT DAY: 86/01/01                          |             |              |        | PAGE 1      |  |
| HROWRP1 REPORT                                |             |              |        |             |  |
| START TIME = 0000 HOURS                       |             |              |        |             |  |
| DATE  | TIME        | SYSTEM IO    | LOG IO | SEVERITY    |  |
| =====   | =====       | =====        | =====  | =====       |  |
| 86/01/01                                      | 00.00.00927 | 0800253000A2 | 338    | ERROR       |  |
| --ERROR-- MPB FAILED ON-BOARD TESTING         |             |              |        |             |  |
| BEFORE INITIALIZATION WAS SUCCESSFUL.         |             |              |        |             |  |
| SLOT NUMBER= 0                                |             |              |        |             |  |
| FATAL ERRORS= 7                               |             |              |        |             |  |
| 86/01/01                                      | 00.00.00930 | 0800253000A2 | 340    | ERROR       |  |
| --ERROR-- PMM HAD RECOVERED PARITY ERRORS     |             |              |        |             |  |
| DURING ON-BOARD TESTING.                      |             |              |        |             |  |
| SLOT NUMBER= 1                                |             |              |        |             |  |
| ERRORS= 39168                                 |             |              |        |             |  |
| FIRST FAILING ADDRESS= 00010000               |             |              |        |             |  |
| 86/01/01                                      | 00.00.00933 | 0800253000A2 | 341    | ERROR       |  |
| --ERROR-- SMM SINGLE BIT ERRORS OCCURRED      |             |              |        |             |  |
| DURING INITIALIZATION.                        |             |              |        |             |  |
| SLOT NUMBER= 2                                |             |              |        |             |  |
| ERRORS= 1942                                  |             |              |        |             |  |
| ERROR LOG= 0648                               |             |              |        |             |  |
| 86/01/01                                      | 00.00.00935 | 0800253000A2 | 342    | ERROR       |  |
| --ERROR-- SMM MULTIPLE BIT ERRORS OCCURRED    |             |              |        |             |  |
| DURING INITIALIZATION.                        |             |              |        |             |  |
| SLOT NUMBER= 2                                |             |              |        |             |  |
| ERRORS= 11671                                 |             |              |        |             |  |
| ERROR LOG= 0473                               |             |              |        |             |  |
| 86/01/01                                      | 00.00.55028 | 0800253000A2 | 19     | INFORMATIVE |  |
| CONFIGURATION COMPLETE,                       |             |              |        |             |  |
| CONFIGURATION FILE SOURCE:                    |             |              |        |             |  |
| NETWORK ID: 41454646, SYSTEM IO: 0800253000BE |             |              |        |             |  |

Figure 5-3. HRDWRP1 Report Data Page

## How To Enter NPA Commands in Screen Mode Format (NOS Only)

If you are using NOS and your terminal is operating in screen mode, the system can use full screen displays to prompt you for parameters and provide you with information to help you execute NPA commands.

### NOTE

---

All NOS NPA commands can use full screen displays except REFCLF which operates in line mode format only.

---

### ARCNDDB

Use ARCNDDB to remove records from the NPA databases and archive this information into an archive file. To enter this command interactively using screen mode, do the following steps.

1. Enter:

```
ARCNDDB
```

2. Press the RETURN key, and the following screen appears:

```

      ARCHIVE NPA DATA BASES

ARCHIVE FILE      :_____
ARCHIVE FILE USER NAME :_____
DATA BASE        :_____
DBFUN            :_____
BEGIN DATE (YYMMDD) :_____
BEGIN TIME (HHMMSS) :_____
END DATE  (YYMMDD)  :_____
END TIME  (HHMMSS)  :_____
OUTPUT          :_____
BEGINNING DATE OFFSET :_____
ENDING DATE OFFSET  :_____
  
```

Specify values and press NEXT when ready

3. A cursor appears on the ARCHIVE FILE line to prompt you to enter this parameter first. The file name is a required parameter and must be entered. If you fail to enter the ARCHIVE FILE parameter, the following prompt appears:

```
Please enter ARCHIVE FILE
```

If you enter an illegal ARCHIVE FILE, the following prompt appears:

```

ILLEGAL FILE NAME ** illegal name **
ARCHIVE PROCESSING ABORTED
  
```

4. Enter parameter values. Press the TAB key to move the cursor to the next parameter line. Use the arrow keys to position the cursor at any parameter line on which you wish to make an entry.
5. Press the RETURN key after you have entered all of your desired parameters, and the selected database(s) are archived into the archive file.

Example:

This example archives all the existing database files into the archive file NPAARC. The remaining parameters, which are all optional, are assigned default values.

Begin by entering the archive file name:

ARCHIVE FILE: NPAARC

Use the arrow key to position the cursor on the database line. Enter the database:

DATA BASE: ALL

Press the RETURN key, and all databases are archived into the archive file NPAARC.

## CHAEOL

Use CHAEOL to replace existing expected operating limits. To enter this command interactively in screen mode:

1. Enter:

```
CHAEOL
```

2. Press the RETURN key, and the following screen appears:

```
CHANGE EXPECTED OPERATING LIMITS PROCEDURE
```

```
REPORT NAME TO CHANGE: _____
```

```
Specify values and press NEXT when ready
```

3. A cursor appears on the REPORT NAME TO CHANGE line to prompt you to enter this parameter. Enter your desired report name from the list of valid keywords that appears in the CHAEOL procedure. If you insert an illegal REPORT NAME, the following prompt appears:

```
Please correct (illegal name)
```

4. A cursor appears on the first line that identifies an NPA expected operating limit. Change the current limit shown on any line by entering a new number over the existing number. Move the cursor from the first line to the next by pressing the TAB key, or position the cursor to any line you desire by using the arrow keys.

Example:

You wish to change the NPA expected operating limits for report ETHRRP2.

Enter ETHRRP2 on the REPORT NAME TO CHANGE line.

```
CHANGE EXPECTED OPERATING LIMITS PROCEDURE
```

```
REPORT NAME TO CHANGE:ETHRRP2_____
```



Press the RETURN key, and the following screen appears:

```
ETHERNET REPORT 2 EOL UPDATE PROCEDURE

      LOW1 LOWER CRC ERROR LIMIT (PER HOUR): 01
      HIGH1 UPPER CRC ERROR LIMIT (PER HOUR): 04
      LOW2 LOWER ALIGNMENT ERROR LIMIT (PER HOUR): 01
      HIGH2 UPPER ALIGNMENT ERROR LIMIT (PER HOUR): 05
      LOW3 LOWER OVERRUN ERROR LIMIT (PER HOUR): 01
      HIGH3 UPPER OVERRUN ERROR LIMIT (PER HOUR): 07
      LOW4 LOWER RESOURCE ERROR LIMIT (PER HOUR): 01
      HIGH4 UPPER RESOURCE ERROR LIMIT (PER HOUR): 08
      LOW5 LOWER ABNORMAL COLLISION DETECTION LOGIC ERROR LIMIT (PER HOUR): 01
      HIGH5 UPPER ABNORMAL COLLISION DETECTION LOGIC ERROR LIMIT (PER HOUR): 09
```

Specify values and press NEXT when ready

-----EOLET2-----

THIS PROCEDURE WILL CHANGE THE EOL FOR THE ETHERNET ERROR STATISTICS.

You wish to change the current values for HIGH1 UPPER CRC ERROR LIMIT, HIGH3 UPPER OVERRUN ERROR LIMIT, and HIGH5 UPPER ABNORMAL COLLISION DETECTION LOGIC ERROR LIMIT on report ETHRRP2 to 7, 9, and 11, respectively.

The cursor appears on the first line. You do not want to change the limit shown on the first line. Therefore, press the TAB key or use the arrow keys to position the cursor on the second line, HIGH1 UPPER CRC ERROR LIMIT.

Change the current value of 04 to the new value of 7 by typing 07 over the current value.

Each time the TAB function executes, the cursor drops one line. Therefore, press the TAB key four times to move the cursor down to the HIGH3 UPPER OVERRUN ERROR LIMIT line. Or, use the arrow keys to position the cursor on the HIGH3 UPPER OVERRUN ERROR LIMIT line.

Enter your new value of 09 over the current value of 07. Press the TAB key four times to move down to the HIGH5 UPPER ABNORMAL COLLISION DETECTION LOGIC ERROR LIMIT line. Or, use the arrow keys to position the cursor on the HIGH5 UPPER ABNORMAL COLLISION DETECTION LOGIC ERROR LIMIT line. Enter the new value of 11 over the current value of 09.

Press the RETURN key, and CHAEOL replaces the old limits with the new ones you have entered.

## CRECAR

Use CRECAR to generate reports. To enter this command interactively in screen mode, do the following steps.

1. Enter:

```
CRECAR
```

2. Press the RETURN key and the following screen appears:

```
CREATE CDCNET ANALYSIS REPORT
```

```
REPORT NAME           : _____
DATA BASE FILE USER NAME : _____
BEGINNING DATE (YYMMDD) : _____
BEGINNING TIME (HHMM)   : _____
ENDING DATE   (YYMMDD)  : _____
ENDING TIME   (HHMM)    : _____
BEGINNING DATE OFFSET   : _____
ENDING DATE OFFSET      : _____
SYSTEM ID      (XXXXXX) : _____
NAME OF OUTPUT FILE     : _____
APPEND REPORT TO OUTPUT?: _____
LOG ID          (XXXXX) : _____
EXCLUDE LOG ID (XXXXX)  : _____
SEVERITY (I,W,E,F,C)    : _____
COMPRESS REPORT?       : _____
```

Specify values and press NEXT when ready

3. A cursor appears on the REPORT NAME line to prompt you to enter this parameter first. Enter your desired report name from the list of valid keywords that appears in the CRECAR procedure. If you fail to enter a REPORT NAME, the following prompt appears:

```
Please enter REPORT NAME
```

If you enter an illegal REPORT NAME, the following prompt appears:

```
Please correct (illegal name)
```

4. REPORT NAME is the only required parameter for the CRECAR procedure. You may generate your chosen report, or report set, by pressing the RETURN key. If you do not enter any of the optional parameters, the report or reports generated are based upon the default parameter values defined in the CRECAR procedure description.

To enter any or all of the optional parameters, use the TAB key or the arrow (cursor control) keys on your terminal to move the cursor to the desired parameter lines. When you press the TAB key, the cursor moves to the next parameter line. When you use the arrow keys, you can position the cursor at any parameter line on which you wish to make an entry.

5. Press the RETURN key after you have entered all of your desired parameters. CRECAR generates the report or reports you have requested based on the parameter values you have entered.

Example:

You wish to generate an HRDWRP1 report to receive a hardware message from all network device interfaces (DIs).

Begin by entering the report name on the REPORT NAME line:

```
CREATE CDCNET ANALYSIS REPORT
```

```
REPORT NAME      :HRDWRP1
```

If you wish to enter any of the other parameters instead of using the default value, press the TAB key until the cursor appears on the line of the parameter you wish to enter.

When you are ready to generate the report, press the RETURN key.

## EDICLM

Use EDICLM to edit the explanatory information about CDCNET log messages (provided by NPA procedure EXPCLM). To enter this command interactively in screen mode:

1. Enter:

```
EDICLM
```

2. Press the RETURN key and the following screen appears:

```
EDIT CDCNET LOG MESSAGE
```

```
MESSAGE NUMBER (XXXXX)   : _____
EDITOR (FSE,EDIT OR XEDIT): _____
```

Specify values and press NEXT when ready

3. The cursor appears on the MESSAGE NUMBER line to prompt you to enter the number of the log message that identifies the log message explanation you are going to edit.

Enter the log message number and press the TAB key, and the cursor moves to the EDITOR line. Or, use the arrow keys to position the cursor on the EDITOR line.

Enter the editing mode you want to use: Full Screen Editor (FSE), EDIT, or XEDIT. Press the RETURN key, and the log message explanation appears on your screen.

If you plan to use FSE, you need not enter a parameter on the EDITOR line. Enter only the message number, and press the RETURN key to create the log message explanation to your screen.

### NOTE

---

Only the Site Information portion of the log message explanation is to be edited.

---

### Example:

You want to edit the Site Information portion of log message explanation 00001 using FSE.

Enter 00001 on the MESSAGE NUMBER line and press the RETURN key. (If you are using FSE, you do not need to make an entry on the EDITOR line.)

The following screen appears:

```
NOS FULL SCREEN EDITOR
Upper Case File NPATMP1 Lines 1 Thru 23 Size 23
.PROC,E00001*I"MESSAGE NUMBER 00001 EXPLANATION".
.HELP.
```

LOG MESSAGE NAME

00001 - - - -> S\_A\_LOCAL\_RECOVERY\_FAILURE

LOG MESSAGE PURPOSE

THIS LOG MESSAGE INDICATES THAT A FAILURE OCCURRED WHILE EXECUTING  
A FAILED TASK'S RECOVERY PROCEDURE.

ACTION REQUIRED

A CDCNET ANALYST SHOULD BE NOTIFIED WITH THE INFORMATION REGARDING  
THE FAILED PROGRAM MODULE TO DETERMINE THE CONDITION OF THE  
CURRENT SYSTEM.

SITE INFORMATION

.ENDHELP  
\$REVERT,NOLIST.

Edit the Site Information portion of the message explanation and execute the QUIT function. The information (your additions, deletions, or changes) is permanent.

**NOTE**

---

In order to view the entire display, you might have to press the F3 key to see the next screen.

---

## EXPCLM

Use EXPCLM to generate explanatory information about CDCNET log messages. To enter this command interactively in screen mode:

1. Enter:

EXPCLM

2. Press the RETURN key, and the following screen appears:

EXPLAIN CDCNET LOG MESSAGE

MESSAGE NUMBER (XXXXX) : \_\_\_\_\_

Specify values and press NEXT when ready

3. The cursor appears on the MESSAGE NUMBER line to prompt you to enter the number of the log message for which you want an explanation. Enter the log message number and press the RETURN key, and a full screen explanation appears. If you enter an illegal MESSAGE NUMBER, the following prompt appears:

Please correct (illegal number)

**Example:**

You want an expanded explanation of log message number 00001. Enter 00001 on the MESSAGE NUMBER line.

MESSAGE NUMBER (XXXXX) :00001

Press the RETURN key, and the following screen appears:

MESSAGE NUMBER 00001 EXPLANATION

Specify values and press NEXT when ready

-----E00001-----

LOG MESSAGE NAME

00001 - - - -> S\_A\_LOCAL\_RECOVERY\_FAILURE

L O G M E S S A G E P U R P O S E

THIS LOG MESSAGE INDICATES THAT A FAILURE OCCURRED WHILE EXECUTING  
A FAILED TASK'S RECOVERY PROCEDURE.

A C T I O N R E Q U I R E D

A CDCNET ANALYST SHOULD BE NOTIFIED WITH THE INFORMATION REGARDING  
THE FAILED PROGRAM MODULE TO DETERMINE THE CONDITION OF THE  
CURRENT SYSTEM.

S I T E I N F O R M A T I O N

**NOTE**

In order to view the entire display, you might have to press the F3 key to see the next screen.

## RELNDB

Use RELNDB to reload records from an archive file into the NPA databases. To enter this command interactively using screen mode, do the following steps.

1. Enter:

```
RELNDB
```

2. Press the RETURN key, and the following screen appears:

```

RELOAD NPA DATA BASES

ARCHIVE FILE      :_____
ARCHIVE FILE USER NAME :_____
DATA BASE        :_____
DBFUN            :_____
BEGIN DATE (YYMMDD) :_____
BEGIN TIME (HHMMSS) :_____
END DATE  (YYMMDD)  :_____
END TIME  (HHMMSS)  :_____
OUTPUT          :_____

```

Specify values and press NEXT when ready

3. A cursor appears on the ARCHIVE FILE line to prompt you to enter this parameter first. The file name is a required parameter and must be entered. If you fail to enter the ARCHIVE FILE, the following prompt appears:

```
Please enter ARCHIVE FILE
```

If you enter an illegal ARCHIVE FILE, the following prompt appears:

```

ILLEGAL FILE NAME  ** illegal name **
RELOAD PROCESSING ABORTED

```

Use the TAB key or the arrow keys on your terminal to move the cursor to the desired parameter line. When you press the TAB key, the cursor moves to the next parameter line. When you use the arrow keys, you can position the cursor at any parameter line on which you wish to make an entry.

Press the RETURN key after you have entered all of your desired parameters. The selected database(s) are reloaded into the CDCNET log file.

Example:

This example reloads all the existing database files from the archive file NPAARC into the CDCNET log file. The remaining parameters, which are all optional, are assigned default values.

Begin by entering the archive file name:

```
ARCHIVE FILE: NPAARC
```

Use the arrow key and position the cursor on the database line. Enter the database:

```
DATA BASE: ALL
```

Press the RETURN key, and the archive file is reloaded into the database.



## How to Enter NPA Commands in Line Mode Format

If your terminal is in line or screen mode, you can execute NPA commands by entering the desired command name, all of the required parameters, and any desired optional parameters for that command, followed by a carriage return. Default values are assigned to the omitted optional parameters.

If you omit a required parameter when using NOS, the terminal reverts back to the Screen Mode Parameter List display (except for REFCLF which uses line mode format only). You must then select the required parameters as you would in screen mode. When this occurs, see How to Enter NPA Commands in Screen Mode Format for parameter entry procedures.

If you omit a required parameter when using NOS/VE, a prompt message appears indicating which parameter is required. The following examples show how to enter the NPA commands in line mode.

### ARCNDDB

Use ARCNDDB to remove records from the NPA databases and archive this information into an archive file.

1. To enter this command in line mode format, enter the following:

```
ARCNDDB,AF=filename,DB=value
```

The ARCHIVE\_FILE parameter is required and must be entered. If you omit the required parameter and you are using NOS, the screen displays the screen mode parameter entry display (see the ARCNDDB screen mode procedure to enter from this display). If you omit the required parameter and you are using NOS/VE, a prompt message appears indicating which required parameter has been omitted. The remaining optional parameters are assigned default values if you do not enter them.

2. After entering the parameters, press the RETURN key and the selected database(s) are archived.

Example:

This example archives all the existing database files into the archive file NPAARC. All optional parameters are assigned default values.

```
ARCNDDB,AF=NPAARC,DB=ALL
```

Press the RETURN key to execute.

## CHAEOL

### NOTE

When CHAEOL is entered in line mode format, the terminal must be in screen mode to enable the limits display and limits value updating.

Use CHAEOL to replace existing expected operating limits. For example, to change the limits on the ETHRRP2 report, perform the following steps.

1. Enter the CHAEOL command and the REPORT\_NAME parameter.

```
CHAEOL,RN=ethrrp2
```

The REPORT\_NAME (RN) parameter is required and must be entered. If you omit the required REPORT\_NAME (RN) parameter and you are using NOS, the screen displays the screen mode parameter entry display. When you omit a required parameter using NOS/VE, a prompt message appears indicating which parameter is required. The remaining optional parameters are assigned default values if you do not enter them.

2. Press the RETURN key and the operating limits for the selected report appear as in the following NOS/VE example:

```
20 "maximum_crc_error      "
0  "minimum_alignment_error"
30 "maximum_alignment_error"
0  "minimum_overrun_error  "
40 "maximum_overrun_error  "
0  "minimum_resource_error "
100 "maximum_resource_error"
0  "minimum_abnormal_logic "
3  "maximum_abnormal_logic "
```

3. A cursor appears on the first line that identifies an NPA expected operating limit. Move the cursor from the first line to the next by pressing the TAB key, or position the cursor to any line you desire by using the arrow keys. Change the current limit shown on any line by entering a new number over the existing number.

## CRECAR

Use the NPA report generator CRECAR to generate reports.

1. To enter this command in line mode format, key in the following:

```
CRECAR,RN=report name
```

The REPORT\_NAME (RN) parameter is required and must be entered. If you omit the required REPORT\_NAME (RN) parameter and you are using NOS, the screen displays the screen mode parameter entry display (see the CRECAR screen mode procedure to enter from this display). When you omit a required parameter using NOS/VE, a prompt message appears indicating which parameter is required. The remaining optional parameters are assigned default values if you do not enter them.

2. After entering the parameters, press the RETURN key and the report is generated.

Example:

This line mode example creates the HRDWRP1 report with all optional parameters set to default values:

```
CRECAR,RN=HRDWRP1
```

Press the RETURN key to execute, and the HRDWRP1 report is placed in file CREOUT.

## EDICLM

Use the NPA help utility procedure EDICLM to edit the explanatory information (Site Information only) about CDCNET log messages provided by procedure EXPCLM.

1. To enter this command in line mode format, key in the following:

```
EDICLM,MN=log id number
```

The MESSAGE\_NUMBER (MN) parameter is required and must be entered. If you omit the required parameter and you are using NOS, the screen displays the screen mode parameter entry display (see the EDICLM screen mode procedure to enter from this display). If you omit the required parameter and you are using NOS/VE, a prompt message appears indicating which parameter is required. The remaining optional parameter is assigned the default value if you do not enter one.

2. After entering the parameters, press the RETURN key to execute.

Example:

In this NOS example, log message number 00001 appears on your terminal screen and you may edit the Site Information portion of the message using FSE (default value).

```
EDICLM,MN=00001
```

Press the RETURN key, and the following message appears (you may have to press F3 to view the entire screen):

```
NOS FULL SCREEN EDITOR
Upper Case File NPATMP1 Lines 1 Thru 23 Size 23
.PROC,E00001*I"MESSAGE NUMBER 00001 EXPLANATION".
.HELP.
```

### LOG MESSAGE NAME

```
00001 - - - -> S_A_LOCAL_RECOVERY_FAILURE
```

### LOG MESSAGE PURPOSE

```
THIS LOG MESSAGE INDICATES THAT A FAILURE OCCURRED WHILE
EXECUTING A FAILED TASK'S RECOVERY PROCEDURE.
```

### ACTION REQUIRED

```
A CDCNET ANALYST SHOULD BE NOTIFIED WITH THE INFORMATION
REGARDING THE FAILED PROGRAM MODULE TO DETERMINE THE CONDITION
OF THE CURRENT SYSTEM.
```

### SITE INFORMATION

```
.ENDHELP
$REVERT,NOLIST.
```

Edit the Site Information portion of the message explanation and execute the QUIT function. The information (your additions, deletions, or changes) is permanent.

## EXPCLM

Use the NPA help utility procedure EXPCLM to generate explanatory information about CDCNET log messages.

1. To enter this command in line mode format, key in the following:

```
EXPCLM,MN=log id number
```

The MESSAGE\_NUMBER (MN) parameter is required and must be entered. If you omit the required parameter and you are using NOS, the screen displays the screen mode parameter entry display (see the EXPCLM screen mode procedure to enter from this display). If you omit a required parameter and you are using NOS/VE, a prompt message appears indicating which required parameter has been omitted. The remaining optional parameter is assigned the default value if you do not enter one.

2. After entering the parameter, press the RETURN key to execute.

Example:

In this NOS example, log message 00001 appears on your terminal screen:

```
EXPCLM,MN=00001
```

Press the RETURN key to execute, and the following message appears:

```
-----E00001-----  
  
  LOG MESSAGE NAME  
  
00001  - - - ->    S_A_LOCAL_RECOVERY_FAILURE  
  
  LOG MESSAGE PURPOSE  
  
      THIS LOG MESSAGE INDICATES THAT A FAILURE OCCURRED WHILE EXECUTING  
      A FAILED TASK'S RECOVERY PROCEDURE.  
  
  ACTION REQUIRED  
  
      A CDCNET ANALYST SHOULD BE NOTIFIED WITH THE INFORMATION REGARDING  
      THE FAILED PROGRAM MODULE TO DETERMINE THE CONDITION OF THE  
      CURRENT SYSTEM.  
  
  SITE INFORMATION
```

---

### NOTE

In order to view the entire display, you might have to press the F3 key to see the next screen.

---

## REFCLF

Use the NPA reformatting process REFCLF to convert network log file records into database records.

1. To enter this command, key in the following:

REFCLF DB=value (NOS/VE)

or

REFCLF.DB=value (NOS)

Either the DATA\_BASE (DB) or USER (U) parameter must be entered or REFCLF terminates with an error message. The remaining optional parameters are assigned default values if not entered.

### **NOTE**

---

In order to use REFCLF, you must have access to the network log files.

---

2. Press the RETURN key and the network log file records are reformatted into database records.

## RELNDB

Use RELNDB to reload records from an archive file into existing NPA databases.

1. To enter this command in line mode, enter the following:

```
RELNDB,AF=filename,DB=value
```

The ARCHIVE\_FILE (AF) parameter is required and must be entered. If you omit this parameter and you are running NOS, the screen displays the screen mode parameter entry display (see the RELNDB screen mode procedure to enter from this display). If you omit the required parameter and you are using NOS/VE, a prompt message appears indicating which required parameter has been omitted. The remaining optional parameters are assigned default values if you do not enter them.

2. After entering the parameters, press the RETURN key to execute.

Example:

This example reloads all the existing database files in the archive file NPAARC to the log file. All optional parameters are assigned default values.

```
RELNDB,AF=NPAARC,DB=ALL
```

Press the RETURN key to execute.

## How To Get Help on NPA Procedures

After you call a procedure interactively, but before the system executes the specified procedure, you can have a dialogue with the system about the procedure.

### NOTE

These procedures are for getting help on commands and parameters. If you want help on log messages, see the EXPCLM command in this chapter.

## How To Get Help in Screen Mode (NOS Only)

In screen mode, you press the HELP key (F5 key on some terminals) to initiate a dialogue with the system. Using this key allows you to:

- Reenter parameter values that are in error
- Request information about a procedure parameter
- Request information about the procedure itself

For example, if you are using the CRECAR procedure in screen mode and you enter an illegal value for the REPORT\_NAME parameter, the system informs you of your error by displaying the following message at the top of your screen:

```
PLEASE CORRECT (erroneous value)
```

To find out why your entry was illegal, ask the system by pressing the HELP key.

A list of legal report names appears at the bottom of your screen. Now you may enter a legal value for the REPORT\_NAME parameter.

If you again press the HELP key, you receive the following information about the CRECAR procedure at the bottom of your screen:

```
-----CRECAR-----  
  
THIS PROCEDURE WILL GENERATE NETWORK PERFORMANCE REPORTS.
```



## How To Get Help in Line Mode (NOS Only)

If you enter an incorrect value for a parameter in line mode, the system informs you of your error by displaying a message.

For example, if you are using CRECAR and enter an illegal value for REPORT\_NAME, the following message appears:

```
CREATE CDCNET ANALYSIS REPORT
CORRECT REPORT NAME ?
```

Enter a report name or, for help, type in a question mark (?) and a list of legal report names is displayed followed by a second prompt for REPORT\_NAME.

Retry entering a report name.

## How To Get Help in Line Mode (NOS/VE Only)

To get help on any command and/or its parameters while using NPA on NOS/VE, enter the following command:

```
display_command_information command name.
```

or

```
disci command name.
```

For example, if you wanted help on the CRECAR command, enter the following:

```
disci crecar
```

The screen then displays the CRECAR command description and its parameters.

# NPA Reports and Report Formats

6

|   |      |
|---|------|
| Common Report Format Features .....   | 6-1  |
| Report Headings .....   | 6-1  |
| Report Data Pages .....   | 6-5  |
| Expected Operating Limits .....   | 6-7  |
| Log Message ID .....  | 6-7  |
| Specific Reports .....  | 6-8  |
| Configuration Report (CONFRP1) .....  | 6-11 |
| CONFRP1 Report Example .....  | 6-12 |
| Connection Statistics Reports (CONNRP1, CONNRP2) .....                      | 6-15 |
| CONNRP1 Report Example .....  | 6-16 |
| CONNRP2 Report Example .....  | 6-17 |
| DI Utilization Statistics Reports (DIOSRP1, DIOSRP2, DIOSRP3, DIOSRP4) .... | 6-19 |
| DIOSRP1 Report Example .....  | 6-20 |
| DIOSRP2 Report Example .....  | 6-21 |
| DIOSRP3 Report Example .....  | 6-22 |
| DIOSRP4 Report Example .....  | 6-23 |
| Ethernet Statistics Reports (ETHRRP1, ETHRRP2) .....                        | 6-26 |
| ETHRRP1 Report Example .....  | 6-27 |
| ETHRRP2 Report Example .....  | 6-28 |
| Event Log Message Reports (EVNTRP1, EVNTRP2, EVNTRP3, EVNTRP4) ....         | 6-31 |
| EVNTRP1 Report Example .....  | 6-32 |
| EVNTRP2 Report Example .....  | 6-33 |
| EVNTRP3 Report Example .....  | 6-34 |
| EVNTRP4 Report Example .....  | 6-35 |
| HDLC Interface Statistics Reports (HDLGRP1, HDLGRP2, HDLGRP3) .....         | 6-37 |
| HDLGRP1 Report Example .....  | 6-38 |
| HDLGRP2 Report Example .....  | 6-39 |
| HDLGRP3 Report Example .....  | 6-40 |
| Hardware Error Message Reports (HRDWRP1, HRDWRP2, HRDWRP3, HRDWRP4).....    | 6-43 |
| HRDWRP1 Report Example .....  | 6-44 |
| HRDWRP2 Report Example .....  | 6-45 |
| HRDWRP3 Report Example .....  | 6-46 |
| HRDWRP4 Report Example .....  | 6-47 |
| Online Loader System Statistics Report (LOADRP1) .....                      | 6-49 |
| LOADRP1 Report Example .....  | 6-50 |
| Mainframe Channel Statistics Reports (MCISRP1, MCISRP2, MCISRP3) .....      | 6-52 |
| MCISRP1 Report Example .....  | 6-53 |
| MCISRP2 Report Example .....  | 6-54 |
| MCISRP3 Report Example .....  | 6-55 |
| Session Statistics Report (SESSRP1) .....                                   | 6-57 |
| SESSRP1 Report Example .....  | 6-58 |
| Software Error Message Reports (SFTWRP1, SFTWRP2, SFTWRP3, SFTWRP4) .       | 6-60 |
| SFTWRP1 Report Example .....  | 6-61 |
| SFTWRP2 Report Example .....  | 6-62 |
| SFTWRP3 Report Example .....  | 6-63 |
| SFTWRP4 Report Example .....  | 6-64 |
| TELNET Connection Statistics (TELNRP1, TELNRP2) .....                       | 6-66 |
| TELNRP1 Report Example .....  | 6-67 |
| TELNRP2 Report Example .....  | 6-68 |

|   |      |
|---|------|
| Terminal Statistics Reports (TERMRP1, TERMRP2) .....        | 6-70 |
| TERMRP1 Report Example .....                                | 6-71 |
| TERMRP2 Report Example .....                                | 6-72 |
| User Statistics Report (USERRP1) .....                      | 6-74 |
| USERRP1 Report Example .....                                | 6-75 |
| X.25 Connection Statistics Reports (X25CRP1, X25CRP2) ..... | 6-77 |
| X25CRP1 Report Example .....                                | 6-78 |
| X25CRP2 Report Example .....                                | 6-79 |

## Common Report Format Features

All report formats assume an 80-column wide data window to permit 10 character-per-inch printers to produce standard sized, 8-1/2-inch wide by 11-inch long reports or line printer output on computer paper that can be cut down to an 8-1/2-inch width.

Each report consists of two parts; a one-page report heading, and a set of one or more report data pages.

### NOTE

---

For more detailed information on the NPA commands used to generate these reports, see the CDCNET Commands Reference manual.

---

## Report Headings

The first page of all uncompressed NPA reports is a report heading similar to that shown in figure 6-1. The date the report was generated is shown in the upper right corner. Centered on the page is the static information for the report. It includes the product name (NETWORK PERFORMANCE ANALYZER); version number of the NPA report module; report full title; report organization information; report brief title; and the date, time period, and system ID requested by the CRECAR parameters.

### NOTE

---

The heading pages of reports can be eliminated by selecting the COMPRESS parameter of the CRECAR command.

---

Some reports also include the log IDs and/or the severity level. Figure 6-2 shows a report heading with the log IDs included. Figure 6-3 shows a report heading with the log IDs and the severity levels included.

### NOTE

---

The example report headings were generated on NOS/VE. On NOS, the report heading pages show slightly different spacing between lines.

---

88/06/01

NETWORK PERFORMANCE ANALYZER  
VERSION 1.10/5501

CDCNET ETHERNET STATISTICS  
SORTED BY SID, DATE, AND CARD SLOT

ETHRRP1 REPORT

TIME PERIOD = 00/01/01 0000 - 99/12/31 2400

SYSTEM IDS SELECTED = 080025100083  
080025100078

**Figure 6-1. Standard Report Heading**

88/06/01

NETWORK PERFORMANCE ANALYZER  
VERSION 1.10/5501

CDCNET CONFIGURATION MESSAGES  
SORTED BY DI, DATE, AND TIME

CONFRP1 REPORT

TIME PERIOD = 00/01/01 0000 - 99/12/31 2400

SYSTEM IDS SELECTED = 0800253000D2  
080025100083

LOG IDS SELECTED = ALL

LOG IDS EXCLUDED = NONE

**Figure 6-2. Report Heading with Log IDs**

88/06/01

NETWORK PERFORMANCE ANALYZER  
VERSION 1.10/5501

CDCNET EVENT LOG MESSAGES  
SORTED BY DATE AND TIME

EVNTRP1 REPORT

TIME PERIOD = 00/01/01 0000 - 99/12/31 2400

SYSTEM IDS SELECTED = 0800253000D2  
080025100083  
0800253000A2

LOG IDS SELECTED = IDS NOT EXCLUDED

LOG IDS EXCLUDED = 00073

SEVERITY SELECTED = CATASTROPHIC  
FATAL  
ERROR  
WARNING  
INFORMATIVE

Figure 6-3. Report Heading with Log IDs and Severity

## Report Data Pages

An abbreviated page heading tops each report data page and contains report dynamic information, some of which is taken from the report data itself. The report day is shown in the left corner. The page number is shown in the right corner. Centered in the page heading is the report brief title. Underneath the brief title might be either variable report-dependent title information or, in some cases, no further information. On many reports, DI TITLE and SID are displayed beneath the report title.

### NOTE

NPA reports on NOS are Control Data display code files. They may appear to contain some garbled data if not viewed interactively in NORMAL mode or if not printed appropriately.

Following the page heading, the content of NPA reports can follow one of two general formats. The first format consists of columns of data aligned under descriptive column headers. These reports usually contain DI statistical or summary data. This type of report may include predefined Control Data Expected Operating Limits (CDC EOL) as part of the column header. The limits are listed directly under the descriptive headers as two numbers. The upper CDC EOL is listed first with the lower CDC EOL listed under it on the next line. In cases where there is no CDC EOL for a particular column, no space is reserved for them. The following is an example showing the first general report format, including CDC EOLs.

```

REPORT DAY: 86/09/05                                     PAGE    1
                                     ETHRRP2 REPORT
                               TITLE = MTI_83              SID = 080025100083

      CRC      ALIGN.  OVERRUN  RESOURCE  ABNORMAL
      ERRORS   ERRORS  ERRORS   ERRORS   LOGIC
ENDING  FRAMES  FRAMES  [  20 ] [  30 ] [  40 ] [ 100 ] [   3 ]
TIME   CS RECEIVED  SENT  [   0 ] [   0 ] [   0 ] [   0 ] [   0 ]
=====
0924   6   13144   13581      0      0      0      0      0
1024   6   13291   13704      0      4      0      0      0
1224   6   11549   11782      0      0      0      0      0
1424   6    8276    8175      0      0      0      0      0
1524   6   13735   14154      0      2      0      0      0

```



The second general report format consists mainly of text lines following the page heading. A brief column header describes the fields within a text header that precedes the text body of the each message. This type of report is generated by NPA by combining DI logged data with static text contained in DI message templates. An example of this report format follows.

#### NOTE

Reports can be optionally compressed. Compressed reports do not contain the report heading page, embedded page eject characters, or page or column headings. They consist of an initial page eject followed by a stream of log message text (event type reports) or data (statistics reports). See the CRECAR command in the CDCNET Commands Reference manual for the COMPRESS parameter usage.

REPORT DAY: 88/01/20

PAGE 1

EVNTRP1 REPORT  
START TIME = 0800 HOURS

| DATE     | TIME        | SYSTEM ID    | LOG ID | SEVERITY    |
|----------|-------------|--------------|--------|-------------|
| 88/01/20 | 08.53.22438 | 0800253000AE | 1554   | INFORMATIVE |

TELNET terminal device connected to destination: PEWTER  
 Local IP address = 192.9.200.15, Local port = 23,  
 Remote IP address = 192.9.200.32, Remote port = 1028,  
 Device = \$CONSOLE\_C009C820\_0404, Device type = CON,  
 TIP = TELNET, Terminal Protocol = NVT,  
 Source address = 0000A00F0800253000AEAEA3,  
 Destination address = 0000A00F080025D4C0793871,

88/01/20 08.53.36009 0800253000AE 1555 INFORMATIVE  
 TELNET terminal device disconnected from destination: PEWTER  
 Local IP address = 192.9.200.15, Local port = 23,  
 ..

When generating a report of this format, NPA may encounter a situation where a particular template is not defined. If this happens, the message is formatted using only the data logged by the DI. The first message in the example above would appear as follows:

88/01/20 08.53.22438 0800253000AE 1554 ERROR  
 --ERROR-- CC=0C 3154 TEXT=?PEWTER?192?9?200?15?23?192?9?200?32?1028?  
 \$CONSOLE\_C009C820\_0404?CON?TELNET?NVT?0000A00F0800253000AEAEA3?  
 0000A00F080025D4C0793871

The common text header is intact and followed by an ERROR indication, product identifier, and template number. The text of the message body consists solely of DI logged data separated by a (?) delimiter.

## Expected Operating Limits

Some reports include expected operating limits. This feature allows you to easily detect unsatisfactory performance conditions in your network. The limits are expressed as two numbers; an upper limit and a lower limit, both of which appear in the column heading portion of your report. The column heading occurs on the first column heading line, the upper limit appears on the next line directly below the column title, and the lower limit appears on the following line directly below that. Any values that do not fall within the specified limit range are called to your attention. A less-than symbol (<) appears to the right of a value that is less than the lower limit. A greater-than symbol (>) appears to the right of a value that is greater than the upper limit. These limits are demonstrated in the following example:

|       |    |    |    |    |    | BLOCKS |       | % BAD |       | BLOCKS |       | % BAD |       |
|-------|----|----|----|----|----|--------|-------|-------|-------|--------|-------|-------|-------|
|       |    |    |    |    |    |        |       | [ 5]  |       |        |       | [ 7]  |       |
|       |    |    |    |    |    | IN     |       | [ 0]  |       | OUT    |       | [ 0]  |       |
| TIME  | CS | LI | PO | SA | DA |        |       |       |       |        |       |       |       |
| ===== | == | == | == | == | == | =====  | ===== | ===== | ===== | =====  | ===== | ===== | ===== |
| 0900  | 01 | 01 | 01 | 23 | 00 | 224    | 22    | 10>   |       | 783    | 48    | 5     |       |
| 0900  | 01 | 02 | 01 | 24 | 00 | 164    | 78    | 5     |       | 564    | 28    | 5     |       |

In this sample report segment, the limits appear directly beneath the two column headings described as % BAD. The upper number always represents the upper limit; the number directly below always defines the lower limit. Here, the first % BAD field defines as acceptable a limit ranging from 0% to 5%; the second % BAD field specifies a lower limit of 0% and an upper limit of 7%. The value, 10, beneath the first % BAD heading is flagged for your attention because it exceeds the upper limit of 5.

Specific ranges of limits for applicable reports have been defined in your NPA software program. However, you may change existing limits by using the CHAEOL command.

## Log Message ID

NPA reports are generated from log messages with unique log message identifiers (ID(s)). Some reports consist of a collection of expanded log message text (configuration report, event message reports, hardware error message reports, and software error message reports). The expanded text for each log message includes the log ID.

The other NPA reports (for example, connection statistics report) are generated from statistical data contained in certain log messages. These reports do not contain the log ID. The log IDs used to generate them are listed in the descriptive text in this manual.

For more information on the IDs, consult the online Diagnostic Messages manual. Or, if you prefer, you can use the EXPCLM command.

## Specific Reports

NPA provides you with a standard report set. You can generate some of these report types in more than one format. For example, you can choose from three varieties of reports that provide mainframe channel interface (MCI) statistical information.

The following is a list of NPA report types and the names of the individual reports available for each general report type. This list also contains the report name keyword value that you enter when you execute NPA procedures. The reports are described and illustrated on the pages following the table.

| Report Type   | Report Name   | Keyword |
|---|---|---------|
| Configuration report                                    | CDCNET Configuration Messages<br>- Sorted by Date and Time                        | CONFRP1 |
| Connection statistics reports                           | CDCNET Connection Statistics  | CONNRP1 |
|   | CDCNET Connection Statistics<br>on a Daily Basis                                  | CONNRP2 |
| Device interface (DI)<br>utilization statistics reports | CDCNET Utilization Statistics<br>- CPU and Memory Utilization                     | DIOSRP1 |
|   | CDCNET Utilization Statistics<br>- CPU and Memory Utilization<br>on a Daily Basis | DIOSRP2 |
|   | CDCNET Utilization Statistics<br>- Memory State Utilization                       | DIOSRP3 |
|   | CDCNET Utilization Statistics<br>- Memory Utilization on a<br>Daily Basis         | DIOSRP4 |
| Ethernet statistics reports                             | CDCNET Ethernet Statistics<br>(Number of frames sent<br>through each Ethernet)    | ETHRRP1 |
|   | CDCNET Ethernet Statistics<br>(Types of errors that occur during<br>transmission) | ETHRRP2 |
| Event log message<br>reports                            | CDCNET Event Log Messages<br>- Sorted by Date and Time                            | EVNTRP1 |
|   | CDCNET Event Log Messages<br>- Sorted by Severity and DI                          | EVNTRP2 |
|   | CDCNET Event Log Message<br>- Frequency Chart                                     | EVNTRP3 |
|   | CDCNET Event Log Message<br>- Frequency Chart Reported by DI                      | EVNTRP4 |

| <b>Report Type</b>   | <b>Report Name</b>   | <b>Keyword</b> |
|--|--|----------------|
| High-level data link control (HDLC) interface statistics reports | CDCNET HDLC Statistics Characters, Frames and Messages                         | HDLCRP1        |
|  | CDCNET HDLC Statistics Characters and Messages - Sorted by DI on a Daily Basis | HDLCRP2        |
|  | CDCNET HDLC Statistics - Frames and Frame Errors                               | HDLCRP3        |
| Hardware error message reports                                   | CDCNET Hardware Messages - Sorted by Date and Time                             | HRDWRP1        |
|  | CDCNET Hardware Messages - Sorted by Severity and DI                           | HRDWRP2        |
|  | CDCNET Hardware Messages - Frequency chart                                     | HRDWRP3        |
|  | CDCNET Hardware Messages - Frequency chart reported by DI                      | HRDWRP4        |
| Online loader system statistics report                           | CDCNET Online Loader System Report   | LOADRP1        |
| Mainframe channel statistics reports                             | CDCNET Mainframe Channel Statistics - Characters and Blocks                    | MCISRP1        |
|  | CDCNET Mainframe Channel Statistics - Sorted by SID on a Daily Basis           | MCISRP2        |
|  | CDCNET Mainframe Channel Statistics - Block Statistics                         | MCISRP3        |
| Session statistics report  | CDCNET Session Statistics  | SESSRP1        |
| Software error message reports                                   | CDCNET Software Messages - Sorted by Date and Time                             | SFTWRP1        |
|  | CDCNET Software Messages - Sorted by Severity and DI                           | SFTWRP2        |
|  | CDCNET Software Message - Frequency Chart                                      | SFTWRP3        |
|  | CDCNET Software Message - Frequency Chart Reported by DI                       | SFTWRP4        |

## Specific Reports

| Report Type                        | Report Name                                       | Keyword |
|------------------------------------|---|---------|
| TELNET statistics reports          | CDCNET TELNET Statistics                          | TELNRP1 |
|                                    | CDCNET TELNET Statistics on a Daily Basis         | TELNRP2 |
| Terminal statistics reports        | CDCNET Terminal Statistics                        | TERMRP1 |
|                                    | CDCNET Terminal Statistics                        | TERMRP2 |
| User statistics report             | CDCNET User Report Unsorted                       | USERRP1 |
| X.25 connection statistics reports | CDCNET X25 Connection Statistics                  | X25CRP1 |
|                                    | CDCNET X25 Connection Statistics on a Daily Basis | X25CRP2 |

## Configuration Report (CONFRP1)

This report provides the configuration report, on an hourly status basis, of the DI hardware and software. The configuration reports allow you to observe hardware availability throughout your network. This information can be used to pinpoint weak areas in the network that may require maintenance.

Use the `DEFINE_SOURCE_LOG_GROUP` command to gather the information needed for this report. The log message IDs are 593 through 597 with an attribute of S.

The configuration report is organized by DI for ease of reading.

**CONFRP1 Report Example**

The first page is an unnumbered report heading similar to that shown in figure 6-2. Following the report heading page is a numbered report data page similar to the following example. Table 6-1 lists the report field names and their definitions.

```

REPORT DAY: 88/02/09                                     PAGE    1

                                CONFRP1 REPORT
                                TITLE = AHD_NDI_10006D      SID = 08002510006D

    DATE      TIME      SYSTEM ID    LOG ID
    =====
    88/02/09 05.55.00204 08002510006D    593
DI SYSTEM STATUS
SYSTEM NAME = AHD_NDI_10006D
SYSTEM ADDRESS = 08002510006D(16)
BOOT VERSION NUMBER = 4308(16)
SOFTWARE RELEASE LEVEL = 4308(16)
NUMBER OF TASKS = 23
FREE SMM MEMORY = 248988
PERCENT CPU UTILIZATION = 13
BUFFER STATE = GOOD
MEMORY STATE = GOOD
DATE AND TIME OF LAST RELOAD = 88/02/05 21.22.59
-
BUFFER STATUS
TYPE      TOTAL BUFFERS  AVAILABLE BUFFERS  BUFFER SIZE
DATA      1720           1074              144
DESCRIPTOR 566           545              32
-
SMM MEMORY STATUS
TOTAL MEMORY  AVAILABLE MEMORY  EXTENTS  DELOADABLE MEMORY
1048576      248988           132      58148
-
PMM MEMORY STATUS
TOTAL MEMORY  AVAILABLE MEMORY  EXTENTS  DELOADABLE MEMORY
131072      24292           5        0
-
MPB RAM STATUS
TOTAL MEMORY  AVAILABLE MEMORY  EXTENTS  DELOADABLE MEMORY
16384        2060           2        0
LARGEST SMM MEMORY EXTENT AVAILABLE = 200690

```

**Table 6-1. Field Definitions for Configuration Report**

| <b>Field</b>        | <b>Definition</b>  |               |  |                   |  |             |  |
|---------------------|--|---------------|--|-------------------|--|-------------|--|
| BOOT VERSION NUMBER | Version number of the boot file currently loaded in and running on the DI. Taken from exception list or INITMDI.   |               |  |                   |  |             |  |
| BUFFER STATE        | Describes level of buffer availability. The four states of buffer availability are GOOD, FAIR, POOR, and CONGESTED. The boundaries between these states is set during configuration. Each boundary is expressed as percentage of the total resource currently allocated after DI configuration.  |               |  |                   |  |             |  |
| BUFFER STATUS       | Displays the following information: <table> <tr> <td>Total Buffers</td><td>Total number of buffers allocated for use by the DI.</td></tr> <tr> <td>Available Buffers</td><td>Number of allocated buffers that are not currently in use.</td></tr> <tr> <td>Buffer Size</td><td>Size in bytes of that particular type of buffer.</td></tr> </table> | Total Buffers | Total number of buffers allocated for use by the DI. | Available Buffers | Number of allocated buffers that are not currently in use. | Buffer Size | Size in bytes of that particular type of buffer. |
| Total Buffers       | Total number of buffers allocated for use by the DI.   |               |  |                   |  |             |  |
| Available Buffers   | Number of allocated buffers that are not currently in use.   |               |  |                   |  |             |  |
| Buffer Size         | Size in bytes of that particular type of buffer.   |               |  |                   |  |             |  |
| DATE                | The date on which the log occurred.  |               |  |                   |  |             |  |
| FREE SMM MEMORY     | The amount of system main memory that is currently available for modules to be loaded into.  |               |  |                   |  |             |  |
| LOG ID              | The log message identification number.   |               |  |                   |  |             |  |
| MEMORY STATE        | Describes level of memory availability. The four states of memory availability are GOOD, FAIR, POOR, and CONGESTED. The boundaries between these states is set during configuration. Each boundary is expressed as a percentage of the total resource currently allocated after DI configuration.  |               |  |                   |  |             |  |

*(Continued)*



**Table 6-1. Field Definitions for Configuration Report (Continued)**

| <b>Field</b>                  | <b>Definition</b>  |              |  |                  |  |         |  |                   |  |
|-------------------------------|--|--------------|--|------------------|--|---------|--|-------------------|--|
| MEMORY STATUS (PMM, SMM, MPB) | Displays the following information: <table> <tr> <td>Total Memory</td><td>Total number of bytes of memory for this DI.</td></tr> <tr> <td>Available Memory</td><td>Number of bytes of memory available for loading modules and allocating structures.</td></tr> <tr> <td>Extents</td><td>Number of memory fragments into which available memory is reached.</td></tr> <tr> <td>Deloadable Memory</td><td>Number of bytes that can be used when a deloadable threshold is reached. Deloadable memory is comprised of modules without an active task.</td></tr> </table> | Total Memory | Total number of bytes of memory for this DI. | Available Memory | Number of bytes of memory available for loading modules and allocating structures. | Extents | Number of memory fragments into which available memory is reached. | Deloadable Memory | Number of bytes that can be used when a deloadable threshold is reached. Deloadable memory is comprised of modules without an active task. |
| Total Memory                  | Total number of bytes of memory for this DI.   |              |  |                  |  |         |  |                   |  |
| Available Memory              | Number of bytes of memory available for loading modules and allocating structures.   |              |  |                  |  |         |  |                   |  |
| Extents                       | Number of memory fragments into which available memory is reached.   |              |  |                  |  |         |  |                   |  |
| Deloadable Memory             | Number of bytes that can be used when a deloadable threshold is reached. Deloadable memory is comprised of modules without an active task.   |              |  |                  |  |         |  |                   |  |
| NUMBER OF TASKS               | The number of tasks executing in the DI.   |              |  |                  |  |         |  |                   |  |
| PERCENT CPU UTILIZATION       | The percent of time the CPU is active.   |              |  |                  |  |         |  |                   |  |
| SEVERITY                      | The description of the severity of the type of error that has occurred.  |              |  |                  |  |         |  |                   |  |
| SOFTWARE RELEASE LEVEL        | The level at which the software was compiled.  |              |  |                  |  |         |  |                   |  |
| SYSTEM ADDRESS                | A 12-digit hexadecimal system ID associated with the DI.   |              |  |                  |  |         |  |                   |  |
| SYSTEM ID                     | The system identification number that identifies the DI.   |              |  |                  |  |         |  |                   |  |
| SYSTEM NAME                   | The logical name given to the DI in its configuration file.  |              |  |                  |  |         |  |                   |  |
| TIME                          | The DI clock time when the log occurred.   |              |  |                  |  |         |  |                   |  |

## Connection Statistics Reports (CONNRP1, CONNRP2)

Connection statistics reports allow you to observe the length and location of terminal session usage throughout your network. This information demonstrates, over a period of time, growth areas in your network defined in sessions. You can then anticipate and meet additional network hardware needs.

Use the `DEFINE_SOURCE_LOG_GROUP` command to gather the information needed for these reports. The log message IDs are 618 and 620 with an attribute of S.

NPA provides two connection statistics reports:

CONNRP1     Sorts connection statistics by DI and time.

CONNRP2     Sorts connection statistics by service name and DI on a daily basis.

**CONNRP1 Report Example**

The first page is an unnumbered report heading similar to that shown in figure 6-1. Following the report heading page is a numbered report data page similar to the following example. Table 6-2 lists the report field names and their definitions.

REPORT DAY: 86/09/05

PAGE 1

**CONNRP1 REPORT**

TITLE = TDI\_6F

SID = 08002510006F

| ENDING<br>TIME | SERVICE NAME | INITIATION | C O N N E C T I O N<br>TERMINATE | AVG TIME | MAX TIME |
|----------------|--------------|------------|----------------------------------|----------|----------|
| =====          | =====        | =====      | =====                            | =====    | =====    |
| 500            | ARH907       | 1          | 1                                | 675      | 675      |
| 800            | ARH907       | 3          | 2                                | 80       | 120      |
| 800            | ARH990       | 1          | 0                                | 0        | 0        |
| 900            | ARH907       | 8          | 2                                | 540      | 590      |
| 900            | ARH990       | 2          | 2                                | 835      | 1350     |
| 1000           | ARH907       | 15         | 11                               | 1061     | 2895     |
| 1000           | ARH990       | 2          | 2                                | 132      | 245      |
| 1100           | ARH907       | 5          | 8                                | 2936     | 5990     |
| 1100           | ARH990       | 2          | 2                                | 147      | 285      |
| 1200           | ARH907       | 8          | 3                                | 461      | 1115     |
| 1200           | ARH990       | 3          | 2                                | 120      | 140      |
| 1300           | ARH907       | 5          | 5                                | 1959     | 4065     |
| 1300           | ARH990       | 2          | 1                                | 95       | 95       |
| 1400           | ARH907       | 11         | 6                                | 1974     | 5990     |
| 1400           | ARH990       | 1          | 0                                | 0        | 0        |
| 1500           | ARH907       | 16         | 16                               | 556      | 2180     |
| 1500           | ARH990       | 7          | 7                                | 3436     | 18245    |
| 1600           | ARH907       | 12         | 13                               | 2250     | 5945     |
| 1600           | ARH990       | 2          | 2                                | 2610     | 4170     |
| 1700           | ARH907       | 10         | 16                               | 2889     | 10240    |
| 1700           | ARH990       | 1          | 1                                | 3560     | 3560     |
| 1800           | ARH907       | 1          | 2                                | 1050     | 1945     |
| 1800           | ARH990       | 0          | 2                                | 3685     | 7250     |

**CONNRP2 Report Example**

The first page is an unnumbered report heading similar to that shown in figure 6-1. Following the report heading page is a report data page similar to the following example. Table 6-2 lists the report field names and their definitions.

```

REPORT DAY: 86/09/05                                     PAGE    1
                                CONNRP2 REPORT
                                TITLE = TDI_6F             SID = 08002510006F

ENDING
DATE          SERVICE NAME          INITIATION  TERMINATE  AVG TIME  MAX TIME
=====
860905 ARH907                95          85      1724    10240
860905 ARH990                23          21      2036    18245

```

**Table 6-2. Field Definitions for Connection Statistics Reports**

| <b>Field</b>          | <b>Definition</b>  |
|-----------------------|--|
| CONNECTION AVG TIME   | The average length, in seconds, of a terminal session established through the DI.                        |
| CONNECTION INITIATION | The number of times during the report interval that a terminal connection was initiated through the DI.  |
| CONNECTION TERMINATE  | The number of times during the report interval that a terminal connection through the DI was terminated. |
| ENDING DATE           | The last date that the reported statistics were tabulated.   |
| ENDING TIME           | The last time that the reported statistics were tabulated.   |
| CONNECTION MAX TIME   | The length, in seconds, of the longest terminal session established through the DI.                      |
| SERVICE NAME          | The name of the service to which the terminal users are connected.                                       |

## DI Utilization Statistics Reports (DIOSRP1, DIOSRP2, DIOSRP3, DIOSRP4)

DI utilization statistics reports are designed to assist you in the long-term planning of your CDCNET resources. These reports list the utilization of the primary DI resources, which are the DI central processor unit (CPU) and the DI memory. This information allows you to contrast the amount of CDCNET resources used against the amount of resources available. You use this comparison to determine whether the available resources are sufficient or if your network requires additional hardware resources, additional memory, or reconfiguration with additional communication capabilities.

If the reported statistics indicate that the memory available is being overutilized or underutilized during a specific reporting period, examine the line regulation statistics reported during the same interval on the TERM RP1 and TERM RP2 reports. This comparison may help you to determine if specific lines are causing unsatisfactory utilization.

Use the `DEFINE_SOURCE_LOG_GROUP` and `START_PROCESS_METRICS` commands to gather the statistics needed for these reports. The log message ID for these reports is 299 with an attribute of S.

NPA provides four DI utilization statistics reports:

|         |  |
|---------|--|
| DIOSRP1 | Provides an hourly device operating report on CPU and memory utilization statistics. |
| DIOSRP2 | Provides a daily device operating report on CPU and memory utilization statistics.   |
| DIOSRP3 | Provides an hourly device operating report on memory state transitions statistics.   |
| DIOSRP4 | Provides a daily device operating report on memory state transitions statistics.     |

**DIOSRP1 Report Example**

The first page is an unnumbered report heading similar to that shown in figure 6-1. Following the report heading is a numbered report data page similar to the following example. Table 6-3 lists the report field names and their definitions.

REPORT DAY: 86/09/05

PAGE 1

**DIOSRP1 REPORT**

TITLE = TDI\_78

SID = 080025100078

| ENDING<br>TIME | MPB-CPU<br>AVG UTL | MPB-CPU<br>MAX UTL | DTA BUF<br>AVG USE | DTA BUF<br>MAX USE | DTA BUF<br>MIN USE | ALC MEM<br>AVG USE | ALC MEM<br>MAX USE | ALC MEM<br>MIN USE | SMM<br>TOTAL | TAM<br>TOTAL | % TAM<br>IN BUFF |
|----------------|--------------------|--------------------|--------------------|--------------------|--------------------|--------------------|--------------------|--------------------|--------------|--------------|------------------|
| 0112           | 4                  | 14                 | 71                 | 73                 | 58                 | 58                 | 1048576            | 464826             | 63           |              |                  |
|                |                    | 2                  |                    | 69                 |                    | 58                 |                    |                    |              |              |                  |
| 0212           | 4                  | 18                 | 70                 | 72                 | 58                 | 58                 | 1048576            | 464826             | 63           |              |                  |
|                |                    | 2                  |                    | 69                 |                    | 58                 |                    |                    |              |              |                  |
| 0312           | 4                  | 15                 | 70                 | 72                 | 57                 | 58                 | 1048576            | 464826             | 63           |              |                  |
|                |                    | 2                  |                    | 69                 |                    | 57                 |                    |                    |              |              |                  |
| 0412           | 4                  | 14                 | 70                 | 72                 | 57                 | 58                 | 1048576            | 464826             | 63           |              |                  |
|                |                    | 2                  |                    | 69                 |                    | 57                 |                    |                    |              |              |                  |
| 0512           | 4                  | 15                 | 72                 | 75                 | 57                 | 58                 | 1048576            | 464826             | 63           |              |                  |
|                |                    | 2                  |                    | 70                 |                    | 57                 |                    |                    |              |              |                  |
| 0612           | 4                  | 16                 | 71                 | 74                 | 57                 | 58                 | 1048576            | 464826             | 63           |              |                  |
|                |                    | 2                  |                    | 69                 |                    | 57                 |                    |                    |              |              |                  |
| 0712           | 4                  | 15                 | 72                 | 74                 | 57                 | 58                 | 1048576            | 464826             | 63           |              |                  |
|                |                    | 2                  |                    | 69                 |                    | 57                 |                    |                    |              |              |                  |
| 0812           | 5                  | 19                 | 71                 | 76                 | 58                 | 60                 | 1048576            | 464826             | 63           |              |                  |
|                |                    | 2                  |                    | 65                 |                    | 58                 |                    |                    |              |              |                  |
| 0912           | 5                  | 23                 | 71                 | 74                 | 59                 | 61                 | 1048576            | 464826             | 63           |              |                  |
|                |                    | 2                  |                    | 67                 |                    | 58                 |                    |                    |              |              |                  |
| 1012           | 5                  | 20                 | 70                 | 74                 | 60                 | 62                 | 1048576            | 464826             | 63           |              |                  |
|                |                    | 2                  |                    | 68                 |                    | 60                 |                    |                    |              |              |                  |
| 1212           | 5                  | 21                 | 72                 | 75                 | 60                 | 62                 | 1048576            | 464826             | 63           |              |                  |
|                |                    | 2                  |                    | 68                 |                    | 59                 |                    |                    |              |              |                  |
| 1312           | 6                  | 22                 | 72                 | 75                 | 60                 | 62                 | 1048576            | 464826             | 63           |              |                  |
|                |                    | 2                  |                    | 68                 |                    | 60                 |                    |                    |              |              |                  |
| 1412           | 5                  | 21                 | 71                 | 75                 | 59                 | 61                 | 1048576            | 464826             | 63           |              |                  |
|                |                    | 2                  |                    | 67                 |                    | 58                 |                    |                    |              |              |                  |
| 1512           | 6                  | 20                 | 70                 | 75                 | 59                 | 60                 | 1048576            | 464826             | 63           |              |                  |
|                |                    | 2                  |                    | 66                 |                    | 59                 |                    |                    |              |              |                  |
| 1612           | 5                  | 20                 | 71                 | 75                 | 59                 | 60                 | 1048576            | 464826             | 63           |              |                  |
|                |                    | 2                  |                    | 68                 |                    | 59                 |                    |                    |              |              |                  |
| 1712           | 5                  | 23                 | 71                 | 75                 | 58                 | 61                 | 1048576            | 464826             | 63           |              |                  |
|                |                    | 2                  |                    | 66                 |                    | 58                 |                    |                    |              |              |                  |
| 1912           | 4                  | 14                 | 72                 | 75                 | 57                 | 57                 | 1048576            | 464826             | 63           |              |                  |
|                |                    | 2                  |                    | 70                 |                    | 57                 |                    |                    |              |              |                  |
| 2012           | 3                  | 14                 | 71                 | 73                 | 57                 | 57                 | 1048576            | 464826             | 63           |              |                  |
|                |                    | 2                  |                    | 70                 |                    | 57                 |                    |                    |              |              |                  |
| 2112           | 3                  | 14                 | 71                 | 73                 | 57                 | 57                 | 1048576            | 464826             | 63           |              |                  |
|                |                    | 2                  |                    | 70                 |                    | 57                 |                    |                    |              |              |                  |

**DIOSRP2 Report Example**

The first page is an unnumbered report heading similar to that shown in figure 6-1. Following the report heading is a numbered report data page similar to the following example. Table 6-3 lists the report field names and their definitions.

```

REPORT DAY: 86/09/05                                PAGE    1
                                DIOSRP2 REPORT
                                TITLE = TDI_78        SID = 080025100078

                                MPB-CPU      DTA BUF      ALC MEM AVERAGE AVERAGE AVERAGE
ENDING MPB-CPU MAX UTL DTA BUF MAX USE ALC MEM MAX USE  SMM      TAM      % TAM
DATE   AVG UTL MIN UTL AVG USE MIN USE AVG USE MIN USE  TOTAL    TOTAL    IN BUFF
=====
860905      4      23      71      76      58      62    96195  464826    63
              2              65              57
860906      3      15      71      75      56      57  1048576  464826    63
              2              70              56

```



**DIOSRP3 Report Example**

The first page is an unnumbered report heading similar to that shown in figure 6-1. Following the report heading is a numbered report data page similar to the following example. Table 6-3 lists the report field names and their definitions.

REPORT DAY: 86/09/05

PAGE 1

**DIOSRP3 REPORT**

TITLE = TDI\_A2

SID = 0800253000A2

| ENDING TIME | TAM<br>GOOD<br>TIM/TRAN | TAM<br>FAIR<br>TIM/TRAN | TAM<br>POOR<br>TIM/TRAN | TAM<br>CONG.<br>TIM/TRAN | BUF<br>GOOD<br>TIM/TRAN | BUF<br>FAIR<br>TIM/TRAN | BUF<br>POOR<br>TIM/TRAN | BUF<br>CONG.<br>TIM/TRAN |
|-------------|-------------------------|-------------------------|-------------------------|--------------------------|-------------------------|-------------------------|-------------------------|--------------------------|
| 0105        | 3600                    | 0                       | 0                       | 0                        | 3600                    | 0                       | 0                       | 0                        |
|             | 0                       | 0                       | 0                       | 0                        | 0                       | 0                       | 0                       | 0                        |
| 0205        | 3600                    | 0                       | 0                       | 0                        | 3600                    | 0                       | 0                       | 0                        |
|             | 0                       | 0                       | 0                       | 0                        | 0                       | 0                       | 0                       | 0                        |
| 0305        | 3600                    | 0                       | 0                       | 0                        | 3600                    | 0                       | 0                       | 0                        |
|             | 0                       | 0                       | 0                       | 0                        | 0                       | 0                       | 0                       | 0                        |
| 0405        | 3600                    | 0                       | 0                       | 0                        | 3600                    | 0                       | 0                       | 0                        |
|             | 0                       | 0                       | 0                       | 0                        | 0                       | 0                       | 0                       | 0                        |
| 0505        | 3600                    | 0                       | 0                       | 0                        | 3600                    | 0                       | 0                       | 0                        |
|             | 0                       | 0                       | 0                       | 0                        | 0                       | 0                       | 0                       | 0                        |
| 0605        | 3600                    | 0                       | 0                       | 0                        | 3600                    | 0                       | 0                       | 0                        |
|             | 0                       | 0                       | 0                       | 0                        | 0                       | 0                       | 0                       | 0                        |
| 0705        | 3600                    | 0                       | 0                       | 0                        | 3600                    | 0                       | 0                       | 0                        |
|             | 0                       | 0                       | 0                       | 0                        | 0                       | 0                       | 0                       | 0                        |
| 0805        | 3600                    | 0                       | 0                       | 0                        | 3600                    | 0                       | 0                       | 0                        |
|             | 0                       | 0                       | 0                       | 0                        | 0                       | 0                       | 0                       | 0                        |
| 0905        | 3600                    | 0                       | 0                       | 0                        | 3600                    | 0                       | 0                       | 0                        |
|             | 0                       | 0                       | 0                       | 0                        | 0                       | 0                       | 0                       | 0                        |
| 1005        | 3600                    | 0                       | 0                       | 0                        | 3600                    | 0                       | 0                       | 0                        |
|             | 0                       | 0                       | 0                       | 0                        | 0                       | 0                       | 0                       | 0                        |
| 1205        | 3600                    | 0                       | 0                       | 0                        | 3600                    | 0                       | 0                       | 0                        |
|             | 0                       | 0                       | 0                       | 0                        | 0                       | 0                       | 0                       | 0                        |
| 1305        | 3600                    | 0                       | 0                       | 0                        | 3600                    | 0                       | 0                       | 0                        |
|             | 0                       | 0                       | 0                       | 0                        | 0                       | 0                       | 0                       | 0                        |
| 1415        | 3562                    | 0                       | 0                       | 0                        | 3562                    | 0                       | 0                       | 0                        |
|             | 0                       | 0                       | 0                       | 0                        | 0                       | 0                       | 0                       | 0                        |
| 1515        | 3600                    | 0                       | 0                       | 0                        | 3600                    | 0                       | 0                       | 0                        |
|             | 0                       | 0                       | 0                       | 0                        | 0                       | 0                       | 0                       | 0                        |
| 1615        | 3600                    | 0                       | 0                       | 0                        | 3600                    | 0                       | 0                       | 0                        |
|             | 0                       | 0                       | 0                       | 0                        | 0                       | 0                       | 0                       | 0                        |
| 1715        | 3600                    | 0                       | 0                       | 0                        | 3600                    | 0                       | 0                       | 0                        |
|             | 0                       | 0                       | 0                       | 0                        | 0                       | 0                       | 0                       | 0                        |
| 1815        | 3600                    | 0                       | 0                       | 0                        | 3600                    | 0                       | 0                       | 0                        |
|             | 0                       | 0                       | 0                       | 0                        | 0                       | 0                       | 0                       | 0                        |
| 1915        | 3600                    | 0                       | 0                       | 0                        | 3600                    | 0                       | 0                       | 0                        |
|             | 0                       | 0                       | 0                       | 0                        | 0                       | 0                       | 0                       | 0                        |
| 2015        | 3600                    | 0                       | 0                       | 0                        | 3600                    | 0                       | 0                       | 0                        |
|             | 0                       | 0                       | 0                       | 0                        | 0                       | 0                       | 0                       | 0                        |

**DIOSRP4 Report Example**

The first page is an unnumbered report heading similar to that shown in figure 6-1. Following the report heading is a numbered report data page similar to the following example. Table 6-3 lists the report field names and their definitions.

```

REPORT DAY: 86/09/05                                PAGE    1
                                DIOSRP4 REPORT
                                TITLE = TDI_78        SID = 080025100078

      TAM      TAM      TAM      TAM      BUF      BUF      BUF      BUF
ENDING GOOD    FAIR    POOR    CONG.    GOOD    FAIR    POOR    CONG.
DATE  TIM/TRAN TIM/TRAN TIM/TRAN TIM/TRAN TIM/TRAN TIM/TRAN TIM/TRAN
=====
860905    3600      0      0      0      3600      0      0      0
          0          0      0      0          0      0      0      0
860906    3600      0      0      0      3600      0      0      0
          0          0      0      0          0      0      0      0

```

**Table 6-3. Field Definitions for DI Utilization Statistics Reports**

| <b>Field</b>                                 | <b>Definition</b>  |
|--|--|
| ALC MEM AVG USE                              | The percentage of total allocatable memory (TAM) in use during the report interval.  |
| ALC MEM MAX USE                              | The maximum percentage of TAM in use during the report interval.   |
| ALC MEM MIN USE                              | The minimum percentage of TAM in use during the report interval.   |
| AVERAGE SMM TOTAL                            | The average number of bytes of system main memory available in the DI during the report period.  |
| AVERAGE % TAM IN BUFF                        | The average percentage of TAM made into buffers after all modules have been loaded into the DI and configuration file processing is completed.   |
| AVERAGE TAM TOTAL                            | The average number of bytes of TAM available after all modules have been loaded into the DI.   |
| BUF STATE (GOOD, FAIR, POOR, CONG.) TIM/TRAN | State the buffers are in. TIM is the number of times that the buffers were in the specified state when sampled every 10 seconds, and TRAN is the number of times that a transition occurred into a state during the report interval. |
| DTA BUF AVG USE                              | The average percentage of data buffers in use.   |
| DTA BUF MAX USE                              | The maximum percentage of data buffers in use during the report interval.  |
| DTA BUF MIN USE                              | The minimum percentage of data buffers in use during the report interval.  |

*(Continued)*

**Table 6-3. Field Definitions for DI Utilization Statistics Reports (Continued)**

| Field   | Definition  |
|---|---|
| ENDING DATE   | The last date during which the reported statistics were tabulated.  |
| ENDING TIME   | The last time at which the reported statistics were tabulated.  |
| MPB-CPU AVG UTL   | The average percentage <sup>1</sup> of time the CPU has spent during the report interval performing master processor board-originated tasks.  |
| MPB-CPU MAX UTL   | The highest percentage <sup>1</sup> of time the CPU has spent on master processor board-originated tasks performed by the CPU during the report interval.   |
| MPB-CPU MIN UTL   | The lowest percentage <sup>1</sup> of time the CPU has spent on master processor board-originated tasks performed by the CPU during the report interval.  |
| SMM TOTAL   | The total amount, in bytes, of system main memory available in the DI.  |
| % TAM IN BUFF   | The percentage of TAM made into buffers after all modules have been loaded into the DI.   |
| TAM STATE (GOOD, FAIR, POOR, CONG.) TIM/TRAN                        | State that memory is in. TIM is the number of times that the memory was in the specified state when sampled every 10 seconds, and TRAN is the number of times that a transition occurred into a state during the report interval. |
| TAM TOTAL   | The amount, in bytes, of TAM available after all modules have been loaded into the DI.  |
| 1. MPB-CPU percent use is calculated when sampled every 10 seconds. |   |

## Ethernet Statistics Reports (ETHRRP1, ETHRRP2)

Ethernet statistics reports allow you to evaluate the performance of your Ethernet and to correct problems before they become catastrophic. Reported statistics tell you the numbers and sizes of data frames transmitted over your Ethernet, the types of transmission errors that have occurred, and the number of data transmission collisions over the reported time interval.

Use the `DEFINE_SOURCE_LOG_GROUP` and `START_TRUNK_METRICS` commands to gather the statistics needed for these reports. The log message ID is 639 with an attribute of S.

NPA provides two Ethernet statistics reports:

ETHRRP1      Ethernet frame size transmission sorted by SID.

ETHRRP2      Ethernet frame transmission errors sorted by SID.

Ethernet statistics messages are forwarded to the network log file after SID initialization is complete.

**ETHRRP1 Report Example**

The first page is an unnumbered report heading similar to that shown in figure 6-1. Following the report heading is a numbered report data page similar to the following example. Table 6-4 lists the report field names and their definitions.

```

REPORT DAY: 86/09/05                                     PAGE    1
                                     ETHRRP1 REPORT
                               TITLE = TDI_78             SID = 080025100078

      XMIT 255 XMIT 511 XMIT 767 XMIT 1023 XMIT 1279 XMIT 1535 COLLIS-
TIME  CS RECV 255 RECV 511 RECV 767 RECV 1023 RECV 1279 RECV 1535 IONS
=====
0912  6      2262      52      2      0      2      7      0
      2651      179      105      0      13      0
1012  6      2196      41      2      0      2      4      2
      2370      458      63      2      6      0
1212  6      2629      41      2      0      2      5      5
      2730      472      127      5      20      0
1312  6      4509      61      2      0      2      5      2
      3423      1615      79      1      4      0
1412  6      1971      48      3      0      1      4      4
      2506      119      62      8      27      0
1512  6      4179      34      2      0      4      8      0
      4374      311      173      9      22      0

```

**ETHRRP2 Report Example**

The first page is an unnumbered report heading similar to that shown in figure 6-1. Following the report heading is a numbered report data page similar to the following example. Table 6-4 lists the report field names and their definitions.

REPORT DAY: 86/09/05

PAGE 1

**ETHRRP2 REPORT**

TITLE = MTI\_83

SID = 080025100083

| ENDING | CS | FRAMES<br>RECEIVED | FRAMES<br>SENT | CRC<br>ERRORS<br>[ 20 ]<br>[ 0 ] | ALIGN.<br>ERRORS<br>[ 30 ]<br>[ 0 ] | OVERRUN<br>ERRORS<br>[ 40 ]<br>[ 0 ] | RESOURCE<br>ERRORS<br>[ 100 ]<br>[ 0 ] | ABNORMAL<br>LOGIC<br>[ 3 ]<br>[ 0 ] |
|--------|----|--------------------|----------------|----------------------------------|-------------------------------------|--------------------------------------|--|-------------------------------------|
| 0924   | 6  | 13144              | 13581          | 0                                | 0                                   | 20                                   | 0                                      | 0                                   |
| 1024   | 6  | 13291              | 13704          | 0                                | 27                                  | 0                                    | 103>                                   | 0                                   |
| 1224   | 6  | 11549              | 11782          | 0                                | 0                                   | 0                                    | 0                                      | 0                                   |
| 1424   | 6  | 8276               | 8175           | 0                                | 0                                   | 44>                                  | 0                                      | 0                                   |
| 1524   | 6  | 13735              | 14154          | 0                                | 33>                                 | 0                                    | 0                                      | 0                                   |

**Table 6-4. Field Definitions for ESCI Statistics Reports**

| <b>Field</b>           | <b>Definition</b>  |                     |  |                    |  |                        |   |                 |   |
|------------------------|--|---------------------|--|--------------------|--|------------------------|---|-----------------|---|
| ABNORMAL LOGIC         | The number of frames for which transmission was aborted because of the following: <table> <tr> <td>Too many collisions</td><td>Occurs when 16 attempts at sending the same block of data fails.</td></tr> <tr> <td>Lost carrier sense</td><td>Occurs when the carrier sense signal is lost on the transmission line.</td></tr> <tr> <td>Transmission underruns</td><td>Occur when a DI can't get data out of memory at a 10-megahertz rate. Usually due to a coding error.</td></tr> <tr> <td>Hardware errors</td><td>Occurs when a hardware error interrupts the transmission of data.</td></tr> </table> | Too many collisions | Occurs when 16 attempts at sending the same block of data fails. | Lost carrier sense | Occurs when the carrier sense signal is lost on the transmission line. | Transmission underruns | Occur when a DI can't get data out of memory at a 10-megahertz rate. Usually due to a coding error. | Hardware errors | Occurs when a hardware error interrupts the transmission of data. |
| Too many collisions    | Occurs when 16 attempts at sending the same block of data fails.   |                     |  |                    |  |                        |   |                 |   |
| Lost carrier sense     | Occurs when the carrier sense signal is lost on the transmission line.   |                     |  |                    |  |                        |   |                 |   |
| Transmission underruns | Occur when a DI can't get data out of memory at a 10-megahertz rate. Usually due to a coding error.  |                     |  |                    |  |                        |   |                 |   |
| Hardware errors        | Occurs when a hardware error interrupts the transmission of data.  |                     |  |                    |  |                        |   |                 |   |
| ALIGN. ERRORS          | The number of frames received with alignment errors. This occurs when the frame isn't a valid number of octets (255, 511, 767, or 1279). Also occurs when a DI receives an underrun error while transmitting.  |                     |  |                    |  |                        |   |                 |   |
| COLLISIONS             | The number of meetings in the Ethernet line of simultaneously transmitted information packets, resulting in retransmission.  |                     |  |                    |  |                        |   |                 |   |
| CRC ERRORS             | The number of cyclic redundancy check (CRC) bit errors. This usually indicates a hardware problem with the ESCI board, transceiver, or coax cable.   |                     |  |                    |  |                        |   |                 |   |
| CS                     | The card slot number identifying the location of the module within the DI. When reporting on IEI (ICA-II Ethernet Interface) statistics, this number is always 0 and meaningless.  |                     |  |                    |  |                        |   |                 |   |
| ENDING TIME            | The time representing the end of the time interval being reported on.  |                     |  |                    |  |                        |   |                 |   |
| FRAMES RECEIVED        | The number of frames of data received.   |                     |  |                    |  |                        |   |                 |   |
| FRAMES SENT            | The number of frames of data transmitted.  |                     |  |                    |  |                        |   |                 |   |

*(Continued)*



**Table 6-4. Field Definitions for ESCI Statistics Reports** *(Continued)*

| <b>Field</b>        | <b>Definition</b>   |
|---------------------|---|
| OVERRUN ERRORS      | The number of lost received frames of data because of internal transfer bus (ITB) traffic. This usually occurs when the DI received the data faster than it can be put in memory due to buffer fragments. |
| RESOURCE ERRORS     | The number of frames of data lost because of the unavailability of receive buffers due to insufficient memory in the DI.  |
| TIME                | The time at which the reported statistics are tabulated.  |
| XMIT 255/RECV 255   | The number of frames transmitted with 255 or fewer bytes.   |
| XMIT 511/RECV 511   | The number of frames transmitted with fewer than 511 bytes and more than 255.   |
| XMIT 767/RECV 767   | The number of frames transmitted with fewer than 767 bytes and more than 511.   |
| XMIT 1033/RECV 1033 | The number of frames transmitted with fewer than 1033 bytes and more than 767.  |
| XMIT 1279/RECV 1279 | The number of frames transmitted with fewer than 1279 bytes and more than 1033.   |
| XMIT 1535/RECV 1535 | The number of frames transmitted with fewer than 1535 bytes and more than 1279.   |

## Event Log Message Reports (EVNTRP1, EVNTRP2, EVNTRP3, EVNTRP4)

Event log message reports encountered in the network by the DI Executive Software Failure Management entity or other software components are reported to the network log file.

Use the `DEFINE_SOURCE_LOG_GROUP` command to gather the information needed for these reports. All log message IDs with an attribute of EL are used.

NPA provides four event log messages reports:

|         |  |
|---------|--|
| EVNTRP1 | Lists the network log messages sorted by date and time.                                      |
| EVNTRP2 | Lists the network log messages sorted by severity and DI.                                    |
| EVNTRP3 | Provides a summary of all event log messages by frequency and error severity.                |
| EVNTRP4 | Provides a summary of all event log messages by frequency and error severity reported by DI. |

**EVNTRP1 Report Example**

The first page is an unnumbered report heading similar to that shown in figure 6-3. Following the report heading page is a numbered report data page similar to the following example. Table 6-5 lists the report field names and their definitions.

REPORT DAY: 86/01/01

PAGE 1

EVNTRP1 REPORT  
START TIME = 0000 HOURS

| DATE  | TIME        | SYSTEM ID    | LOG ID | SEVERITY    |
|---|-------------|--------------|--------|-------------|
| 86/01/01  | 00.00.00785 | 0800253000A2 | 1319   | WARNING     |
| --WARNING-- INVALID LOG REQUEST FOR SYSTEM FAILURE TABLE -<br>INVALID DATA; ENTRY 0 CLEARED   |             |              |        |             |
| 86/01/01  | 00.00.00787 | 0800253000A2 | 1319   | WARNING     |
| --WARNING-- INVALID LOG REQUEST FOR SYSTEM FAILURE TABLE -<br>INVALID DATA; ENTRY 1 CLEARED   |             |              |        |             |
| 86/01/01  | 00.00.00794 | 0800253000A2 | 1319   | WARNING     |
| --WARNING-- INVALID LOG REQUEST FOR SYSTEM FAILURE TABLE -<br>INVALID DATA; ENTRY 5 CLEARED   |             |              |        |             |
| 86/01/01  | 00.00.00796 | 0800253000A2 | 1319   | WARNING     |
| --WARNING-- INVALID LOG REQUEST FOR SYSTEM FAILURE TABLE -<br>INVALID DATA; ENTRY 7 CLEARED   |             |              |        |             |
| 86/01/01  | 00.00.00950 | 0800253000A2 | 608    | WARNING     |
| --WARNING-- INITIAL LOADER CHECKSUM BAD, CHECKSUM = DFFF, DATA BUFFER LENGTH =<br>0000FFFF,<br>DESCRIPTOR BUFFER LENGTH = 0040FFFF.   |             |              |        |             |
| 86/01/01  | 00.00.01254 | 0800253000A2 | 765    | INFORMATIVE |
| DVM HAS STARTED IP NUMBER 0007  |             |              |        |             |
| 86/01/01  | 00.00.01316 | 0800253000A2 | 475    | INFORMATIVE |
| ETHERNET NETWORK DEFINED AND STARTED BY BOOT SOURCE FOR TRUNK .<br>CARD SLOT = 0007.  |             |              |        |             |
| 86/01/01  | 00.00.09528 | 0800253000A2 | 481    | INFORMATIVE |
| SYSTEM_NAME = TDI_A2<br>DATA_BUFFER_SIZE = 144<br>BUFFER_PERCENTAGE = 50<br>BUFFER_BOUNDARY_PERCENTAGES = (40, 20, 5)<br>MEMORY_BOUNDARY_PERCENTAGES = (40, 15, 2)<br>MEMORY_MANAGER_PERIOD = 1<br>RESERVED_SYSTEM_SPACE = 1000<br>STANDARD_STACK_SIZE = 2048<br>CLOCKING_SYSTEM = NO |             |              |        |             |

**EVNTRP2 Report Example**

The first page is an unnumbered report heading similar to that shown in figure 6-3. Following the report heading is a numbered report data page similar to the following example. Table 6-5 lists the report field names and their definitions.

REPORT DAY: 87/03/04

PAGE 1

EVNTRP2 REPORT  
ERROR

| DATE   | TIME        | SYSTEM ID    | LOG ID | SEVERITY |
|--|-------------|--------------|--------|----------|
| 87/03/04   | 04.45.38635 | D8002510006F | 622    | ERROR    |
| --ERROR-- PROCEDURE FILE CANNOT BE ACCESSED, FILE = PSUTDP_990                 |             |              |        |          |
| REJECT REASON CODE = 0008  |             |              |        |          |
| 87/03/04   | 07.41.17809 | 080025100074 | 73     | ERROR    |
| --ERROR-- DEPENDENT FILE ACCESS RECEIVED AN INVALID UCEPID FROM TRANSPORT.     |             |              |        |          |
| UCEPID: 001D3DB2.  |             |              |        |          |
| INDEPENDENT FILE ACCESS PROTOCOL DATA UNIT: <NO DATA>                          |             |              |        |          |
| GENERIC TRANSPORT INDICATION: 0002.  |             |              |        |          |
| 87/03/04   | 07.26.03909 | 080025100078 | 73     | ERROR    |
| --ERROR-- DEPENDENT FILE ACCESS RECEIVED AN INVALID UCEPID FROM TRANSPORT.     |             |              |        |          |
| UCEPID: 001C8D80.  |             |              |        |          |
| INDEPENDENT FILE ACCESS PROTOCOL DATA UNIT: <NO DATA>                          |             |              |        |          |
| GENERIC TRANSPORT INDICATION: 0002.  |             |              |        |          |
| 87/03/04   | 04.06.59701 | 08002510008B | 498    | ERROR    |
| --ERROR-- K-DISPLAY RECEIVED REQUEST FROM OSA WHEN NOT RUNNING: REQUEST TYPE = |             |              |        |          |
| 0000.  |             |              |        |          |
| THE REQUEST WILL BE DISCARDED.   |             |              |        |          |
| TRUNK NAME = \$MCI5.   |             |              |        |          |
| 87/03/04   | 09.15.34059 | 08002510008B | 73     | ERROR    |
| --ERROR-- DEPENDENT FILE ACCESS RECEIVED AN INVALID UCEPID FROM TRANSPORT.     |             |              |        |          |
| UCEPID: 001ED444.  |             |              |        |          |
| INDEPENDENT FILE ACCESS PROTOCOL DATA UNIT: <NO DATA>                          |             |              |        |          |
| GENERIC TRANSPORT INDICATION: 0002.  |             |              |        |          |
| 87/03/04   | 13.24.28648 | 08002510008B | 498    | ERROR    |
| --ERROR-- K-DISPLAY RECEIVED REQUEST FROM OSA WHEN NOT RUNNING: REQUEST TYPE = |             |              |        |          |
| 0000.  |             |              |        |          |
| THE REQUEST WILL BE DISCARDED.   |             |              |        |          |
| TRUNK NAME = \$MCI5.   |             |              |        |          |

**EVNTRP3 Report Example**

The first page is an unnumbered report heading similar to that shown in figure 6-3. Following the report heading page is a numbered report data page similar to the following example. Table 6-5 lists the report field names and their definitions.

REPORT DAY: 86/01/01

PAGE 1

**EVNTRP3 REPORT**

| LOG NUMBER | FREQUENCY | INFORMATIVE | WARNING | ERROR | FATAL | CATASTROPHIC |
|------------|-----------|-------------|---------|-------|-------|--------------|
| =====      | =====     | =====       | =====   | ===== | ===== | =====        |
| 19         | 9         | 9           | 0       | 0     | 0     | 0            |
| 67         | 2         | 2           | 0       | 0     | 0     | 0            |
| 129        | 1         | 0           | 0       | 1     | 0     | 0            |
| 207        | 4         | 0           | 4       | 0     | 0     | 0            |
| 210        | 1         | 1           | 0       | 0     | 0     | 0            |
| 429        | 4         | 4           | 0       | 0     | 0     | 0            |
| 457        | 4         | 0           | 4       | 0     | 0     | 0            |
| 502        | 3         | 3           | 0       | 0     | 0     | 0            |
| 546        | 4         | 4           | 0       | 0     | 0     | 0            |
| 548        | 1         | 1           | 0       | 0     | 0     | 0            |
| 552        | 9         | 9           | 0       | 0     | 0     | 0            |
| 559        | 1         | 1           | 0       | 0     | 0     | 0            |
| 560        | 1         | 1           | 0       | 0     | 0     | 0            |
| 561        | 1         | 1           | 0       | 0     | 0     | 0            |
| 575        | 2         | 2           | 0       | 0     | 0     | 0            |
| 593        | 4         | 4           | 0       | 0     | 0     | 0            |
| 594        | 4         | 4           | 0       | 0     | 0     | 0            |
| 595        | 4         | 4           | 0       | 0     | 0     | 0            |
| 596        | 4         | 4           | 0       | 0     | 0     | 0            |
| 597        | 4         | 4           | 0       | 0     | 0     | 0            |
| 603        | 1         | 0           | 0       | 0     | 1     | 0            |
| 605        | 50        | 50          | 0       | 0     | 0     | 0            |
| 631        | 1         | 0           | 0       | 1     | 0     | 0            |
| -----      |           |             |         |       |       |              |
| TOTALS     | 119       | 108         | 8       | 2     | 1     | 0            |

**EVNTRP4 Report Example**

The first page is an unnumbered report heading similar to that shown in figure 6-3. Following the report heading page is a numbered report data page similar to the following example. Table 6-5 lists the report field names and their definitions.

```

REPORT DAY: 86/09/05                                     PAGE 11
                                EVNTRP4 REPORT
                                TITLE = SVLTDI2           SID = 0800253000D5

LOG NUMBER FREQUENCY INFORMATIVE WARNING  ERROR  FATAL CATASTROPHIC
=====
207          3          0          3          0          0          0
593          1          1          0          0          0          0
594          1          1          0          0          0          0
595          1          1          0          0          0          0
596          1          1          0          0          0          0
597          1          1          0          0          0          0

```

**Table 6-5. Field Definitions for Event Log Messages Reports**

| <b>Field</b>                                     | <b>Definition</b>  |
|--|--|
| DATE   | The date on which the error occurred.  |
| FREQUENCY  | The number of log messages for this log ID.                                      |
| INFORMATIVE/WARNING/<br>ERROR/FATAL/CATASTROPHIC | The number of log messages of this severity. Totals are listed on the last line. |
| LOG ID   | The log message identification number.   |
| LOG NUMBER                                       | The log message identification number.   |
| SEVERITY   | The description of the severity of the type of error that has occurred.          |
| SYSTEM ID  | The system identification number that identifies the DI.                         |
| TIME   | The network clock time when the error occurred.                                  |

## HDLC Interface Statistics Reports (HDLCRP1, HDLCRP2, HDLCRP3)

HDLC interface statistics reports provide character, frames, and message information on a daily or hourly basis. The reports are forwarded to the network log file after DI initialization is completed.

Use the `DEFINE_SOURCE_LOG_GROUP` and `START_TRUNK_METRICS` commands to gather the statistics needed for these reports. The log message ID is 665 with an attribute of S.

NPA provides three HDLC interface statistic reports:

- |         |   |
|---------|---|
| HDLCRP1 | Provides characters, frames, and messages sorted by the DI on an hourly basis.                            |
| HDLCRP2 | Provides characters and messages sorted by the DI on a daily basis.                                       |
| HDLCRP3 | Provides S/U frames transmitted/received and error frame information sorted by the DI on an hourly basis. |



## HDLCRP1 Report Example

The first page is an unnumbered report heading similar to that shown in figure 6-1. Following the report heading page is a numbered report data page similar to the following example. Table 6-6 lists the report field names and their definitions.

REPORT DAY: 86/09/05

PAGE 1

## HDLCRP1 REPORT

TITLE = SVLN011

SID = 0800253001A7

| ENDING |    |    | CHARS   | CHARS | CHARS     | CHARS   | CHARS | CHARS     |
|--------|----|----|---------|-------|-----------|---------|-------|-----------|
| TIME   | LI | PO | RECVD   | RECVD | DISCARDED | XMIT    | XMIT  | RE-XMIT'D |
| =====  | == | == | =====   | ===== | =====     | =====   | ===== | =====     |
| 0050   | 1  | 0  | 392390  | 6118  | 436       | 484388  | 6437  | 0         |
| 0050   | 1  | 1  | 300677  | 5510  | 170       | 562945  | 5930  | 0         |
| 0050   | 1  | 2  | 0       | 0     | 0         | 0       | 0     | 0         |
| 0723   | 1  | 0  | 249900  | 3825  | 2         | 270380  | 4051  | 0         |
| 0723   | 1  | 1  | 219614  | 3883  | 1         | 344911  | 4151  | 0         |
| 0723   | 1  | 2  | 0       | 0     | 0         | 0       | 0     | 0         |
| 0823   | 1  | 0  | 320513  | 4368  | 31        | 708292  | 4914  | 0         |
| 0823   | 1  | 1  | 218909  | 3984  | 20        | 424349  | 4288  | 0         |
| 0823   | 1  | 2  | 0       | 0     | 0         | 0       | 0     | 0         |
| 0923   | 1  | 0  | 558019  | 6268  | 470       | 1794165 | 7655  | 0         |
| 0923   | 1  | 1  | 271817  | 4780  | 632       | 518807  | 4908  | 0         |
| 0923   | 1  | 2  | 0       | 0     | 0         | 0       | 0     | 0         |
| 1223   | 1  | 0  | 3372787 | 13226 | 27        | 2070857 | 12103 | 0         |
| 1223   | 1  | 1  | 279191  | 5041  | 38        | 574037  | 5459  | 0         |
| 1223   | 1  | 2  | 0       | 0     | 0         | 0       | 0     | 0         |
| 1423   | 1  | 0  | 2743135 | 10081 | 0         | 815544  | 8134  | 0         |
| 1423   | 1  | 1  | 256690  | 4644  | 0         | 464411  | 4922  | 0         |
| 1423   | 1  | 2  | 0       | 0     | 0         | 0       | 0     | 0         |
| 1623   | 1  | 0  | 7406521 | 19878 | 14        | 1320397 | 13978 | 0         |
| 1623   | 1  | 1  | 247386  | 4367  | 1         | 556413  | 4728  | 0         |
| 1623   | 1  | 2  | 0       | 0     | 0         | 0       | 0     | 0         |
| 1723   | 1  | 0  | 5220177 | 15045 | 1         | 630203  | 10597 | 0         |
| 1723   | 1  | 1  | 237856  | 4110  | 0         | 431704  | 4341  | 0         |
| 1723   | 1  | 2  | 0       | 0     | 0         | 0       | 0     | 0         |
| 1823   | 1  | 0  | 1275356 | 6085  | 0         | 375556  | 5470  | 0         |
| 1823   | 1  | 1  | 218100  | 4379  | 0         | 412092  | 4324  | 0         |
| 1823   | 1  | 2  | 0       | 0     | 0         | 0       | 0     | 0         |
| 1923   | 1  | 0  | 3588949 | 11813 | 0         | 914496  | 9537  | 0         |
| 1923   | 1  | 1  | 273157  | 5012  | 0         | 379184  | 4618  | 0         |
| 1923   | 1  | 2  | 0       | 0     | 0         | 0       | 0     | 0         |
| 2023   | 1  | 0  | 362115  | 4335  | 0         | 447011  | 4640  | 0         |
| 2023   | 1  | 1  | 223359  | 3893  | 0         | 361838  | 3983  | 0         |
| 2023   | 1  | 2  | 0       | 0     | 0         | 0       | 0     | 0         |
| 2123   | 1  | 0  | 2605898 | 8818  | 0         | 345696  | 6696  | 0         |
| 2123   | 1  | 1  | 217826  | 3831  | 0         | 394383  | 4071  | 0         |
| 2123   | 1  | 2  | 0       | 0     | 0         | 0       | 0     | 0         |
| 2223   | 1  | 0  | 244405  | 3550  | 0         | 307916  | 3772  | 0         |
| 2223   | 1  | 1  | 216580  | 3749  | 0         | 387946  | 3958  | 0         |
| 2223   | 1  | 2  | 0       | 0     | 0         | 0       | 0     | 0         |

## HDLCRP2 Report Example

The first page is an unnumbered report heading similar to that shown in figure 6-1. Following the report heading page is a numbered report data page similar to the following example. Table 6-6 lists the report names and their definitions.

REPORT DAY: 86/09/04

PAGE 1

## HDLCRP2 REPORT

| ENDING<br>DATE | LI | PO | DI           | CHARS<br>RECVD/<br>1000 | MSG<br>RECVD | AVG<br>CHARS/<br>MSG | CHARS<br>XMIT/<br>1000 | MSG<br>XMIT | AVG<br>CHARS/<br>MSG |
|----------------|----|----|--------------|-------------------------|--------------|----------------------|------------------------|-------------|----------------------|
| =====          | == | == | =====        | =====                   | =====        | =====                | =====                  | =====       | =====                |
| 86/09/04       | 1  | 0  | 0800253001A7 | 328                     | 4476         | 73                   | 348                    | 4743        | 73                   |
| 86/09/04       | 1  | 1  | 0800253001A7 | 249                     | 4683         | 53                   | 469                    | 5024        | 93                   |
| 86/09/04       | 1  | 2  | 0800253001A7 | 0                       | 0            | 0                    | 0                      | 0           | 0                    |
| 86/09/05       | 1  | 0  | 0800253001A7 | 29669                   | 119329       | 248                  | 10797                  | 103115      | 104                  |
| 86/09/05       | 1  | 1  | 0800253001A7 | 3388                    | 60878        | 55                   | 6185                   | 63563       | 97                   |
| 86/09/05       | 1  | 2  | 0800253001A7 | 0                       | 0            | 0                    | 0                      | 0           | 0                    |
| 86/09/06       | 1  | 0  | 0800253001A7 | 1852                    | 13812        | 134                  | 1002                   | 13432       | 74                   |
| 86/09/06       | 1  | 1  | 0800253001A7 | 628                     | 11560        | 54                   | 1114                   | 12081       | 92                   |
| 86/09/06       | 1  | 2  | 0800253001A7 | 0                       | 0            | 0                    | 0                      | 0           | 0                    |

## HDLCRP3 Report Example

The first page is an unnumbered report heading similar to that shown in figure 6-1. Following the report heading page is a numbered report data page similar to the following example. Table 6-6 lists the report names and their definitions.

REPORT DAY: 86/09/05

PAGE 1

## HDLCRP3 REPORT

TITLE = SVLNDI1

SID = 0800253001A7

| ENDING |    |    | S FRAMES | S FRAMES | U FRAMES | U FRAMES | CRC    | BAD    | FRAMES   |
|--------|----|----|----------|----------|----------|----------|--------|--------|----------|
| TIME   | LI | PO | RECVD    | XMIT     | RECVD    | XMIT     | ERRORS | FRAMES | OUT OF   |
|        |    |    |          |          |          |          |        |        | SEQUENCE |
| =====  | == | == | =====    | =====    | =====    | =====    | =====  | =====  | =====    |
| 0050   | 1  | 0  | 4208     | 3845     | 1        | 1        | 313    | 7      | 4        |
| 0050   | 1  | 1  | 4128     | 3198     | 0        | 0        | 106    | 0      | 2        |
| 0050   | 1  | 2  | 0        | 0        | 0        | 0        | 0      | 0      | 0        |
| 0723   | 1  | 0  | 2587     | 2350     | 1        | 1        | 0      | 0      | 0        |
| 0723   | 1  | 1  | 2705     | 2300     | 1        | 1        | 0      | 0      | 0        |
| 0723   | 1  | 2  | 0        | 0        | 0        | 0        | 0      | 0      | 0        |
| 0823   | 1  | 0  | 2864     | 2205     | 1        | 2        | 19     | 0      | 2        |
| 0823   | 1  | 1  | 3052     | 2319     | 0        | 0        | 16     | 0      | 1        |
| 0823   | 1  | 2  | 0        | 0        | 0        | 0        | 0      | 0      | 0        |
| 0923   | 1  | 0  | 3417     | 1370     | 5        | 9        | 306    | 2      | 9        |
| 0923   | 1  | 1  | 3318     | 2655     | 333      | 332      | 292    | 21     | 7        |
| 0923   | 1  | 2  | 0        | 0        | 0        | 0        | 0      | 0      | 0        |
| 1223   | 1  | 0  | 1357     | 2955     | 3        | 1        | 13     | 0      | 6        |
| 1223   | 1  | 1  | 3952     | 3197     | 0        | 0        | 27     | 0      | 1        |
| 1223   | 1  | 2  | 0        | 0        | 0        | 0        | 0      | 0      | 0        |
| 1423   | 1  | 0  | 895      | 3357     | 0        | 0        | 0      | 0      | 0        |
| 1423   | 1  | 1  | 3341     | 2961     | 0        | 0        | 0      | 0      | 0        |
| 1423   | 1  | 2  | 0        | 0        | 0        | 0        | 0      | 0      | 0        |
| 1623   | 1  | 0  | 503      | 8231     | 4        | 2        | 2      | 0      | 8        |
| 1623   | 1  | 1  | 3239     | 2510     | 0        | 0        | 0      | 0      | 0        |
| 1623   | 1  | 2  | 0        | 0        | 0        | 0        | 0      | 0      | 0        |
| 1723   | 1  | 0  | 1852     | 7764     | 0        | 0        | 1      | 0      | 0        |
| 1723   | 1  | 1  | 2980     | 2515     | 0        | 0        | 0      | 0      | 0        |
| 1723   | 1  | 2  | 0        | 0        | 0        | 0        | 0      | 0      | 0        |
| 1823   | 1  | 0  | 2347     | 3568     | 0        | 0        | 0      | 0      | 0        |
| 1823   | 1  | 1  | 2656     | 2488     | 0        | 0        | 0      | 0      | 0        |
| 1823   | 1  | 2  | 0        | 0        | 0        | 0        | 0      | 0      | 0        |
| 1923   | 1  | 0  | 2487     | 6013     | 0        | 0        | 0      | 0      | 0        |
| 1923   | 1  | 1  | 2776     | 2794     | 0        | 0        | 0      | 0      | 0        |
| 1923   | 1  | 2  | 0        | 0        | 0        | 0        | 0      | 0      | 0        |
| 2023   | 1  | 0  | 3027     | 2829     | 0        | 0        | 0      | 0      | 0        |
| 2023   | 1  | 1  | 2637     | 2388     | 0        | 0        | 0      | 0      | 0        |
| 2023   | 1  | 2  | 0        | 0        | 0        | 0        | 0      | 0      | 0        |
| 2123   | 1  | 0  | 1930     | 4927     | 0        | 0        | 0      | 0      | 0        |
| 2123   | 1  | 1  | 2797     | 2297     | 0        | 0        | 0      | 0      | 0        |
| 2123   | 1  | 2  | 0        | 0        | 0        | 0        | 0      | 0      | 0        |
| 2223   | 1  | 0  | 2575     | 2465     | 0        | 0        | 0      | 0      | 0        |
| 2223   | 1  | 1  | 2730     | 2300     | 0        | 0        | 0      | 0      | 0        |
| 2223   | 1  | 2  | 0        | 0        | 0        | 0        | 0      | 0      | 0        |

**Table 6-6. Field Definitions for HDLC Interface Statistics Reports**

| <b>Field</b>           | <b>Definition</b>   |
|------------------------|---|
| AVG CHARS/MSG          | The average number of characters per message received from the MCI.   |
| BAD FRAMES             | The number of bad frames from the protocol's viewpoint. Bad frames occur when the sequence of numbers is outside the window limits. |
| CHARS RECVD            | The number of characters received at the host from the terminal.  |
| CHARS RECVD/1000       | The number of characters, in thousands, received at the host from the terminal.   |
| CHARS XMIT             | The number of characters transmitted from the host to the terminal.   |
| CHARS XMIT/1000        | The number of characters, in thousands, transmitted from the host to the terminal.  |
| CRC ERRORS             | The number of cyclic redundancy check (CRC) bit errors. Usually caused by line noise or too many HDLCs on one CIM.                  |
| DI                     | The device interface identification number.   |
| ENDING DATE            | The last date that the reported statistics were tabulated.  |
| ENDING TIME            | The clock time representing the end of the time interval being reported on.   |
| FRAMES DISCARDED       | The number of frames discarded. Discarded frames are caused by bad frames, CRC errors, and frames out-of-sequence.                  |
| FRAMES OUT OF SEQUENCE | The number of frames received out-of-sequence.  |
| FRAMES RE-XMIT'D       | The number of discarded frames retransmitted due to bad frames, CRC errors, or frames out-of-sequence.                              |

*(Continued)*

**Table 6-6. Field Definitions for HDLC Interface Statistics Reports** *(Continued)*

| <b>Field</b>  | <b>Definition</b>  |
|---------------|--|
| LI            | The slot number of the line interface module (LIM) on the communications interface module (CIM). |
| MSGs RECD     | The number of information (I) frames received.   |
| MSGs XMIT     | The number of I frames transmitted.  |
| PO            | The LIM port number.   |
| S FRAMES RECV | The number of supervision (S) frames received.   |
| S FRAMES XMIT | The number of S frames transmitted.  |
| U FRAMES RECD | The number of unnumbered (U) frames received.  |
| U FRAMES XMIT | The number of U frames transmitted.  |

## Hardware Error Message Reports (HRDWRP1, HRDWRP2, HRDWRP3, HRDWRP4)

Hardware error reports list the location, nature, and severity of hardware errors occurring in your network. These reports help you to determine which equipment has failed or is about to fail. You may then implement the required maintenance that returns your network to order, or performs the actions that prevent abnormal interruptions of network service.

Use the `DEFINE_SOURCE_LOG_GROUP` command to gather the information needed for these reports. All log message IDs with an attribute of HE are used.

NPA offers four hardware errors reports:

- |         |  |
|---------|--|
| HRDWRP1 | Provides a chronological listing of hardware errors detected in the network, sorted by the date and time of the error occurrences. |
| HRDWRP2 | Lists hardware errors detected in the network, sorted by DI and error severity.  |
| HRDWRP3 | Lists a network log messages frequency chart.  |
| HRDWRP4 | Lists a network log messages frequency chart reported by DI.   |

**HRDWRP1 Report Example**

The first page is an unnumbered report heading similar to that shown in figure 6-3. Following the report heading page is a numbered report data page similar to the following example. Table 6-7 lists the report field names and their definitions.

REPORT DAY: 86/01/01

PAGE 1

HRDWRP1 REPORT  
START TIME = 0000 HOURS

| DATE  | TIME        | SYSTEM ID    | LOG ID | SEVERITY    |
|---|-------------|--------------|--------|-------------|
| 86/01/01  | 00.00.00927 | 0800253000A2 | 338    | ERROR       |
| --ERROR-- MPB FAILED ON-BOARD TESTING<br>BEFORE INITIALIZATION WAS SUCCESSFUL.<br>SLOT NUMBER= 0<br>FATAL ERRORS= 7                         |             |              |        |             |
| 86/01/01  | 00.00.00930 | 0800253000A2 | 340    | ERROR       |
| --ERROR-- PMM HAD RECOVERED PARITY ERRORS<br>DURING ON-BOARD TESTING.<br>SLOT NUMBER= 1<br>ERRORS= 39168<br>FIRST FAILING ADDRESS= 00010000 |             |              |        |             |
| 86/01/01  | 00.00.00933 | 0800253000A2 | 341    | ERROR       |
| --ERROR-- SMM SINGLE BIT ERRORS OCCURRED<br>DURING INITIALIZATION.<br>SLOT NUMBER= 2<br>ERRORS= 1942<br>ERROR LOG= 0648                     |             |              |        |             |
| 86/01/01  | 00.00.00935 | 0800253000A2 | 342    | ERROR       |
| --ERROR-- SMM MULTIPLE BIT ERRORS OCCURRED<br>DURING INITIALIZATION.<br>SLOT NUMBER= 2<br>ERRORS= 11671<br>ERROR LOG= 0473                  |             |              |        |             |
| 86/01/01  | 00.00.55028 | 0800253000A2 | 19     | INFORMATIVE |
| CONFIGURATION COMPLETE,<br>CONFIGURATION FILE SOURCE:<br>NETWORK ID: 41454646, SYSTEM ID: 0800253000BE                                      |             |              |        |             |

## HRDWRP2 Report Example

The first page is an unnumbered report heading similar to that shown in figure 6-3. Following the report heading page is a numbered report data page similar to the following example. Table 6-7 lists the report field names and their definitions.

REPORT DAY: 86/01/01

PAGE 1

### HRDWRP2 REPORT

#### ERROR

| DATE  | TIME        | SYSTEM ID    | LOG ID | SEVERITY |
|---|-------------|--------------|--------|----------|
| 86/01/01  | 00.00.00927 | 0800253000A2 | 338    | ERROR    |
| --ERROR-- MPB FAILED ON-BOARD TESTING<br>BEFORE INITIALIZATION WAS SUCCESSFUL.<br>SLOT NUMBER= 0<br>FATAL ERRORS= 7                         |             |              |        |          |
| 86/01/01  | 00.00.00930 | 0800253000A2 | 340    | ERROR    |
| --ERROR-- PMM HAD RECOVERED PARITY ERRORS<br>DURING ON-BOARD TESTING.<br>SLOT NUMBER= 1<br>ERRORS= 39168<br>FIRST FAILING ADDRESS= 00010000 |             |              |        |          |
| 86/01/01  | 00.00.00933 | 0800253000A2 | 341    | ERROR    |
| --ERROR-- SMM SINGLE BIT ERRORS OCCURRED<br>DURING INITIALIZATION.<br>SLOT NUMBER= 2<br>ERRORS= 1942<br>ERROR LOG= 0648                     |             |              |        |          |
| 86/01/01  | 00.00.00935 | 0800253000A2 | 342    | ERROR    |
| --ERROR-- SMM MULTIPLE BIT ERRORS OCCURRED<br>DURING INITIALIZATION.<br>SLOT NUMBER= 2<br>ERRORS= 11671<br>ERROR LOG= 0473                  |             |              |        |          |



**HRDWRP3 Report Example**

The first page is an unnumbered report heading similar to that shown in figure 6-3. Following the report heading page is a numbered report data page similar to the following example. Table 6-7 lists the report field names and their definitions.

REPORT DAY: 86/01/01

PAGE 1

**HRDWRP3 REPORT**

| LOG NUMBER | FREQUENCY | INFORMATIVE | WARNING | ERROR | FATAL | CATASTROPHIC |
|------------|-----------|-------------|---------|-------|-------|--------------|
| =====      | =====     | =====       | =====   | ===== | ===== | =====        |
| 19         | 9         | 9           | 0       | 0     | 0     | 0            |
| 351        | 1         | 1           | 0       | 0     | 0     | 0            |
| 457        | 4         | 0           | 4       | 0     | 0     | 0            |
| 578        | 4         | 0           | 0       | 4     | 0     | 0            |
| 631        | 1         | 0           | 0       | 1     | 0     | 0            |
| -----      |           |             |         |       |       |              |
| TOTALS     | 19        | 10          | 4       | 5     | 0     | 0            |

**HRDWRP4 Report Example**

The first page is an unnumbered report heading similar to that shown in figure 6-3. Following the report heading page is a numbered report data page similar to the following example. Table 6-7 lists the report field names and their definitions.

REPORT DAY: 86/07/08

PAGE 1

**HRDWRP4 REPORT**

TITLE = MDI\_8C

SID = 08002510008C

| LOG NUMBER | FREQUENCY | INFORMATIVE | WARNING | ERROR | FATAL | CATASTROPHIC |
|------------|-----------|-------------|---------|-------|-------|--------------|
| =====      | =====     | =====       | =====   | ===== | ===== | =====        |
| 457        | 3         | 0           | 3       | 0     | 0     | 0            |
| 578        | 3         | 0           | 0       | 3     | 0     | 0            |
| 631        | 1         | 0           | 0       | 1     | 0     | 0            |

**Table 6-7. Field Definitions for Hardware Error Message Reports**

| <b>Field</b>                                     | <b>Definition</b>  |
|--|--|
| DATE   | The date on which the error occurred.  |
| FREQUENCY  | Number of log messages for this log ID.                                      |
| INFORMATIVE/WARNING/<br>ERROR/FATAL/CATASTROPHIC | Number of log messages of this severity. Totals are listed on the last line. |
| LOG ID   | The log message identification number.                                       |
| LOG NUMBER                                       | The log message identification number.                                       |
| SEVERITY   | The description of the severity of the type of error that has occurred.      |
| SYSTEM ID  | The system identification number that identifies the DI.                     |
| TIME   | The network clock time when the error occurred.                              |

## Online Loader System Statistics Report (LOADRP1)

Proper module assignment throughout your CDCNET reduces loading overhead and system response times. The loader system statistics report can help you determine the extent of task-loading activities and possible system impact upon network communication between the DI and the source host mainframe.

For example, you may detect that a frequently called module is always being loaded from the host through the network communications link. The resulting network impact of this task can be reduced if its residency assignment is changed from the host to the DI Unused Module List.

Use the `DEFINE_SOURCE_LOG_GROUP` command to gather the information needed for this report. The log message ID is 605 with an attribute of S.

This report chronologically lists the modules that have been loaded in your network.

This report may be produced to cover a daily or weekly time interval.

**LOADRP1 Report Example**

The first page is an unnumbered report heading similar to that shown in figure 6-1. Following the report heading page is a numbered report data page similar to the following example. Table 6-8 lists the report field names and their definitions.

REPORT DAY: 86/06/13

PAGE 1

**LOADRP1 REPORT**

TITLE = MTI\_1

SID = D80025100085

| TIME  | MODULE NAME                 | DESTINATION |       |          | NO.<br>LOADS | SRCE  | CHECK<br>SUM |
|-------|-----------------------------|-------------|-------|----------|--------------|-------|--------------|
|       |                             | MPB         | PMM   | SMM      |              |       |              |
| ===== | =====                       | =====       | ===== | =====    | =====        | ===== | =====        |
| 1700  | OSA_COMMAND_PROCESSORS      | 0000        | 0000  | 00000000 | 1            | DEL   | 0000         |
| 1700  | ALARMING_COMMAND_PROCESSORS | 0000        | 0000  | 00002BD8 | 1            | SYS   | 58AB         |
| 1700  | OSA_COMMAND_PROCESSORS      | 0000        | 0000  | 00000000 | 1            | OEL   | 0000         |
| 1700  | ACCESS_DIAGNOSTIC_ENTRY     | 0000        | 0000  | 00000000 | 1            | OEL   | 0000         |
| 1700  | CMD_CHANGE_ELEMENT_STATE    | 0000        | 0000  | 000009F0 | 1            | SYS   | 732C         |
| 1700  | ACCESS_DIAGNOSTIC_ENTRY     | 0000        | 0000  | 00000000 | 1            | DEL   | 0000         |
| 1700  | CMD_CHANGE_ELEMENT_STATE    | 0000        | 0000  | DDDD0000 | 1            | DEL   | 0000         |
| 1700  | OSA_COMMAND_PROCESSORS      | 0000        | 0000  | 00000000 | 1            | DEL   | D000         |
| 1700  | ACCESS_DIAGNOSTIC_ENTRY     | DDDD        | 0000  | 00000000 | 1            | DEL   | 0000         |
| 1700  | CMD_CHANGE_ELEMENT_STATE    | 0000        | 0000  | 00000000 | 1            | DEL   | 0000         |
| 1700  | OSA_COMMAND_PROCESSORS      | 0000        | 0000  | 00000000 | 1            | DEL   | DD00         |
| 1700  | ACCESS_DIAGNOSTIC_ENTRY     | 0000        | 0000  | 00000000 | 1            | DEL   | 0000         |
| 1700  | CMD_CHANGE_ELEMENT_STATE    | 0000        | 0000  | 00000000 | 1            | DEL   | 0000         |
| 1700  | OSA_COMMAND_PROCESSORS      | 0000        | 0000  | 00000000 | 1            | DEL   | 0000         |
| 1700  | ACCESS_DIAGNOSTIC_ENTRY     | 0000        | 0000  | 00000000 | 1            | DEL   | 0000         |
| 1700  | CMD_CHANGE_ELEMENT_STATE    | 0000        | 0000  | 00000000 | 1            | DEL   | 0000         |
| 1700  | OSA_COMMAND_PROCESSORS      | 0000        | 0000  | 00000000 | 1            | DEL   | 0000         |
| 1700  | ACCESS_DIAGNOSTIC_ENTRY     | 0000        | 0000  | 00000000 | 1            | DEL   | 0000         |
| 17DD  | CMD_CHANGE_ELEMENT_STATE    | 0000        | 0000  | 00000000 | 1            | DEL   | D0DD         |
| 1700  | OSA_COMMAND_PROCESSORS      | 0000        | 0000  | 00000000 | 1            | DEL   | 0000         |
| 1700  | ACCESS_DIAGNOSTIC_ENTRY     | 0000        | 0000  | 00000000 | 1            | DEL   | 0000         |
| 1700  | CMD_CHANGE_ELEMENT_STATE    | 0000        | 0000  | 00000000 | 1            | DEL   | 0000         |
| 1700  | OSA_COMMAND_PROCESSORS      | 0000        | 0000  | 00000000 | 1            | DEL   | 0000         |
| 1700  | ACCESS_DIAGNOSTIC_ENTRY     | 0000        | 0000  | 00000000 | 1            | DEL   | 0000         |
| 1700  | CMD_CHANGE_ELEMENT_STATE    | 0000        | 0000  | 00000000 | 1            | DEL   | 0000         |
| 1700  | OSA_COMMAND_PROCESSORS      | 0000        | 0000  | 00000000 | 2            | OEL   | 0000         |
| 1700  | ACCESS_DIAGNOSTIC_ENTRY     | 0000        | 0000  | 00000000 | 1            | DEL   | 0000         |
| 1700  | DGMESCO                     | 0000        | 0000  | 000031C8 | 1            | SYS   | DD66         |
| 1700  | DIAGNOSTIC_COMMON_ROUTINES  | 0000        | 0000  | 000005E6 | 1            | SYS   | 4C19         |
| 1700  | ACCESS_DIAGNOSTIC_ENTRY     | 0000        | 0000  | 00000000 | 1            | OEL   | 0000         |

SRCE = SOURCE OF MODULE

SYS = SYSTEM LIBRARY

DEL = OLOADABLE MODULE LIST (I.E. DI MEMORY)

**Table 6-8. Field Definitions for Online Loader System Statistics Report**

| <b>Field</b>    | <b>Definition</b>  |
|-----------------|--|
| CHECK SUM       | This number is a checksum of the loader text. If the module checksum for one module at one version is different, loader text corruption occurs. This leads to unpredictable DI events. Corruption can occur anywhere in the data path. |
| DESTINATION MPB | The number of bytes of software information loaded into the main processor board (MPB) of the loaded DI.   |
| DESTINATION PMM | The number of bytes of software information loaded into the private memory module (PMM) of the loaded DI.  |
| DESTINATION SMM | The number of bytes of software information loaded into the system main memory (SMM) of the loaded DI.   |
| MODULE NAME     | The name of the loaded module.   |
| NO. LOADS       | The number of times the identified module was loaded.  |
| SRCE            | The source from which the module is loaded. The source can be SYS (the system library) or DEL (the deloadable module list in the DI memory).   |
| TIME            | The time that the reported statistics are tabulated.   |

## Mainframe Channel Statistics Reports (MCISRP1, MCISRP2, MCISRP3)

Mainframe channel statistics reports provide you with information that allows you to monitor the mainframe channel usage in your network, locate mainframe channel transmission problems, and take corrective action that prevents any problems from becoming catastrophic. These reports detail the amount of data transmitted in and out of your mainframe channels for both characters and blocks of data generated and received. MCISRP3 includes the expected operating limits feature, which draws your attention to any unacceptably high frequency of data retransmissions or bad block transmission.

Use the `DEFINE_SOURCE_LOG_GROUP` and `START_TRUNK_METRICS` commands to gather the statistics needed for these reports. The log message ID is 562 with an attribute of S.

Three mainframe channel interface reports are provided:

- |         |   |
|---------|---|
| MCISRP1 | Lists the number of characters and blocks of data used as input and output through the mainframe channel. The data presented in MCISRP1 is sorted by the SID. |
| MCISRP2 | Lists the number of characters and blocks sorted by the SID on a daily basis.   |
| MCISRP3 | Compares the number of good blocks of information to the number of bad blocks of information transmitted. Data is sorted by the SID with EOL.                 |

## MCISRP1 Report Example

The first page is an unnumbered report heading similar to that shown in figure 6-1. Following the report heading page is a numbered report data page similar to the following example. Table 6-9 lists the report field names and their definitions.

REPORT DAY: 86/09/05

PAGE 1

## MCISRP1 REPORT

TITLE = MDI\_8A

SID = 08002510008A

| ENDING<br>TIME | CS | CHARS<br>IN | BLOCKS<br>IN | AVERAGE<br>CHAR/BLK | CHARS<br>OUT | BLOCKS<br>OUT | AVERAGE<br>CHAR/BLK |
|----------------|----|-------------|--------------|---------------------|--------------|---------------|---------------------|
| =====          | == | =====       | =====        | =====               | =====        | =====         | =====               |
| 0124           | 7  | 0           | 0            | 0                   | 0            | 0             | 0                   |
| 0224           | 7  | 828         | 36           | 23                  | 1203         | 36            | 33                  |
| 0324           | 7  | 1656        | 72           | 23                  | 2412         | 72            | 33                  |
| 0424           | 7  | 0           | 0            | 0                   | 0            | 0             | 0                   |
| 0524           | 7  | 0           | 0            | 0                   | 0            | 0             | 0                   |
| 0624           | 7  | 17938       | 764          | 23                  | 833851       | 767           | 1087                |
| 0724           | 7  | 13938       | 280          | 49                  | 71134        | 283           | 251                 |
| 0824           | 7  | 1207006     | 912          | 1323                | 20157        | 909           | 22                  |
| 0924           | 7  | 54822       | 478          | 114                 | 38290        | 492           | 77                  |
| 1024           | 7  | 593878      | 4419         | 134                 | 5131138      | 4431          | 1158                |
| 1224           | 7  | 61268       | 535          | 114                 | 13446        | 543           | 24                  |
| 1424           | 7  | 224311      | 1032         | 217                 | 35178        | 1040          | 33                  |
| 1524           | 7  | 139976      | 3328         | 42                  | 2876477      | 3332          | 863                 |
| 1624           | 7  | 51494       | 2328         | 22                  | 3145753      | 2330          | 1350                |
| 1724           | 7  | 186372      | 5029         | 37                  | 6233287      | 5041          | 1236                |
| 1824           | 7  | 13193       | 81           | 162                 | 3181         | 82            | 38                  |
| 1924           | 7  | 445         | 6            | 74                  | 159          | 6             | 26                  |
| 2024           | 7  | 0           | 0            | 0                   | 0            | 0             | 0                   |
| 2124           | 7  | 0           | 0            | 0                   | 0            | 0             | 0                   |
| 2224           | 7  | 0           | 0            | 0                   | 0            | 0             | 0                   |
| 2324           | 7  | 506921      | 22770        | 22                  | 30472157     | 22801         | 1336                |



**MCISRP2 Report Example**

The first page is an unnumbered report heading similar to that shown in figure 6-1. Following the report heading page is a numbered report data page similar to the following example. Table 6-9 lists the report field names and their definitions.

REPORT DAY: 86/09/05

PAGE 1

**MCISRP2 REPORT**

| ENDING<br>DATE | CS | SID          | CHARS<br>IN/1000 | BLOCKS<br>IN | AVERAGE<br>CHAR/BLK | CHARS<br>OUT/1000 | BLOCKS<br>OUT | AVERAGE<br>CHAR/BLK |
|----------------|----|--------------|------------------|--------------|---------------------|-------------------|---------------|---------------------|
| =====          | == | =====        | =====            | =====        | =====               | =====             | =====         | =====               |
| 86/09/05       | 7  | 08002510008A | 3074             | 42070        | 73                  | 48877             | 42165         | 1159                |
| 86/09/05       | 4  | 08002510008B | 2627             | 62549        | 42                  | 79192             | 62701         | 1263                |
| 86/09/05       | 7  | 080025100081 | 6593             | 60372        | 109                 | 2100              | 60762         | 35                  |
| 86/09/05       | 7  | 0800253000BE | 86143            | 247215       | 348                 | 41464             | 247987        | 167                 |
| 86/09/05       | 7  | 0800253000C0 | 403221           | 460183       | 876                 | 23765             | 461014        | 52                  |
| 86/09/06       | 7  | 08002510008A | 201              | 9008         | 22                  | 11875             | 9027          | 1316                |
| 86/09/06       | 4  | 08002510008B | 362              | 14733        | 25                  | 19227             | 14758         | 1303                |
| 86/09/06       | 7  | 080025100081 | 471              | 4511         | 104                 | 188               | 4536          | 42                  |
| 86/09/06       | 7  | 0800253000BE | 17404            | 17186        | 1013                | 2849              | 17204         | 166                 |
| 86/09/06       | 7  | 0800253000C0 | 95481            | 82328        | 1160                | 2827              | 82427         | 34                  |

### MCISRP3 Report Example

The first page is an unnumbered report heading similar to that shown in figure 6-1. Following the report heading page is a numbered report data page similar to the following example. Table 6-9 lists the report field names and their definitions.

REPORT DAY: 86/09/05

PAGE 1

## MCISRP3 REPORT

TITLE = MDI\_8A

SID = 08002510008A

| ENDING<br>TIME | CS | BLOCKS<br>IN | BLOCKS<br>BAD IN | % BAD   |       | BLOCKS<br>BAD OUT | BLOCKS<br>OUT | % BAD   |       |
|----------------|----|--------------|------------------|---------|-------|-------------------|---------------|---------|-------|
|                |    |              |                  | [ 100 ] | [ 0 ] |                   |               | [ 100 ] | [ 0 ] |
| 0124           | 7  | 0            | 0                | 0       |       | 0                 | 0             | 0       |       |
| 0224           | 7  | 36           | 0                | 0       |       | 36                | 0             | 0       |       |
| 0324           | 7  | 72           | 0                | 0       |       | 72                | 0             | 0       |       |
| 0424           | 7  | 0            | 0                | 0       |       | 0                 | 0             | 0       |       |
| 0524           | 7  | 0            | 0                | 0       |       | 0                 | 0             | 0       |       |
| 0624           | 7  | 764          | 0                | 0       |       | 767               | 0             | 0       |       |
| 0724           | 7  | 280          | 0                | 0       |       | 283               | 0             | 0       |       |
| 0824           | 7  | 912          | 0                | 0       |       | 909               | 0             | 0       |       |
| 0924           | 7  | 478          | 0                | 0       |       | 492               | 0             | 0       |       |
| 1024           | 7  | 4419         | 0                | 0       |       | 4431              | 0             | 0       |       |
| 1224           | 7  | 535          | 0                | 0       |       | 543               | 0             | 0       |       |
| 1424           | 7  | 1032         | 0                | 0       |       | 1040              | 0             | 0       |       |
| 1524           | 7  | 3328         | 0                | 0       |       | 3332              | 0             | 0       |       |
| 1624           | 7  | 2328         | 0                | 0       |       | 2330              | 0             | 0       |       |
| 1724           | 7  | 5029         | 0                | 0       |       | 5041              | 0             | 0       |       |
| 1824           | 7  | 81           | 0                | 0       |       | 82                | 0             | 0       |       |
| 1924           | 7  | 6            | 0                | 0       |       | 6                 | 0             | 0       |       |
| 2024           | 7  | 0            | 0                | 0       |       | 0                 | 0             | 0       |       |
| 2124           | 7  | 0            | 0                | 0       |       | 0                 | 0             | 0       |       |
| 2224           | 7  | 0            | 0                | 0       |       | 0                 | 0             | 0       |       |
| 2324           | 7  | 22770        | 0                | 0       |       | 22801             | 0             | 0       |       |

**Table 6-9. Field Definitions for Mainframe Channel Statistics Reports**

| <b>Field</b>                     | <b>Definition</b>  |
|----------------------------------|--|
| AVERAGE CHAR/BLK<br>(BLOCKS IN)  | The average number of characters-per-block received from the mainframe channel or the ICI (ICA-II Channel Interface).                                |
| AVERAGE CHAR/BLK<br>(BLOCKS OUT) | The average number of characters-per-block transmitted to the mainframe channel or the ICI.  |
| BLOCKS BAD IN                    | The number of retransmitted blocks of data received from the mainframe channel or the ICI.   |
| BLOCKS BAD OUT                   | The number of blocks of data retransmitted to the mainframe channel or the ICI.  |
| BLOCKS IN                        | The number of data blocks received from the mainframe channel or the ICI.  |
| BLOCKS OUT                       | The number of data blocks transmitted to the mainframe channel or the ICI.   |
| CHARS IN                         | The number of characters received from the mainframe channel or the ICI.   |
| CHARS IN/1000                    | The number of characters, in thousands, received from the mainframe channel or the ICI.  |
| CHARS OUT                        | The number of characters transmitted to the mainframe channel or the ICI.  |
| CHARS OUT/1000                   | The number of characters, in thousands, transmitted to the mainframe channel or the ICI.   |
| CS                               | The card slot number identifying the location of the board within the DI. When reporting on ICI statistics, this number is always 0 and meaningless. |
| SID                              | The device interface identification number.  |
| ENDING DATE                      | The last date that the reported statistics were tabulated.   |
| ENDING TIME                      | The last time that the reported statistics were tabulated.   |
| % BAD (BLOCKS IN)                | The percentage of bad blocks of data received from the mainframe channel.  |
| % BAD (BLOCKS OUT)               | The percentage of blocks of data sent to the mainframe channel.  |

## **Session Statistics Report (SESSRP1)**

The SESSRP1 report logs summary statistics of Session layer activity.

Use the `DEFINE_SOURCE_LOG_GROUP` and `START_PROCESS_METRICS` commands to gather the statistics needed for this report. The log message ID is 737 with an attribute of S.

**SESSRP1 Report Example**

The first page is an unnumbered report heading similar to that shown in figure 6-1. Following the report heading page is a numbered report data page similar to the following example. Table 6-10 lists the report field names and their definitions.

REPORT DAY: 86/09/05

PAGE 1

**SESSRP1 REPORT**

TITLE = MDI\_8A

SID = 08002510008A

| ENDING<br>TIME<br>===== | DATA PDU'S<br>RECEIVED<br>===== | OVERHEAD<br>PDU'S<br>RECEIVED<br>===== | DATA PDU'S<br>TRANSMITTED<br>===== | OVERHEAD<br>PDU'S<br>TRANSMITTED<br>===== |
|-------------------------|---------------------------------|--|------------------------------------|---|
| 0124                    | 0                               | 0                                      | 0                                  | 0   |
| 0224                    | 0                               | 0                                      | 0                                  | 0   |
| 0324                    | 0                               | 0                                      | 0                                  | 0   |
| 0424                    | 0                               | 0                                      | 0                                  | 0   |
| 0524                    | 0                               | 0                                      | 0                                  | 0   |
| 0624                    | 646                             | 7                                      | 75                                 | 4   |
| 0724                    | 140                             | 6                                      | 91                                 | 3   |
| 0824                    | 47                              | 1                                      | 859                                | 2   |
| 0924                    | 146                             | 11                                     | 261                                | 15  |
| 1024                    | 3598                            | 13                                     | 240                                | 9   |
| 1224                    | 150                             | 5                                      | 320                                | 7   |
| 1424                    | 243                             | 35                                     | 607                                | 6   |
| 1524                    | 2301                            | 74                                     | 860                                | 3   |
| 1624                    | 2193                            | 4                                      | 113                                | 2   |
| 1724                    | 4467                            | 18                                     | 456                                | 15  |
| 1824                    | 15                              | 1                                      | 33                                 | 0   |
| 1924                    | 0                               | 0                                      | 0                                  | 0   |
| 2024                    | 0                               | 0                                      | 0                                  | 0   |
| 2124                    | 0                               | 0                                      | 0                                  | 0   |
| 2224                    | 0                               | 0                                      | 0                                  | 0   |

**Table 6-10. Field Definitions for Session Statistics Report**

| <b>Field</b>               | <b>Definition</b>   |
|----------------------------|---|
| DATA PDU'S RECEIVED        | Number of protocol data units (PDUs) received by the Session layer during the report interval.        |
| DATA PDU'S TRANSMITTED     | Number of PDUs transmitted by the Session layer during the report interval.                           |
| ENDING TIME                | The last time at which the reported statistics are tabulated.   |
| OVERHEAD PDU'S RECEIVED    | Number of PDUs received by the Session layer used to control data flow during the report interval.    |
| OVERHEAD PDU'S TRANSMITTED | Number of PDUs transmitted by the Session layer used to control data flow during the report interval. |

## **Software Error Message Reports (SFTWRP1, SFTWRP2, SFTWRP3, SFTWRP4)**

Software error reports list the location, nature, and severity of software errors occurring in your network. These reports help you to determine which software routines have failed or are malfunctioning. You may then implement the required maintenance to return your network to order or perform actions to prevent abnormal interruptions of network service.

Use the `DEFINE_SOURCE_LOG_GROUP` command to gather the information needed for these reports. All the log message IDs with an attribute of SE are used.

NPA offers four software errors reports:

- |         |   |
|---------|---|
| SFTWRP1 | Provides a chronological listing of software errors detected in the network.              |
| SFTWRP2 | Lists software errors detected in the network sorted by DI and error severity.            |
| SFTWRP3 | Provides a summary of all software errors by frequency and error severity.                |
| SFTWRP4 | Provides a summary of all software errors by frequency and error severity reported by DI. |

## SFTWRP1 Report Example

The first page is an unnumbered report heading similar to that shown in figure 6-3. Following the report heading page is a numbered report data page similar to the following example. Table 6-11 lists the report field names and their definitions.

REPORT DAY: 87/03/04

PAGE 1

### SFTWRP1 REPORT START TIME = 0300 HOURS

| DATE     | TIME        | SYSTEM ID    | LOG ID | SEVERITY |
|----------|-------------|--------------|--------|----------|
| 87/03/04 | 03.17.53759 | 08002510008B | 430    | ERROR    |

|          |             |              |     |       |
|----------|-------------|--------------|-----|-------|
| 87/03/04 | 03.17.53759 | 08002510008B | 430 | ERROR |
|----------|-------------|--------------|-----|-------|

--ERROR-- LOG\_SUPPORT\_APPLICATION RECEIVED A GENERIC\_TRANSPORT DISCONNECT INDICATION

FOR ALARMING TO SAPID 000000630800253000D230F6, CONNECTION ESTABLISHMENT WILL BE RETRIED.

PEER DISCONNECT REASON = NOT PROVIDED

|          |             |              |      |       |
|----------|-------------|--------------|------|-------|
| 87/03/04 | 03.47.14839 | 08002530008E | 1282 | ERROR |
|----------|-------------|--------------|------|-------|

--ERROR-- BIP HAS RECEIVED FORWARD DATA FROM APPLICATION UNEXPECTEDLY.

CONNECTION'S BIP TRANSMITTER STATE = TERM PENDING

CONNECTION NUMBER = 0003

COUPLER NODE = 003B.

MFI NODE = 003C.

TRUNK NAME = \$MCI7.

|          |             |              |     |       |
|----------|-------------|--------------|-----|-------|
| 87/03/04 | 03.47.14842 | 08002530008E | 129 | ERROR |
|----------|-------------|--------------|-----|-------|

--ERROR-- THE NP\_IVT GATEWAY MADE A APPL REQUEST TO BIP THAT WAS REJECTED

SVM CEPID = 001065A4

BIP REQUEST = 0002

TRUNK NAME = \$MCI7.

|          |             |              |      |       |
|----------|-------------|--------------|------|-------|
| 87/03/04 | 03.50.09115 | 08002530008E | 1282 | ERROR |
|----------|-------------|--------------|------|-------|

--ERROR-- BIP HAS RECEIVED FORWARD DATA FROM APPLICATION UNEXPECTEDLY.

CONNECTION'S BIP TRANSMITTER STATE = TERM PENDING

CONNECTION NUMBER = 0003

COUPLER NODE = 003B.

MFI NODE = 003C.

TRUNK NAME = \$MCI7.

|          |             |              |     |       |
|----------|-------------|--------------|-----|-------|
| 87/03/04 | 03.50.09117 | 08002530008E | 129 | ERROR |
|----------|-------------|--------------|-----|-------|

--ERROR-- THE NP\_IVT GATEWAY MADE A APPL REQUEST TO BIP THAT WAS REJECTED

SVM CEPID = 0010650C

BIP REQUEST = 0002

TRUNK NAME = \$MCI7.



**SFTWRP2 Report Example**

The first page is an unnumbered report heading similar to that shown in figure 6-3. Following the report heading page is a numbered report data page similar to the following example. Table 6-11 lists the report field names and their definitions.

REPORT DAY: 87/03/04

PAGE 1

SFTWRP2 REPORT  
ERROR

| DATE     | TIME        | SYSTEM ID    | LOG ID | SEVERITY |
|----------|-------------|--------------|--------|----------|
| 87/03/04 | 04.45.16276 | 08002510D06D | 413    | ERROR    |

```

87/03/04 04.45.16276 08002510D06D      413      ERROR
--ERROR-- LOG_SUPPORT_APPLICATION RECEIVED A GENERIC_TRANSPORT DISCONNECT
INDICATION
FOR LOGGING TO SAPID 000000010800253000C071BA, CONNECTION ESTABLISHMENT WILL
BE RETRIED.
PEER DISCONNECT REASON = SERVICE UNAVAILABLE

```

```

87/03/04 04.45.15473 08002510006F      413      ERROR
--ERROR-- LOG_SUPPORT_APPLICATION RECEIVED A GENERIC_TRANSPORT DISCONNECT
INDICATION
FOR LOGGING TO SAPID 41454B4B080025300070913E, CONNECTION ESTABLISHMENT WILL
BE RETRIED.
PEER DISCONNECT REASON = NOT PROVIDED

```

```

87/03/04 04.45.39053 08002510006F      430      ERROR
--ERROR-- LOG_SUPPORT_APPLICATION RECEIVED A GENERIC_TRANSPORT DISCONNECT
INDICATION
FOR ALARMING TO SAPID 000000630800253000D230F6, CONNECTION ESTABLISHMENT WILL
BE RETRIED.
PEER DISCONNECT REASON = NOT PROVIDED

```

```

87/03/04 07.35.07010 08002510006F      73       ERROR
--ERROR-- DEPENDENT FILE ACCESS RECEIVED AN INVALID UCEPID FROM TRANSPORT.
UCEPID: 001D289E.
INDEPENDENT FILE ACCESS PROTOCOL DATA UNIT: <NO DATA>
GENERIC TRANSPORT INDICATION: 0002.

```

```

87/03/04 04.45.18727 080025100074      413      ERROR
--ERROR-- LOG_SUPPORT_APPLICATION RECEIVED A GENERIC_TRANSPORT DISCONNECT
INDICATION
FOR LOGGING TO SAPID 41454B4B080025300070913E, CONNECTION ESTABLISHMENT WILL
BE RETRIED.
PEER DISCONNECT REASON = NOT PROVIDED

```

```

87/03/04 07.40.53612 080025100074      73       ERROR
--ERROR-- DEPENDENT FILE ACCESS RECEIVED AN INVALID UCEPID FROM TRANSPORT.
UCEPID: 001D31D2.
INDEPENDENT FILE ACCESS PROTOCOL DATA UNIT: <NO DATA>

```

**SFTWRP3 Report Example**

The first page is an unnumbered report heading similar to that shown in figure 6-3. Following the report heading page is a numbered report data page similar to the following example. Table 6-11 lists the report field names and their definitions.

REPORT DAY: 86/01/01

PAGE 1

**SFTWRP3 REPORT**

| LOG NUMBER | FREQUENCY | INFORMATIVE | WARNING | ERROR | FATAL | CATASTROPHIC |
|------------|-----------|-------------|---------|-------|-------|--------------|
| =====      | =====     | =====       | =====   | ===== | ===== | =====        |
| 8          | 2         | 2           | 0       | 0     | 0     | 0            |
| 19         | 2         | 2           | 0       | 0     | 0     | 0            |
| 73         | 15        | 0           | 0       | 15    | 0     | 0            |
| 129        | 96        | 0           | 0       | 96    | 0     | 0            |
| 413        | 19        | 0           | 0       | 19    | 0     | 0            |
| 427        | 5         | 5           | 0       | 0     | 0     | 0            |
| 429        | 1         | 1           | 0       | 0     | 0     | 0            |
| 430        | 2         | 0           | 0       | 2     | 0     | 0            |
| 529        | 1         | 0           | 0       | 1     | 0     | 0            |
| 651        | 1495      | 0           | 0       | 1495  | 0     | 0            |
| 809        | 2         | 2           | 0       | 0     | 0     | 0            |
| 1242       | 2         | 0           | 0       | 2     | 0     | 0            |
| 1257       | 1         | 0           | 0       | 1     | 0     | 0            |
| 1282       | 139       | 0           | 0       | 139   | 0     | 0            |
| -----      |           |             |         |       |       |              |
| TOTALS     | 1782      | 12          | 0       | 1770  | 0     | 0            |

**SFTWRP4 Report Example**

The first page is an unnumbered report heading similar to that shown in figure 6-3. Following the report heading page is a numbered report data page similar to the following example. Table 6-11 lists the report field names and their definitions.

```

REPORT DAY: 86/09/05                                PAGE    9
                SFTWRP4 REPORT
        TITLE = MDI_300115                SID = 080025300115

LOG NUMBER FREQUENCY INFORMATIVE WARNING  ERROR  FATAL CATASTROPHIC
=====
413          1          0          0          1          0          0
429          1          1          0          0          0          0
430          1          0          0          1          0          0

```

**Table 6-11. Field Definitions for Software Error Message Reports**

| <b>Field</b>                                     | <b>Definition</b>  |
|--|--|
| DATE   | The date on which the error occurred.  |
| FREQUENCY  | Number of log messages for this log ID.                                      |
| INFORMATIVE/WARNING/<br>ERROR/FATAL/CATASTROPHIC | Number of log messages of this severity. Totals are listed on the last line. |
| LOG ID   | The log message identification number.                                       |
| LOG NUMBER                                       | The log message identification number.                                       |
| SEVERITY   | The description of the severity of the type of error that has occurred.      |
| SYSTEM ID  | The system identification number that identifies the DI.                     |
| TIME   | The network clock time when the error occurred.                              |

## TELNET Connection Statistics (TELNRP1, TELNRP2)

TELNET Connection Statistics reports monitor the TELNET usage on your network. These reports show you the number of connections initiated and terminated, average connect time, and maximum connect time.

Use the `DEFINE_SOURCE_LOG_GROUP` command to gather the information needed for these reports. The log message IDs are 1554 and 1555 with an attribute of S.

NPA provides the following two TELNET reports:

- TELNRP1      Provides an hourly TELNET connection report.
- TELNRP2      Provides a daily TELNET connection report.

**TELNRP1 Report Example**

The first page is an unnumbered report heading page similar to that shown in figure 6-1. Following the report heading page is a numbered report data page similar to the following example. Table 6-12 lists the report field names and their definitions.

REPORT DAY: 88/01/25

PAGE 1

## TELNRP1 REPORT

TITLE = D3000F2

SID = 0800253000F2

| ENDING<br>TIME | SERVICE NAME | C O N N E C T I O N |           |          |          |
|----------------|--------------|---------------------|-----------|----------|----------|
|                |              | INITIATION          | TERMINATE | AVG TIME | MAX TIME |
| 200            | PEWTER       | 10                  | 10        | 8        | 10       |
| 600            | PEWTER       | 4                   | 4         | 12       | 15       |
| 700            | PEWTER       | 13                  | 13        | 10       | 15       |
| 800            | PEWTER       | 14                  | 14        | 24       | 215      |
| 900            | PEWTER       | 16                  | 14        | 25       | 225      |
| 1000           | PEWTER       | 3                   | 3         | 265      | 760      |
| 1000           | PEWTER       | 22                  | 22        | 145      | 1170     |
| 1100           | PEWTER       | 17                  | 16        | 251      | 1160     |
| 1100           | PEWTER       | 28                  | 27        | 102      | 815      |
| 1200           | PEWTER       | 7                   | 6         | 89       | 385      |
| 1200           | PEWTER       | 16                  | 18        | 73       | 365      |
| 1300           | PEWTER       | 9                   | 9         | 405      | 2915     |
| 1300           | PEWTER       | 17                  | 17        | 81       | 665      |
| 1400           | PEWTER       | 8                   | 7         | 575      | 3010     |
| 1400           | PEWTER       | 8                   | 7         | 15       | 25       |
| 1500           | PEWTER       | 8                   | 8         | 310      | 1800     |
| 1500           | PEWTER       | 17                  | 17        | 75       | 855      |
| 1600           | PEWTER       | 11                  | 11        | 674      | 4970     |
| 1600           | PEWTER       | 20                  | 20        | 221      | 2775     |
| 1700           | PEWTER       | 8                   | 8         | 733      | 4130     |
| 1700           | PEWTER       | 15                  | 16        | 200      | 2865     |
| 1800           | PEWTER       | 12                  | 13        | 115      | 375      |
| 1800           | PEWTER       | 11                  | 11        | 17       | 95       |
| 1900           | PEWTER       | 7                   | 6         | 272      | 595      |
| 1900           | PEWTER       | 8                   | 8         | 21       | 95       |
| 2000           | PEWTER       | 4                   | 5         | 214      | 900      |
| 2000           | PEWTER       | 14                  | 14        | 27       | 230      |
| 2100           | PEWTER       | 7                   | 5         | 58       | 80       |
| 2100           | PEWTER       | 12                  | 12        | 10       | 15       |
| 2200           | PEWTER       | 4                   | 6         | 253      | 1250     |
| 2200           | PEWTER       | 12                  | 12        | 10       | 15       |
| 2300           | PEWTER       | 3                   | 3         | 120      | 300      |
| 2300           | PEWTER       | 14                  | 14        | 10       | 15       |
| 2400           | PEWTER       | 17                  | 17        | 42       | 295      |

**TELNRP2 Report Example**

The first page is an unnumbered report heading page similar to that shown in figure 6-1. Following the report heading page is a numbered report data page similar to the following example. Table 6-12 lists the report field names and their definitions.

```

REPORT DAY:  88/01/25                                PAGE    1
                                TELNRP2 REPORT
                                TITLE = D3000F2        SID = 0800253000F2

ENDING                                C O N N E C T I O N
DATE                                SERVICE NAME      INITIATION TERMINATE  AVG TIME  MAX TIME
=====
880125 PEWTER                        108          106        331      4970
880125 PEWTER                        288          287        71       2865
880126 PEWTER                         4            4         90       220
880126 PEWTER                        28           28         13       100

```

**Table 6-12. Field Definitions for TELNET Statistics Reports**

| <b>Field</b>          | <b>Definition</b>   |
|-----------------------|---|
| CONNECTION AVG TIME   | The average length, in seconds, of a TELNET session.                                    |
| CONNECTION INITIATION | The number of times during the report interval that a TELNET connection was initiated.  |
| CONNECTION TERMINATE  | The number of times during the report interval that a TELNET connection was terminated. |
| ENDING DATE           | The last date that the reported statistics were tabulated.                              |
| ENDING TIME           | The last time that the reported statistics were tabulated.                              |
| CONNECTION MAX TIME   | The length, in seconds, of the longest TELNET session.                                  |
| SERVICE NAME          | The name of the service to which the TELNET users are connected.                        |



## Terminal Statistics Reports (TERMRP1, TERMRP2)

Terminal statistics reports monitor terminal usage on your network. These reports show you the amount of input and output information passing to and from your network's terminals. Terminal activity is measured in characters and blocks of information generated and received.

NPA provides two terminal statistics reports. These reports are usually produced on a daily or weekly basis and may be produced to illustrate condensed time periods.

Use the `DEFINE_SOURCE_LOG_GROUP` and `START_LINE_METRICS` commands to gather the statistics needed for these reports. The log message ID is 166 with an attribute of S.

NPA has two terminal statistics reports:

- |         |   |
|---------|---|
| TERMRP1 | Lists the number of bad blocks and good blocks of data that are transferred through each CIM, LIM, and DI. The report is sorted by line and terminal. Includes the expected operating limits feature, which calls your attention to problem areas that require corrective action. |
| TERMRP2 | Lists the characters and blocks of data that are used as input and output through each CIM, LIM, and DI in your network. The information provided in this report is sorted by line and by terminal.   |

**TERMRP1 Report Example**

The first page is a unnumbered report heading similar to that shown in figure 6-1. Following the report heading page is a numbered report data page similar to the following example. Table 6-13 lists the report field names and their definitions.

REPORT DAY: 86/09/05

PAGE 1

## TERMRP1 REPORT

TITLE = TDI\_6F

SID = 08002510006F

| ENDING | LI | PO | BLOCKS | BLOCKS | % BAO | BLOCKS | BLOCKS  | % BAD | TIME- |
|--------|----|----|--------|--------|-------|--------|---------|-------|-------|
| TIME   |    |    | IN     | BAD IN | [ 3 ] | OUT    | BAD OUT | [ 3 ] | OUTS  |
|        |    |    |        |        | [ 0 ] |        |         | [ 0 ] |       |
| 1905   | 0  | 0  | 119    | 0      | 0     | 385    | 0       | 0     | 0     |
| 1905   | 0  | 1  | 247    | 0      | 0     | 1015   | 0       | 0     | 0     |
| 1905   | 0  | 2  | 350    | 0      | 0     | 1291   | 0       | 0     | 0     |
| 1905   | 0  | 3  | 532    | 0      | 0     | 1646   | 0       | 0     | 0     |
| 1905   | 1  | 0  | 193    | 0      | 0     | 567    | 0       | 0     | 0     |
| 1905   | 1  | 1  | 83     | 0      | 0     | 290    | 0       | 0     | 0     |
| 1905   | 1  | 2  | 614    | 0      | 0     | 1990   | 0       | 0     | 0     |
| 1905   | 1  | 3  | 494    | 0      | 0     | 1273   | 0       | 0     | 0     |
| 1905   | 2  | 0  | 167    | 0      | 0     | 676    | 0       | 0     | 0     |
| 1905   | 2  | 1  | 770    | 0      | 0     | 3078   | 0       | 0     | 0     |
| 1905   | 2  | 2  | 46     | 0      | 0     | 155    | 0       | 0     | 0     |
| 1905   | 2  | 3  | 0      | 0      | 0     | 0      | 0       | 0     | 0     |
| 1905   | 3  | 0  | 146    | 0      | 0     | 511    | 0       | 0     | 0     |
| 1905   | 3  | 1  | 762    | 0      | 0     | 3480   | 0       | 0     | 0     |
| 1905   | 3  | 2  | 695    | 0      | 0     | 1607   | 0       | 0     | 0     |
| 1905   | 3  | 3  | 690    | 0      | 0     | 3680   | 0       | 0     | 0     |
| 1905   | 4  | 0  | 0      | 0      | 0     | 0      | 0       | 0     | 0     |
| 1905   | 4  | 1  | 641    | 0      | 0     | 1904   | 0       | 0     | 0     |
| 1905   | 4  | 2  | 0      | 0      | 0     | 0      | 0       | 0     | 0     |
| 1905   | 4  | 3  | 0      | 0      | 0     | 0      | 0       | 0     | 0     |
| 1905   | 5  | 0  | 0      | 0      | 0     | 0      | 0       | 0     | 0     |
| 1905   | 5  | 1  | 39     | 0      | 0     | 171    | 0       | 0     | 0     |
| 1905   | 5  | 2  | 725    | 0      | 0     | 2895   | 0       | 0     | 0     |
| 1905   | 5  | 3  | 528    | 0      | 0     | 1590   | 0       | 0     | 0     |
| 1905   | 6  | 0  | 1164   | 0      | 0     | 4496   | 0       | 0     | 0     |
| 1905   | 6  | 1  | 0      | 0      | 0     | 0      | 0       | 0     | 0     |
| 1905   | 6  | 2  | 0      | 0      | 0     | 0      | 0       | 0     | 0     |
| 1905   | 6  | 3  | 365    | 0      | 0     | 1544   | 0       | 0     | 0     |
| 1905   | 7  | 0  | 0      | 0      | 0     | 0      | 0       | 0     | 0     |
| 1905   | 7  | 1  | 950    | 0      | 0     | 1994   | 0       | 0     | 0     |
| 1905   | 7  | 2  | 818    | 0      | 0     | 3031   | 0       | 0     | 0     |
| 1905   | 7  | 3  | 0      | 0      | 0     | 0      | 0       | 0     | 0     |

**TERMRP2 Report Example**

The first page is an unnumbered report heading similar to that shown in figure 6-1. Following the report heading page is a numbered report data page similar to the following example. Table 6-13 lists the report field names and their definitions.

REPORT DAY: 86/09/05

PAGE 1

**TERMRP2 REPORT**

TITLE = TDI\_6F

SIO = 08002510006F

| ENDING<br>TIME | LI | PO | CHARS<br>IN/K | CHARS<br>OUT/K |
|----------------|----|----|---------------|----------------|
| =====          | == | == | =====         | =====          |
| 1905           | 0  | 0  | 1.4           | 47.1           |
| 1905           | 0  | 1  | 1.6           | 166.3          |
| 1905           | 0  | 2  | 2.1           | 230.2          |
| 1905           | 0  | 3  | 6.9           | 182.3          |
| 1905           | 1  | 0  | 2.9           | 70.8           |
| 1905           | 1  | 1  | 0.7           | 42.2           |
| 1905           | 1  | 2  | 4.0           | 297.8          |
| 1905           | 1  | 3  | 1.8           | 165.9          |
| 1905           | 2  | 0  | 2.0           | 103.9          |
| 1905           | 2  | 1  | 10.5          | 668.0          |
| 1905           | 2  | 2  | 0.4           | 16.8           |
| 1905           | 2  | 3  | 0.0           | 0.0            |
| 1905           | 3  | 0  | 1.0           | 69.5           |
| 1905           | 3  | 1  | 4.3           | 650.9          |
| 1905           | 3  | 2  | 5.2           | 245.8          |
| 1905           | 3  | 3  | 4.5           | 704.7          |
| 1905           | 4  | 0  | 0.0           | 0.0            |
| 1905           | 4  | 1  | 5.1           | 216.1          |
| 1905           | 4  | 2  | 0.0           | 0.0            |
| 1905           | 4  | 3  | 0.0           | 0.0            |
| 1905           | 5  | 0  | 0.0           | 0.0            |
| 1905           | 5  | 1  | 0.3           | 27.1           |
| 1905           | 5  | 2  | 8.9           | 486.7          |
| 1905           | 5  | 3  | 6.6           | 169.1          |
| 1905           | 6  | 0  | 6.6           | 734.1          |
| 1905           | 6  | 1  | 0.0           | 0.0            |
| 1905           | 6  | 2  | 0.0           | 0.0            |
| 1905           | 6  | 3  | 3.0           | 257.2          |
| 1905           | 7  | 0  | 0.0           | 0.0            |
| 1905           | 7  | 1  | 5.8           | 78.6           |
| 1905           | 7  | 2  | 7.6           | 444.4          |
| 1905           | 7  | 3  | 0.0           | 0.0            |

**Table 6-13. Field Definitions for Terminal Statistics Reports**

| <b>Field</b>       | <b>Definition</b>  |
|--------------------|--|
| BLOCKS BAD IN      | The number of bad blocks of data received at the DI from the terminal.           |
| BLOCKS BAD OUT     | The number of bad blocks of data retransmitted from the DI to the terminal.      |
| BLOCKS IN          | The number of blocks of data received at the DI from the terminal.               |
| BLOCKS OUT         | The number of blocks of data transmitted from the DI to the terminal.            |
| CHARS IN/K         | The number of characters, in thousands, received at the DI from the terminal.    |
| CHARS OUT/K        | The number of characters, in thousands, transmitted from the DI to the terminal. |
| ENDING TIME        | The clock time representing the end of the time interval being reported on.      |
| LI                 | The slot number of the LIM on the CIM.   |
| PO                 | The LIM port number.   |
| TIME-OUTS          | The number of time-outs received.  |
| % BAD (BLOCKS IN)  | The percentage of bad blocks of data sent from the terminal to the DI.           |
| % BAD (BLOCKS OUT) | The percentage of bad blocks of data sent from the DI to the terminal.           |

## User Statistics Report (USERRP1)

The user statistics report is a debugging tool. It displays the contents of a log message in a readable format; the management data unit (MDU) format. Each variable field is reformatted and identified by the type of field it is. Each field is displayed as \*field\_type\*variable\_value. The following is a list of log message fields:

| Field Type             | Abbreviation | Value Format |
|------------------------|--------------|--------------|
| Template specification | *TP*         | Hexadecimal  |
| Binary octet           | *BO*         | Hexadecimal  |
| Binary string          | *BS*         | Binary       |
| Character octet        | *CO*         | Alphanumeric |
| Binary integer         | *BI*         | Decimal      |
| Binary signed integer  | *BSI*        | Decimal      |
| Binary-coded decimal   | *BCD*        | Decimal      |

Any or all log messages in a log file may provide the information needed for this report. The USER parameter in the REFCLF command determines which log messages provide the report information by specifying their corresponding attribute.

## USERRP1 Report Example

The first page is an unnumbered report heading similar to that shown in figure 6-2. Following the report heading page is a numbered report data page similar to the following example. Table 6-14 lists the report field names and their definitions.

REPORT DAY: 86/01/01

PAGE 1

## USERRP1 REPORT

| DATE  | TIME        | DI           | LOG-NUMBER |
|---|-------------|--------------|------------|
| =====   | =====       | =====        | =====      |
| 86/01/01  | 00.00.00927 | 0800253000A2 | 00338      |
| *TP*1030*BI*0*BI*7  |             |              |            |
| 86/01/01  | 00.00.00930 | 0800253000A2 | 00340      |
| *TP*1032*BI*1*BI*39168*BO*00010000                                      |             |              |            |
| 86/01/01  | 00.00.00933 | 0800253000A2 | 00341      |
| *TP*1033*BI*2*BI*1942*BO*0648   |             |              |            |
| 86/01/01  | 00.00.00935 | 0800253000A2 | 00342      |
| *TP*1034*BI*2*BI*11671*BO*0473  |             |              |            |
| 86/01/01  | 00.00.55028 | 0800253000A2 | 00019      |
| *TP*477*TP*480*TP*5029*BO*41454646*BO*0800253000BE                      |             |              |            |
| 87/03/04  | 07.28.42691 | 0800253000A2 | 00351      |
| *TP*1043*CO*LIM *BO*2608*CO*CIM SLOT*BI*5*CO*LIM SLOT*BI*0*TP*1073*BI*5 |             |              |            |
| 87/03/04  | 07.39.25820 | 0800253000A2 | 00019      |
| *TP*477*TP*480*TP*5029*BO*41454646*BO*0800253000BE                      |             |              |            |
| 87/03/04  | 07.59.32410 | 0800253000A2 | 00351      |
| *TP*1043*CO*CIM *BO*2608*CO*CIM SLOT*BI*5*TP*1073*BI*5                  |             |              |            |

**Table 6-14. Field Definitions for User Statistics Report**

| <b>Field</b> | <b>Definition</b>                                    |
|--------------|--|
| DATE         | The date that the reported statistics are tabulated. |
| LOG-NUMBER   | The identifiable log message number.                 |
| DI           | The device interface identification number.          |
| TIME         | The time that the reported statistics are tabulated. |

## **X.25 Connection Statistics Reports (X25CRP1, X25CRP2)**

These reports provide the X.25 connection statistics. These reports are forwarded to the network log file.

Use the `DEFINE_SOURCE_LOG_GROUP` command to gather the information needed for these reports. The log message IDs are 1160, 1161, 1342, and 1343 with an attribute of S.

There are two X.25 connection statistics reports:

- |         |   |
|---------|---|
| X25CRP1 | Provides a connection statistics report sorted by DI and time.                          |
| X25CRP2 | Provides a connection statistics report sorted by service name and DI on a daily basis. |



**X25CRP1 Report Example**

The first page is an unnumbered report heading similar to that shown in figure 6-1. Following the report heading page is a numbered report data page similar to the following example. Table 6-15 lists the report field names and their definitions.

REPORT DAY: 86/09/05

PAGE 1

**X25CRP1 REPORT**

TITLE = D3000F2

SID = 0800253000F2

| ENDING<br>TIME | SERVICE NAME | INITIATION | CONNECTION<br>TERMINATE | AVG TIME | MAX TIME |
|----------------|--------------|------------|-------------------------|----------|----------|
| =====          | =====        | =====      | =====                   | =====    | =====    |
| 200            | \$GW_NP_39   | 10         | 10                      | 8        | 10       |
| 600            | \$GW_NP_39   | 4          | 4                       | 12       | 15       |
| 700            | \$GW_NP_39   | 13         | 13                      | 10       | 15       |
| 800            | \$GW_NP_39   | 14         | 14                      | 24       | 215      |
| 900            | \$GW_NP_39   | 16         | 14                      | 25       | 225      |
| 1000           |              | 3          | 3                       | 265      | 760      |
| 1000           | \$GW_NP_39   | 22         | 22                      | 145      | 1170     |
| 1100           |              | 17         | 16                      | 251      | 1160     |
| 1100           | \$GW_NP_39   | 28         | 27                      | 102      | 815      |
| 1200           |              | 7          | 6                       | 89       | 385      |
| 1200           | \$GW_NP_39   | 16         | 18                      | 73       | 365      |
| 1300           |              | 9          | 9                       | 405      | 2915     |
| 1300           | \$GW_NP_39   | 17         | 17                      | 81       | 665      |
| 1400           |              | 8          | 7                       | 575      | 3010     |
| 1400           | \$GW_NP_39   | 8          | 7                       | 15       | 25       |
| 1500           |              | 8          | 8                       | 310      | 1800     |
| 1500           | \$GW_NP_39   | 17         | 17                      | 75       | 855      |
| 1600           |              | 11         | 11                      | 674      | 4970     |
| 1600           | \$GW_NP_39   | 20         | 20                      | 221      | 2775     |
| 1700           |              | 8          | 8                       | 733      | 4130     |
| 1700           | \$GW_NP_39   | 15         | 16                      | 200      | 2865     |
| 1800           |              | 12         | 13                      | 115      | 375      |
| 1800           | \$GW_NP_39   | 11         | 11                      | 17       | 95       |
| 1900           |              | 7          | 6                       | 272      | 595      |
| 1900           | \$GW_NP_39   | 8          | 8                       | 21       | 95       |
| 2000           |              | 4          | 5                       | 214      | 900      |
| 2000           | \$GW_NP_39   | 14         | 14                      | 27       | 230      |
| 2100           |              | 7          | 5                       | 58       | 80       |
| 2100           | \$GW_NP_39   | 12         | 12                      | 10       | 15       |
| 2200           |              | 4          | 6                       | 253      | 1250     |
| 2200           | \$GW_NP_39   | 12         | 12                      | 10       | 15       |
| 2300           |              | 3          | 3                       | 120      | 300      |
| 2300           | \$GW_NP_39   | 14         | 14                      | 10       | 15       |
| 2400           | \$GW_NP_39   | 17         | 17                      | 42       | 295      |

**X25CRP2 Report Example**

The first page is an unnumbered report heading similar to that shown in figure 6-1. Following the report heading page is a numbered report data page similar to the following example. Table 6-15 lists the report field names and their definitions.

REPORT DAY: 86/09/05

PAGE 1

## X25CRP2 REPORT

TITLE = D3000F2

SID = 0800253000F2

| ENDING |              | C O N N E C T I O N |           |          |          |
|--------|--------------|---------------------|-----------|----------|----------|
| DATE   | SERVICE NAME | INITIATION          | TERMINATE | AVG TIME | MAX TIME |
| =====  | =====        | =====               | =====     | =====    | =====    |
| 860905 |              | 108                 | 106       | 331      | 4970     |
| 860905 | \$GW_NP_39   | 288                 | 287       | 71       | 2865     |
| 860906 |              | 4                   | 4         | 90       | 220      |
| 860906 | \$GW_NP_39   | 28                  | 28        | 13       | 100      |

**Table 6-15. Field Definitions for X.25 Connection Statistics Reports**

| <b>Field</b>          | <b>Definition</b>  |
|-----------------------|--|
| CONNECTION AVG TIME   | The average length in minutes of a terminal session established through the DI.                                    |
| CONNECTION INITIATION | The number of times during the report interval that a terminal connection was initiated through the DI.            |
| CONNECTION TERMINATE  | The number of times during the report interval that a terminal connection initiated through the DI was terminated. |
| ENDING DATE           | The last date during which the reported statistics were tabulated.   |
| ENDING TIME           | The clock time representing the end of the time interval reported on.  |
| CONNECTION MAX TIME   | The length, in minutes, of the longest terminal session established through the DI.                                |
| SERVICE NAME          | The name of the service to which the terminal users are connected.   |

# How To Create Customized NPA Reports Using IPF2 Database Files

---

7

|  |      |
|--|------|
| Customized Software Error Report Example .....                               | 7-1  |
| Step 1 .....   | 7-3  |
| NOS Only .....   | 7-3  |
| NOS/VE Only .....  | 7-4  |
| Step 2 .....   | 7-10 |
| Step 3 .....   | 7-12 |
| Creating a Customized NPA Summary Accounting Statistics Report Example ..... | 7-13 |
| Step 1 .....   | 7-13 |
| Step 2 .....   | 7-29 |
| Step 3 .....   | 7-33 |

(

(

(

(

(

(

(

# How To Create Customized NPA Reports Using IPF2 Database Files

---

7

This chapter provides examples of how to create customized NPA reports using the IPF2 database files. If you need more information than is provided with these examples, see the IPF2 Reference manual listed in Additional Related Manuals.

In order to create a customized report using IPF2, you must have the following:

- IPF2 software package including the MONITOR, REPORT, DEFINE, and UTILITY subsystems. The MONITOR subsystem is the central monitoring facility for IPF2. The REPORT subsystem is used to create report programs. The DEFINE subsystem is used to define the format of a database. It is only used if the report being created requires a change in the format of the database being reported (IPF2 requires all variables [virtual fields] used in a report process to be defined in the database format definition). The UTILITY subsystem provides an option for generating a structure listing of the format of the databases. This listing shows the database definitions of all fields in the databases.
- A copy of the NPA database definition files. These files are NPBDBS1, NPBDBS2, NPBDBS3, and if you are using NOS, NPBDBS4. These files are provided to all customers.

## Customized Software Error Report Example

In this example, we want to change the standard NPA Software Error Message Report (SFTWRP1 shown in figure 7-1) to do the following:

- Report only catastrophic and fatal errors
- Report the system name instead of system ID
- Sort messages by system name and then date/time
- Produce a different page header

|  |             |              |                   |
|--|-------------|--------------|-------------------|
| REPORT DAY: 88/02/15   |             | PAGE 1       |                   |
| SFTWRP1 REPORT   |             |              |                   |
| START TIME = 1000 HOURS  |             |              |                   |
| DATE   | TIME        | SYSTEM ID    | LOG ID SEVERITY   |
| =====  | =====       | =====        | =====             |
| 88/02/15   | 10.13.22861 | 0800253004F0 | 1492 ERROR        |
| --ERROR-- TELNET GATEWAY RECEIVED A BAD REQUEST                  |             |              |                   |
| REQUEST TO = 0002  |             |              |                   |
| RETURNED STATUS = 0003   |             |              |                   |
| 88/02/15   | 10.15.27786 | 0800253004F0 | 366 ERROR         |
| --ERROR-- SESSION LAYER RECEIVED AN UNEXPECTED EVENT FROM A USER |             |              |                   |
| CEPID = 0019B600   |             |              |                   |
| STATE = 0009   |             |              |                   |
| EVENT = 0004   |             |              |                   |
| 88/02/15   | 10.15.27789 | 0800253004F0 | 1492 ERROR        |
| --ERROR-- TELNET GATEWAY RECEIVED A BAD REQUEST                  |             |              |                   |
| REQUEST TO = 0001  |             |              |                   |
| RETURNED STATUS = 0004   |             |              |                   |
| 88/02/15   | 10.20.10711 | 0800253004F0 | 1228 CATASTROPHIC |
| --CATASTROPHIC-- DI RESET INDICATION. RESET CODE: 0018           |             |              |                   |
| REASON: TASK ERROR WITH NO RECOVERY PROCEDURE                    |             |              |                   |

Figure 7-1. Software Error Message Report (SFTWRP1)

## Step 1

The first step is to produce a listing of the IPF2 NPBSERR database fields (figure 7-2) contained in the NPA database (NPBDBS). To generate this listing, perform the following command sequence (this produces a listing of all the database fields, but this example uses only those fields in file NPBSERR):

### NOS Only

1. Set normal mode by entering:

```
NORMAL
```

2. Access database structure files by entering:

```
DEFINE, NPBDBS1, NPBDBS2, NPBDBS3, NPBDBS4
ATTACH, DBS1=NPBDBS1/UN=NETADMN
ATTACH, DBS2=NPBDBS2/UN=NETADMN
ATTACH, DBS3=NPBDBS3/UN=NETADMN
ATTACH, DBS4=NPBDBS4/UN=NETADMN
COPYEI, DBS1, NPBDBS1
COPYEI, DBS2, NPBDBS2
COPYEI, DBS3, NPBDBS3
COPYEI, DBS4, NPBDBS4
RETURN, DBS1, DBS2, DBS3, DBS4
```

3. Access IPF2 by entering:

```
GET, IPF2/UN=APPLLIB.
```

4. Run IPF2 by entering:

```
BEGIN, , IPF2.
```

5. The following prompt appears:

```
PLEASE ENTER DATABASE NAME?
```

Enter:

```
NPBDBS
```

6. The following prompt appears:

```
USING WHICH VIEW (ENTER A RECORD-NAME OR COMBINATION-NAME)?
```

Enter:

```
carriage return
```

7. The following prompt appears:

```
PLEASE ENTER A MONITOR COMMAND, A SUBSYSTEM NAME OR TYPE "HELP".
```

Enter:

```
UTILITY
```



8. The following prompt appears:

```
> BEGIN IPF UTILITY  
UTILITY COMMAND?
```

Enter:

```
LIST
```

9. The following prompt appears:

```
> BEGIN LIST PROCESS  
STRUCTURE LIST OF DATABASE "NPBDBS" MAY BE FOUND ON LOCAL  
FILE "DBLIST"  
> END LIST PROCESS  
UTILITY COMMAND?
```

Enter:

```
END
```

10. The following prompt appears:

```
> END IPF UTILITY  
MONITOR COMMAND?
```

Enter:

```
END
```

A listing of the entire definition/structure of the the database (NPBDBS) is now on local file DBLIST and may be printed.

## NOS/VE Only

1. Set your working catalog to a permanent catalog by entering:

```
SETWC $USER
```

2. Access the database structure definition files by entering:

```
COPF $SYSTEM.CDCNET.VERSION_XXXX.NPA.NPBDBS1,NPBDBS1  
COPF $SYSTEM.CDCNET.VERSION_XXXX.NPA.NPBDBS2,NPBDBS2  
COPF $SYSTEM.CDCNET.VERSION_XXXX.NPA.NPBDBS3,NPBDBS3
```

3. Access IPF2 by entering:

```
ATTF $SYSTEM.APPLICATIONS.IPF2.VER_2_6.IPF2
```

4. Run IPF2 by entering:

```
IPF2
```

5. The following prompt appears:

PLEASE ENTER DATABASE NAME?

Enter:

NPBDBS

6. The following prompt appears:

USING WHICH VIEW (ENTER A RECORD-NAME OR COMBINATION-NAME)?

Enter:

carriage return

7. The following prompt appears:

PLEASE ENTER A MONITOR COMMAND, A SUBSYSTEM NAME OR TYPE "HELP".

Enter:

UTILITY

8. The following prompt appears:

> BEGIN IPF UTILITY  
UTILITY COMMAND?

Enter:

LIST

9. The following prompt appears:

> BEGIN LIST PROCESS  
STRUCTURE LIST OF DATABASE "NPBDBS" MAY BE FOUND ON LOCAL  
FILE "DBLIST"  
> END LIST PROCESS  
UTILITY COMMAND?

Enter:

END

10. The following prompt appears:

> END IPF UTILITY  
MONITOR COMMAND?

Enter:

END

A listing of the entire definition/structure of the database (NPBDBS) is now on local file DBLIST and may be printed.

Figure 7-2 shows the listing of NPBSERR database fields created by the sequence in step 1.

| STRUCTURE REPORT OF<br>DATABASE NPBDBS<br>08/12/88 |         |                    |                  |                    |       |
|--|---------|--------------------|------------------|--------------------|-------|
| RECORD: NPASER                                     |         | TYPE: EXTERNAL     |                  | FILE(S): NPBSERR   |       |
| RECORD LENGTH: 1034                                |         | ORG: S RT: Z       |                  | NUM: IPF           |       |
| PH1: DEVICE INTERFACE                              |         |                    |                  |                    |       |
| PH2: SOFTWARE ERRORS                               |         |                    |                  |                    |       |
|  |         |                    |                  |                    |       |
| -----  |         | -----              | -----            | -----              | ----- |
| FIELD NAME/<br>SYNONYM                             | LEV OCC | COLUMN<br>HEADINGS | COL POS/<br>TYPE | FORMAT/<br>PICTURE | REQ?  |
| -----  |         | -----              | -----            | -----              | ----- |
| KEY-FIELD  |         | KEY                | 1                | 35X                |       |
|  | 1 1     | FIELD              | KEY              | X(035)             |       |
| STAT-DATE  |         | DATE               | 1                | 6X                 |       |
|  | 2 1     |                    |                  | XX/XX/XX           |       |
| STAT-YEAR  |         | YEAR               | 1                | 2N                 |       |
|  | 3 1     |                    |                  | 99/                |       |
| STAT-MONTH   |         | MONTH              | 3                | 2N                 |       |
|  | 3 1     |                    |                  | 99/                |       |
| STAT-DAY   |         | DAY                | 5                | 2N                 |       |
|  | 3 1     |                    |                  | 99                 |       |
| STAT-TIME  |         | TIME               | 7                | 9X                 |       |
|  | 2 1     |                    |                  | XX/XX/XXXXX        |       |
| STAT-TMX   |         | TIME               | 7                | 4X                 |       |
|  | 3 1     |                    |                  | XXXX               |       |
| STAT-HOUR  |         | HOUR               | 7                | 2N                 |       |
|  | 4 1     |                    |                  | 99                 |       |
| STAT-MIN   |         | MINUTE             | 9                | 2N                 |       |
|  | 4 1     |                    |                  | 99.                |       |
| STAT-SEC   |         | SECONDS            | 11               | 5N                 |       |
|  | 3 1     |                    |                  | 99999              |       |
| NETWORK-ID   |         | NETWORK            | 16               | 8X                 |       |
|  | 2 1     | ID                 |                  | X(008)             |       |

Figure 7-2. NPBSERR File

(Continued)



(Continued)

| STRUCTURE REPORT OF<br>DATABASE NPBDBS<br>08/12/88 |         |                    |                  |                     |      |       |
|--|---------|--------------------|------------------|---------------------|------|-------|
| RECORD: NPASER                                     |         | TYPE: EXTERNAL     |                  | FILE(S): NPBSEERR   |      |       |
| RECORD LENGTH: 1034                                |         | ORG: S RT: Z       |                  | NUM: IPF            |      |       |
| PH1: DEVICE INTERFACE                              |         |                    |                  |                     |      |       |
| PH2: SOFTWARE ERRORS                               |         |                    |                  |                     |      |       |
| -----  |         | -----              |                  | -----               |      | ----- |
| FIELD NAME/<br>SYNONYM                             | LEV OCC | COLUMN<br>HEADINGS | COL POS/<br>TYPE | FORMAT/<br>PICTURE  | REQ? |       |
| -----  |         | -----              |                  | -----               |      | ----- |
| END-TIME   | 1 1     | END<br>TIME        | VIR              | 4X<br>X(004)        |      |       |
| END-HOUR   | 2 1     | END<br>HOUR        | VIR              | 2N<br>99.           |      |       |
| END-MIN  | 2 1     | END<br>MINUTE      | VIR              | 2N<br>99.           |      |       |
| DI-NO  | 1 1     | DI<br>NUMBER       | VIR              | 12X<br>X(012)       |      |       |
| SEVERITY-NAME                                      | 1 1     | SEVERITY<br>NAME   | VIR              | 12X<br>X(012)       |      |       |
| NPA-USER-NAME                                      | 1 1     | USER<br>NAME       | VIR              | 10X<br>X(010)       |      |       |
| BREAK-IND  | 1 1     | BREAK<br>INDICATOR | VIR              | 7N<br>-(007)9       |      |       |
| SUBTOTAL   | 1 1     |                    | VIR              | 7N<br>-(007)9       |      |       |
| SEVERITY-COUNT                                     | 1 5     |                    | VIR              | 7N<br>-(007)9       |      |       |
| SID-SELECT   | 1 1     | SID<br>SELECT      | VIR              | 1X<br>X(001)        |      |       |
| SID  | 1 10    | SYSTEM<br>ID       | VIR              | 12X<br>XXXXXXXXXXXX |      |       |

Figure 7-2. NPBSEERR File

(Continued)

(Continued)

STRUCTURE REPORT OF  
DATABASE NPBDBS  
08/12/88

RECORD: NPASER      TYPE: EXTERNAL      FILE(S): NPBSEERR  
RECORD LENGTH: 1034      ORG: S      RT: Z      NUM: IPF

PH1: DEVICE INTERFACE  
PH2: SOFTWARE ERRORS

| FIELD NAME/<br>SYNONYM | LEV | OCC | COLUMN<br>HEADINGS | COL POS/<br>TYPE | FORMAT/<br>PICTURE  | REQ? |
|------------------------|-----|-----|--------------------|------------------|---------------------|------|
| LOGID-SELECT           | 1   | 1   | LOGID<br>SELECT    | VIR              | 1X<br>X(001)        |      |
| ID                     | 1   | 10  | LOG<br>IDS         | VIR              | 5X<br>XXXXX         |      |
| LOGID-EXCLUDE          | 1   | 1   | LOGID<br>EXCLUDE   | VIR              | 1X<br>X(001)        |      |
| EID                    | 1   | 10  | EX LOG<br>IDS      | VIR              | 5X<br>XXXXX         |      |
| SEV                    | 1   | 5   | SEVERITY<br>LEVELS | VIR              | 1X<br>X(001)        |      |
| SEV-NAME               | 1   | 5   | SEVERITY<br>NAMES  | VIR              | 12X<br>XXXXXXXXXXXX |      |
| FILL1                  | 1   | 1   | FILLER<br>ONE      | VIR              | 1X<br>X(001)        |      |
| FILL2                  | 1   | 1   | FILLER<br>TWO      | VIR              | 1X<br>X(001)        |      |
| FILL3                  | 1   | 1   | FILLER<br>THREE    | VIR              | 1X<br>X(001)        |      |
| FILL4                  | 1   | 1   | FILLER<br>FOUR     | VIR              | 1X<br>X(001)        |      |

Figure 7-2. NPBSEERR File

## Step 2

The next step is to define this report based on the database definition. The following monitor commands are used to initiate the IPF2 report session.

```
/DATABASE IS NPBDBS
/VIEW IS NPASER
/REPORT
```

Next, the user is prompted to supply the commands necessary to produce the report. The following produces the customized report output as shown in figure 7-3.

```
***** COMPONENT NAME: SFTWRP1 *****
*
*   PURPOSE:
*
*   THIS PROCEDURE WILL GENERATE A SOFTWARE ERROR REPORT SORTED BY SYSTEM
*   NAME, DATE, AND TIME.
*
*   DESIGN:
*
*   EACH EVENT REPORTED TO THE LOG FILE IS LISTED ON THE REPORT.
*   THE DATE, TIME, SYSTEM NAME, ERROR CODE, SEVERITY AND ERROR MESSAGE
*   ARE LISTED.
*
*****
SET MARGINS 1,90
SET TERMINAL PRINTER.
SET PAGE-SIZE 60.
SUPPRESS COLUMN HEADINGS.

PAGE-HEADING 1 TAB 5 "NETWORK PERFORMANCE ANALYZER", TAB 66 "RUN DATE: ",
  SPACE 0 DATE.
PAGE-HEADING 2 TAB 5 "VERSION 0123",
  TAB 55 START-DATE, SPACE 1 START-TIME,
  SPACE 1 "-", SPACE 1 END-DATE, SPACE 1 END-TIME.
PAGE-HEADING 3 TAB 5 "CUSTOM REPORT",
  TAB 64 "REPORT DAY: ", SPACE 0 STAT-YEAR, SPACE 0 STAT-MONTH,
  SPACE 0 STAT-DAY.
PAGE-HEADING 5 TAB 26 " CDCNET SOFTWARE MESSAGES".
PAGE-HEADING 6 TAB 28 "SORTED BY DATE AND TIME".
PAGE-HEADING 8 TAB 5 " DATE", TAB 17 "TIME", TAB 26 " SYSTEM NAME ",
  TAB 58 "LOG ID", TAB 65 "SEVERITY".
PAGE-HEADING 9 TAB 5 "=====", TAB 14 "=====",
  TAB 26 "=====",
  TAB 58 "=====", TAB 65 "=====".

PROMPT "ENTER STARTING DATE FOR REPORT (YYMMDD):" FOR START-DATE.
PROMPT "ENTER STARTING TIME FOR REPORT (HHMM):" FOR START-TIME.
PROMPT "ENTER ENDING DATE FOR REPORT (YYMMDD):" FOR END-DATE.
PROMPT "ENTER ENDING TIME FOR REPORT (HHMM):" FOR END-TIME.
PROMPT "ENTER DI NUMBER FOR REPORT (HHHHHHHHHHH):" FOR DI-NO.

SELECT (((STAT-DATE > START-DATE) AND (STAT-DATE < END-DATE)) OR
  ((STAT-DATE = START-DATE) AND (STAT-TMX >= START-TIME) AND
  (START-DATE <> END-DATE)) OR
```

```

      ((STAT-DATE = END-DATE) AND (STAT-TMX <= END-TIME) AND
      (START-DATE <> END-DATE)) OR
      ((START-DATE = END-DATE) AND (STAT-TMX >= START-TIME) AND
      (STAT-TMX <= END-TIME) AND (STAT-DATE = START-DATE))) AND
      ((DI-NO = DI-NUMBER) OR (DI-NO = "080025000000")) AND
      ((SEVERITY = 4) OR (SEVERITY = 5)).

```

SORT ON SYSTEM-TITLE, STAT-DATE, STAT-TIME.

SCROLL EXPLANATION 79,12.

LOOKUP SEVERITY-NAME FROM SEVERITY

```

      AS "INFORMATIVE " FOR "1"
      AS "  WARNING   " FOR "2"
      AS "   ERROR    " FOR "3"
      AS "   FATAL    " FOR "4"
      AS "CATASTROPHIC" FOR "5".

```

BREAK ON BREAK-IND.

COMPUTE BREAK-IND = LAST BREAK-IND + 1.

IF CONT-IND <> "00"

MOVE LAST BREAK-IND TO BREAK-IND.

PRINT 1 TAB 5 EXPLANATION.

BREAK-HEADING BREAK-IND 1 TAB 5 STAT-YEAR,

```

      TAB 8 STAT-MONTH,
      TAB 11 STAT-DAY,
      TAB 14 STAT-HOUR, SPACE 0 " . ",
      TAB 17 STAT-MIN,
      TAB 20 STAT-SEC,
      TAB 26 SYSTEM-TITLE,
      TAB 58 LOG-ID,
      TAB 65 SEVERITY-NAME.

```

GO.

When you enter GO, IPF2 generates the report; it then returns you to the REPORT subsystem.



### Step 3

The IPF2 SAVE command may be used to save the report program for future execution.

#### NOTE

The NPA database to be reported on must be a permanent file (direct on NOS) resident in the catalog belonging to the user generating the report. This is a standard IPF2 database residency restriction.

Figure 7-3 provides an example of the report generated with the custom report processor.

|  |             |                |                               |              |
|--|-------------|----------------|-------------------------------|--------------|
| NETWORK PERFORMANCE ANALYZER                           |             |                | RUN DATE: 8/18/88             |              |
| VERSION 0123   |             |                | 00/01/01 0000 - 99/21/31 2400 |              |
| CUSTOM REPORT  |             |                | REPORT DAY: 88/02/15          |              |
| CDCNET SOFTWARE MESSAGES                               |             |                |                               |              |
| SORTED BY DATE AND TIME                                |             |                |                               |              |
| DATE   | TIME        | SYSTEM NAME    | LOG ID                        | SEVERITY     |
| -----  | -----       | -----          | -----                         | -----        |
| 88/02/15   | 10.20.10711 | AHP_TDI_3004F0 | 1228                          | CATASTROPHIC |
| --CATASTROPHIC-- DI RESET INDICATION. RESET CODE: 0018 |             |                |                               |              |
| REASON: TASK ERROR WITH NO RECOVERY PROCEDURE          |             |                |                               |              |

Figure 7-3. Customized Software Error Message Report

## Creating a Customized NPA Summary Accounting Statistics Report Example

The NPA CRECAR command does not generate a Summary Accounting Statistics report. To create this report, you must use the IPF2 database files. The following example outlines this procedure.

### Step 1

The first step is to produce a listing of the IPF2 NPBSUMM database fields (figure 7-4) contained in the NPA database (NPBDBS). To generate this listing, follow the NOS or NOS/VE customized report example sequence for generating the NPBSERR database field listing described earlier in this chapter.

The following connection statistics are accumulated in the database file NPBSUMM:

- Terminal Support (log messages 617-620, 1538)
- Telnet TIP (log messages 1462-1466)
- X.25 Terminal Gateway (log messages 38, 39)
- X.25 Gateway (log messages 1160, 1161)
- Passthrough (log messages 235, 236, 239, 240)
- Device Outcall (log messages 233,234, 237, 238)

A record is generated for each log message. However some fields in the record are not appropriate for some log messages. Inappropriate fields are set to 0, if numeric, or blank, if alphanumeric.

Figure 7-5 shows the data fields generated for the log messages.

| STRUCTURE REPORT OF<br>DATABASE NPBDDBS<br>3/09/90 |     |                |                    |                  |                    |      |
|--|-----|----------------|--------------------|------------------|--------------------|------|
| RECORD: NPASUM                                     |     | TYPE: EXTERNAL |                    | FILE: NPBSUMM    |                    |      |
| RECORD LENGTH: 828                                 |     | ORG: S         | RT: V              | NUM: IPF         |                    |      |
| PH1: SUMMARY ACCOUNTING                            |     |                |                    |                  |                    |      |
| PH2: STATISTICS                                    |     |                |                    |                  |                    |      |
| -----  |     |                |                    |                  |                    |      |
| FIELD NAME/<br>SYNONYM                             | LEV | OCC            | COLUMN<br>HEADINGS | COL POS/<br>TYPE | FORMAT/<br>PICTURE | REQ? |
| -----  |     |                |                    |                  |                    |      |
| KEY-FIELD  |     |                | KEY                | 1                | 35X                |      |
|  | 1   | 1              | FIELD              | KEY              | X(035)             |      |
| STAT-DATE  |     |                | DATE               | 1                | 6X                 |      |
|  | 2   | 1              |                    |                  | XX/XX/XX           |      |
| STAT-YEAR  |     |                | YEAR               | 1                | 2N                 |      |
|  | 3   | 1              |                    |                  | 99/                |      |
| STAT-MONTH   |     |                | MONTH              | 3                | 2N                 |      |
|  | 3   | 1              |                    |                  | 99/                |      |
| STAT-DAY   |     |                | DAY                | 5                | 2N                 |      |
|  | 3   | 1              |                    |                  | 99                 |      |
| STAT-TIME  |     |                | TIME               | 7                | 9X                 |      |
|  | 2   | 1              |                    |                  | XX/XX/XXXXX        |      |
| STAT-TMX   |     |                | TIME               | 7                | 4X                 |      |
|  | 3   | 1              |                    |                  | XXXX               |      |
| STAT-HOUR  |     |                | HOUR               | 7                | 2N                 |      |
|  | 4   | 1              |                    |                  | 99.                |      |
| STAT-MIN   |     |                | MINUTE             | 9                | 2N                 |      |
|  | 4   | 1              |                    |                  | 99.                |      |
| STAT-SEC   |     |                | SECONDS            | 11               | 5N                 |      |
|  | 3   | 1              |                    |                  | 99999              |      |
| NETWORK-ID   |     |                | NETWORK            | 16               | 8X                 |      |
|  | 2   | 1              | ID                 |                  | X(008)             |      |

Figure 7-4. NPBSUMM File

(Continued)

(Continued)

| STRUCTURE REPORT OF<br>DATABASE NPBDBS<br>3/09/90 |     |                |                          |                  |                    |      |
|---|-----|----------------|--------------------------|------------------|--------------------|------|
| RECORD: NPASUM                                    |     | TYPE: EXTERNAL |                          | FILE: NPBSUMM    |                    |      |
| RECORD LENGTH: 828                                |     | ORG: S RT: V   |                          | NUM: IPF         |                    |      |
| PH1: SUMMARY ACCOUNTING                           |     |                |                          |                  |                    |      |
| PH2: STATISTICS                                   |     |                |                          |                  |                    |      |
| -----   |     | -----          |                          | -----            |                    | ---- |
| FIELD NAME/<br>SYNONYM                            | LEV | OCC            | COLUMN<br>HEADINGS       | COL POS/<br>TYPE | FORMAT/<br>PICTURE | REQ? |
| -----   |     | -----          |                          | -----            |                    | ---- |
| DI-NUMBER   | 2   | 1              | DI<br>NUMBER             | 24               | 12X<br>X(012)      |      |
| SYSTEM-TITLE                                      | 1   | 1              | SYSTEM<br>TITLE          | 36               | 31X<br>X(031)      |      |
| LOG-TYPE  | 1   | 1              | LOG PDU<br>TYPE          | 67               | 4X<br>X(004)       |      |
| USER-ID   | 1   | 1              | USER<br>ID               | 71               | 31X<br>X(031)      |      |
| FAMILY-DOMAIN                                     | 1   | 1              | FAMILY OR<br>DOMAIN NAME | 102              | 31X<br>X(031)      |      |
| APPLICATION-ID                                    | 1   | 1              | APPLICATION<br>ID        | 133              | 31X<br>X(031)      |      |
| CHARS-SENT  | 1   | 1              | CHARACTERS<br>SENT       | 164              | 10N<br>ZZZZZZZZZ9  |      |
| CHARS-RECV  | 1   | 1              | CHARACTERS<br>RECEIVED   | 174              | 10N<br>ZZZZZZZZZ9  |      |
| BLOCKS-SENT                                       | 1   | 1              | BLOCKS<br>SENT           | 184              | 10N<br>ZZZZZZZZZ9  |      |
| BLOCKS-RECV                                       | 1   | 1              | BLOCKS<br>RECEIVED       | 194              | 10N<br>ZZZZZZZZZ9  |      |
| PROCS-EXEC  | 1   | 1              | PROCEDURES<br>EXECUTED   | 204              | 5N<br>ZZZZ9        |      |

Figure 7-4. NPBSUMM File

(Continued)

(Continued)

```

STRUCTURE REPORT OF
DATABASE NPBDDBS
3/09/90

```

|                    |                |               |
|--------------------|----------------|---------------|
| RECORD: NPASUM     | TYPE: EXTERNAL | FILE: NPBSUMM |
| RECORD LENGTH: 828 | ORG: S RT: V   | NUM: IPF      |

PH1: SUMMARY ACCOUNTING  
PH2: STATISTICS

| FIELD NAME/<br>SYNONYM | LEV OCC | COLUMN<br>HEADINGS       | COL POS/<br>TYPE | FORMAT/<br>PICTURE | REQ? |
|------------------------|---------|--------------------------|------------------|--------------------|------|
| CONNECTION-LENGTH      | 1 1     | CONNECTION<br>LENGTH     | 209              | 10N<br>ZZZZZZZZZ9  |      |
| CLUSTER-DEVICE         | 1 1     | CLUSTER OR<br>DEVICE     | 219              | 7X<br>X(007)       |      |
| DEVICE-NAME            | 1 1     | DEVICE<br>NAME           | 226              | 31X<br>X(031)      |      |
| DEVICE-TYPE            | 1 1     | DEVICE<br>TYPE           | 257              | 3X<br>X(003)       |      |
| TIP-NAME               | 1 1     | TIP<br>NAME              | 260              | 31X<br>X(031)      |      |
| TERMINAL-PROTOCOL      | 1 1     | TERMINAL<br>PROTOCOL     | 291              | 10X<br>X(010)      |      |
| SOURCE-OR-CLIENT-ADD   | 1 1     | SOURCE-CLIENT<br>ADDRESS | 301              | 24X<br>X(024)      |      |
| DEST-OR-SERVER-ADD     | 1 1     | DEST-SERVER<br>ADDRESS   | 325              | 60X<br>X(060)      |      |
| TERMINATION-REASON     | 1 1     | TERMINATION<br>REASON    | 385              | 31X<br>X(031)      |      |
| LINE-NAME              | 1 1     | LINE<br>NAME             | 416              | 31X<br>X(031)      |      |
| LINE-SPEED             | 1 1     | LINE<br>SPEED            | 447              | 6N<br>ZZZZZ9       |      |

Figure 7-4. NPBSUMM File

(Continued)

(Continued)

```

STRUCTURE REPORT OF
DATABASE NPBDBS
3/09/90

```

```

RECORD: NPASUM          TYPE: EXTERNAL          FILE: NPBSUMM
RECORD LENGTH: 828      ORG: S      RT: V      NUM: IPF

```

```

PH1: SUMMARY ACCOUNTING
PH2: STATISTICS

```

| FIELD NAME/<br>SYNONYM | LEV | OCC | COLUMN<br>HEADINGS | COL POS/<br>TYPE | FORMAT/<br>PICTURE | REQ? |
|------------------------|-----|-----|--------------------|------------------|--------------------|------|
| LINE-SU7-TYPE          |     |     | LINE SUB<br>TYPE   | 453              | 31X<br>X(031)      |      |
|                        | 1   | 1   |                    |                  |                    |      |
| LINE-TYPE              |     |     | LINE<br>TYPE       | 484              | 3X<br>X(003)       |      |
|                        | 1   | 1   |                    |                  |                    |      |
| LIM-NUMBER             |     |     | LIM<br>NUMBER      | 487              | 1N<br>9            |      |
|                        | 1   | 1   |                    |                  |                    |      |
| PORT-NUMBER            |     |     | PORT<br>NUMBER     | 488              | 1N<br>9            |      |
|                        | 1   | 1   |                    |                  |                    |      |
| CLUSTER-ADDRESS        |     |     | CLUSTER<br>ADDRESS | 489              | 2N<br>Z9           |      |
|                        | 1   | 1   |                    |                  |                    |      |
| DEVICE-ADDRESS         |     |     | DEVICE<br>ADDRESS  | 491              | 2N<br>Z9           |      |
|                        | 1   | 1   |                    |                  |                    |      |
| TRUNK-NAME             |     |     | TRUNK<br>NAME      | 493              | 31X<br>X(031)      |      |
|                        | 1   | 1   |                    |                  |                    |      |
| TRUNK-LIM-NUMBER       |     |     | LIM<br>NUMBER      | 524              | 1N<br>9            |      |
|                        | 1   | 1   |                    |                  |                    |      |
| TRUNK-PORT-NUMBER      |     |     | PORT<br>NUMBER     | 525              | 1N<br>9            |      |
|                        | 1   | 1   |                    |                  |                    |      |
| TERMINAL-SPEED         |     |     | TERMINAL<br>SPEED  | 526              | 6N<br>ZZZZZ9       |      |
|                        | 1   | 1   |                    |                  |                    |      |
| PDN-NAME               |     |     | PDN<br>NAME        | 532              | 31X<br>X(031)      |      |
|                        | 1   | 1   |                    |                  |                    |      |

Figure 7-4. NPBSUMM File

(Continued)

(Continued)

```

STRUCTURE REPORT OF
DATABASE NPDBBS
3/09/90

```

|                         |                |               |
|-------------------------|----------------|---------------|
| RECORD: NPASUM          | TYPE: EXTERNAL | FILE: NPBSUMM |
| RECORD LENGTH: 828      | ORG: S RT: V   | NUM: IPF      |
| PH1: SUMMARY ACCOUNTING |                |               |
| PH2: STATISTICS         |                |               |

| FIELD NAME/<br>SYNONYM | LEV | OCC | COLUMN<br>HEADINGS                | COL POS/<br>TYPE | FORMAT/<br>PICTURE | REQ? |
|------------------------|-----|-----|-----------------------------------|------------------|--------------------|------|
| DTE-ADDRESS            | 1   | 1   | DTE<br>ADDRESS                    | 563              | 15X<br>X(015)      |      |
| CIRCUIT-TYPE           | 1   | 1   | CIRCUIT<br>TYPE                   | 578              | 3X<br>X(003)       |      |
| CHANNEL-NUMBER         | 1   | 1   | CHANNEL<br>NUMBER                 | 581              | 6N<br>ZZZZZ9       |      |
| SEND-PACK-LEN          | 1   | 1   | SENDING PACKET<br>LENGTH-PWR OF 2 | 587              | 3N<br>ZZ9          |      |
| RECV-PACK-LEN          | 1   | 1   | RECV PACKET<br>LENGTH-PWR OF 2    | 590              | 3N<br>ZZ9          |      |
| SEND-WINDOW-SIZE       | 1   | 1   | SENDING<br>WINDOW SIZE            | 593              | 3N<br>ZZ9          |      |
| RECV-WINDOW-SIZE       | 1   | 1   | RECEIVING<br>WINDOW SIZE          | 596              | 3N<br>ZZ9          |      |
| CALLING-CLASS          | 1   | 1   | CALLING<br>CLASS                  | 599              | 6X<br>X(006)       |      |
| CALLED-CLASS           | 1   | 1   | CALLED<br>CLASS                   | 605              | 6X<br>X(006)       |      |
| INITIATOR              | 1   | 1   | INITIATOR                         | 611              | 6X<br>X(006)       |      |
| CHARGED-SYSTEM         | 1   | 1   | CHARGED<br>SYSTEM                 | 617              | 3X<br>X(003)       |      |

Figure 7-4. NPBSUMM File

(Continued)

(Continued)

| STRUCTURE REPORT OF<br>DATABASE NPBDDBS<br>3/09/90 |  |                |       |                                   |                  |                    |      |
|--|--|----------------|-------|-----------------------------------|------------------|--------------------|------|
| RECORD: NPASUM                                     |  | TYPE: EXTERNAL |       | FILE: NPBSUMM                     |                  |                    |      |
| RECORD LENGTH: 828                                 |  | ORG: S         | RT: V | NUM: IPF                          |                  |                    |      |
| PH1: SUMMARY ACCOUNTING                            |  |                |       |                                   |                  |                    |      |
| PH2: STATISTICS                                    |  |                |       |                                   |                  |                    |      |
| -----  |  |                |       |                                   |                  |                    |      |
| FIELD NAME/<br>SYNONYM                             |  | LEV            | OCC   | COLUMN<br>HEADINGS                | COL POS/<br>TYPE | FORMAT/<br>PICTURE | REQ? |
| -----  |  |                |       |                                   |                  |                    |      |
| GATEWAY-NAME                                       |  | 1              | 1     | GATEWAY<br>NAME                   | 620              | 31X<br>X(031)      |      |
| DESTINATION-NAME                                   |  | 1              | 1     | DESTINATION<br>NAME               | 651              | 31X<br>X(031)      |      |
| SERVER-NAME  |  | 1              | 1     | SERVER<br>NAME                    | 682              | 31X<br>X(031)      |      |
| CHAR-SENT-APPL                                     |  | 1              | 1     | CHARACTERS SENT<br>TO APPLICATION | 713              | 10N<br>ZZZZZZZZZ9  |      |
| PACKETS-SENT                                       |  | 1              | 1     | PACKETS<br>SENT                   | 723              | 10N<br>ZZZZZZZZZ9  |      |
| SEGMENTS-SENT                                      |  | 1              | 1     | SEGMENTS<br>SENT                  | 733              | 10N<br>ZZZZZZZZZ9  |      |
| CHAR-RECV-APPL                                     |  | 1              | 1     | CHARACTERS RECV<br>FROM APPL      | 743              | 10N<br>ZZZZZZZZZ9  |      |
| PACKETS-RECV                                       |  | 1              | 1     | PACKETS<br>RECEIVED               | 753              | 10N<br>ZZZZZZZZZ9  |      |
| SEGMENTS-RECV                                      |  | 1              | 1     | SEGMENTS<br>RECEIVED              | 763              | 10N<br>ZZZZZZZZZ9  |      |
| LOCAL-IP-ADDRESS-1                                 |  | 1              | 1     | LOCAL IP<br>ADDRESS 1             | 773              | 3N<br>ZZ9          |      |
| LOCAL-IP-ADDRESS-2                                 |  | 1              | 1     | LOCAL IP<br>ADDRESS 2             | 776              | 3N<br>ZZ9          |      |

Figure 7-4. NPBSUMM File

(Continued)



(Continued)

| STRUCTURE REPORT OF<br>DATABASE NPDBBS<br>3/09/90 |         |                    |                  |                    |       |
|---|---------|--------------------|------------------|--------------------|-------|
| RECORD: NPASUM                                    |         | TYPE: EXTERNAL     |                  | FILE: NPBSUMM      |       |
| RECORD LENGTH: 828                                |         | ORG: S             | RT: V            | NUM: IPF           |       |
| PH1: SUMMARY ACCOUNTING                           |         |                    |                  |                    |       |
| PH2: STATISTICS                                   |         |                    |                  |                    |       |
| <br>  |         |                    |                  |                    |       |
| -----   |         | -----              | -----            | -----              | ----  |
| FIELD NAME/<br>SYNONYM                            | LEV OCC | COLUMN<br>HEADINGS | COL POS/<br>TYPE | FORMAT/<br>PICTURE | REQ?  |
| -----   |         | -----              | -----            | -----              | ----- |
| LOCAL-IP-ADDRESS-3                                |         | LOCAL IP           | 779              | 3N                 |       |
|   | 1 1     | ADDRESS 3          |                  | ZZ9                |       |
| LOCAL-IP-ADDRESS-4                                |         | LOCAL IP           | 782              | 3N                 |       |
|   | 1 1     | ADDRESS 4          |                  | ZZ9                |       |
| LOCAL-PORT  |         | LOCAL              | 785              | 5N                 |       |
|   | 1 1     | PORT               |                  | ZZZZ9              |       |
| REMOTE-IP-ADDRESS-1                               |         | REMOTE IP          | 790              | 3N                 |       |
|   | 1 1     | ADDRESS 1          |                  | ZZ9                |       |
| REMOTE-IP-ADDRESS-2                               |         | REMOTE IP          | 793              | 3N                 |       |
|   | 1 1     | ADDRESS 2          |                  | ZZ9                |       |
| REMOTE-IP-ADDRESS-3                               |         | REMOTE IP          | 796              | 3N                 |       |
|   | 1 1     | ADDRESS 3          |                  | ZZ9                |       |
| REMOTE-IP-ADDRESS-4                               |         | REMOTE IP          | 799              | 3N                 |       |
|   | 1 1     | ADDRESS 4          |                  | ZZ9                |       |
| REMOTE-PORT                                       |         | REMOTE             | 802              | 5N                 |       |
|   | 1 1     | PORT               |                  | ZZZZ9              |       |
| CLIENT-LIM  |         | CLIENT             | 807              | 1N                 |       |
|   | 1 1     | LIM                |                  | 9                  |       |
| CLIENT-PORT                                       |         | CLIENT             | 808              | 1N                 |       |
|   | 1 1     | PORT               |                  | 9                  |       |
| SERVER-LIM  |         | SERVER             | 809              | 1N                 |       |
|   | 1 1     | LIM                |                  | 9                  |       |

Figure 7-4. NPBSUMM File

(Continued)

(Continued)

| STRUCTURE REPORT OF<br>DATABASE NPBD8S<br>3/09/90 |     |                |                       |                  |                    |      |
|---|-----|----------------|-----------------------|------------------|--------------------|------|
| RECORD: NPASUM                                    |     | TYPE: EXTERNAL |                       | FILE: NPBSUMM    |                    |      |
| RECORD LENGTH: 828                                |     | ORG: S         | RT: V                 | NUM: IPF         |                    |      |
| PH1: SUMMARY ACCOUNTING                           |     |                |                       |                  |                    |      |
| PH2: STATISTICS                                   |     |                |                       |                  |                    |      |
| -----   |     |                |                       |                  |                    |      |
| FIELD NAME/<br>SYNONYM                            | LEV | OCC            | COLUMN<br>HEADINGS    | COL POS/<br>TYPE | FORMAT/<br>PICTURE | REQ? |
| -----   |     |                |                       |                  |                    |      |
| SERVER-PORT                                       | 1   | 1              | SERVER<br>PORT        | 810              | 1N<br>9            |      |
| DIAL-NUMBER                                       | 1   | 1              | NUMBER TO<br>DIAL     | 811              | 15X<br>X(015)      |      |
| DIALING-STATUS                                    | 1   | 1              | DIALING<br>STATUS     | 826              | 3X<br>X(003)       |      |
| PRINT-FLAG-VIR                                    | 1   | 1              | PRINT<br>FLAG         | VIR              | 70X<br>X(D70)      |      |
| VIR-STAT-DATE                                     | 2   | 1              | STATISTICS<br>DATE    | VIR              | 6X<br>X(006)       |      |
| VIR-STAT-HOUR                                     | 2   | 1              | STATISTICS<br>HOUR    | VIR              | 2N<br>Z9           |      |
| VIR-USER-ID                                       | 2   | 1              | USER<br>ID            | VIR              | 31X<br>X(031)      |      |
| VIR-FAMILY  | 2   | 1              | FAMILY<br>NAME        | VIR              | 31X<br>X(031)      |      |
| LOAD-HOUR-CH                                      | 1   | 1              | LOAD<br>HOUR          | VIR              | 4X<br>X(004)       |      |
| LOAD-HOUR   | 2   | 1              | LOAD<br>HOUR          | VIR              | 4N<br>ZZZ9         |      |
| SUM-CON-VIR                                       | 1   | 1              | SUM OF<br>CONNECTIONS | VIR              | 10N<br>ZZZZZZZZZ9  |      |

Figure 7-4. NPBSUMM File

(Continued)

(Continued)

| STRUCTURE REPORT OF<br>DATABASE NPBDBS<br>3/09/90 |     |                |                    |                  |                    |
|---|-----|----------------|--------------------|------------------|--------------------|
| RECORD: NPASUM                                    |     | TYPE: EXTERNAL |                    | FILE: NPBSUMM    |                    |
| RECORD LENGTH: 828                                |     | ORG: S         | RT: V              | NUM: IPF         |                    |
| PH1: SUMMARY ACCOUNTING                           |     |                |                    |                  |                    |
| PH2: STATISTICS                                   |     |                |                    |                  |                    |
| -----   |     |                |                    |                  |                    |
| FIELD NAME/<br>SYNONYM                            | LEV | OCC            | COLUMN<br>HEADINGS | COL POS/<br>TYPE | FORMAT/<br>PICTURE |
| -----   |     |                |                    |                  |                    |
| SUM-PROCS-VIR                                     |     |                | SUM OF             |                  | 10N                |
|   | 1   | 1              | PROCEDURES         | VIR              | ZZZZZZZZZ9         |
| SERV-CON-VIR                                      |     |                | SERVICE            |                  | 10N                |
|   | 1   | 1              | CONNECT TIME       | VIR              | ZZZZZZZZZ9         |
| NW-CON-VIR  |     |                | NETWORK            |                  | 10N                |
|   | 1   | 1              | CONNECT TIME       | VIR              | ZZZZZZZZZ9         |
| RECV-CH-VIR                                       |     |                | CHARACTERS         |                  | 10N                |
|   | 1   | 1              | RECEIVED           | VIR              | ZZZZZZZZZ9         |
| TRANS-CH-VIR                                      |     |                | CHARACTERS         |                  | 10N                |
|   | 1   | 1              | TRANSMITTED        | VIR              | ZZZZZZZZZ9         |
| RECV-BL-VIR                                       |     |                | BLOCKS             |                  | 10N                |
|   | 1   | 1              | RECEIVED           | VIR              | ZZZZZZZZZ9         |
| TRANS-BL-VIR                                      |     |                | BLOCKS             |                  | 10N                |
|   | 1   | 1              | TRANSMITTED        | VIR              | ZZZZZZZZZ9         |
| RECV-CH-APPL-VIR                                  |     |                | CHARACTERS         |                  | 10N                |
|   | 1   | 1              | RECV-APPL          | VIR              | ZZZZZZZZZ9         |
| TRANS-CH-APPL-VIR                                 |     |                | CHARACTERS         |                  | 10N                |
|   | 1   | 1              | TRANS-APPL         | VIR              | ZZZZZZZZZ9         |
| RECV-PACKETS-VIR                                  |     |                | PACKETS            |                  | 10N                |
|   | 1   | 1              | RECEIVED           | VIR              | ZZZZZZZZZ9         |
| TRANS-PACKETS-VIR                                 |     |                | PACKETS            |                  | 10N                |
|   | 1   | 1              | TRANSMITTED        | VIR              | ZZZZZZZZZ9         |

Figure 7-4. NPBSUMM File

(Continued)



## 7-24 CDCNET Network Operations and Analysis

(Continued)

|                      |           | SUMMARY ACCOUNTING DATABASE (NPBSUMM) |   |   |   |                                |   |   |   |                  |   |   |   |              |   |   |   | TELNET TIP    |   |   |   |
|----------------------|-----------|---------------------------------------|---|---|---|--------------------------------|---|---|---|------------------|---|---|---|--------------|---|---|---|---------------|---|---|---|
|                      |           | X.25 Terminal Gateway                 |   |   |   | Passthrough and Device Outcall |   |   |   | Terminal Support |   |   |   | X.25 Gateway |   |   |   | X.25 Asynctip |   |   |   |
| * LOG MSG. DATA * *  | FIELD * * | 3                                     | 3 | 8 | 9 | 2                              | 3 | 3 | 3 | 2                | 2 | 2 | 2 | 2            | 2 | 2 | 2 | 1             | 1 | 1 | 1 |
| DEVC-NAME            |           |                                       |   |   |   |                                |   |   |   |                  |   |   |   |              |   |   |   |               |   |   |   |
| DEVC-TYPE            |           |                                       |   |   |   |                                |   |   |   |                  |   |   |   |              |   |   |   |               |   |   |   |
| TIP-NAME             |           |                                       |   |   |   |                                |   |   |   |                  |   |   |   |              |   |   |   |               |   |   |   |
| TERMINAL-PROTOCOL    |           |                                       |   |   |   |                                |   |   |   |                  |   |   |   |              |   |   |   |               |   |   |   |
| SOURCE-DR-CLIENT-ADD |           |                                       |   |   |   |                                |   |   |   |                  |   |   |   |              |   |   |   |               |   |   |   |
| DEST-DR-SERVER-ADD   |           |                                       |   |   |   |                                |   |   |   |                  |   |   |   |              |   |   |   |               |   |   |   |
| TERMINATION-REASON   |           |                                       |   |   |   |                                |   |   |   |                  |   |   |   |              |   |   |   |               |   |   |   |
| LINE-NAME            |           |                                       |   |   |   |                                |   |   |   |                  |   |   |   |              |   |   |   |               |   |   |   |
| LINE-SPEED           |           |                                       |   |   |   |                                |   |   |   |                  |   |   |   |              |   |   |   |               |   |   |   |
| LINE-SUB-TYPE        |           |                                       |   |   |   |                                |   |   |   |                  |   |   |   |              |   |   |   |               |   |   |   |
| LINE-TYPE            |           |                                       |   |   |   |                                |   |   |   |                  |   |   |   |              |   |   |   |               |   |   |   |
| LIN-NUMBER           |           |                                       |   |   |   |                                |   |   |   |                  |   |   |   |              |   |   |   |               |   |   |   |
| PORT-NUMBER          |           |                                       |   |   |   |                                |   |   |   |                  |   |   |   |              |   |   |   |               |   |   |   |

Figure 7-5. NPBSUMM Log Message/Data Field Associations

(Continued)

2. X represents data value supplied.

(Continued)

60

SUMMARY ACCOUNTING DATABASE (NPBSUMM)

| * LDG<br>DATA *<br>FIELD * | X.25<br>Terminal<br>Gateway | Passthrough<br>and<br>Device Outcall |   |   |   | Terminal<br>Support |   |   |   | X.25<br>Gateway |   |   |   | X.25<br>Asynctip |   |   |   | TELNET<br>TIP |   |   |   |   |   |   |   |
|----------------------------|-----------------------------|--------------------------------------|---|---|---|---------------------|---|---|---|-----------------|---|---|---|------------------|---|---|---|---------------|---|---|---|---|---|---|---|
|                            |                             | 2                                    | 3 | 8 | 9 | 2                   | 2 | 3 | 3 | 3               | 3 | 4 | 5 | 6                | 7 | 8 | 9 | 0             | 1 | 2 | 3 | 4 | 5 | 6 | 7 |
| CLUSTER-<br>ADDRESS        |                             |                                      |   |   |   |                     |   |   |   |                 |   |   |   |                  |   |   |   |               |   |   |   |   |   |   |   |
| DEVICE-<br>ADDRESS         |                             |                                      |   |   |   |                     |   |   |   |                 |   |   |   |                  |   |   |   |               |   |   |   |   |   |   |   |
| TRUNK-<br>NAME             |                             |                                      |   |   |   |                     |   |   |   |                 |   |   |   |                  |   |   |   |               |   |   |   |   |   |   |   |
| TRUNK-<br>LIM-<br>NUMBER   |                             |                                      |   |   |   |                     |   |   |   |                 |   |   |   |                  |   |   |   |               |   |   |   |   |   |   |   |
| TRUNK-<br>PORT-<br>NUMBER  |                             |                                      |   |   |   |                     |   |   |   |                 |   |   |   |                  |   |   |   |               |   |   |   |   |   |   |   |
| TERMINAL-<br>SPEED         |                             |                                      |   |   |   |                     |   |   |   |                 |   |   |   |                  |   |   |   |               |   |   |   |   |   |   |   |
| PDN-<br>NAME               |                             |                                      |   |   |   |                     |   |   |   |                 |   |   |   |                  |   |   |   |               |   |   |   |   |   |   |   |
| DTE-<br>ADDRESS            |                             |                                      |   |   |   |                     |   |   |   |                 |   |   |   |                  |   |   |   |               |   |   |   |   |   |   |   |
| CIRCUIT-<br>TYPE           |                             |                                      |   |   |   |                     |   |   |   |                 |   |   |   |                  |   |   |   |               |   |   |   |   |   |   |   |
| CHANNEL-<br>NUMBER         |                             |                                      |   |   |   |                     |   |   |   |                 |   |   |   |                  |   |   |   |               |   |   |   |   |   |   |   |
| SEND-<br>PACK-<br>LEN      |                             |                                      |   |   |   |                     |   |   |   |                 |   |   |   |                  |   |   |   |               |   |   |   |   |   |   |   |
| RCV-<br>PACK-<br>LEN       |                             |                                      |   |   |   |                     |   |   |   |                 |   |   |   |                  |   |   |   |               |   |   |   |   |   |   |   |
| SEND-<br>WINDOW-<br>SIZE   |                             |                                      |   |   |   |                     |   |   |   |                 |   |   |   |                  |   |   |   |               |   |   |   |   |   |   |   |

63

Figure 7-5. NPBSUMM Log Message/Data Field Associations

(Continued)

3. X represents data value supplied.

(Continued)

4

SUMMARY ACCOUNTING DATABASE (NPBSUMM)

X.25  
Terminal  
Gateway

Passthrough  
and  
Device Outcall

Terminal  
Support

X.25  
Gateway

X.25  
Asynctip

TELNET  
TIP

\* LOG  
DATA \*  
FIELD \*

\* LOG

DATA \*

FIELD \*

\* LOG

DATA \*

FIELD \*

\* LOG

DATA \*

FIELD \*

\* LOG

DATA \*

FIELD \*

\* LOG

DATA \*

FIELD \*

\* LOG

DATA \*

FIELD \*

\* LOG

DATA \*

FIELD \*

\* LOG

DATA \*

FIELD \*

\* LOG

DATA \*

FIELD \*

\* LOG

DATA \*

FIELD \*

\* LOG

DATA \*

FIELD \*

\* LOG

DATA \*

FIELD \*

\* LOG

DATA \*

FIELD \*

\* LOG

DATA \*

FIELD \*

\* LOG

DATA \*

FIELD \*

\* LOG

DATA \*

FIELD \*

\* LOG

DATA \*

FIELD \*

\* LOG

DATA \*

FIELD \*

\* LOG

DATA \*

FIELD \*

\* LOG

DATA \*

FIELD \*

Figure 7-5. NPBSUMM Log Message/Data Field Associations

(Continued)

4. X represents data value supplied.



60461520 H

## Step 2

The next step is to define this report based on the database definition. The following monitor commands are used to initiate the IPF2 report session.

```
/DATABASE IS NPBDBS
/VIEW IS NPASUM
/REPORT
```

Next, the user is prompted to supply the commands necessary to produce the report. The following produces the customized report output as shown in figure 7-6.

```
SET MARGINS 1,95
SET TERMINAL PRINTER.
SET PAGE-SIZE 62.
SUPPRESS COLUMN HEADINGS.
SUPPRESS DETAIL.
SUPPRESS TOTAL.
*
REPORT-HEADING 1 TAB 72 DATE.
REPORT-HEADING 14 TAB 32 "C D C N E T".
REPORT-HEADING 15 TAB 24 "NETWORK PERFORMANCE ANALYZER".
REPORT-HEADING 17 TAB 19 "TERMINAL SUPPORT ACCOUNTING STATISTICS".
REPORT-HEADING 18 TAB 24 "SORTED BY USER ID AND FAMILY".
REPORT-HEADING 20 TAB 17 "TIME PERIOD = ",
TAB 31 START-DATE,SPACE 1 START-TIME,
SPACE 1 "-",SPACE 1 END-DATE,SPACE 1 ENO-TIME.
*
PAGE-HEADING 1 TAB 71 "PAGE ", SPACE 0 PAGE-NUMBER.
PAGE-HEADING 2 TAB 1 " ".
PAGE-HEADING 3 TAB 21 "TERMINAL SUPPORT ACCOUNTING STATISTICS".
PAGE-HEADING 5 TAB 24 "USER ID = ", SPACE 0 USER-ID.
PAGE-HEADING 6 TAB 24 "FAMILY/DOMAIN = ",SPACE 0 FAMILY-DOMAIN.
*
PAGE-HEADING 8 TAB 4 "ENDING",
TAB 16 "NETWORK",
TAB 28 "NUMBER",
TAB 39 "NUMBER",
TAB 49 "SERVICE",
TAB 60 "RECEIVED",
TAB 70 "TRANSMITTD".
*
PAGE-HEADING 9 TAB 3 "DATE/TIME",
TAB 16 "CONNECT",
TAB 30 "OF",
TAB 41 "OF",
TAB 49 "CONNECT",
TAB 59 "CHARACTERS",
TAB 70 "CHARACTERS".
*
PAGE-HEADING 10 TAB 17 "TIME",
TAB 26 "PROCEDURES",
TAB 38 "CONNECTS",
TAB 50 "TIME",
TAB 61 "BLOCKS",
TAB 72 "BLOCKS".
```

```

*
PAGE-HEADING 11 TAB 1 "=====",
TAB 15 "=====",
TAB 26 "=====",
TAB 37 "=====",
TAB 48 "=====",
TAB 59 "=====",
TAB 70 "=====".
*
PROMPT "ENTER STARTING DATE FOR REPORT (YYMMDD):" FOR START-DATE.
PROMPT "ENTER STARTING TIME FOR REPORT (HHMM):" FOR START-TIME.
PROMPT "ENTER ENDING DATE FOR REPORT (YYMMDD):" FOR END-DATE.
PROMPT "ENTER ENDING TIME FOR REPORT (HHMM):" FOR END-TIME.
*
SELECT (((STAT-DATE > START-DATE) AND (STAT-DATE < END-DATE)) OR
((STAT-DATE = START-DATE) AND (STAT-TMX >= START-TIME) AND
(START-DATE <> END-DATE)) OR
((STAT-DATE = END-DATE) AND (STAT-TMX <= END-TIME) AND
(START-DATE <> END-DATE)) OR
((START-DATE = END-DATE) AND (STAT-TMX >= START-TIME) AND
(STAT-TMX <= END-TIME) AND (STAT-DATE = START-DATE))).
SELECT ((LOG-TYPE = "1538") OR (LOG-TYPE = "618 ") OR (LOG-TYPE = "619 ") OR
(LOG-TYPE = "620 ")).
*
SORT HERE ON USER-ID,FAMILY-DOMAIN,STAT-DATE,STAT-HOUR,STAT-MIN,STAT-SEC,NETWORK--
ID.
*
SELECT ((KEY-FIELD NOT= LAST KEY-FIELD) OR
(USER-ID NOT= LAST USER-ID) OR (FAMILY-DOMAIN NOT= LAST FAMILY-DOMAIN)).
*
BREAK ON PRINT-FLAG-VIR.
*
PAGE ON USER-ID,FAMILY-DOMAIN,STAT-DATE.
*
COMPUTE LOAD-HOUR = (STAT-HOUR + 1) * 100.
*
* THESE MOVES SET UP THE BREAK FIELD
*
MOVE STAT-DATE TO VIR-STAT-DATE.
MOVE STAT-HOUR TO VIR-STAT-HOUR.
MOVE USER-ID TO VIR-USER-ID.
MOVE FAMILY-DOMAIN TO VIR-FAMILY.
*
* ALWAYS CARRY FORWARD THE SUBTOTALS.
*
MOVE LAST NW-CON-VIR TO NW-CON-VIR.
MOVE LAST SERV-CON-VIR TO SERV-CON-VIR.
MOVE LAST SUM-CON-VIR TO SUM-CON-VIR.
MOVE LAST SUM-PROCS-VIR TO SUM-PROCS-VIR.
MOVE LAST RECV-CH-VIR TO RECV-CH-VIR.
MOVE LAST TRANS-CH-VIR TO TRANS-CH-VIR.
MOVE LAST RECV-BL-VIR TO RECV-BL-VIR.
MOVE LAST TRANS-BL-VIR TO TRANS-BL-VIR.
*
IF (PRINT-FLAG-VIR <> LAST PRINT-FLAG-VIR)
MOVE 0 TO SUM-CON-VIR.

```

```

IF (PRINT-FLAG-VIR <> LAST PRINT-FLAG-VIR)
MOVE 0 TO SUM-PROCS-VIR.
IF (PRINT-FLAG-VIR <> LAST PRINT-FLAG-VIR)
MOVE 0 TO NW-CON-VIR.
IF (PRINT-FLAG-VIR <> LAST PRINT-FLAG-VIR)
MOVE 0 TO SERV-CON-VIR.
IF (PRINT-FLAG-VIR <> LAST PRINT-FLAG-VIR)
MOVE 0 TO RECV-CH-VIR.
IF (PRINT-FLAG-VIR <> LAST PRINT-FLAG-VIR)
MOVE 0 TO TRANS-CH-VIR.
IF (PRINT-FLAG-VIR <> LAST PRINT-FLAG-VIR)
MOVE 0 TO RECV-BL-VIR.
IF (PRINT-FLAG-VIR <> LAST PRINT-FLAG-VIR)
MOVE 0 TO TRANS-BL-VIR.
*
* CALCULATIONS THAT ARE DEPENDENT ON A CONNECTION EVENT.
*
IF ((LOG-TYPE = "1538") OR (LOG-TYPE = "618 ")) AND
(PRINT-FLAG-VIR = LAST PRINT-FLAG-VIR)
COMPUTE SUM-CON-VIR = LAST SUM-CON-VIR + 1.
IF ((LOG-TYPE = "1538") OR (LOG-TYPE = "618 ")) AND
(PRINT-FLAG-VIR <> LAST PRINT-FLAG-VIR)
MOVE 1 TO SUM-CON-VIR.
*
* CALCULATIONS THAT ARE DEPENDENT ON A TERMINATION EVENT.
*
IF ((LOG-TYPE = "619 ") AND
(PRINT-FLAG-VIR = LAST PRINT-FLAG-VIR))
COMPUTE SUM-PROCS-VIR = LAST SUM-PROCS-VIR + PROCS-EXEC.
IF ((LOG-TYPE = "619 ") AND
(PRINT-FLAG-VIR <> LAST PRINT-FLAG-VIR))
MOVE PROCS-EXEC TO SUM-PROCS-VIR.
*
IF ((LOG-TYPE = "619 ") AND
(PRINT-FLAG-VIR = LAST PRINT-FLAG-VIR))
COMPUTE NW-CON-VIR = LAST NW-CON-VIR + CONNECTION-LENGTH.
IF ((LOG-TYPE = "619 ") AND
(PRINT-FLAG-VIR <> LAST PRINT-FLAG-VIR))
MOVE CONNECTION-LENGTH TO NW-CON-VIR.
*
IF ((LOG-TYPE = "620 ") AND
(PRINT-FLAG-VIR = LAST PRINT-FLAG-VIR))
COMPUTE SERV-CON-VIR = LAST SERV-CON-VIR + CONNECTION-LENGTH.
IF ((LOG-TYPE = "620 ") AND
(PRINT-FLAG-VIR <> LAST PRINT-FLAG-VIR))
MOVE CONNECTION-LENGTH TO SERV-CON-VIR.
*
IF ((LOG-TYPE = "619 ") OR (LOG-TYPE = "620 ")) AND
(PRINT-FLAG-VIR = LAST PRINT-FLAG-VIR)
COMPUTE RECV-CH-VIR = LAST RECV-CH-VIR + CHARS-RECV.
IF ((LOG-TYPE = "619 ") OR (LOG-TYPE = "620 ")) AND
(PRINT-FLAG-VIR <> LAST PRINT-FLAG-VIR)
MOVE CHARS-RECV TO RECV-CH-VIR.
*
IF ((LOG-TYPE = "619 ") OR (LOG-TYPE = "620 ")) AND
(PRINT-FLAG-VIR = LAST PRINT-FLAG-VIR)

```

```

COMPUTE TRANS-CH-VIR = LAST TRANS-CH-VIR + CHARS-SENT.
IF ((LOG-TYPE = "619 ") OR (LOG-TYPE = "620 ")) AND
(PRINT-FLAG-VIR <> LAST PRINT-FLAG-VIR)
MOVE CHARS-SENT TO TRANS-CH-VIR.
*
IF ((LOG-TYPE = "619 ") OR (LOG-TYPE = "620 ")) AND
(PRINT-FLAG-VIR = LAST PRINT-FLAG-VIR)
COMPUTE RECV-BL-VIR = LAST RECV-BL-VIR + BLOCKS-RECV.
IF ((LOG-TYPE = "619 ") OR (LOG-TYPE = "620 ")) AND
(PRINT-FLAG-VIR <> LAST PRINT-FLAG-VIR)
MOVE BLOCKS-RECV TO RECV-BL-VIR.
*
IF ((LOG-TYPE = "619 ") OR (LOG-TYPE = "620 ")) AND
(PRINT-FLAG-VIR = LAST PRINT-FLAG-VIR)
COMPUTE TRANS-BL-VIR = LAST TRANS-BL-VIR + BLOCKS-SENT.
IF ((LOG-TYPE = "619 ") OR (LOG-TYPE = "620 ")) AND
(PRINT-FLAG-VIR <> LAST PRINT-FLAG-VIR)
MOVE BLOCKS-SENT TO TRANS-BL-VIR.
*
* THESE SUBTOTALS ARE PRINTED AS THE MAIN INFORMATION IN THIS REPORT.
*
BREAK-FOOTING PRINT-FLAG-VIR 2 TAB 1 STAT-YEAR, SPACE 0 STAT-MONTH,
SPACE 0 STAT-DAY, SPACE 1 LOAD-HOUR,
TAB 15 NW-CON-VIR,
TAB 26 SUM-PROCS-VIR,
TAB 37 SUM-CON-VIR,
TAB 48 SERV-CON-VIR,
TAB 59 RECV-CH-VIR,
TAB 70 TRANS-CH-VIR.
*
BREAK-FOOTING PRINT-FLAG-VIR 3 TAB 59 RECV-BL-VIR,
TAB 70 TRANS-BL-VIR.
GO.

```

### Step 3

The IPF2 SAVE command may be used to save the report program for future execution.

#### NOTE

The NPA database to be reported on must be a permanent file (direct on NOS) resident in the catalog belonging to the user generating the report. This is a standard IPF2 database residency restriction.

Figure 7-6 provides an example of the report generated with the custom report processor.

| 3/14/90                                     |                            |                            |                          |                            |                                  |                                    |
|---|----------------------------|----------------------------|--------------------------|----------------------------|----------------------------------|------------------------------------|
| C D C N E T                                 |                            |                            |                          |                            |                                  |                                    |
| NETWORK PERFORMANCE ANALYZER                |                            |                            |                          |                            |                                  |                                    |
| TERMINAL SUPPORT ACCOUNTING STATISTICS      |                            |                            |                          |                            |                                  |                                    |
| SORTED BY USER ID AND FAMILY                |                            |                            |                          |                            |                                  |                                    |
| TIME PERIOD = 00/00/00 0000 - 99/12/31 2400 |                            |                            |                          |                            |                                  |                                    |
| TERMINAL SUPPORT ACCOUNTING STATISTICS      |                            |                            |                          |                            |                                  |                                    |
| USER ID = JFC                               |                            |                            |                          |                            |                                  |                                    |
| FAMILY/DOMAIN = FIRST_DOMAIN                |                            |                            |                          |                            |                                  |                                    |
| ENDING<br>DATE/TIME                         | NETWORK<br>CONNECT<br>TIME | NUMBER<br>OF<br>PROCEDURES | NUMBER<br>OF<br>CONNECTS | SERVICE<br>CONNECT<br>TIME | RECEIVED<br>CHARACTERS<br>BLOCKS | TRANSMITTD<br>CHARACTERS<br>BLOCKS |
| =====                                       | =====                      | =====                      | =====                    | =====                      | =====                            | =====                              |
| 90/03/13 1500                               | 116                        | 0                          | 5                        | 50                         | 151<br>22                        | 1242<br>24                         |
| 90/03/13 1600                               | 0                          | 0                          | 3                        | 685                        | 648<br>71                        | 4309<br>73                         |
| 90/03/13 1700                               | 200                        | 0                          | 4                        | 15                         | 210<br>16                        | 43<br>5                            |

Figure 7-6. Customized Terminal Support Accounting Statistics Report



# Device Interface Dump Analyzer 8

---

|   |      |
|---|------|
| How To Initiate the Dump Analyzer .....                   | 8-2  |
| Dump Analyzer Conventions .....                           | 8-4  |
| How To Retrieve a DI Dump File .....                      | 8-5  |
| CDCNET File Name .....                                    | 8-7  |
| CDCNET-to-NOS File Name Map .....                         | 8-7  |
| Using EDIT_CATALOG to Find Dump Files (NOS/VE Only) ..... | 8-9  |
| How To Use the Dump Analyzer Input File .....             | 8-9  |
| How To Manage Dump Analyzer Output .....                  | 8-10 |
| How To End a Dump Analyzer Session .....                  | 8-12 |
| How To Transfer Dump Files Between NOS/VE and NOS .....   | 8-12 |
| Sample Input File for NOS/VE or NOS .....                 | 8-13 |
| Sample Output File for NOS/VE or NOS .....                | 8-14 |
| Summary of ANACD Subcommands .....                        | 8-15 |





The DI Dump Analyzer program resides on a Control Data host computer and runs under NOS/VE or NOS. It processes subcommands that extract and format the information collected when DI memory is written to a dump file. The Dump Analyzer helps troubleshoot CDCNET by identifying events that have caused its DIs to reset.

This chapter includes the following main topics:

- How to Initiate the Dump Analyzer
- Dump Analyzer Conventions
- How to Retrieve a DI Dump File
- How to Use the Dump Analyzer Input File
- How to Manage Dump Analyzer Output
- How To End a Dump Analyzer Session
- How to Transfer Dump Files Between NOS/VE and NOS
- Sample Input File for NOS/VE or NOS
- Sample Output File for NOS/VE or NOS
- Summary of ANACD Subcommands

---

## NOTE

For more detailed information on the commands used in this chapter, see the CDCNET Commands Reference manual.

If you are doing operations on a CDCNET Network Management Station, refer to the CDCNET Network Management Station manual.

---

## How To Initiate the Dump Analyzer

Use one of the following procedures to initiate the Dump Analyzer.

### NOS/VE Only

1. Log in to the host computer by entering your required user name and password. If you successfully log in, you receive a slash.

/

2. You use the `CREATE_COMMAND_LIST_ENTRY` command to make the Dump Analyzer available to your job.

```
crecle $system.cdcnet.version_independent.command_library
```

---

#### NOTE

This command may be added to your user prolog so that the Dump Analyzer is available to you whenever you log in.

---

3. Execute the `ANALYZE_CDCNET_DUMP` command, abbreviated `ANACD`. The output from this command is a summary of the `ANACD` subcommand descriptions found later in this chapter.

This example accepts subcommands from file `CMDFILE` and writes output to the terminal.

```
ANACD,DF=DIAA132,I=CMDFILE
```

This example begins an interactive Dump Analyzer session on a dump file from `SYSTEM_0800253000DA`.

```
ANACD,DF=$SYSTEM.CDCNET.DUMP.SYSTEM_0800253000DA.FULL_8701050856249189
```

---

#### NOTE

Refer to `Dump Analyzer Conventions`, later in this chapter, for more information on the `ANACD` command.

---

4. You have successfully started a Dump Analyzer session under NOS/VE if you see the Dump Analyzer's banner message and the NOS/VE Dump Analyzer prompt:

```
COPYRIGHT CONTROL DATA CORPORATION 1985, 1986, 1987  ALL RIGHTS RESERVED
```

```
CDCNET DUMP ANALYZER VERSION = 1614
```

```
CDCNET DI SOFTWARE BOOT VERSION RECORDED IN MPB_RAM = 1614
```

```
CDCNET DI SOFTWARE RELEASE LEVEL RECORDED IN SYSTEM_DATA = 1614
```

```
DA/
```

**NOS Only**

1. Log in to the host computer by entering your required user name and password. If you successfully log in, you receive a slash.

/

2. Execute the ANALYZE\_CDCNET\_DUMP command, abbreviated ANACD. The output from this command is a summary of the ANACD subcommand descriptions found later in this chapter.

```
ANACD,DF=DIAA132,I=CMDFILE
```

This example begins an interactive Dump Analyzer session, specifying 2404 as the version of the Dump Analyzer to be used.

```
ANACD,DF=DSA9189,V=2404
```

**NOTE**


---

Refer to Dump Analyzer Conventions, later in this chapter, for more information on the ANACD command.

---

3. You have successfully started a Dump Analyzer session under NOS if you see the Dump Analyzer's banner message and the following prompt.

```
COPYRIGHT CONTROL DATA CORPORATION 1985, 1986, 1987  ALL RIGHTS RESERVED
```

```
CDCNET DUMP ANALYZER VERSION = 1614
```

```
CDCNET DI SOFTWARE BOOT VERSION RECORDED IN MPB_RAM = 1614
```

```
CDCNET DI SOFTWARE RELEASE LEVEL RECORDED IN SYSTEM_DATA = 1614
```

```
?
```

## Dump Analyzer Conventions

In order to function properly, the Dump Analyzer must be able to locate and interpret certain data structures from the DI dump file. Because these data structures can change (in location or structure) from version to version, it is important to use a Dump Analyzer that can read the dump file under analysis. If you do not specify an alternative version of the Dump Analyzer, the version used is the version selected by your CDCNET site administrator.

To help identify which alternative Dump Analyzer version to use, two version numbers are displayed at the start of the Dump Analyzer session. One identifies the official release level of the CDCNET software product. This version number is stored into the DI's System Data Table during initialization.

The other version number, the **boot version**, is stored in MPB RAM and identifies the software version of the boot file that is used to reload the DI. Unless your site develops software in conjunction with Control Data, the boot version number should match the release level version number.

If the version level of the Dump Analyzer you are using does not match the release level version of the dump file, the Dump Analyzer displays diagnostic message number 86 (see appendix J). You might find it necessary to restart the Dump Analyzer program and specify the CDCNET software version level of the dump file for the **VERSION (V)** parameter on the **ANACD** command. If a copy of the Dump Analyzer program built at this software version level is available at the site, it is used.

The following conventions are used for the Dump Analyzer.

- Under NOS/VE, the **ANACD** command and its parameters may be entered in their full or abbreviated forms. Under NOS, only the abbreviated form of this command, including its parameters, is allowed.
- The command name and its parameters may be separated by commas or spaces.
- **ANACD** may be entered at any time in response to the NOS prompt. However, because some Dump Analyzer displays are in uppercase and lowercase letters, you must be in ASCII mode to receive correctly formatted output. To set ASCII mode at your terminal, simply enter ASCII in response to the NOS prompt before starting your Dump Analyzer session.
- Dump Analyzer messages received using NOS are written to file **OUTPUT**.
- Under NOS/VE, Dump Analyzer error messages are always written to the file **\$ERRORS**, which is usually attached to your terminal.
- Under both NOS/VE and NOS, error messages are also written to the currently active output file, if this is not a terminal.
- The file named in an output parameter on a subcommand takes precedence over the output file named on the **ANACD** command during execution of that subcommand.

## How To Retrieve a DI Dump File

### NOS/VE Only

Under NOS/VE, DI dump files are placed in the `SYSTEM_` subcatalog of the `$SYSTEM.CDCNET.DUMP` catalog, where `ssssssssss` represents the system identifier of the source system. If this catalog does not exist when a dump file belonging there is created, it is created by the host at this time.

The file name of a cataloged DI dump file has the form:

`FULL_yymmddhhmmss`

where `yymmddhhmmss` is the timestamp put on the dump file by the DI from which it originated. The complete path to a DI dump file has the following form:

`$SYSTEM.CDCNET.DUMP.SYSTEM_``ssssssssss``.FULL_``yymmddhhmmss`

A dump file can be copied to a file in your local, working, or personal catalog with the `SCL COPY_FILE (COPF)` command. It is often useful to copy a dump file into a working catalog file named `DUMPFIL`, since this is the default file name for the `DUMP_FILE` parameter on the `ANACD` command.

The following command copies a dump file into file `DUMPFIL` in the current working catalog. A subsequent `ANACD` command automatically chooses this dump file for analysis if no other file is specified with the `DUMP_FILE` parameter.

`COPF $SYSTEM.CDCNET.DUMP.SYSTEM_0800253000A0.FULL_870216073930 DUMPFIL`

This dump file was created when the DI with a system identifier of `0800253000A0` reset at about 7:39 a.m. on the 16th of February 1987.

As an alternative to copying the dump file, you can specify its complete path name for the `DUMP_FILE` parameter on the `ANACD` command.

## NOS Only

Under NOS, each DI dump stored has a NOS permanent file name that is cataloged under user name NETOPS. Access privilege to user name NETOPS, and the dump files stored there, is site-dependent.

The NOS permanent file name for a DI dump file stored under NETOPS is constructed to indicate the sequential position of this dump with respect to other dumps received by the host, as follows:

Dyxxnnn

| Parameter | Description  |
|-----------|--|
| y         | One alphabetic character in the range I through R for dumps from any Mainframe Terminal Interface (MTI), or from the Mainframe DI (MDI) attached to the Control Data host that loads the CDCNET. This character is initially I and is incremented each time the xx field goes from 99 to AA (for example, DI99nnn, DJAAnnn, DJABnnn, and so on).<br><br>Or, one alphanumeric character in the range S through Z, then 0 through 9, for dumps from DIs other than the MDI attached to the Control Data host that loads the CDCNET. This character is initially S and is incremented each time the xx field goes from 99 back to AA (for example, DS99nnn, DTAAnnn, DTABnnn, and so on). |
| xx        | Two alphanumeric characters in the range AA through ZZ, then 00 through 99. These characters are initially AA and are incremented each time a NOS file is created for a CDCNET dump.   |
| nnn       | The three-digit network invocation number that is incremented each time NAM initiated.   |

The dump file you specify on the ANACD command must be local to your NOS job. Because the ANACD command uses a local file named DUMPFIL if the DF parameter is not specified, it can be useful to attach a local file named DUMPFIL that references the direct-access dump file you are interested in.

For example, the following NOS command creates a local working copy of DIAA132 (which resides under the site-selected user name NETMGR):

```
ATTACH,DUMPFIL=DIAA132/UN=NETMGR
```

## CDCNET File Name

All DI dump files are initially created as CDCNET files and are given CDCNET file names that indicate the originating DI's system identifier and the time at reset. CDCNET file names cannot be used on the ANACD command, but they can be very useful for identifying the origin of a dump file.

The CDCNET file name for a DI dump file is constructed as follows:

DUMP#FULL\_XXXXXXXXXX\_yymmddhhmmss

| Parameter     | Description   |
|---------------|---|
| XXXXXXXXXX    | The 12-character ASCII-coded hexadecimal number representing the system identifier of the device interface whose memory has dumped. |
| yyymmddhhmmss | The ASCII-coded hexadecimal number indicating the year, month, day, hour, minute, and second at the time of the dump.               |

## CDCNET-to-NOS File Name Map

A mapping between DI dump file's CDCNET file names and their corresponding NOS file names is retained in NETDIR. NETDIR is a private, direct-access, permanent file that resides under user name NETOPS. NETDIR can be accessed through the Network File Management (NETFM) utility by site-specified users. If you are permitted to access NETDIR, take the following steps to display CDCNET-to-NOS dump file name maps:

1. After you have logged on to the NOS host under a user name with NETDIR access privilege, use the following command to start NETFM:

```
NETFM,UN=NETOPS
```

The UN parameter tells NETFM where to find NETDIR (UN=NETOPS is actually the default username for the NETFM command). You are prompted for NETFM directives with a question mark (?).

2. Enter NETFM's LIST directive to see the directory entries you are interested in. For example, the following LIST directive lists the CDCNET and NOS file names of all dumps from the DI system with a system identifier of 080025100088:

```
LIST,NF=DUMP#FULL_080025100088*,LO=F
```

The NF parameter identifies the CDCNET file name(s) to be searched for in the directory; the asterisk is a wildcard character that represents any string of characters, and which, if entered as the last character of the string, produces a match with any file name that begins with the specified string.

If you use a list option of full (LO=F), you get a display that includes NOS permanent file names. Otherwise, you see only the CDCNET file names. A full display is formatted as follows:



| NETWORK | FILE NAME | PFN | TYPE | DN | UN | PN | CREATION  | LAST MOD  |
|---------|-----------|-----|------|----|----|----|-----------|-----------|
|         |           |     | FS   |    |    | RT | DATE/TIME | DATE/TIME |
|         | COMMENT   |     |      |    |    |    |           |           |

LIST,NF=DUMP#FULL\_080025100088\*,LO=F

|                 |         |     |   |        |   |           |           |
|-----------------|---------|-----|---|--------|---|-----------|-----------|
| DUMP#FULL_08002 | DIAA613 | DIR | 2 | NETOPS | 0 | 87/02/19. | 87/02/19. |
| 5100088_8702191 | 3471    |     |   |        | F | 17.34.33. | 17.34.33. |
| 73527           |         |     |   |        |   |           |           |
| DUMP#FULL_08002 | DIAD617 | DIR | 3 | NETOPS | 0 | 87/02/23. | 87/02/23. |
| 5100088_8702231 | 3857    |     |   |        | F | 14.12.55. | 14.12.55. |
| 41348           |         |     |   |        |   |           |           |
| DUMP#FULL_08002 | DIAE617 | DIR | 3 | NETOPS | 0 | 87/02/23. | 87/02/23. |
| 5100088_8702231 | 3511    |     |   |        | F | 14.22.31. | 14.22.31. |
| 42322           |         |     |   |        |   |           |           |

The CDCNET file names are in the first column. NOS permanent file names are in the second column. For example, the dump file with CDCNET file name DUMP#FULL\_080025100088\_870219173527 is stored in a NOS permanent file named DIAA613.

3. Leave NETFM by entering a blank command line (use a carriage return or line feed in response to the NETFM prompt).

See the CDCNET Configuration Guide for more information on using NETFM and its LIST directive.

#### NOTE

Under NOS, each time NAM is idled or aborted, the host's COLLECT utility writes certain NOS files to tape for long-term storage, including CDCNET dump files (COLLECT records the dump's CDCNET file name with each dump file collected).

COLLECT has an option to keep file types separate by writing them to different tapes. If this option is selected, your CDCNET dump files are written to tape as a set whenever COLLECT is invoked; otherwise, CDCNET dump files are interspersed with any other files collected. In either case, collected files are purged from the system.

See the NOS Version 2 Analysis Handbook for further information about COLLECT.

## Using EDIT\_CATALOG to Find Dump Files (NOS/VE Only)

Use the SCL command EDIT\_CATALOG (abbreviated EDIC) to help locate available dump files. For example, you can use the following EDIC command to see a list of all systems for which a dump file subcatalog has been created:

```
EDIC $SYSTEM.CDCNET.DUMP
```

The screen display from this subcommand lists all systems for which there might be dump files cataloged. You can choose to VIEW the contents of any of these subcatalogs by using the EDIC function keys.

## How To Use the Dump Analyzer Input File

### NOS/VE Only

Under NOS/VE, if you specify an input file on the ANACD command, you are not prompted for subcommands. Instead, output is written to the active output file and control returns directly to NOS/VE when the Dump Analyzer reads a QUIT subcommand or reaches the end-of-information (EOI) on the input file.

By SCL convention, the Dump Analyzer terminates input file processing if it encounters any abnormal status of severity ERROR or greater. None of the subcommands after the one causing the error are processed. This restriction applies even if INPUT=\$INPUT.

If the call to ANACD is embedded in an SCL procedure, the command stream is considered to be inside that procedure. In this case, INPUT=\$INPUT is the only way to permit input from the terminal. Again, any error causes the Dump Analyzer to terminate.

### NOS Only

Under NOS, if you specify an input file on the ANACD command (it must be local to your job), you are not prompted for subcommands. Instead, output is written to the active output file and control returns directly to NOS when the Dump Analyzer reads a QUIT subcommand, or reaches the end-of-information (EOI) on the input file.

See the section later in this chapter titled Sample Input File for NOS/VE or NOS for an example of useful input file subcommands.

## How To Manage Dump Analyzer Output

### NOS/VE Only

Under NOS/VE, output management is very flexible. You can easily alternate between displays sent directly to your terminal and displays written to other files. Moreover, you can edit output files without leaving the Dump Analyzer session you are engaged in.

If you do not specify an alternative output file on the ANACD command or on the Dump Analyzer subcommand being executed, displays from the Dump Analyzer are written to file \$OUTPUT, which is connected to terminal output file OUTPUT. The SCL command CREATE\_FILE\_CONNECTION (CREFC) lets you direct \$OUTPUT to other files as well.

If you do not specify an alternative output file on the ANACD command, but do so on the Dump Analyzer subcommand being executed, display from that subcommand is written to the specified file.

If you do specify an alternative output file on the ANACD command, output from the Dump Analyzer subcommands is directed to the specified file *except* for display from subcommands on which you specify a different output file. You may even specify file \$OUTPUT for a subcommand output file. This provides you with an immediate display, when output would otherwise have been written directly to the output file named on the ANACD command.

These options are summarized in the following table:

| Alternative<br>output file<br>on ANACD? | Active<br>subcommand<br>output file? | Output is written to:                    |
|---|--------------------------------------|--|
| NO                                      | NO                                   | \$OUTPUT                                 |
| YES                                     | NO                                   | ANACD output file                        |
| NO                                      | YES                                  | Subcommand output file                   |
| YES                                     | YES                                  | Subcommand output file (may be \$OUTPUT) |

Because NOS/VE lets you nest different utilities, you can edit a Dump Analyzer output file from within a Dump Analyzer session. Use the SCL command EDIT\_FILE (EDIF) in response to the Dump Analyzer prompt, and specify the appropriate Dump Analyzer output file for its FILE parameter. When you finish editing the file by specifying QUIT, you are automatically returned to the Dump Analyzer session in progress.

This can be especially useful if you need to locate values in a long Dump Analyzer display (such as DISPLAY\_MEMORY\_MAP) before effectively continuing your Dump Analyzer session.

## NOS Only

Under NOS, you can direct Dump Analyzer output using the O parameter on the ANACD command or the OUTPUT parameter on any subcommands that provide one.

If you do not specify an alternative output file on the ANACD command or on the Dump Analyzer subcommand being executed, displays from the Dump Analyzer are written to file OUTPUT, which is usually connected to the terminal.

If you do not specify an alternative output file on the ANACD command, but do so on the Dump Analyzer subcommand being executed, display from that subcommand is written to the specified file.

If you do specify an alternative output file on the ANACD command, output from the Dump Analyzer subcommands is directed to the specified file *except* for display from subcommands on which you specify a different output file. You can also specify OUTPUT for a subcommand output file, which provides you with an immediate display when output would otherwise have been written directly to the output file named on the ANACD command.

These options are summarized in the following table:

| Alternative<br>output file<br>on ANACD? | Active<br>subcommand<br>output file? | Output is written to:                      |
|---|--------------------------------------|--|
| NO                                      | NO                                   | OUTPUT (usually attached to your terminal) |
| YES                                     | NO                                   | ANACD output file                          |
| NO                                      | YES                                  | Subcommand output file                     |
| YES                                     | YES                                  | Subcommand output file (may be OUTPUT)     |

You cannot edit a Dump Analyzer output file from within a Dump Analyzer session. If you need to look through an output file before continuing, QUIT the current Dump Analyzer session, edit the output file, and begin a new Dump Analyzer session using the ANACD command.

## How To End a Dump Analyzer Session

Under both NOS/VE and NOS you can end a Dump Analyzer session and return control to NOS/VE or NOS with the Dump Analyzer QUIT subcommand, or with the user break 2 sequence entered at the terminal in response to the Dump Analyzer prompt.

QUIT

### NOTE

---

If you enter the user break 2 sequence while a subcommand is being processed, only that subcommand is terminated and the Dump Analyzer prompt is issued.

---

## How To Transfer Dump Files Between NOS/VE and NOS

To transfer a DI dump file from NOS to NOS/VE on a dual-state host, use the NOS/VE GET\_FILE command and set the DATA\_CONVERSION parameter to B64.

To transfer a DI dump file from NOS/VE to NOS on a dual-state host, use the NOS/VE REPLACE\_FILE command and set the DATA\_CONVERSION parameter to B64.

See the NOS/VE System Usage manual for further information about the GET\_FILE and REPLACE\_FILE commands.

## Sample Input File for NOS/VE or NOS

By using a Dump Analyzer input file, a single ANACD command can be used to process a group of Dump Analyzer subcommands. Use the host's file editing utilities to create Dump Analyzer input files. Use the host's file management utilities to store and retrieve these files for routine use.

Following is a sample input file for use on NOS/VE or NOS. This set of subcommands reveals important information about the dump file and can help determine if further analysis is required.

```
DISPLAY_EXECUTIVE_ERROR_TABLE
DISPLAY_DI_SYSTEM_STATUS
DISPLAY_TASK_CONTROL_BLOCK TASK_IDENTIFIER=ALL
VALIDATE_GLOBAL_INFORMATION
DISPLAY_NETWORK_STATUS
DISPLAY_HARDWARE_STATUS DISPLAY_OPTION=FULL
DISPLAY_SYSTEM_CONFIGURATION_TABLE
DISPLAY_MEMORY ADDRESS=400 REPEAT_COUNT=320(10)
DISPLAY_MEMORY_MAP
DISPLAY_CALL TASK_IDENTIFIER=ALL
```

See the respective subcommand descriptions for explanations and examples of the information displayed from these subcommands.

## Sample Output File for NOS/VE or NOS

Dump Analyzer output is written either to the screen of your terminal or to a specified output file.

If Dump Analyzer output is written to a separate output file, each page of output includes a header that identifies the level of Dump Analyzer you are using, date and time of subcommand execution, and the Dump Analyzer subcommand being executed. The subcommand is shown in its unabbreviated form, regardless of how it was entered. Parameters are echoed exactly as they were entered.

Following is a sample of output that was written to an output file:

```
1  COPYRIGHT CONTROL DATA CORPORATION 1985, 1986, 1987  ALL RIGHTS RESERVED
   ANACD - Level 4104      November 13, 1987      1:42 PM      PAGE      1
   DISPLAY_NETWORK_STATUS  o=netstat
```

### DISPLAY NETWORK STATUS

```
network_name      = MTI_JONAS_NETWORK_1
network_type      = HDLC
network_identifier = 0000A004(16)
network_status    = active
network_cost      = 0037D(16)
```

```
network_name      = MTI_JONAS_NETWORK_2
network_type      = HDLC
network_identifier = 0000A005(16)
network_status    = active
network_cost      = 0037D(16)
```

All Dump Analyzer output that is written to a separate output file uses this header convention.

### NOTE

---

Subcommand lines up to 256 characters long are accepted and written to the display file without truncation, although printing on paper designed for 80 or 132 columns may result in loss of visible data.

---

## Summary of ANACD Subcommands

ANACD subcommands processed by the Dump Analyzer fall into six major categories, as summarized in the following table.

| <b>Dump Analyzer<br/>Control Subcommand</b> | <b>Description</b>   |
|---|--|
| QUIT (QUI)                                  | Terminates the Dump Analyzer session and returns control to the operating system.  |
| <b>Dump Analyzer<br/>Help Subcommands</b>   | <b>Description</b>   |
| DISPLAY_COMMAND_INFORMATION (DISCI)         | Displays parameter information for a specified Dump Analyzer subcommand.   |
| DISPLAY_COMMAND_LIST (DISCL)                | Displays a list of available Dump Analyzer subcommands.  |
| HELP (HEL)                                  | Displays a list of available Dump Analyzer subcommands, or parameter information for a specified Dump Analyzer subcommand. |
| <b>Dump Summary Subcommands</b>             | <b>Description</b>   |
| DISPLAY_AUTO_DUMP_TABLE (DISADT)            | Displays the contents of the auto dump table and the map of memory available in the dump file.                             |
| DISPLAY_BOARD_MAP_TABLE (DISBMT)            | Displays the contents of the board map table.  |
| DISPLAY_DI_SYSTEM_STATUS (DISDSS)           | Displays system configuration information from the time of reset.  |
| DISPLAY_EXECUTIVE_ERROR_TABLE (DISEET)      | Displays information from the executive error table.   |
| DISPLAY_HARDWARE_STATUS (DISHS)             | Displays information about the modular DI hardware from the time of reset.   |
| DISPLAY_ICA_SYSTEM_STATUS (DISISS)          | Displays system configuration information from the time of reset.  |
| DISPLAY_NETWORK_STATUS (DISNS)              | Displays status of networks connected to the DI at reset.  |
| DISPLAY_SYSTEM_CONFIG_TABLE (DISSCT)        | Displays information from the system configuration table.  |
| VALIDATE_GLOBAL_INFORMATION (VALGI)         | Displays general diagnostic information, serving as a preliminary guide to further analysis.                               |



| Address-Oriented Subcommands  | Description  |
|-------------------------------|--|
| DISPLAY_BUFFER_CHAIN (DISBC)  | Displays buffer chain information starting from the specified machine address. All descriptor buffers or data buffers are displayed for all messages in the chain.                 |
| DISPLAY_DATA_QUEUE (DISDQ)    | Displays buffer chain information associated with the queue control block at the specified machine address.  |
| DISPLAY_LINKED_LIST (DISLL)   | Displays a linked list of structured elements given the machine address of the first element and offset to a pointer within the structure linking it to the next item in the list. |
| DISPLAY_MEMORY (DISM)         | Displays memory contents. The display begins at a specified machine address or entry-point address and is of a specified length. Both hexadecimal and ASCII formats are displayed. |
| DISPLAY_MEMORY_HEADER (DISMH) | Displays information from the allocation header of the memory extent that contains the specified address.  |
| DISPLAY_TREE (DIST)           | Displays all nodes of a binary tree structure, or a specified node matching a user-supplied key.   |

| <b>Task-Oriented Subcommands</b>    | <b>Description</b>   |
|-------------------------------------|--|
| DISPLAY_CALL (DISC)                 | Displays information about the dynamic call chain (or module traceback) of the specified task, or all tasks.                       |
| DISPLAY_MEMORY_USERS (DISMU)        | Displays information about the allocation of memory extents to various tasks or other users in the system.                         |
| DISPLAY_TASK_CONTROL_BLOCK (DISTCB) | Displays information from the task control block for the specified task, or all tasks.   |
| SELECT_TASK (SELT)                  | Specifies the task to be examined in subsequent task-oriented subcommands (designates the task to be considered the current task). |
| VALIDATE_STACK_AREAS (VALSA)        | Checks integrity of the reserved and user stack areas of any or all tasks.   |
| <b>Miscellaneous Subcommands</b>    | <b>Description</b>   |
| DISPLAY_LINE_CONTROL_BLOCK (DISLCB) | Displays information from the configured line control block for a given line, or all lines.  |
| DISPLAY_LOG_QUEUES (DISLQ)          | Displays the preserve and initialization log message queues.   |
| DISPLAY_MEMORY_MAP (DISMM)          | Displays a memory map of the modules that were loaded in the DI before it was reset.   |



# Analyzing the Network

9

|  |      |
|--|------|
| Analysis Tools .....   | 9-1  |
| How Networks Are Formed .....                                      | 9-2  |
| Analyzing Network Configuration .....                              | 9-3  |
| Analyzing Network Configuration Using NETOU .....                  | 9-4  |
| Displaying System Titles .....                                     | 9-4  |
| Displaying System Titles Under NOS .....                           | 9-5  |
| Displaying System Titles Under NOS/VE .....                        | 9-5  |
| DISPLAY_DI_SYSTEM_STATUS Command .....                             | 9-6  |
| DISPLAY_NETWORK_STATUS Command .....                               | 9-7  |
| Analyzing Network Configuration Using the Dump Analyzer .....      | 9-8  |
| DISPLAY_DI_SYSTEM_STATUS Subcommand .....                          | 9-8  |
| DISPLAY_NETWORK_STATUS Subcommand .....                            | 9-8  |
| Analyzing DI Hardware Configurations .....                         | 9-9  |
| Analyzing DI Hardware Configurations Using NETOU .....             | 9-13 |
| Analyzing DI Hardware Configurations Using the Dump Analyzer ..... | 9-14 |
| DISPLAY_HARDWARE_STATUS Subcommand .....                           | 9-14 |
| Locating and Interpreting the Major Card Status Table (MCST) ..... | 9-14 |
| Board Name .....   | 9-15 |
| Board State .....  | 9-15 |
| Board Status .....   | 9-15 |
| Board Version Number and ROM Level .....                           | 9-16 |
| Bus Registers and Addresses .....                                  | 9-16 |
| Board Type-Specific Information .....                              | 9-16 |
| Locating and Interpreting the LIM Status Table (LST) .....         | 9-17 |
| LIM Name .....   | 9-17 |
| LIM State .....  | 9-18 |
| LIM Status .....   | 9-18 |
| LIM Type .....   | 9-18 |
| The Owning CIM, Owned Ports .....                                  | 9-18 |
| Locating and Interpreting a Port Status Table (PST) .....          | 9-19 |
| Port Name .....  | 9-19 |
| Port State .....   | 9-19 |
| Port Status .....  | 9-19 |
| Port User .....  | 9-20 |
| Locating and Interpreting an SMM Bank Status Table (SBST) .....    | 9-21 |
| SMM Memory Banks .....   | 9-21 |
| Locating and Interpreting a PMM Bank Status Table (PBST) .....     | 9-22 |
| Analyzing DI Hardware Configurations Using NPA .....               | 9-23 |
| Analyzing Line and Terminal Connections .....                      | 9-24 |
| Analyzing Connections Using NETOU .....                            | 9-27 |
| Analyzing Connections Using the Dump Analyzer .....                | 9-29 |
| DISPLAY_LINE_CONTROL_BLOCKS Subcommand .....                       | 9-29 |
| Locating the ALCB .....  | 9-30 |
| Locating the CLCB Chain .....                                      | 9-32 |
| Locating the TCCB Chain .....                                      | 9-33 |
| Locating a TDCB Chain .....  | 9-34 |
| Locating a DCCB Chain .....  | 9-35 |
| Displaying the Output Queue .....                                  | 9-36 |

|                                       |      |
|---------------------------------------|------|
| Analyzing Connections Using NPA ..... | 9-37 |
|---------------------------------------|------|

Each network is a complex data communications facility with its own unique configuration of network solutions, DIs, hosts, terminals, and peripheral devices. Yet, despite the complexity and domain of CDCNET, it is designed so that the typical user is barely aware of its presence.

Trained network analysts must be able to discover the relationships among the varied CDCNET network components and help maintain the transparency of the network to the end user. The CDCNET product is equipped with tools to help the network analyst perform these functions.

## Analysis Tools

The tools available for analyzing the network include the Network Operator Utility (NETOU), the DI Dump Analyzer, and the Network Performance Analyzer (NPA). Each of these tools reveals the network in a different way.

NETOU has a set of commands that let you look at the network from an active DI's perspective. Several of the NETOU commands cause a DI to display information that it maintains in its memory's data structures, or that it can find out from other active DIs on the network.

The DI Dump Analyzer can display some of the same data structures, but only from a host-based file that is created when a DI dumps its memory at reset. Instead of telling you about an active DI, the Dump Analyzer displays information about a specific point in time in the past—the point when the DI was forced to reload.

In contrast, NPA looks at the network over time. This tool generates statistics based on CDCNET log files. It can reveal trends and averages that are useful when analyzing the network's performance.

Table 9-1 summarizes each of these network analysis tools according to its mode of operation, its residence, and its specific application.

**Table 9-1. Network Analysis Tools**

| <b>Tool</b>      | <b>Mode of Operation</b>       | <b>Residence</b>   | <b>Application</b>   |
|------------------|--------------------------------|--------------------|--|
| NETOU            | Causes DIs to process commands | Host- and DI-based | Used to query active DIs   |
| DI Dump Analyzer | Processes DI dump files        | Host-based         | Displays information from the time of DI reset   |
| NPA              | Processes CDCNET log files     | Host-based         | Reformats log files to provide statistical information from selected time periods or generates event/error reports based on log messages in the network log file |

Among other things, these tools allow the network analyst to evaluate the following:

- Network configuration
- DI hardware configuration
- Lines and terminal connections

## How Networks Are Formed

The structure of a network is a function of the network configuration commands entered interactively or via procedure files, and the physical status of network hardware components. By using the network analysis tools described in this chapter, you can discover and/or verify network configurations and topologies.

To help with your analysis, gather as much existing information as you can about how the network was formed. Examine the following:

- DI Configuration Procedures
- Exception List
- Terminal Definition Procedures
- Terminal User Procedures

Work with the site operations personnel and secure a map of the physical layout of the major network hardware components (hosts, DIs, and trunks), including the default and assigned names of these components. Determine if there is an online database describing the network and study it carefully if there is one. If you have been called in to analyze someone's network, begin by using your tools to verify the site's current base of information.

## Analyzing Network Configuration

The roadmap of a concatenated network (or catenet) is a function of its major hardware configuration—the interconnection of its DIs, hosts, and trunks. Traffic patterns, bottlenecks, and detours are the result of configuration decisions and hardware conditions. See the CDCNET Configuration Guide for descriptions of the commands used to configure a CDCNET.

Figure 9-1 shows a sample network configuration with six DIs.




Figure 9-1. Network Configuration Map



## Analyzing Network Configuration Using NETOU

After you have started a NETOU session, you can begin to query the individual CDCNET systems that service the catenet.

For example, assume that your network looks like the one in figure 9-1, that your terminal is connected to the network through TDI\_A, and that you are unable to create a connection to HOST\_B. You begin a NETOU session on (NOS) HOST\_A, with MDI\_A as the Command MDI, and find that you receive no response from commands sent to NDI\_B, MDI\_B, or TDI\_B.

Looking at the map, you immediately suspect a problem in the link from network solution A to network solution B. You could check this hypothesis by sending a DISPLAY\_NETWORK\_STATUS (DISNS) command to NDI\_A.

If you are plotting a configuration map from scratch, first discover the system titles (this is described in the next section, Displaying System Titles) and then use NETOU's DISPLAY\_NETWORK\_STATUS (DISNS) command (described later in this section). As you collect network hardware information, group the systems according to the network solutions they serve. Thus grouped, you should be able to draw a catenet configuration map like the one in figure 9-1. This map can help you probe the network and isolate potential trouble spots quickly.

### Displaying System Titles

System titles are used in a NETOU session to identify CDCNET systems, as when you specify a name on the SENC command. If the title you specify cannot be located, the command you enter cannot be delivered for execution and an error results. It is therefore useful to know, at any given time, which DI systems are active on the catenet.

There are two system names for each CDCNET system that can be addressed: the default system name and the logical system name (if one was specified when the system was defined). Default names are of the form \$DI\_system\_id, where system\_id is the DI's 12-hexadecimal-digit system identifier.

Knowing the site conventions for assigning logical names can be very useful. A convention that makes an obvious connection between the alias and the default system name can save you time during analysis.

Because the default system name is based on a unique system identifier, tracking this name ensures that you do not confuse one CDCNET system for another. Keeping track of the system identifier is also useful if you plan to use NPA's CRECAR command. One of the parameters on the CRECAR command specifies the system identifier of the system to be covered in the report.

*Displaying System Titles Under NOS*

If you are using NETOU under NOS and want to display the active system titles, the Command MDI can make a system title search throughout the catenet. This search provides you with the titles of all CDCNET systems that the Command MDI can now address. You can order this search with the following command:

```
DISPLAY_CATENET_TITLES
```

or its abbreviated form:

```
DISCT
```

Display from DISCT is formatted as follows:

```
FROM MDI_8B                      33565
Catenet Titles

system titles
$DI_080025100083                TDI_91
$DI_080025100091                $DI_080025100078
MTI_83                          $DI_080025100083
MDI_8B                          TDI_78
```

*Displaying System Titles Under NOS/VE*

There is no DISCT command under NOS/VE, but you can add an SCL procedure to your command library that has the same capability. The following procedure, called `DISPLAY_SYSTEM_NAMES` in the example, yields a display of active DI systems when executed as a command.

```
PROC display_system_names, dissn (
  system, s    string = '[A-Z]*'
)

  x = $matching_names($translate(lower_to_upper, $value(system)))
  FOR i = $variable(x, lower_bound) TO $variable(x, upper_bound) DO
    display x(i)
  FOREND

PROCEND display_system_names
```

If you need help adding this procedure to your command library, see the NOS/VE System Usage manual. If you have successfully added this procedure, simply type `DISSN` from within a NETOU session under NOS/VE to see a display of the logical names of all DI systems that are active on the network. For a display of the logical and default system names, type:

```
DISSN '*'
```

The asterisk is a wildcard character on NETOU. When used in this way, with this command, it enables matching of system names that begin with any character (not just alphabetic), and hence the default system names, which begin with a dollar sign (\$), are included in the display.

The asterisk wildcard character can be used with this command in other ways, too. For example, to display only the default system names, type:

```
DISSN '$*'
```

**DISPLAY\_DI\_SYSTEM\_STATUS Command**

Use the **DISPLAY\_DI\_SYSTEM\_STATUS** (DISDSS) command to correlate a system's default name and its site-given alias. Simply send a DISDSS command to one of the titles in question.

For example, the following command displays the system name(s) of the DI whose default system name is \$DI\_080025300091:

```
SENC 'DISDSS' $DI_080025300091
```

Output from this command is formatted as follows:

```
FROM TD1_91                      33115

DI System Status
system name = TD1_91
system address = 080025300091(16)
boot version number = 190B(16)
software release level = 190B(16)
number of tasks = 54
free SMM memory = 64526
percent CPU utilization = 7
buffer state = good
memory state = good
date and time of last reload = 86/10/09 06:58:30

Buffer Status
type      total buffers  available buffers  buffer size
data      1225           886                144
descriptor 410           362                32

SMM Memory Status
total memory  available memory  fragments  deloadable memory
1048576      64526                96         83938

MPB RAM Status
total memory  available memory  fragments  deloadable memory
16384        1820                1          0
```

The site-assigned logical name of this DI is listed next to the heading system name. The default system name is constructed by prefixing the system address with the four-character string \$DI\_. If you know one name and not the other, you can always find the other by sending DISDSS to the name you know.

## DISPLAY\_NETWORK\_STATUS Command

The network solutions served by a CDCNET system can be displayed by sending the `DISPLAY_NETWORK_STATUS` (DISNS) command to the system of interest. For each network solution directly connected to the CDCNET system, the network solution name, type, id, status, and cost are displayed. The name of the CDCNET system hardware device that services each of the network solutions (such as ESCI or LIM/PORT) is also displayed.

For example, the following command displays the network solutions directly connected to CDCNET system `AHL_TDI_30011c`:

```
SENC 'DISNS' AHL_TDI_30011C
```

Output from this command is formatted as follows:

```
FROM AHL_TDI_30011C

Network Status
network_name = LCLSH_ETHER_NET
network_type = Ethernet
network_id = 0000A002(16)
network_status = active
network_cost = 000A(16)
trunk_name = LCLSH_ETHER_NET
device_name = $ESCI7
average time network is congested = 0 %
date and time network last became active = 89/10/02 05.17 15

network_name = RTI_LINK_NETWORK_1
network_type = HDLC
network_id = 0000A205(16)
network_status = active
network_cost = 06FA(16)
trunk_name = RTI_LINK_NETWORK_1
device_name = $LIM7_PORT0
average time network is congested = .0 %
date and time network last became active = 89/10/02 05.17 45
```

Like CDCNET systems, network solutions can be known by more than one name. One system on the catenet might refer to a network solution by one name, while another system refers to the same network solution by a different name.

The common denominator for referencing network solutions is the `network_id`. Use the `network_id` to gather information about network solutions on a catenet. This number is the same for all references to the same network solution and is unique on the catenet.

For example, the `network_id` for the first of the two networks in the previous display is `0000A002(16)`, and the `network_name` is `LCLSH_ETHER_NET`. Any other system must refer to this network solution by the same `network_id`, but might use a different `network_name`.

## Analyzing Network Configuration Using the Dump Analyzer

The Dump Analyzer is equipped with its own `DISPLAY_DI_SYSTEM_STATUS` and `DISPLAY_NETWORK_STATUS` subcommands. These subcommands reveal information that is similar to what their NETOU counterparts display, but from a DI dump file instead of from an active DI.

### DISPLAY\_DI\_SYSTEM\_STATUS Subcommand

The Dump Analyzer's `DISPLAY_DI_SYSTEM_STATUS` (DISDSS) subcommand is designed to reveal much of the same information as the NETOU command that has the same name. During a DI Dump Analyzer session, simply enter:

```
DISDSS
```

Output from this subcommand is formatted as follows:

```
DISPLAY DI SYSTEM STATUS

System name      = MDI_84
System identifier = 080025100084(16)  Master clock    =      FALSE
Release level    =      2007           Number of tasks =      31
Boot version     =      DDDD           CPU utilization =      5 %
DI loaded from   = MCI board in slot 7  Helping system  = 000000000000(16)

Buffers
  free    total    size
Data      81      451    144      State is GOOD
Desc       39      100     32

Memory      (1 MB Configuration)
  free    fragments  deloadable
MPB       3074         1         0
PMM       49258        2         0      State is GOOD
SMM       346390        6      83394
RESERVED   1000         1        N/A

50% of memory after configuration made into buffers
--WARNING DA 118-- Address  980001(16) is not within valid memory_
ranges.

Largest SMM memory fragment available =    65537
```

### DISPLAY\_NETWORK\_STATUS Subcommand

Again, the `DISPLAY_NETWORK_STATUS` (DISNS) subcommand is designed to reveal much of the same information as the NETOU command by the same name. During a DI Dump Analyzer session, simply enter:

```
DISNS
```

Output from this subcommand is formatted as follows:

```
DISPLAY NETWORK STATUS

network_name      = $NET_1
network_type      = Ethernet
network_identifier = 00000001(16)
network_status    = active
network_cost      = 0000A(16)
```

This example shows the DISNS display for a DI that has one directly connected network. Following is an example of DISNS output for a DI that had no directly connected networks:

```
DISPLAY NETWORK STATUS
No networks defined
```

## Analyzing DI Hardware Configurations

The modularity of DI hardware design permits dozens of DI hardware configurations. Standard, generalized configuration types are the TDI, the MDI, the MTI, the NDI, and the RTI. Each of these DI types can have further variation, so that the DI can be matched to an exact and specialized role in the network. For example, some DIs have two SMM boards; others have two CIMs.

Every DI has an MPB and at least one SMM board. Following are some sample DI hardware configurations (board slot numbers follow board type abbreviations; for example, MCI6 is an MCI board in slot 6):

| DI_A  | DI_B  | DI_C  | DI_D  | DI_E  |
|-------|-------|-------|-------|-------|
| MPB0  | MPB0  | MPB0  | MPB0  | MPB0  |
| SMM1  | PMM1  | PMM1  | SMM2  | PMM1  |
| SMM2  | SMM2  | SMM2  | CIM4  | SMM2  |
| CIM5  | SMM3  | CIM5  | ESCI6 | SMM3  |
| ESCI6 | CIM4  | ESCI7 |       | ESCI5 |
|       | CIM5  |       |       | MCI7  |
|       | MCI6  |       |       |       |
|       | ESCI7 |       |       |       |

It is a good idea to keep up-to-date records of DI hardware configurations. This information can make network analysis much easier.

The DI maintains its own hardware status tables in order to record the status of its internal hardware configuration. Software components use these tables to update and access information about the modular hardware installed in a DI.

There are five types of DI hardware status tables. These types, and the functions they perform, are listed in table 9-2:

**Table 9-2. Summary of Board Status Tables**

| Hardware Status Table          | Description   |
|--------------------------------|---|
| Major Card Status Table (MCST) | This table has one entry for each major board installed in the DI. Each entry records the identity, status, and location of a major board. For a CIM, SMM, or PMM board, the entry also records a pointer to the next appropriate hardware status table.                                      |
| LIM Status Table (LST)         | This table has one entry for each LIM or URI installed in the DI. Each entry records the identity, status, and location of a LIM/URI. The entry also records the major card slot number of the parent CIM board and the address of a port status table for the ports serviced by the LIM/URI. |
| Port Status Table (PST)        | Each LST entry may have an associated PST. In a PST there is one entry for each port serviced by the controlling LIM/URI. Each PST entry records the identity, status, and location of a port.  |
| SMM Bank Status Table (SBST)   | This table records information about the memory banks on the SMM board. It records the size and location of each SMM memory bank and the status of the SMM board itself.  |
| PMM Bank Status Table (PBST)   | This table records information about the memory banks on an installed PMM board. It records information about the PMM memory bank and the status of the PMM board itself.   |

Figure 9-2 illustrates the relationships among the various hardware status tables maintained in DI memory. The configuration shown in the MCST is arbitrary. Only the MPB board must reside in the designated position, slot 0 (a PMM, if present, must reside in slot 1).




Figure 9-2. Summary of Board Status Table Relationships



The hardware status tables indicate the state and status of hardware devices internal to the DI. The range of values for state and status types is described in tables 9-3 and 9-4, respectively. The hexadecimal digit values in these tables can be used to interpret certain memory locations described in this chapter.

**Table 9-3. Device State**

| <b>State</b> | <b>Hex Digits</b> | <b>Description</b>  |
|--------------|-------------------|---|
| On           | 0000              | This state implies that the device is either fully operational or is operating in a degraded mode. This state further implies that the device is available for use by the system, which may include concurrent diagnostic maintenance.  |
| Off          | 0001              | This state indicates that the device is not available to the system or diagnostics. A device may be placed in this state to prohibit its further use. The logical equivalent of this state is that the device is not present in the DI. |
| Down         | 0002              | This state indicates that the device is only available for use by the diagnostics software. The device is not available for normal system use.  |

**Table 9-4. Device Status**

| <b>Status</b>     | <b>Hex Digits</b> | <b>Description</b>  |
|-------------------|-------------------|---|
| Not Configured    | 0000              | The hardware device has not been configured.  |
| Configured        | 0001              | The hardware device has been configured, but not enabled.   |
| Enabled           | 0002              | The hardware device has been configured and the software driving the device has been started; however, the device is not currently active.  |
| Active            | 0003              | The hardware device is active.  |
| Protocol Mismatch | 0004              | The hardware device has been configured and the software driving the device has been started; however, the software has detected a protocol mismatch with its peer. (This state is currently used only for the MCI board, to indicate that the MCI driver could not negotiate a common channel protocol with a NOS host.) |

The hardware configuration and status of active DIs can be discovered using NETOU. Use the Dump Analyzer to find the same information about a DI that has dumped its memory. NPA can generate reports about hardware configuration and status over time.

## Analyzing DI Hardware Configurations Using NETOU

NETOU is equipped with a command called `DISPLAY_HARDWARE_STATUS` (DISHS) that causes the DI to display information from its hardware status tables. In the following example, the hardware status of an MDI is displayed (note that DISHS must be enclosed in a SENC command):

```
SENC 'DISHS' MDI_A1
```

Output from this command is formatted as follows:

```
FROM MDI_A1                      33021

Hardware Status
device name  state  status  version  lim/bank/port  type
$MPB0       on    configured  0000(16)
$PMM1       on    configured  0008(16)
$SMM2       on    configured  0002(16)
3           off    not config. 0000(16)
4           off    not config. 0000(16)
$ESC15      on    active    0010(16)
6           off    not config. 0000(16)
$MC17       on    active    0000(16)
```

Following is an example of the display format for a TDI.

```
FROM TDI_A1                      33021

Hardware Status
device name  state  status  version  lim/bank/port  type
$MPB0       on    configured  0000(16)
1           off    not config. 0000(16)
$SMM2       on    configured  0002(16)
$CIM3       on    configured  0000(16)  0,1,2,3,4,5,6,7
4           off    not config. 0000(16)
$ESC15      on    active    0000(16)
6           off    not config. 0000(16)
7           off    not config. 0000(16)
$LIM0       on    configured  4          RS232
$LIM1       on    configured  4          RS232
$LIM2       on    configured  4          RS232
$LIM3       on    configured  4          RS232
$LIM4       on    configured  4          RS232
$LIM5       on    configured  4          RS232
$LIM6       on    configured  4          RS232
$LIM7       on    configured  4          RS232
```

## Analyzing DI Hardware Configurations Using the Dump Analyzer

With the Dump Analyzer, you can look at DI hardware status either by using a specialized subcommand or by looking at the memory corresponding to the DI's hardware status tables.

### DISPLAY\_HARDWARE\_STATUS Subcommand

The Dump Analyzer is equipped with a subcommand that displays information in the MCST and LST from the dump file. This subcommand, called `DISPLAY_HARDWARE_STATUS` (DISHS), is very much like its NETOU counterpart. During a DI Dump Analyzer session, simply enter:

```
DISHS
```

Output from this subcommand is formatted as follows:

#### DI HARDWARE STATUS

| Slot | Card type | Card ok | Boot enabled | State | Status     | Version (16) | ROM level | Dump address (16) |
|------|-----------|---------|--------------|-------|------------|--------------|-----------|-------------------|
| 0    | MPB       | yes     | no           | on    | configured | 0            | 50C       | 0                 |
| 1    | EMPTY     |         |              |       |            |              |           |                   |
| 2    | SMM       | yes     | no           | on    | configured | 2            | 0         | 100000            |
| 3    | SMM       | yes     | no           | on    | configured | 0            | 0         | 200000            |
| 4    | EMPTY     |         |              |       |            |              |           |                   |
| 5    | CIM       | yes     | no           | on    | configured | 0            | 50C       | 90000             |
| 6    | CIM       | yes     | no           | on    | configured | 0            | 50C       | A0000             |
| 7    | ESCI      | yes     | yes          | on    | active     | 10           | 806       | B0000             |

#### Line Interface Modules

| Slot | State | Status     | Parent CIM | LIM Type |
|------|-------|------------|------------|----------|
| 0    | on    | configured | \$CIM6     | rs232    |
| 1    | on    | configured | \$CIM6     | rs232    |
| 2    | on    | configured | \$CIM6     | rs232    |
| 3    | on    | configured | \$CIM6     | rs232    |
| 4    | on    | configured | \$CIM6     | rs232    |
| 5    | on    | configured | \$CIM6     | rs232    |
| 6    | on    | configured | \$CIM6     | rs232    |
| 7    | on    | configured | \$CIM5     | rs232    |

If you need to look at the memory corresponding to the individual DI hardware status tables, you can use the Dump analyzer's `DISPLAY_MEMORY` (DISM) subcommand, as described in the following subsections.

### Locating and Interpreting the Major Card Status Table (MCST)

The MCST is the root through which all other hardware status tables in DI memory can be located. To first locate the MCST, use the Dump Analyzer `DISPLAY_MEMORY_MAP` subcommand, or address the MCST symbolically as `major_card_status_table`. The MCST contains 52 bytes of information for each board slot. Its total length is 416 bytes.

Because each entry in the MCST has the same length, it is easy to display the MCST entry by entry. To do this, use the following subcommand:

```
DISM A=MAJOR_CARD_STATUS_TABLE BC=52(10) RC=8
```

An example of the display from this subcommand appears below. Each entry begins on a new line, making it easy to locate the same field in more than one entry.

```

STARTING ADDRESS    151280

HEX ADDR           HEXADECIMAL DATA           ASCII DATA

151280  2440 5042 3020 2020 2020 2000 0000 0001  $MPB0
        0000 0000 0000 050C 0000 0000 0000 0000
        0000 0000 0000 0000 0000 0000 0000 0000
        0010 32BA                                2
1512B4  2450 4040 3120 2020 2020 2000 0000 0001  $PMM1
        0001 0008 0008 050C 0000 8000 0000 0000
        0000 0000 0000 0000 0000 0000 0010 3352      3R
        0010 3306                                3
1512E8  2453 4040 3220 2020 2020 2000 0000 0001  $SMM2
        0002 0009 0002 0000 FFFC 8800 0000 00FB
        0090 0000 0000 6011 0010 0000 0010 33C4      3
        0010 3378                                3x
15131C  2020 2020 2020 2020 2020 2000 0001 0000
        0003 000F 0000 0000 FFFF 0000 0000 0000
        0000 0000 0000 0000 0000 0000 0000 0000
        0000 0000
151350  2443 494D 3420 2020 2020 2000 0000 0001  $CIM4
        0004 0001 0000 050C 0000 8880 FF00 00F7
        00A0 0000 0000 6021 0008 0000 0015 1420
        0010 3436                                46
151384  2020 2020 2020 2020 2020 2000 0001 0000
        0005 000F 0000 0000 FFFF 0000 0000 0000
        0000 0000 0000 0000 0000 0000 0000 0000
        0000 0000
1513B8  2445 5343 4936 2020 2020 2000 0000 0003  $ESC16
        0006 0002 0010 0806 FFFE 8800 0000 00F3
        00B0 0000 0000 6031 000A 0000 001B 365A      `1    6Z
        0010 4522                                E"
1513EC  244D 4349 3720 2020 2020 2000 0000 0003  $MCI7
        0007 0000 0000 050C FFFE C000 0000 00B6
        00B8 0000 0000 6039 000B 0000 0019 752E      `9    u
        0010 456E                                En

```

Each 52-byte-long segment from the MCST is an entry that records information about a single DI board. Because each entry has the same structure, the following discussion applies equally to any entry in the MCST.

#### *Board Name*

The name of each major board is recorded in bytes 0 through 10 of its MCST entry. Each name begins with a dollar sign (hexadecimal 24), indicates the board type, and is completed with the board slot number. For example, \$MCI7. The remaining length of the name field is blank-filled (hexadecimal 20).

#### *Board State*

The board state is recorded in bytes 12 and 13 of the MCST entry. See table 9-3 for explanations of the range of values for these bytes. In the previous DISPLAY\_MEMORY example, the MCST entries for slots 3 and 5 show the device state is off. No boards were installed in those slots when the DI was reset.

#### *Board Status*

The board status is recorded in bytes 14 and 15 of the MCST entry. See table 9-4 for explanations of these values. In the previous DISPLAY\_MEMORY example, the MCST entries for slots 3 and 5 show the device status is not\_configured. No boards were installed in those slots when the DI was reset.

There are five boolean values coded into byte 26 that further record the board's status. Following is a description of these boolean values.

| Bit | Significance   |
|-----|--|
| 0   | If 1, the board passed diagnostics (not applicable to MPB)                           |
| 1   | If 1, the board is available   |
| 2   | If 1, the board is running in degraded mode  |
| 3   | If 1, the attention switch on the board has been set                                 |
| 4   | If 1, the DI may not be booted over this board (not applicable to ESCI, CIM, or MCI) |

#### *Board Version Number and ROM Level*

The version number of the installed board is recorded in bytes 20 and 21. Bytes 22 and 23 record the board's ROM level.

#### *Bus Registers and Addresses*

The value of Internal Control Bus (ICB) write register 0 is recorded in bytes 30 and 31 of each MCST entry. The ICB write register 1 value is in bytes 32 and 33.

The ICB address is in bytes 36 through 39. Bytes 40 through 43 record the ITB address.

#### *Board Type-Specific Information*

Information specific to the MPB, CIM, or ESCI board is stored in byte 27. The significance of this byte is as follows:

| Board Type | Significance  |
|------------|---|
| MPB        | Number of errors since last reset   |
| CIM        | Number of LIMs supported  |
| ESCI       | A boolean value that indicates whether the ESCI transceiver is bad; if byte 28 is 80(16) or greater, the transceiver is bad |

There is an address in bytes 44 through 47 that points to further information for certain board types, as follows:

| Board Type | Further Information          |
|------------|------------------------------|
| PMM        | PMM Bank Status Table (PBST) |
| MCI        | Link Interface Block (LIB)   |
| SMM        | SMM Bank Status Table (SBST) |
| CIM        | LIM Status Table (LST)       |

## Locating and Interpreting the LIM Status Table (LST)

There is a single LST in DI memory that records information about all LIM boards in the DI. It maintains a 38-byte-long entry for each LIM slot.

There are three ways to find the LST:

1. Bytes 44 through 47 of a CIM board's MCST entry point to the first entry in the LST that belongs to a LIM it controls.
2. The Dump Analyzer DISPLAY\_MEMORY\_MAP subcommand displays an address for the `lim_status_table`.
3. The LST can be addressed symbolically as `lim_status_table`.

To display the entire LST, use the following subcommand (readability of the LST display is improved if you specify a byte count the length of a single LST entry and a repeat count equal to the total number of entries):

```
DISM A=_LIM_STATUS_TABLE BC=38(10) RC=8
```

Output from this subcommand is formatted as follows:

| STARTING ADDRESS | 151420   |                   |  |
|------------------|--|-------------------|--|
| HEX ADDR         | HEXADECIMAL DATA   | ASCII DATA        |  |
| 15142C           | 244C 494D 3020 2020 2020 2000 0000 0001<br>0010 34CE 0000 0100 0000 0001 000F 0004<br>0004 0010 3482 | \$LIM0<br>4<br>4  |  |
| 151446           | 244C 494D 3120 2020 2020 2000 0000 0001<br>0010 36E2 0001 0100 0000 0001 000F 0004<br>0004 0010 3696 | \$LIM1<br>6<br>6  |  |
| 15146C           | 244C 494D 3220 2020 2020 2000 0000 0001<br>0010 38F6 0002 0100 0000 0001 000F 0004<br>0004 0010 38AA | \$LIM2<br>8<br>8  |  |
| 151492           | 244C 494D 3320 2020 2020 2000 0000 0001<br>0010 3B0A 0003 0100 0000 0001 000F 0004<br>0004 0010 3ABE | \$LIM3<br>;<br>:  |  |
| 1514B8           | 244C 494D 3420 2020 2020 2000 0000 0001<br>0010 3D1E 0004 0100 0000 0001 000F 0004<br>0004 0010 3CD2 | \$LIM4<br>=<br><  |  |
| 1514DE           | 244C 494D 3520 2020 2020 2000 0000 0001<br>0010 3F32 0005 0100 0000 0001 000F 0004<br>0004 0010 3EE6 | \$LIM5<br>?2<br>> |  |
| 151504           | 244C 494D 3620 2020 2020 2000 0000 0001<br>0010 4146 0006 0100 0000 0001 000F 0004<br>0004 0010 40FA | \$LIM6<br>AF<br>@ |  |
| 15152A           | 244C 494D 3720 2020 2020 2000 0000 0001<br>0010 435A 0007 0100 0000 0001 000F 0004<br>0004 0010 430E | \$LIM7<br>CZ<br>C |  |

Each 38-byte entry in the LST records information about a single LIM board. Because each entry has the same structure, the following discussion applies equally to any entry in the LST.

### LIM Name

The name of each LIM board is recorded in bytes 0 through 10 of its LST entry. Each name is of the form `$LIMn`, where `n` is the LIM slot number. For example, `$LIM7`. The remaining bytes of the name field are blank-filled (hexadecimal 20).

*LIM State*

The state of each LIM board is recorded in bytes 12 and 13 of its LST entry. See table 9-3 for explanations of the values for these bytes. In the example, all LIMs are on. A value of 01 in byte 23 indicates that LIM service is degraded.

*LIM Status*

LIM status is recorded in bytes 14 and 15 of each LST entry. See table 9-4 for explanations of the values for these bytes. In the example, all LIMs are configured.

*LIM Type*

The LIM type is recorded in bytes 26 and 27 of each LST entry. The hexadecimal value of these bytes has the following significance:

| Hex<br>Digits | Significance             |
|---------------|--------------------------|
| 0000          | RS-449                   |
| 0001          | RS-232                   |
| 0002          | URD_BP1500               |
| 0003          | URD_B300                 |
| 0004          | URD_E_SERIES             |
| 0005          | URD_LINE_WRITER          |
| 0006          | URD_FASTBAND             |
| 0007          | URD_DATA_PRODUCTS_BASICS |
| 0008          | URD_CENTRONICS_360X_720X |
| 0009          | URD_CENTRONICS_703       |
| 000A          | V35                      |
| 000B          | X21                      |
| 000C          | LIM_SLOT_EMPTY           |

All LIMs in the example are type RS-232.

*The Owing CIM, Owned Ports*

The major board slot number of the CIM board that is parent to a LIM is recorded in bytes 30 and 31 of the LIM's LST entry. Bytes 32 and 33 indicate the number of ports that the LIM owns; this number ranges from 0 through 0F(16). Each LIM board in the example owns four ports.

## Locating and Interpreting a Port Status Table (PST)

The PST is a data structure that maintains information about the ports controlled by a single LIM. It has one entry for each port serviced by the LIM (currently there is a maximum of eight ports per LIM).

Bytes 16 through 19 of the LST entry for the controlling LIM board point to its PST. Use this address with the Dump Analyzer `DISPLAY_MEMORY` subcommand to display 28 bytes for each port.

To display the entire PST associated with LIM 0 of the previous example, use the following subcommand (readability of this display is improved if you specify a byte count the length of a single PST entry and a repeat count equal to the total number of entries in the PST):

```
DISM A=1034CE BC=38(10) RC=4
```

Output from this subcommand is formatted as follows:

| STARTING ADDRESS | 1034CE                                  |               |
|------------------|---|---------------|
| HEX ADDR         | HEXADECIMAL DATA                        | ASCII DATA    |
| 1034CE           | 244C 494D 305F 504F 5254 30D4 0000 0002 | \$LIM0_PORT0  |
|                  | 0000 0003 001C 10DA 0010 3566           | 5f            |
| 1034EA           | 244C 494D 305F 504F 5254 311A 0000 0002 | \$LIM0_PORT1  |
|                  | 0001 0003 001E BE56 0010 35B2           | V 5           |
| 103506           | 244C 494D 305F 504F 5254 324B 0000 0002 | \$LIM0_PORT2K |
|                  | 0002 0003 001E C5E8 0010 35FE           | 5             |
| 103522           | 244C 494D 305F 504F 5254 33EC 0000 0002 | \$LIM0_PORT3  |
|                  | 0003 0003 001E C52A 0010 364A           | * 6J          |

Each 28-byte-long entry from the PST records information about a single port. Because each entry has the same structure, the following discussion applies equally to any entry in the PST.

### *Port Name*

The name of each port is recorded in bytes 0 through 10 of its PST entry. Each port name is of the form `$LIMn_PORTm`, where `n` is the slot number of the parent LIM and `m` is the number of the port associated with the PST entry. The name field is blank-filled (hexadecimal 20).

### *Port State*

The state of each port is recorded in bytes 12 and 13 of its PST entry. See table 9-3 for explanations of state values. All ports in the previous example are on.

### *Port Status*

The status of each port is recorded in bytes 14 and 15 of its PST entry. See table 9-4. All ports in the previous example are enabled.



*Port User*

The port user type is recorded in bytes 18 and 19 of each PST entry. These bytes have the following significance:

| <b>Hex<br/>Digits</b> | <b>Significance</b> |
|-----------------------|---------------------|
| 0000                  | Port available      |
| 0001                  | HDLC owner          |
| 0002                  | X.25 owner          |
| 0003                  | LCM owner           |

All ports in the previous example are owned by the Line Control Module (LCM).

Bytes 20 through 23 of the PST point to the port user configuration table. The type of table depends on the port owner type, as follows:

| <b>Port<br/>Owner</b> | <b>Table Type</b>  |
|-----------------------|--|
| HDLC                  | HDLC Link Interface Block (LIB)  |
| X.25                  | X.25 LIB   |
| LCM                   | Configured Line Control Block (CLCB); see the section of this chapter on Analyzing Line and Terminal Connections |

## Locating and Interpreting an SMM Bank Status Table (SBST)

The SBST is a data structure that records the size, location, and status of a DI's SMM memory banks. There is a single SBST assigned for each SMM board installed in the DI. An SBST is 54 bytes long.

There is a pointer to the SBST in bytes 44 through 47 of the SMM board's MCST entry. The SBST for the SMM board in the MCST example in this chapter is displayed with the following subcommand:

```
DISM A=1033C4 RC=54(10)
```

Output from this subcommand is formatted as follows.

```
STARTING ADDRESS    1033C4

HEX ADDR            HEXADECEIMAL DATA            ASCII DATA
1033C4 0002 0008 0000 2453 4D4D 325F 4241 4E4B      $SMM2_BANK
1033D4 3020 0000 0001 0010 0000 0000 0000 2453      0      $$
1033E4 4D4D 325F 4241 4E4B 31EF 0000 0001 0018      MM2_BANK1
1033F4 0000 0000 0000
```

### *SMM Memory Banks*

Each SMM board has either one or two memory banks. Bytes 0 and 1 of the SBST indicate the number of memory banks on the associated SMM board. Bytes 2 through 5 represent the size of the SMM memory banks in bytes. In the example, there are two memory banks, each of size 80000(16), or 1/2 megabyte.

The name of the first memory bank (bank 0) is recorded in bytes 6 through 16 of the SBST entry. This name is of the form \$SMMn\_BANK0, where n is the board slot number of the SMM board. The remaining length of the name field is blank-filled (hexadecimal 20). The name of the second memory bank (bank 1) is recorded in bytes 30 through 40.

The codes for the state and status of each memory bank, and its starting address, are found in the following byte locations of the SBST:

|       | State       | Status      | Starting Address |
|-------|-------------|-------------|------------------|
| BANK0 | Bytes 18-19 | Bytes 20-21 | Bytes 22-25      |
| BANK1 | Bytes 42-43 | Bytes 44-45 | Bytes 46-49      |

Locating and Interpreting a PMM Bank Status Table (PBST)

The PBST is a data structure that records the size, location, and status of a DI's PMM memory. There is a single PBST created for each PMM board installed in the DI. Each PBST is 24 bytes long.

There is a pointer to the PBST in bytes 44 through 47 of the PMM board's MCST entry. The PBST for the PMM board in the MCST example in this chapter is displayed with the following subcommand:

```
DISM A=103352 RC=24(10)
```

Output from this subcommand is formatted as follows.

|                   |   |                  |  |  |  |  |  |  |  |  |  |
|-------------------|---|------------------|--|--|--|--|--|--|--|--|--|
| STARTING ADDRESS: |   | 103352           |  |  |  |  |  |  |  |  |  |
| HEX ADDR          |   | HEXADECIMAL DATA |  |  |  |  |  |  |  |  |  |
|                   |   | ASCII DATA       |  |  |  |  |  |  |  |  |  |
| 103352            | 0002 0000 2450 4D4D 315F 4241 4E4B 309E | \$PMM1_BANK0     |  |  |  |  |  |  |  |  |  |
| 103362            | 0000 0001 0000 0000                     |                  |  |  |  |  |  |  |  |  |  |

Each PMM has a single memory bank. Bytes 0 through 3 of the PBST indicate the size of that memory bank in bytes. The PMM board in the example has 128 K bytes of memory.

The name of the PMM memory bank is recorded in bytes 4 through 14 of the PBST entry. This name is of the form \$PMMn\_BANK0, where n is the board slot of the PMM board. The remaining length of the name field is blank-filled (hexadecimal 20).

Bytes 16 and 17 record the state of the PMM memory bank. See table 9-3.

Bytes 18 and 19 record the status of the PMM memory bank. See table 9-4.

## Analyzing DI Hardware Configurations Using NPA

NPA's CRECAR command reports on the DI hardware *and* software. This report is called CONFRP1. An example of CONFRP1 appears below (the actual report appears on two pages):

1  
88/07/26

NETWORK PERFORMANCE ANALYZER  
VERSION 1.10/5303

CDONET CONFIGURATION MESSAGES  
SORTED BY DI, DATE, AND TIME

CONFRP1 REPORT

TIME PERIOD = 00/01/01 0000 - 99/12/31 2400

SYSTEM IDS SELECTED = ALL

LOG IDS SELECTED = ALL

LOG IDS EXCLUDED = NONE

1  
REPORT DAY 88/07/23  
CONFRP1 REPORT  
PAGE 1

TITLE = AHD\_NDI\_10006D  
SID = 08002510006D

| DATE     | TIME        | SYSTEM ID    | LOG ID |
|----------|-------------|--------------|--------|
| 88/07/23 | 00 55 00230 | 08002510006D | 593    |

DI SYSTEM STATUS  
SYSTEM NAME = AHD\_NDI\_10006D  
SYSTEM ADDRESS = 08002510006D(16)  
BOOT VERSION NUMBER = 5303(16)  
SOFTWARE RELEASE LEVEL = 5303(16)  
NUMBER OF TASKS = 23  
FREE SMM MEMORY = 244946  
PERCENT CPU UTILIZATION = 31  
BUFFER STATE = GOOD  
MEMORY STATE = GOOD  
DATE AND TIME OF LAST RELOAD = 88/07/09 09.01.52

| BUFFER STATUS |               |                   |             |
|---------------|---------------|-------------------|-------------|
| TYPE          | TOTAL BUFFERS | AVAILABLE BUFFERS | BUFFER SIZE |
| DATA          | 1752          | 1091              | 144         |
| DESCRIPTOR    | 571           | 547               | 32          |

| SMM MEMORY STATUS |                  |         |                   |
|-------------------|------------------|---------|-------------------|
| TOTAL MEMORY      | AVAILABLE MEMORY | EXTENTS | DELOADABLE MEMORY |
| 1048576           | 244946           | 123     | 57146             |

| PMM MEMORY STATUS |                  |         |                   |
|-------------------|------------------|---------|-------------------|
| TOTAL MEMORY      | AVAILABLE MEMORY | EXTENTS | DELOADABLE MEMORY |
| 131072            | 4912             | 1       | 0                 |

| MPB RAM STATUS |                  |         |                   |
|----------------|------------------|---------|-------------------|
| TOTAL MEMORY   | AVAILABLE MEMORY | EXTENTS | DELOADABLE MEMORY |
| 16384          | 1794             | 1       | 0                 |

LARGEST SMM MEMORY EXTENT AVAILABLE = 218840

## Analyzing Line and Terminal Connections

CDCNET terminal users reach the network over communications lines or connections. Being able to analyze these connections is highly important for the following reason: CDCNET operators and analysts are in the business of providing a reliable service to terminal users.

The DI maintains a series of chained data structures to record information about terminals connected to a TDI or MTI. The end user's connection can be traced through these data structures with the help of network analysis tools.

The five types of line and terminal control blocks are listed in table 9-5. They are listed in order, from the most aggregated to the least aggregated (from the control block root for the whole DI to the control block for an individual data connection).

**Table 9-5. Summary of Terminal Control Blocks**


| Terminal Control Block                | Description   |
|---------------------------------------|---|
| Allocated Line Control Block (ALCB)   | The ALCB is the terminal control block root. It points to the first element in the CLCB chain (described next). There is one ALCB, and it remains in DI memory whether or not any lines are actually configured.  |
| Configured Line Control Block (CLCB)  | There is one CLCB for each one of the DI's configured lines. Each CLCB records information about the line attributes, the locations of its owning ALCB, the next element in the CLCB chain (if any), and the first element in the TCCB chain it controls (described next). This control block is built by the Line Control Module (LCM) whenever a new line is defined.   |
| Terminal Cluster Control Block (TCCB) | There is one TCCB for each set of clustered terminal devices (including sets of one terminal). Each TCCB maintains terminal accounting information and records the locations of its owning CLCB, the next element in the TCCB chain (if any), and the first element in the TDCB chain it controls (described next). There can be as many TCCBs as the number and capacities of configured lines in the DI permit. |

*(Continued)*

**Table 9-5. Summary of Terminal Control Blocks** *(Continued)*

| Terminal Control Block               | Description   |
|--------------------------------------|---|
| Terminal Device Control Block (TDCB) | <p>There is one TDCB for each configured terminal device. Each TDCB records the associated terminal's device status, definition, accounting, and protocol information. It also records the locations of its owning TCCB, the next element in the TDCB chain (if any), and the first element in the DCCB chain it controls (described next). The LCM builds a TDCB when a new terminal or batch device is defined. If the new terminal device is the first one for a terminal cluster, the LCM also constructs a TCCB.</p>   |
| Data Connection Control Block (DCCB) | <p>There is one DCCB for each data connection to a configured terminal device, whether unidirectional or bidirectional. Each DCCB records connection parameters and attributes, TDSM-defined values, the locations of its owning TDCB, the next element in the DCCB chain (if any), and an output buffer queue. Site administration sets the number of data connections allowed per terminal.</p> <p>There are two types of DCCBs, as follows:</p> <ul style="list-style-type: none"> <li>• <code>\$CDCNET_COMMAND</code>, for interactive connections</li> <li>• <code>\$INPUT/\$OUTPUT</code>, for batch and interactive connections</li> </ul> <p>For each terminal device, the LCM constructs the initial DCCB for the <code>\$CDCNET_COMMAND</code> connection. <code>\$INPUT/\$OUTPUT</code> DCCBs are constructed for terminal devices when connections are created by the terminal user. For batch devices, only one <code>\$INPUT/\$OUTPUT</code> DCCB is maintained per operational batch device.</p> |


Figure 9-3 shows the relationships among the terminal control blocks. There is always one ALCB. Various configurations of the other control blocks may exist within DI memory. The PST type is described earlier in this chapter, under Analyzing DI Hardware Configurations.



**Figure 9-3. Terminal Control Block Relationships**

Each of these control blocks has address fields that link it to its owning control block, its owned control blocks, and to the next control block of its type in the chain. The locations of these fields are consistent throughout the five control block types.

Figure 9-4 shows the locations of these fields. The exceptions are for the ALCB, which has neither an owning control block nor any peers, and the DCCB, which owns no control blocks. Bytes 6 through 9 of the DCCB structure point to an output buffer queue.



**Figure 9-4. Control Block Pointers**

The consistent construction of the various control block types results in distinct advantages when you are using the Dump Analyzer. You can use the Dump Analyzer's `DISPLAY_LINKED_LIST` subcommand to display a chain of one type of control block, or a succession of the terminal control block types.

The complete structure of each line and terminal control block type is described in appendix F.

## Analyzing Connections Using NETOU

A NETOU command called `DISPLAY_LINE_STATUS` (DISLS) causes the DI to display information from its line and terminal control blocks. DISLS must be enclosed in a `SENC` command, as in the following example:

```
SENC 'DISLS' TDI_A1
```

Output from this command is formatted as follows:

```
FROM TDI_A1                      33010

Line Status
line name                        line   line tip   line physical
                                state  type  name  speed device name
LINE00                          active ded  async 19200 $LIM0_PORT0
LINE01                          active ded  async 19200 $LIM0_PORT1
LINE02                          active ded  async 9600  $LIM0_PORT2
LINE03                          active ded  async 9600  $LIM0_PORT3

.

LINE70                          active ded  async 9600  $LIM7_PORT0
LINE71                          active ded  async 9600  $LIM7_PORT1
LINE72                          active ded  async 9600  $LIM7_PORT2
LINE73                          active ded  async 9600  $LIM7_PORT3
```

The preceding display is an example of the summary display option, which is the default for this command. DISLS has two other display options: `EXPANDED` and `DETAIL`.

The `EXPANDED` option displays the connected device name(s) for each line. It is selected as in the following example:

```
SENC 'DISLS DO=E' TDI_A1
```

Output from this command is formatted as follows:

```
FROM TDI_A1                      33010

Line Status

LINE00                          tip name: bsc3270
device name: REAL_CLUSTER_CONTROLLER address: 0 /0 state: not ready

LINE01                          tip name: bsc3270
device name: $CONSOLE_3000A1_010000 address: 0 /0 state: active

LINE02                          tip name: bsc3270

LINE03                          tip name: bsc3270

.

LINE70                          tip name: async
device name: $CONSOLE_3000A1_700000 address: 0 /0 state: active

LINE71                          tip name: async
device name: $CONSOLE_3000A1_710000 address: 0 /0 state: active

LINE72                          tip name: async
device name: $CONSOLE_3000A1_720000 address: 0 /0 state: active

LINE73                          tip name: async
device name: $CONSOLE_3000A1_730000 address: 0 /0 state: active
```



The **DETAIL** option provides information about each of the connections. It also indicates with a pointer ( > ) which connection is currently active. The **DETAIL** option is selected as follows:

```
SENC 'DISLS DO=D' TDI_A1
```

Output from this command is formatted as follows:

```
FROM TDI_A1                      33010

Line Status

REAL_CLUSTER_CONTROLLER          line name: LINE00
> service name: $CDCNET_COMMAND  INTERACTIVE
input state: active      output state: send      output queued  0 /0

$CONSOLE_3000A1_010000          line name: LINE01
> service name: $CDCNET_COMMAND  INTERACTIVE
input state: active      output state: send      output queued  0 /0

.
.
.

$CONSOLE_3000A1_710000          line name: LINE71
> service name: $CDCNET_COMMAND  INTERACTIVE
input state: active      output state: send      output queued  0 /0

$CONSOLE_3000A1_720000          line name: LINE72
> service name: $CDCNET_COMMAND  INTERACTIVE
input state: active      output state: send      output queued  0 /0

$CONSOLE_3000A1_7300000000      line name: LINE73
service name: $CDCNET_COMMAND  INTERACTIVE
input state: off      output state: send      output queued  0 /0
service name: NOS875907        INTERACTIVE
input state: off      output state: hold      output queued  0 /0
service name: NOS990102        INTERACTIVE
input state: off      output state: hold      output queued  0 /0
service name: NOS830605        INTERACTIVE
input state: off      output state: hold      output queued  0 /0
> service name: NOS174817      INTERACTIVE
input state: active      output state: send      output queued  0 /0
```

## Analyzing Connections Using the Dump Analyzer

The Dump Analyzer can be used to locate and display the actual terminal connection control blocks from a DI dump file. It is also equipped with a subcommand, called `DISPLAY_LINE_CONTROL_BLOCK` (DISLCB), that displays fields from the CLCB for one or for all lines.

### DISPLAY\_LINE\_CONTROL\_BLOCKS Subcommand

The following subcommand displays CLCB information from the dump file for LINE00.

```
DISLCB LN=LINE00
```

Output from this subcommand is formatted as follows:

```
CONFIGURED LINE CONTROL BLOCK    AT ADDRESS    1B9712(16)

POINTER TO FIRST TCCB            1850B2(16)
POINTER TO ACTIVE LCB            1A1470(16)
POINTER TO NEXT CLCB            1B33C4(16)
OPTIONAL TIP EXTENSION POINTER    29C634(16)
LINE NAME                        LINE00
LINE INTERFACE MODULE            0
PORT NUMBER                      0
TIP TYPE                         ASYNC TIP
LINE TYPE                        SWITCHED
FRAMING TYPE                     ASYNC
CARRIER TYPE                   CONSTANT
LINE SPEED                      19200
ASYNC AUTOREC TYPE              NONE
CONNECT TIME TIMEOUT            30
DISCONNECT TIMEOUT              30
USER CONNECTION LIMIT           4
EIA FLOW CONTROL                FALSE
EFC CLOCKING                    0
LCSM TASK ID                    0(16)
TIP TASK ID                     1CA9FA(16)
CONFIGURATION CMD QUEUE          0(16)
ADD CB COUNT                    0
LCM STATE                       VALUE =      8(16)
LINE DOWN REASON                VALUE =     FF(16)
AUTOREC TIP TYPE                 ASYNC TIP
AUTOREC LINE SPEED              26
AUTOREC CODE SET                AUTO
AUTOREC PARITY                  MARK
CONNECT TIMER                   0
LCSM LINE ENABLE STATUS         TRUE
LCSM STATE                      VALUE =     4(16)
LCSM AUTOREC STATE              VALUE =     0(16)
```

The following subsections describe how to locate and display the actual line control blocks from a DI dump file. The memory displays can be interpreted using the tables provided in appendix F.

## Locating the ALCB

A 10-byte-long ALCB is created in TDI or MTI memory when a line is first configured for the DI. There is an entry point in DI memory, called LCMX, that corresponds with the location of the ALCB.

The ALCB can be displayed using the following Dump Analyzer subcommand:

```
DISM A=LCMX RC=0A
```

The ALCB can also be located by taking the following steps (this is a longer, but perhaps more informative, means of locating the ALCB):

1. Display the first four bytes of the software status service access point (SAP) table using the following Dump Analyzer subcommand:

```
DISM A=SOFTWARE_STATUS_SAP_TABLE RC=4
```

An example of the output from this subcommand follows. These four bytes are a pointer to the first status SAP.

| STARTING ADDRESS | 11F122           |            |
|------------------|------------------|------------|
| HEX ADDR         | HEXADECIMAL DATA | ASCII DATA |
| 11F122           | 0010 690E        | 1          |

2. Display a linked list of the status SAP entries using the following Dump Analyzer subcommand:

```
DISLL A=first_status_sap_entry LC=0A BC=20 RC=8
```

first\_status\_sap\_entry is equal to the address found in the software status SAP table.

Following is an example of the display from this subcommand. Bytes 17 through 31 of each entry is the SAP entry name. Its ASCII representation appears on the right of the display, under the heading ASCII DATA.

```
DISPLAY_LINKED_LIST
START ADDRESS: 10690E
```

| HEX ADDR | HEXADECIMAL DATA                        | ASCII DATA      |
|----------|---|-----------------|
| 10690E   | 0001 0013 7162 0010 7B2A 0010 6C06 000D | qb {* 1         |
| 10691E   | 584E 535F 5452 414E 5350 4F52 5443 4B20 | OSI_TRANSPORTCK |

ADDRESS OF NEXT ELEMENT: 106C06

| HEX ADDR | HEXADECIMAL DATA                        | ASCII DATA      |
|----------|---|-----------------|
| 106C06   | 0002 0013 ADF2 0010 7C0E 0010 6F24 000A | _ c\$           |
| 106C16   | 434F 4D4D 414E 445F 4D45 5354 4143 4B20 | COMMAND_MESTACK |

ADDRESS OF NEXT ELEMENT: 106F24

| HEX ADDR | HEXADECIMAL DATA                        | ASCII DATA       |
|----------|---|------------------|
| 106F24   | 0003 0014 1962 0010 7CF2 0019 2740 0017 | b _ '@           |
| 106F34   | 4C4F 475F 5355 5050 4F52 545F 4150 504C | LOG_SUPPORT_APPL |

```

ADDRESS OF NEXT ELEMENT: 192740

HEX ADDR          HEXADECIMAL DATA          ASCII DATA
192740 0004 0012 5F98 0019 3B24 001A E632 0007      _;$ 2
192750 524F 5554 494E 4700 0000 0007 0000 0015  ROUTING

ADDRESS OF NEXT ELEMENT. 1AE632

HEX ADDR          HEXADECIMAL DATA          ASCII DATA
1AE632 0005 001A AC7E 0000 0000 001E BD98 0003      ~
1AE642 4F53 4100 022C 322C FFDC 4A01 6632 3D7C  OSA .2, J f2=_

ADDRESS OF NEXT ELEMENT 1EBD98

HEX ADDR          HEXADECIMAL DATA          ASCII DATA
1EBD98 0006 001E B18E 001E A812 0000 0000 000F
1EBDA8 4C43 4D5F 4C49 4E45 5F53 5441 5455 5332  LCM_LINE_STATUS2

```

The SAP entry named LCM\_LINE\_STATUS leads you to the ALCB. Bytes 2 through 5 of this entry record the address of a software status table. The address is 1EB18E(16) in the example.

If there is no LCM\_LINE\_STATUS entry, the terminal support software has not been loaded into this DI.

Display the first four bytes of the software status table for the LCM\_LINE\_STATUS SAP entry with the following Dump Analyzer subcommand:

```
DISM A=lcm_software_status_table RC=4
```

lcm\_software\_status\_table is equal to the address found in the LCM\_LINE\_STATUS SAP entry.

Following is an example of the output from this subcommand. These four bytes indicate the starting address of the ALCB.

```

STARTING ADDRESS 1EB18E

HEX ADDR          HEXADECIMAL DATA          ASCII DATA
1EB18E 001D C2EE

```

Once its address is determined, the 10-byte-long ALCB can be displayed using the following Dump Analyzer subcommand:

```
DISM A=alcb_address RC=0A
```

alcb\_address is the address found in the software status table for LCM\_LINE\_STATUS.

Following is an example of the display from this subcommand.

```

START ADDRESS: 1DC2EE

HEX ADDR          HEXADECIMAL DATA          ASCII DATA
1DC2EE 0100 414C 4342 0022 43E6                  ALCB

```

The abbreviated name of the control block is recorded in bytes 2 through 5. Bytes 6 through 9 point to the first entry in the CLCB chain. All of the fields in the ALCB record are described in appendix F of this manual.

Locating the CLCB Chain

There is a pointer to the first CLCB in bytes 6 through 9 of the ALCB.

There is also a pointer to the first CLCB for an LCM-controlled port in bytes 20 through 23 of the associated PST entry. To verify that a port is owned by LCM, look for the value 0003 in bytes 18 and 19 of the PST entry in question. For a complete description of the PST and its entries, see the section of this chapter titled Analyzing DI Hardware Configurations Using the Dump Analyzer.

To display the first CLCB associated with the ALCB of the previous example, use the following subcommand:

```
DISM A=2243E6 RC=9A
```

Output from this subcommand is formatted as follows:

| STARTING ADDRESS |                  | 2243E6 |      |      |      |      |      |      |            |       |            |   |   |  |
|------------------|------------------|--------|------|------|------|------|------|------|------------|-------|------------|---|---|--|
| HEX ADDR         | HEXADECIMAL DATA |        |      |      |      |      |      |      |            |       | ASCII DATA |   |   |  |
| 2243E6           | 0202             | 434C   | 4342 | 0028 | 008A | 001F | BD2E | 0022 | CLCB ( = . |       |            |   |   |  |
| 2243F6           | 4ABA             | 0002   | 42C6 | 001F | 1462 | 01F2 | 0403 | 01C2 | J          | BF    | b          | r | B |  |
| 224406           | 0000             | 0201   | 0000 | 2580 | 0202 | 0101 | 0100 | 0004 | %          |       |            |   |   |  |
| 224416           | 0002             | 0000   | 0000 | 0000 | 0028 | 133E | 0000 | 0000 | ( >        |       |            |   |   |  |
| 224426           | 001F             | BED0   | 0000 | 0000 | 2580 | 08FF | 0200 | 0200 | >P         | %     |            |   |   |  |
| 224436           | 00C0             | 0400   | 0000 | 0000 | 0C00 | 0000 | 0000 | 0000 | @          | "Cf & |            |   |   |  |
| 224446           | 0000             | 0022   | 43E6 | 0000 | 0000 | 0000 | 00A6 | 0093 |            |       |            |   |   |  |
| 224456           | 001F             | 7860   | 0000 | 0000 | 0001 | 17F4 | 0000 | 0000 | x          | t     |            |   |   |  |
| 224466           | 0000             | 0000   | 0100 | 0000 | 1D7C | 0000 | 0398 | 0000 |            |       |            |   |   |  |
| 224476           | 2DEC             | 0000   | 01F9 | 0000 | 0000 | -1 y |      |      |            |       |            |   |   |  |

To display a linked list of four CLCBs, use the following subcommand:

```
DISLL A=first_clcb LO=0F BC=9A RC=4
```

first\_clcb is the address of the first CLCB in the linked list.

The abbreviated name of the control block is recorded in bytes 2 through 5. Bytes 6 through 9 point to the first TCCB owned by this CLCB. Bytes 10 through 13 point to the system's ALCB. Bytes 14 through 17 point to the next CLCB in the CLCB chain.

**Locating the TCCB Chain**

The address of the first in a chain of TCCBs is in bytes 6 through 9 of the CLCB that owns the chain.

To display the first TCCB associated with the CLCB of the previous example, use the following subcommand:

```
DISM A=28008A RC=30
```

Output from this subcommand is formatted as follows:

```
STARTING ADDRESS:  28008A

HEX ADDR          HEXADECIMAL DATA          ASCII DATA
28008A  0203 5443 4342 0028 0738 0022 43E6 0000  TCCB ( 8 "Cf
28009A  0000 0000 0000 0000 0000 0000 0268 0000      h
2800AA  0000 0000 0000 0000 0000 0000 0000 0000
```

To display a linked list of four TCCBs, use the following subcommand:

```
DISLL A=first_tcb LO=0F BC=30 RC=4
```

0

first\_tcb is the address of the first TCCB in the linked list.

The abbreviated name of the control block is recorded in bytes 2 through 5. Bytes 6 through 9 point to the first TDCB owned by this TCCB. Bytes 10 through 13 point to the owning CLCB. Bytes 14 through 17 point to the next TCCB in the TCCB chain.

Locating a TDCB Chain

The address of the first TDCB in a chain of TDCBs owned by a TCCB is in bytes 6 through 9 of the owning TCCB.

To display the first TDCB associated with the TCCB of the previous example, use the following subcommand:

```
DISM A=280738 RC=7C
```

Output from this subcommand is formatted as follows:

| STARTING ADDRESS |  | 280738           |  |  |  |  |  |  |  |  |  |  |  |  |  |            |  |            |  |
|------------------|--|------------------|--|--|--|--|--|--|--|--|--|--|--|--|--|------------|--|------------|--|
| HEX ADDR         |  | HEXADECIMAL DATA |  |  |  |  |  |  |  |  |  |  |  |  |  |            |  | ASCII DATA |  |
| 280738           | 0204 5444 4342 0028 067A 0028 008A 0000      |                  |  |  |  |  |  |  |  |  |  |  |  |  |  | TDCB ( z ( |  |            |  |
| 280748           | 0000 0000 0000 0000 0000 0000 0000 01E6      |                  |  |  |  |  |  |  |  |  |  |  |  |  |  | f          |  |            |  |
| 280758           | 0312 0201 01C2 0000 0000 0000 0028 067A 0028 |                  |  |  |  |  |  |  |  |  |  |  |  |  |  | B ( z (    |  |            |  |
| 280768           | 067A 0000 0000 8000 0000 0268 0000 0537      |                  |  |  |  |  |  |  |  |  |  |  |  |  |  | z h 7      |  |            |  |
| 280778           | 0000 0036 0000 0451 0000 006F 0000 0001      |                  |  |  |  |  |  |  |  |  |  |  |  |  |  | 6 Q o      |  |            |  |
| 280788           | 0000 0020 2020 2001 0D20 010A 2001 0C20      |                  |  |  |  |  |  |  |  |  |  |  |  |  |  |            |  |            |  |
| 280798           | 2020 2020 2000 0000 0000 0000 1850 0025      |                  |  |  |  |  |  |  |  |  |  |  |  |  |  | P %        |  |            |  |
| 2807A8           | 000A 0D08 1800 0201 0002 0000                |                  |  |  |  |  |  |  |  |  |  |  |  |  |  |            |  |            |  |

To display a linked list of four TDCBs, use the following subcommand:

```
DISLL A=first_tdcbb LO=0F BC=7C RC=4
```

first\_tdcbb is the address of the first TDCB in the linked list.

The abbreviated name of the control block is recorded in bytes 2 through 5. Bytes 6 through 9 point to the first DCCB owned by this TDCB. Bytes 10 through 13 point to the owning TCCB. Bytes 14 through 17 point to the next TDCB in the TDCB chain.

## Locating a DCCB Chain

The address of the first DCCB in a chain of DCCBs owned by a TDCB is in bytes 6 through 9 of the owning TDCB.

To display the first DCCB associated with the TDCB of the previous example, use the following subcommand:

```
DISM A=28067A RC=56
```

Output from this subcommand is formatted as follows:

| STARTING ADDRESS |   | 28067A       |  |
|------------------|---|--------------|--|
| HEX ADDR         | HEXADECIMAL DATA                        | ASCII DATA   |  |
| 28067A           | 0205 4443 4342 0026 D94C 0028 0738 0000 | DCCB &YL ( 8 |  |
| 28068A           | 0000 0000 0000 0301 0000 0101 0000 0000 |              |  |
| 28069A           | 0000 0000 0000 0100 0000 0000 0000 0000 |              |  |
| 2806AA           | 0000 0000 0000 0000 0028 133E 0205 0000 | ( >          |  |
| 2806BA           | 4800 8000 00A0 00FF 020D 8D2D 2002 0D8D | H            |  |
| 2806CA           | 2020 0100 2040                          | @            |  |

To display a linked list of two DCCBs, use the following subcommand:

```
DISLL A=first_dccb L0=0F BC=56 RC=2
```

first\_dccb is the address of the first DCCB in the linked list.

The abbreviated name of the control block is recorded in bytes 2 through 5. Bytes 6 through 9 point to an output buffer queue for this connection. Bytes 10 through 13 point to the owning TDCB. Bytes 14 through 17 point to the next DCCB in the DCCB chain.



## Displaying the Output Queue

The address of the data connection output queue is in bytes 6 through 9 of the owning DCCB. Use the Dump Analyzer's `DISPLAY_BUFFER_CHAIN` subcommand to display the associated data.

To display the output queue associated with the DCCB of the previous example, use the following subcommand:

```
DISBC 26D94C
```

Output from this subcommand is formatted as follows:

### BUFFER CHAIN DISPLAY

```
DATA_DESCRIPTOR 26D94C(16)  NEXT_DESCRIPTOR 24BF36(16)
NEXT_MESSAGE    2605C6(16)  THE_DATA      26D8B4(16)
OFFSET          8B(16)      COUNT_BUFFER   5(16)
COUNT_MESSAGE  2A(16)      USAGE_DESCRIPTOR 0(16)
```

```
USAGE COUNT      0(16)
```

```
DATA AT THE_DATA
```

```
26D8B4 0000 0121 0404 00FF FF00 2A42 0500 00A2      '      *B
26D8C4 0108 0025 1000 8303 FF00 0CA0 0108 0025      %      %
26D8D4 3000 C04A 0B80 0049 EA4A 2500 0102 EA02 0 J I J%
26D8E4 ED87 1221 2313 2719 9000 000F 020D C000      !# '
26D8F4 0108 0025 3001 0BE8 212D 4803 0140 0024      %0 ' -H @ $
26D904 5553 4552 5F50 524F 4301 CC04 0400 FFFF USER_PRCC
26D914 0033 C012 0835 0611 0900 25FF FFFF 0014 3 5 %
26D924 0000 A201 0800 2510 0083 0014 0101 0F00      %
26D934 0000 2455 5345 525F 5052 4F43 [0001 0000 $USER_PROC
26D944 2E]
```

```
DATA_DESCRIPTOR 24BF36(16)  NEXT_DESCRIPTOR 0(16)
NEXT_MESSAGE    0(16)      THE_DATA      24BE9E(16)
OFFSET          1(16)      COUNT_BUFFER   25(16)
COUNT_MESSAGE  0(16)      USAGE_DESCRIPTOR 0(16)
```

```
USAGE COUNT      0(16)
```

```
DATA AT THE_DATA:
```

```
24BE9E 0000 [0A0D 4578 7065 6374 696E 6720 636F      Expecting co
24BEAE 6D6D 616E 642C 2066 6F75 6E64 2048 495F      mmand, found H1_
24BEBE 4A4F 4E41 533A 2E] JONAS:.
```

```
DATA_DESCRIPTOR 2605C6(16)  NEXT_DESCRIPTOR 0(16)
NEXT_MESSAGE    2714F8(16)  THE_DATA      22D370(16)
OFFSET          7B(16)      COUNT_BUFFER   15(16)
COUNT_MESSAGE  15(16)      USAGE_DESCRIPTOR 0(16)
```

```
USAGE COUNT      D(16)
```

```
DATA AT THE_DATA:
```

```
22D370 0000 03C6 0404 00FF FF00 2AC4 0500 00A2      *
22D380 0108 0025 1000 8303 FD00 0000 6308 0025      %      c %
22D390 3001 6161 9980 00FE D34D 4F00 0100 0200 0 aa MO
22D3A0 0925 FFFF FF00 0000 0000 0000 0000 0000      %
22D3B0 0000 0000 0000 0000 0000 0000 0000 0000
22D3C0 0000 0000 0000 0000 0000 0000 0000 0000
22D3D0 0001 E201 E404 0400 FFFF 002A 5010 4C01      *P L
22D3E0 A004 0400 FFFF 0043 C005 0DC0 [0001 0000      C
22D3F0 2E49 6E70 7574 2064 6973 6361 7264 6564 .Input discarded
22D400 2E]
.
.
.
.
.
.
.
.
```

## Analyzing Connections Using NPA

NPA generates statistical reports about connections and terminals. These report types are summarized in table 9-6. Examples of all of the following reports can be found in chapter 6, NPA Reports and Report Formats.

**Table 9-6. NPA Reports**

| <b>NPA Report</b> | <b>Description</b>  |
|-------------------|---|
| CONNRP1           | Hourly connection report on the number of connections initiated and terminated, by service. |
| CONNRP2           | Daily connection report on the number of connections initiated and terminated, by service.  |
| TELNRP1           | Hourly TELNET connection report.  |
| TELNRP2           | Daily TELNET connection report.   |
| TERMRP1           | Hourly terminal report on block input and output.   |
| TERMRP2           | Hourly terminal statistics report on characters input and output.                           |
| X25CRP1           | X.25 connection statistics report sorted by DI and time.                                    |
| X25CRP2           | X.25 connection statistics report sorted by service name and DI on a daily basis.           |



# Remote Line Monitor Utility (RLM) 10

---

|  |       |
|--|-------|
| Starting a Remote Line Monitor Session ..... | 10-1  |
| Main Menu Screen .....                       | 10-2  |
| Screens .....                                | 10-4  |
| Setup Screen (Setup) .....                   | 10-4  |
| File Management (FilMgt) .....               | 10-6  |
| Record (Record) .....                        | 10-7  |
| Display (Dis) .....                          | 10-8  |
| Display and Record (DisRec) .....            | 10-8  |
| Format and Edit (FormEd) .....               | 10-9  |
| Edit (Edit) .....                            | 10-11 |
| Data Integrity .....                         | 10-12 |
| Data Formats .....                           | 10-12 |
| Unformatted Data (Recorded) .....            | 10-12 |
| Formatted Data .....                         | 10-13 |
| Display Formats .....                        | 10-13 |
| ASYNCR-ASCII Display Format .....            | 10-14 |
| ASYNCR-HEX Display Format .....              | 10-16 |
| HASP-ASCII Display Format .....              | 10-18 |
| HASP-HEX Display Format .....                | 10-20 |
| Security .....                               | 10-21 |
| Cancelling the DI Remote Line Monitor .....  | 10-21 |



The NOS/VE Remote Line Monitor records and/or displays all received and transmitted characters on a LIM and port that are supported by the standard CDCNET CIM Firmware and that use protocols defined for Remote Line Monitor (only ASYNC and HASP protocols have been defined).

Remote Line Monitor has two parts, the Remote Line Monitor utility, a NOS/VE application, and the CDCNET Remote Line Monitor TIP. Only the NOS/VE application is discussed in this chapter.

Commands to define and delete the NOS/VE application are included in `MANAGE_APPLICATION_DEFINITIONS` and requires `NETWORK_APPLICATION_MANAGEMENT` capability.

You must be validated to use the `NETWORK_OPERATOR_UTILITY` to use the Remote Line Monitor. To use the Remote Line Monitor, enter the following commands:

```
CREATE_COMMAND_LIST_ENTRY . .  
ENTRY=: $SYSTEM.$SYSTEM.REMOTE_LINE_MONITOR.LMF$COMMAND_LIBRARY  
REMOTE_LINE_MONITOR
```

Only one communication line can be monitored at a time in a Remote Line Monitor session. Only one line at a time (a CDCNET Remote Line Monitor TIP restriction) may be monitored in any given DI.

## Starting a Remote Line Monitor Session

The following command starts a Remote Line Monitor session.

```
REMOTE_LINE_MONITOR, REMLM, RLM  
STATUS = status variable
```

*STATUS*

The normal NOS/VE status parameter.

## Main Menu Screen

When the REMOTE\_LINE\_MONITOR starts, it displays the Main Menu screen which shows the various functions available for a Remote Line Monitor session. See figure 10-1.

| REMOTE LINE MONITOR        |           | Lines 1 to 19 of 19               |           |
|----------------------------|-----------|-----------------------------------|-----------|
| FUNCTION KEYS              |           | CURRENT SETTINGS                  |           |
| MAINTENANCE                |           | Monitored System = AHR_TDI_300784 |           |
| SF1 to - Setup             |           | Monitored Lim = 3                 |           |
| F1 to - Manage files       |           | Monitored Port = 1                |           |
| MONITORING                 |           | Forward Timer = 2000              |           |
| F2 to - Record             |           | Line Protocol = ASYNC             |           |
| F3 to - Display            |           | Display Format = ASCII            |           |
| F4 to - Display and Record |           | Display Width = 80                |           |
| ANALYSIS                   |           |                                   |           |
| F7 to - Format and Edit    |           |                                   |           |
| F8 to - Edit               |           | { Use Setup to change settings. } |           |
| f1 Setup                   | f2 Record | f3 Dis                            | f4 DisRec |
| f5 HELP                    | f6 Quit   | f7 FormEd                         | f8 Edit   |

Figure 10-1. Main Menu Screen

The following table describes the function keys available on the Main Menu screen.

| Key      | Description   |
|----------|---|
| Shift F1 | Displays the Setup screen where you set values to indicate the line to monitor, the forwarding timeout value for the Remote Line Monitor TIP, the protocol in use on the monitored line, the display format used for formatting line data, and the page width for formatted data. See Setup Screen section later in this chapter. |
| F1       | Starts the NOS/VE File Manager. See File Management section later in this chapter.  |
| F2       | Starts monitoring a remote line and writes the unformatted data to a file. See Record section later in this chapter.  |
| F3       | Starts monitoring a line and displays the formatted data to the terminal. See Display section later in this chapter.  |
| F4       | Starts monitoring a line and displays the formatted data to the terminal and writes the unformatted data to a file. See Record and Format and Edit sections later in this chapter for file naming conventions.  |
| F5       | Displays a help screen with a row of function keys. Press the corresponding keyboard function key for the subject about which you want help; this displays a help screen for that function. Some of the function keys have both brief and full help available.  |
| F6       | Ends the Remote Line Monitor session. Terminates the utility.   |
| F7       | Formats a file of recorded line data and starts a NOS/VE File Editor session with the formatted result file. See Format and Edit section later in this chapter.   |
| F8       | Starts a NOS/VE File Editor session with a formatted result file. See Edit section later in this chapter.   |



## Screens

The following subsections describe the screens that you can go to by using the function keys on the Main Menu screen.

Keys not under the direct control of the REMOTE\_LINE\_MONITOR are defined by various screen interfaces that the Remote Line Monitor uses and are not discussed in this chapter. If you need help with these keys, refer to Creating Interactive Procedures and Utilities section of the NOS/VE System Usage manual, or use the HELP key while in these screen interfaces to obtain help.

### Setup Screen (Setup)

The Setup screen (figure 10-2) is where you set the values for controlling the remote line monitoring and evaluating the data. This screen is the first screen displayed when you start a Remote Line Monitor session if you have not previously used Remote Line Monitor and/or if Monitored System=UNKNOWN. You can reach this screen by pressing the Setup function key (Shift F1) on the Main Menu screen.

The Setup screen is a text-based interface with a title bar labeled "SETUP". It contains seven numbered configuration items, each with a range and a current value. Below the list is a prompt "Press f6 to accept". At the bottom of the screen is a row of function key labels: f1, f2, f3, f4, f5, f6, f7, f8. The labels for f1, f4, f6, and f7 contain text: "CtrlEol", "Help", "Cancel OK", and "Zoom" respectively. The other labels are empty.

| Item                | Range         | Value   |
|---------------------|---------------|---------|
| 1. Monitored System | (DI name):    | UNKNOWN |
| 2. Monitored Lim    | (0..7):       | 0       |
| 3. Monitored Port   | (0..7):       | 0       |
| 4. Forward Timer    | (200..30000): | 2000    |
| 5. Line Protocol    | (ASYNC,HASP): | ASYNC   |
| 6. Display Format   | (ASCII,HEX):  | ASCII   |
| 7. Display Width    | (40..132):    | 80      |

Press f6 to accept

f1 CtrlEol f2 f3 f4 Help f5 f6 Cancel OK f7 Zoom f8

Figure 10-2. Setup Screen

The following table describes the values of the current settings on the Setup screen:

| Value            | Description   |
|------------------|---|
| Monitored System | The name of the monitored DI.   |
| Monitored Lim    | The LIM number on the DI with the monitored port.   |
| Monitored Port   | The port number on the LIM.   |
| Forward Timer    | <p>The time period, specified in milliseconds, that is to be used by the Remote Line Monitor TIP as the criterion for deciding when to forward buffered data. The Remote Line Monitor TIP forwards monitored data to the Remote Line Monitor NOS/VE application whenever either the timer specified by this parameter expires or when the TIP's internal buffer, approximately 1400 bytes, is full.</p> <p>Decreasing the Forward Timer value increases the frequency at which data packets are forwarded. You might want to do this to increase the apparent real-time updating of your display or to obtain more frequent millisecond clock timings in the recorded data. However, this can cause congestion on the network by increasing the number of network packets on the network.</p> <p>Increasing the Forward Timer value decreases the frequency at which data packets are forwarded and increases the amount of data in the packets (until the buffer limit is reached). You might want to do this when you don't require precise timing information and when you want to prevent congestion on the network and minimize the loss of data due to flow control.</p> <p>If most data packets are forwarded because the TIP buffer is full, then changing the Forward Timer value has little or no effect unless decreased below the time it takes to fill the TIP buffer.</p> |
| Line Protocol    | The protocol in use on the monitored line. This corresponds to the line TIP. This is not verified by the utility and affects only the formatting of data.   |
| Display Format   | The format in which monitored data is displayed to the terminal or formatted to a result file.  |
| Display Width    | The maximum number of columns of formatted data displayed to the terminal or formatted to a result file. The number of characters displayed may not be as wide as specified since symbolic characters and hex characters are not broken across lines.   |

Values set on this screen are saved until changed, including between Remote Line Monitor sessions. These values and others maintained internally by the utility are saved in file \$USER.\$REMOTE\_LINE\_MONITOR.CONFIGURATION.

## File Management (FilMgt)

The File Management function key enters the NOS/VE File Manager so you can maintain your Remote Line Monitor files. See figure 10-3.

When NOS/VE File Manager starts, it is positioned in the catalog hierarchy as close to the current files being used as the Remote Line Monitor can deduce from the environment. If a system is known, then the catalog containing files for that system is shown; otherwise, the \$USER.\$REMOTE\_LINE\_MONITOR catalog is shown. Function key F6 (Quit) ends the File Manager session and returns you to the Remote Line Monitor Main Menu.




Figure 10-3. File Management Screen

The following shows an example of the Remote Line Monitor catalog structure:

```
$bcm {user}
  $remote_line_monitor
    ahl_tdi_3006b9 { system name }
      formatted
        12p3_hasp_900222_1005am_hex
        12p3_hasp_900222_1009am_ascii
        12p3_hasp_900224_1021am_hex
        12p3_hasp_900224_1024am_hex
        13p0_async_900108_1005am_ascii
        13p0_async_900108_1005am_hex
      recorded
        12p3_hasp_900222_1009am
        12p3_hasp_900224_1021am
        12p3_hasp_900224_1024am
        12p3_hasp_900224_1032am
        13p0_async_900108_1005am
    configuration { settings saved between remote line monitor sessions }
    rlm_tdi { system name }
      formatted
        12p3_hasp_900222_1005am_hex
        12p3_hasp_900222_1009am_ascii
        13p0_async_900108_1005am_ascii
        13p0_async_900108_1005am_hex
      recorded
        12p3_hasp_900222_1009am
        13p0_async_900108_1005am
```

## Record (Record)

The Record function key starts monitoring a remote line as specified by the system, LIM, and port values from the Setup screen and writes the unformatted data to a file.

The recorded data file is located in catalog:

`$USER.$REMOTE_LINE_MONITOR.system.RECORDED`

where *system* is the value of system from the Setup screen.

The file is named `LlimPport_protocol_date_time`.

where *lim*, *port*, and *protocol* are values from the Setup screen. Date and time are determined at the time the Record function starts. File naming is done automatically by the Remote Line Monitor; you cannot change or alter it. However, you can change the file names later using File Management.

While data is recorded, the Remote Line Monitor displays the size of the file receiving the data. Function key F6 (Stop) terminates recording and returns you to the Remote Line Monitor Main Menu.

Each time the file size is updated on the display, the time (displayed on the title line) is also updated. The refresh rate is approximately 10 seconds.

## Display (Dis)

The Display function key starts monitoring a remote line and displays formatted data at your terminal. The data format is determined by values set on the Setup screen. Default is ASCII.

As soon as the connection between the Remote Line Monitor on NOS/VE and the Remote Line Monitor on the DI is established, the DI sends an elapsed time of 0 millisecond with no data. Your screen clears and displays <0 milliseconds elapsed>, letting you know that NOS/VE and the DI are communicating. This is important because it lets you know that the connection is made in cases where there is no data on the line being monitored.

To stop the display and return to the Main Menu screen, enter a terminate break.

---

### NOTE

Remote Line Monitor is in screen mode and only an Attention Character with ATTENTION\_CHARACTER\_ACTION of 2 to 9 or a Break Key with a BREAK\_KEY\_ACTION of 2 to 9 terminates the display and returns you the Main Menu screen.

In the event that both ATTENTION\_CHARACTER\_ACTION and BREAK\_KEY\_ACTION have values outside the range of 2 to 9, the sequence of <break> <ctrl-x>%2 performs the same function.

---

To use the hold page function to control viewing displayed data, you must select the hold page attributes before starting the display function (you can do this from the home line or before entering Remote Line Monitor).

See Data Integrity later in this chapter for a discussion of minimizing potential for lost data when using the display function. See Formatted Data later in this chapter for examples and explanations of formatted data.

## Display and Record (DisRec)

The Display and Record function key works the same as the Display function key, except that it records unformatted data to a file and displays formatted data to the terminal.

## Format and Edit (FormEd)

The Format and Edit function key formats a file and then starts a NOS/VE File Editor session so you can edit the file. You begin by deciding which recorded file to format from a file selection screen. The file selection screen is positioned at the last recorded data file. If no last recorded data file exists or the Setup screen has been changed, then the file selection screen is positioned at the first file in the catalog containing the recorded data files for the specified system. If the specified system catalog does not exist, then the file selection screen shows the \$USER.\$REMOTE\_LINE\_MONITOR catalog. Use the UpCtlg and View functions of the file selection screens to find and select different recorded data files. Position cursor on the desired file and press function key F6 (Accept) to select the file.

After you press function key F6, the utility begins formatting. While the file is formatting, a display continuously shows the current size of the file being formatted. When formatting completes, a NOS/VE File Editor session begins using the formatted file. Enter function key F6 (Stop) to terminate formatting before all data has been processed and to return you to the Main Menu screen.

### NOTE

---

The formatted file is approximately twice the size of the recorded file.

---

The formatted data file is located in catalog:

`$USER.$REMOTE_LINE_MONITOR.system.FORMATTED`

where *system* is the value of system from the Setup screen.

The file is named `.LlimPport_protocol_date_time_format`.

where *format* is the display format from the Setup screen appended to the recorded file name.

Each time the file size is updated on the display, the time (displayed on the title line) is also updated. The refresh rate is approximately 10 seconds.

The formatted file name is the same as the recorded file name, except that the formatted file is located in the catalog FORMATTED, and a display format extension (ASCII or HASP) has been added to the end of the name. See figure 10-4.

See Data Integrity later in this chapter for a discussion of minimizing lost data when using the display function.

See Formatted Data later in this chapter for examples and explanations of data.

| REMOTE LINE MONITOR   |            |    |      | Lines 1 to 19 of 19   |        |    |        |
|---|------------|----|------|---|--------|----|--------|
| <div> <div>Select a file to FORMAT</div> <div> <div>Catalog: recorded</div> <div> 13p0_async_901011_825am<br/> 13p3_async_901011_835am </div> </div> </div> |            |    |      | <div> <div>NT SETTINGS</div> <div> system = \$DI_0000253006B9<br/> im = 3<br/> ort = 3<br/> er = 2000<br/> ol = ASYNC<br/> mat = ASCII<br/> th = 80 </div> </div> |        |    |        |
| Press f6 to accept  |            |    |      |   |        |    |        |
| F7 to - Format and Edit   |            |    |      | { Use Setup to change settings. }   |        |    |        |
| F8 to - Edit  |            |    |      |   |        |    |        |
| f1  | Find<br>Up | f2 | Down | f3  | NewCat | f4 | AltCat |
|   |            |    |      |   |        |    | Help   |
|   |            |    |      | f5  | DisA   | f6 | Cancel |
|   |            |    |      |   |        |    | Accept |
|   |            |    |      | f7  | UpCtig | f8 | NewFil |
|   |            |    |      |   |        |    | View   |
|   |            |    |      |   |        |    | OpnPos |

Figure 10-4. Format and Edit Screen

# Edit (Edit)

The Edit function key is similar to Format and Edit, except that the file selection screen is initially positioned at the most recently formatted file. If no formatted data file exists or the Setup screen has been changed, then the file selection screen is positioned at the first file on the catalog containing the formatted data files for the specified system. If the specified system catalog does not exist, then the file selection screen shows the \$USER.\$REMOTE\_LINE\_MONITOR catalog. Position to the desired file, then enter function key F6 (Accept) to start a NOS/VE File Editor session using the formatted file. Function key F7 (View) is a read-only display and is part of the NOS/VE file Generic Screen interface. See figure 10-5.




Figure 10-5. Edit Screen



## Data Integrity

If losing data would be a problem for you, then you should configure Remote Line Monitor as efficiently as possible to optimize data capture. The following table lists some possible reasons for loss of data and actions you can take to prevent or minimize loss of data.

| Reason   | Solutions  |
|--|--|
| Use of Hold Page.  | Hold Page = OFF.<br>Use Record function.   |
| Use of Ctrl-S, Ctrl-Q.   | Use Record function.   |
| Monitoring terminal line speed less than monitored line speed. | Use a monitoring terminal speed $\geq$ to monitored line speed.<br>Use Record function.  |
| Large volume of data traffic being monitored.                  | Use a monitoring terminal line speed greater than monitored line speed.<br>Use Record function.  |
| Remote Line Monitor competing for VE host resources.           | Increase application priority using application scheduling (see NOS/VE System Performance and Maintenance manual, volume 1).<br>Use Record function. |
| Busy/congested network.  | Monitor at a less busy time.   |

The first four reasons assume you are displaying the data. The last two reasons apply to all monitoring modes.

The best way to minimize any type of data loss is to record unformatted data to disk.

### NOTE

Do not increase the user's job priority; doing so can impact overall system performance. Use application scheduling to ensure the application gets higher priority with a limit on CPU use.

## Data Formats

Remote Line Monitor uses unformatted and formatted data. The differences are discussed in the following sections.

### Unformatted Data (Recorded)

Data is written (recorded) to a system-specified variable record type file exactly as it is received from the Remote Line Monitor application on the DI. The first line of each recorded data file contains the date and time that the first data was received. Each block of data is written as a variable length record. Each record contains the data header from the DI application followed by up to 1400 bytes of line data.

## Formatted Data

Data is formatted as a result of interactive viewing (Dis and DisRec functions) and as a result of formatting (FormEd function) previously recorded data. Data is formatted to the number of columns specified by the display width value on the Setup screen.

Formatting is based on values set using the Setup function. Display Format determines how characters are displayed (ASCII or HEX). Line Protocol determines what character translation is performed when displaying ASCII. Display Width determines the number of columns used for page width for formatted data.

In a formatted result file, the first line of the file is a string identifying the file as FORMATTED REMOTE LINE MONITOR DATA, and the second line is the file name of the recorded data file which was formatted (this line may wrap to the third line if the name is longer than the page width). The third line indicates the time recording was initiated and serves as an approximate reference point for the milliseconds elapsed counters throughout the rest of the formatted data.

In data displayed to the terminal (using Display or Display and Record), the first three lines of information are not displayed.

## Display Formats

In the following examples (figures 10-6 through 10-9), the paired lines starting with:

```
--I>
O>
```

indicate simultaneous input and output. The examples have been formatted using a 60-character page width.

Data is displayed as it is processed by the DI (full duplex must be processed synchronously by the DI one character at a time). Either the input character or the output character is the monitored character (never both). The character on the corresponding input or output representation is a placeholder only, not data.

Each block is preceded with the milliseconds elapsed since the first block was received. Lost data indicates the number of characters lost between the preceding block and the following block. The milliseconds elapsed following lost characters indicates the time the first character of the actual data that follows was recorded.

Certain escape characters embedded in the data by the DI are displayed symbolically inside < > when formatted (for example, <CRC> and <bad CRC>). This allows use of new escape characters for the DI code without breaking this application. When an unknown escape character is found, it is formatted as <?hex\_number>.

## ASYN-ASCII Display Format

Figure 10-6 show an example of the ASYN-ASCII display format. ASYN protocol is displayed using the ASCII display format.

Periods (.) and colons (:) act as placeholders on the line opposite the processed data. A period indicates a character with the parity bit set to 0. A : (colon) indicates a character with the parity bit set to 1. Blanks indicate that the data on the other line represents one character, starting from the placeholder (for example, when displaying an unprintable character or symbol, only the first character has a placeholder on the opposite line).

On the input and output lines, the values inside < > (angle brackets) are ASCII symbols, or HEX values for nondisplayable characters (greater than 127), or symbolically displayed escape sequences (see examples later in this section).

The following example shows the DISPLAY\_CATALOG command followed by a carriage return on the input line and then a line feed on the output line. Note that the parity is for the symbolically displayed character, not the leading < (angle bracket).

```
--I>DISC<CR>.
O>: : : : <LF>
```

If either . (period) or : (colon) is displayed on both lines (a very rare occurrence), then you need to format the data in HEX display format to determine whether the character was input or output.

```

FORMATTED REMOTE LINE MONITOR DATA
FILE :PEWTER.BCM.$REMOTE_LINE_MONITOR.RLM_TDI.RECORDED.L2P2_
ASYNC_900212_250PM
Remote Line Monitoring began February 12, 1990 14:50:14.447

    < 0 milliseconds elapsed>

    < 55470 milliseconds elapsed>

--I>DISV $TIME<CR>: . . . . . : .DISV
O>..... <LF><CR>14:51:13<CR><LF>/....

    < 59530 milliseconds elapsed>

--I> $DATE<CR>: . . . . . : .
O>..... <LF><CR>1990-02-12<CR><LF>/

    < 66790 milliseconds elapsed>

--I>DISC
O>.....

    < 71510 milliseconds elapsed>

--I>D0=F<CR>: . . . . . : . . . . .
O>..... <LF><CR>$FILE_MANAGER_BF<CR><LF>    NUMBER OF C

--I>:..... : .....
O>YCLES:    1, ACCOUNT: NONE, PROJECT: NONE<CR><LF>ASCII

--I>:..... : .....
O>_EXAMPLE<CR><LF>    NUMBER OF CYCLES:    1, ACCOUNT: N

--I>:..... : .....
O>ONE, PROJECT: NONE<CR><LF>ASYNCASC<CR><LF>    NUMBER OF

```

Figure 10-6. ASYNC-ASCII Display

## ASYNCH-HEX Display Format

Figure 10-7 shows an example of the ASYNCH-HEX display format. HEX displays are very similar except all characters are displayed in HEX and the only characters displayed inside < > are DI escape codes. No parity is indicated since all 8 bits are displayed in the HEX values. This example uses the same data as the ASYNCH-ASCII examples. The ASCII values for characters (both input and output) are displayed on the third line of each input/output set.

```

FORMATTED REMOTE LINE MONITOR DATA
FILE :PEWTER.BCM.$REMOTE_LINE_MONITOR.RLM_TDI.RECORDED.L2P2_
ASYNCR900212.250PM
Remote Line Monitoring began February 12, 1990 14:50:14.447

< 0 milliseconds elapsed>

< 55470 milliseconds elapsed>

--I>44495356202454494D450D. . . . . 44495356
O>. . . . . 8A0D3134BAB531BA31B30D8A2F. . . .
DISV $TIME 14:51:13 /DISV

< 59530 milliseconds elapsed>

--I>2024444154450D. . . . .
O>. . . . . 8A0D31B9B9B0ADB032AD31320D8A2F
$DATE 1990-02-12 /

< 66790 milliseconds elapsed>

--I>444953432020
O>. . . . .
DISC

< 71510 milliseconds elapsed>

--I>444F3D460D. . . . .
O>. . . . . 8A0DA446494C45DFCDC1CEC1C74552DFC2460D8A202020
DO = F $FILE_MANAGER_BF

--I>. . . . .
O>20CED5CDC24552204F462043D9434C45D3BA20202020312C20C143
NUMBER OF CYCLES: 1, AC

--I>. . . . .
O>434FD5CE54BA20CE4FCE452C20D0524F4A454354BA20CE4FCE450D8A
COUNT: NONE, PROJECT: NONE

--I>. . . . .
O>C1D3434949DF4558C1CDD04C450D8A202020CED5CDC24552204F46
ASCII_EXAMPLE NUMBER OF

--I>. . . . .
O>2043D9434C45D3BA20202020312C20C143434FD5CE54BA20CE4FCE
CYCLES: 1, ACCOUNT: NON

```

Figure 10-7. ASYNC-HEX Display

## HASP-ASCII Display Format

Figure 10-8 shows an example of the HASP-ASCII display format.

The display is processed identically to ASYNC-ASCII, except that all characters are translated to EBCDIC before they are displayed and all 8 bits are valid so no parity is indicated. No special formatting is done for the HASP protocol.

### NOTE

EBCD26 and EBCD29 character sets for HASP are incorrectly translated as EBCDIC when formatted for ASCII display; however, you can see untranslated EBCD26 and EBCD29 values by setting the display format to HEX.

```

FORMATTED REMOTE LINE MONITOR DATA
FILE :PEWTER.BCM.$REMOTE_LINE_MONITOR.RLM_TDI.RECORDED.L2P3_
HASP_900213_355PM
Remote Line Monitoring began February 13, 1990 15:55:40.240

    < 0 milliseconds elapsed>

    < 330 milliseconds elapsed>

--I><SYN><SYN><DLE><ACK0>. . . . .
O>. . . . . <SYN><SYN><SYN><DLE><STX> {ja :PE

--I>..... <SYN><SYN><DLE>
O>WTER.BPF<NUL><NUL><DLE><ETB><CRC><PAD>. . .

--I><ACK0>. . . . . <SYN>
O>. <SYN><SYN><SYN><DLE><ACK0><PAD><PAD><PAD>.

--I><SYN><DLE><ACK0>. . . . .
O>. . . . . <SYN><SYN><SYN><DLE><ACK0><PAD><PAD>

--I>. <SYN><SYN><DLE><ACK0>. . . . .
O><PAD>. . . . . <SYN><SYN><SYN><DLE><ACK0>

--I>. . . . . <SYN><SYN><DLE><ACK0>. . . . .
O><PAD><PAD><PAD>. . . . . <SYN><SYN><SYN>

```

Figure 10-8. HASP-ASCII Display

(Continued)

(Continued)

```

--I> . . . . . <SYN><SYN><DLE><ACK0>.
O><DLE><ACK0><PAD><PAD><PAD>. . . . . <SYN>

--I> . . . . . <SYN><SYN><DLE>
O><SYN><SYN><DLE><ACK0><PAD><PAD><PAD>. . . . .

--I><ACK0>. . . . .
O>. <SYN><SYN><SYN><DLE><STX> {jab<NUL>jab<NUL>jab

--I> . . . . .
O><PAD>display_catalog NOS

--I> . . . . .
O>/VE a9180 SJVL <NUL>jab4

--I> . . . . .
O> 1990-02-13 15:55:42 PAGE 1<NUL>jabCATALOG :pe

--I> . . . . .
O>wter.bpf<NUL>jab<NUL>jab FILE: CFG140<NUL>jabJ FILE:

--I> . . . . .
O> CONF_138<NUL>jab} FILE: CONF_LM<NUL>jabL FILE: DISC_

--I> . . . . .
O>$USER<NUL>jab FILE: EL<NUL>jab FILE: PROLOG<NUL>jabM

--I> . . . . .
O> FILE: RLM_DI_8103<NUL>jab FILE: RLM_MESSAGE_TEMPLA

--I> . . . . .
O>TES<NUL>jab FILE: SCU_EDITOR_EPILOG<NUL><NUL><DLE>

--I> . . . . . <SYN><SYN><DLE><ACK0>.
O><ETB><CRC><PAD>. . . . . <SYN><SYN><SYN>

```

Figure 10-8. HASP-ASCII Display



## HASP-HEX Display Format

Figure 10-9 shows an example of the HASP-HEX display format. The HEX display format leaves all HASP characters untranslated. The display is identical to an ASYNC-HEX display.

```

FORMATTED REMOTE LINE MONITOR DATA
FILE :PEWTER.BCM.$REMOTE_LINE_MONITOR.RLM_TDI.RECORDED.L2P3_
HASP_900213_355PM
Remote Line Monitoring began February 13, 1990 15:55:40.240

< 0 milliseconds elapsed>

< 330 milliseconds elapsed>

--I>32321070. . . . .
O>. . . . 32323210028D80C09181CB7AD7C5E6E3C5D94BC2D7C60000
      { j a : P E W T E R . B P F
--I>. . . . 32321070. . . . . 32321070. . . . .
O>1026<CRC>FF. . . . 3232321070FFFFFF. . . . 3232321070FF

--I>. . . . 32321070. . . . . 32321070. . . . . 3232
O>FFFF. . . . 3232321070FFFFFF. . . . 3232321070FFFFFF. .

--I>1070. . . . . 32321070. . . . .
O>. . . . 3232321070FFFFFF. . . . 32323210028E80C0918182009181
      { j a b j a
--I>. . . . .
O>82009181FF8489A2979381A8608381A38193968740404040404040
      b j a d i s p l a y _ c a t a l o g
--I>. . . . .
O>40404040404040404040404040404040404040404040D5D6E261
      N O S /
--I>. . . . .
O>E5C5404081F9F1F8F04040E2D1E5D34040404040404040404040
      V E a 9 1 8 0 S J V L
--I>. . . . .
O>4040009181F440404040404040404040404040404040F1F9F9F0
      j a 4 1 9 9 0
--I>. . . . .
O>60F0F260F1F34040404040F1F57AF5F57AF4F240404040D7C1C7C5
      - 0 2 - 1 3 1 5 : 5 5 : 4 2 P A G E
--I>. . . . .
O>40F1009181D3C3C1E3C1D3D6C7407A9785A6A385994B829786009181
      1 j a L C A T A L O G : p e w t e r . b p f j a
--I>. . . . .
O>82009181CF404040C6C9D3C57A40C3C6C7F1F4F0009181D1404040C6
      b j a F I L E : C F G 1 4 0 j a J F

```

Figure 10-9. HASP-HEX Display

## Security

All uses of the Remote Line Monitor are recorded to discourage misuse. On NOS/VE, information is written to `:$SYSTEM.$SYSTEM.REMOTE_LINE_MONITOR_USAGE`. Users should only be allowed to append data to this file. The following is an example of data recorded for one monitoring session:

```
Remote Line Monitoring starting: 02/15/90 14:15:01
  User=BCM
  From family PEWTER
  Monitoring - LIM=2 Port=3 System=RLM_TDI
Remote Line Monitoring ending: 02/15/90 14:15:08
  User=BCM
  From family PEWTER
  Monitoring - LIM=2 Port=3 System=RLM_TDI
  Total data received = 898
```

The Remote Line Monitor TIP also logs similar information in the DI logs.

## Cancelling the DI Remote Line Monitor

In the unlikely event that the NOS/VE Remote Line Monitor terminates after it sends a `DEFINE_REMOTE_LINE_MONITOR` to the DI and before it establishes a connection to the Remote Line Monitor TIP, you must enter `NETOU` and send the `CANCEL_REMOTE_LINE_MONITOR` command to the DI. Until you do this, it appears to NOS/VE that there is already a Remote Line Monitor session in progress and NOS/VE informs you that `REMOTE_LINE_MONITOR` is already defined.

### **CAUTION**

---

Do not cancel another user's Remote Line Monitor session.

---



# Appendixes

---

|  |     |
|--|-----|
| Glossary .....                                   | A-1 |
| Character Set .....                              | B-1 |
| DI Reset Codes .....                             | C-1 |
| Procedures to Enhance Operator Environment ..... | D-1 |
| MPB Memory Map .....                             | E-1 |
| System Tables .....                              | F-1 |
| Line and Terminal Control Blocks .....           | G-1 |
| Task and Queue Control Blocks .....              | H-1 |
| Stack Frames .....                               | I-1 |
| Dump Analyzer Error Messages .....               | J-1 |



# Glossary

---

# A

## A

### A-to-A

Refer to Application-to-Application.

### Address Resolution Protocol (ARP)

A term used for routing on a LAN. ARP is used to map IP addresses into Ethernet addresses. ARP is not required for connection to ARPANET or MILNET, but is useful in the LAN workstation environment.

### Alarm

A log message that is routed to an operator. Any CDCNET log message may be designated as an alarm.

### Alarm History

A chronological record of the alarms received at a network operator's alarm buffer since the start of an operations session. An alarm history may be displayed using a network operations command.

### Application-to-Application (A-to-A)

Can refer to either a type of link between two OSI layers, or a type of network processing:

1. An application-to-application link is an end-to-end link between an application layer of one system and the application layer of another for the exchange of information.
2. Application-to-application network processing that enables data to be exchanged between applications programs executing on different host computers or workstations.

### ARP

Refer to Address Resolution Protocol.

### ARPANET

A Defense Data Network (DDN) developed by the Defense Advanced Research Projects Agency. ARPANET supports research and development projects funded by the Department of Defense.

### Asynchronous TIP

The terminal interface program (TIP) that configures terminal devices and establishes terminal attributes for a generic, asynchronous terminal connected to a device interface. The asynchronous TIP resides in a device interface that is configured to support asynchronous terminals.

### Auto-Configured I/O Station

An I/O station that is logically configured and ready to use when the lines to which the devices in the I/O station become active and when a station operator connects to batch services. Contrast with Operator-configured I/O station. Configuring an auto-configured I/O station is possible when all the devices of the I/O station always connect to the same DI ports. Also known as a predefined I/O station.

## B

### Batch Device

Individual devices in an I/O station controlled by batch services and protocols and used for batch input and/or output. Examples of batch devices include card readers, line printers, card punches and plotters.

### Block

In the context of network communications, a portion or all of a message. A message is divided into blocks to facilitate buffering, transmission, error detection, and correction for variable-length datastreams. Differing block protocols apply to the host-to-device interface and the device-interface-to-terminal interfaces.

During input from a terminal, a block is a single transmission consisting of one or more lines of one or more messages.

During input to a service, a block is a single line consisting of part or all of a message. Terminal transmission blocks are divided into as many service input blocks as needed, until the message is completed.

During output from a host application program, a block is one or more lines. During output from a device interface to a terminal, a block is one terminal transmission buffer.

### Board

Refer to Logic Board.

### Break 2 Sequence

A series of interactive terminal keystrokes that cause interruption in the datastream, stopping delivery of a message or output from the host. Some terminals are equipped with a single key that causes a break 2 sequence. Refer to your terminal user's manual for your terminal's exact sequence.

### BSC3270 TIP

A terminal interface program that provides support for the IBM 3270 Information Display System. The 3270 Bisynchronous TIP allows 3271, 3274, 3275, and 3276 control units to connect directly to CDCNET in order to communicate with a CDCNET terminal device interface (TDI) over dedicated or dial-up lines using the centralized multipoint Binary Synchronous Communication protocol. The 3270 TIP Bisynchronous supports up to 32 multi-dropped clusters of up to 32 devices on each line.

### Buffer

One of two structures for the storage of data in device interface memory. See also Data Buffer and Descriptor Buffer.

### Byte

1. (ISO) A binary character string operated upon as a unit and usually shorter than a computer word.
2. (ISO) A group of contiguous bits. Unless prefixed (for example, a 6-bit byte), the term implies 8-bit groups. An 8-bit byte is sometimes called an octet. When used for encoding character data, a byte represents a single character.

## C

### **Catenet**

A group of connected CDCNET network solutions. This term is often used when referring to all the device interfaces and network solutions in a site's network.

### **Central Processor Unit (CPU)**

The high-speed arithmetic processing unit that carries out the basic instructions required in program execution.

### **Channel**

The physical link or logical path between a Mainframe Device Interface (MDI) and the network host computer, or between an Integrated Communication Adapter (ICA) and the Integrated Controller Interface (ICI) in the network host computer.

### **Clock Synchronization**

A function that ensures that all device interfaces in a catenet are synchronized within 1 second of each other. Clock synchronization involves setting or resetting the master clock for the catenet (controlled by the Independent Clock ME) and synchronizing all of the device interface clocks in the catenet (controlled by the Dependent Clock ME in each device interface) according to the master clock. The `DEFINE_SYSTEM` command defines whether or not a device interface contains the Independent Clock ME.

On NOS, the device interface that contains the Independent Clock ME contains the master clock for the catenet, which synchronizes the rest of the clocks in the network.

On NOS/VE the Independent Clock ME is configured on the host.

### **Cluster Address**

A sequence of bits, characters, or group of characters that identifies the location of a device (controller) that handles the remote communication processing for multiple (usually dumb) terminals or workstations.

### **Coaxial Cable**

A transmission cable that provides large bandwidth and high data/low error rates. This cable contains a central carrier wire surrounded by fine copper mesh and/or an aluminum sleeve.

### **Code Set Procedure**

A CDCNET load procedure that allows a site to define its own code sets for input and output devices.

### **Command File**

A NOS file of network operations commands. Commands in the command file can be executed using the `EXECUTE_COMMAND_FILE`. Similar to a procedure file.

### **Communication Line**

A terminal line that establishes a complete communication circuit between a terminal or workstation and a CDCNET device interface.



## **Configuration**

The process by which various computer-related resources are coordinated to function together. Under CDCNET, various types of configuration activities are performed.

1. Network configuration, whereby hosts, terminals, workstations, and unit record devices are interconnected into a network using CDCNET device interfaces and appropriate communications media.
2. Device interface hardware configurations, whereby decisions are made regarding which logic boards to install in a particular CDCNET device interface.
3. Device interface software configuration, whereby CYBER hosts decide which CDCNET software to downline-load into a specific CDCNET device interface.
4. Creation of device interface configuration files, whereby network administrators or communications consultants identify/describe the specific CDCNET device interfaces that reside in their networks and place this information in host-maintained permanent files.

See also Logical Configuration.

## **Configuration Command**

A command that establishes, cancels, or redefines the configuration of a network component in the network's logical definition.

## **Configuration File**

Refer to Configuration Procedure.

## **Configuration Procedure**

A procedure containing configuration commands that configure the software in a device interface. Each device interface has a unique configuration file, which is read whenever the device interface is reset and loaded. Also known as configuration file.

## **Configure**

To define the variable attributes of a CDCNET device (such as the device interface, a single board, network solution, communication line or gateway). Examples of configurable attributes include buffer sizes, line speeds, and logical names.

## **Congested**

One of the operational states of a network solution or communication line; indicates excessive traffic. See also Congestion.

## **Congestion**

A condition in which there is more message traffic on a network solution or communication line than the line's carrying capacity. Continued congestion results in lengthy message delay and discarding of new messages.

## **Connection-Oriented Network Service (CONS)**

OSI connection oriented network service specification used in conjunction with X.25.

## **CONS**

See Connection-Oriented Network Service.

**Control Facility**

A NOS/VE service that monitors I/O stations and their batch devices, executes device and file control commands for the I/O station, and controls selection of files for output devices for the I/O station.

**Cost**

A relative measure assigned to a path (such as a network solution) that is used for transmitting data through a CDCNET-type network. The cost of each possible path is computed and stored into tables by the Routing Management Entity (ME). From these tables, the Routing ME determines the path that has the least cost. The path with the least cost is used to transmit data. The cost of a path may change depending upon the amount of congestion on the path. A congested network solution has a higher cost than an uncongested network solution.

**Coupler**

A hardware module on a Mainframe Device Interface (MDI) that connects a host's peripheral processor to CDCNET.

**Coupler Node**

A logical identification assigned to the coupler that connects a host channel and an MDI.

**CPU**

Refer to Central Processor Unit.

**D****Data Buffer**

A structure for storing user data in device interface memory. A pointer is associated with the first character of data in the buffer. Data buffer length is configurable. Contrast with Descriptor Buffer.

**Datagram**

A self-contained package of data carrying enough information to be routed from source to destination without reliance on earlier exchanges between source or destination and the transporting network.

**DDN**

Refer to Defense Data Network.

**Deadman Timeout (DMTO)**

A device interface hardware reset that occurs automatically if software does not work normally for 10 seconds.

**Dedicated Line**

A communication line that permanently connects a terminal to a device interface. Contrast with Switched Line.

**Default**

A pre-selected value supplied for a missing parameter upon the entry of a command or subcommand.

**Defense Data Network (DDN)**

A packet-switching network provided by the Department of Defense (DOD) to meet its current and projected data communication requirements. It is based upon the Defense Advanced Research Projects Agency Network (ARPANET), an existing operational network.

**Descriptor Buffer**

A data structure used for chaining data buffers. Contrast with Data Buffer.

**DI Name Resolver**

A program that resides in a DI and provides an interface between the DI and domain name servers. If a TCP/IP user specifies a domain name, the name resolver requests a domain name server to translate the name into the corresponding IP address.

**Diagnostic**

1. Software and/or microcode that isolates failing hardware/software components within a CDCNET device interface.
2. A message indicating a malfunction within a CDCNET device interface or one of its related communications media.

**Dial-up Line**

A communications circuit created by dialing a destination over a common carrier's switched lines.

**Disabled**

Cannot be used for normal network operation. Applies to boards, communication lines and network solutions.

**DMTO**

Refer to Deadman Timeout.

**DOD**

Department of Defense.

**Domain Label**

Part of a domain name and contains up to 63 characters. The label must begin with a letter (A..Z or a..z), which can be followed by letters, digits, or hyphens. The label must end with a letter or a digit.

**Domain Name**

TCP/IP users typically use domain names instead of IP addresses to reference TCP/IP services. Domain names identify hosts or other resources connected to a TCP/IP network. A domain name consists of a sequence of domain labels, arranged in a hierarchical order, and separated by periods. For example, the name PINK.ARH.CDC.COM, could specify a machine called PINK at the Arden Hills (ARH) facility of Control Data, which is a commercial organization (COM). The length of a domain name including the separating periods can be up to 255 characters.

**Domain Name Server**

A program that resides in a host connected to the TCP/IP network and responds to queries for information about domain names.

**Down**

A status of suspended service.

**Dump**

Refer to Memory Dump.

**Dump Analyzer**

CDCNET troubleshooting software that enables communications support analysts to review detailed memory dumps generated by malfunctioning CDCNET device interfaces. Refer to Analyze\_CDCNET\_Dump (ANACD).

**E****Echoplex**

A procedure in which the receiving station automatically retransmits each character received so that the sender may verify the correctness of his transmission. This process usually occurs on asynchronous full-duplex communication lines; however, not all terminals on full-duplex communication lines are capable of echoplex operation.

**EEPROM**

Refer to Electronically Erasable Programmable Read Only Memory.

**EGP**

Refer to Exterior Gateway Protocol.

**Electronically Erasable Programmable Read Only Memory (EEPROM)**

Read only memory that can be updated dynamically by the software at configuration time.

**ESCI**

Refer to Ethernet Serial Channel Interface.

**Ethernet**

A baseband local area network protocol developed by the Xerox Corporation. CDCNET supports an Ethernet-compatible network.

**Ethernet Serial Channel Interface (ESCI)**

The logic board within a CDCNET device interface that controls transmissions between an Ethernet (IEEE 802.3) transceiver and the internal system bus (ISB) of the device interface.

**Exception List**

A file that determines how to process the load requests of the network's device interfaces (DIs). The exception list is a file of commands that specify the version of software to be loaded into the device interface, and which error codes should trigger a dump of the device interface memory. There is one exception list for the network, containing a default entry and any exceptions to the default entry.

**Exterior Gateway Protocol (EGP)**

A TCP/IP protocol that allows for transfer and negotiation of routing information.

## **F**

### **File Prefix Procedure (FPP)**

A device configuration procedures containing strings of characters and/or control codes to be sent to the printer before every print file. An FPP is used for printers that use the PostScript language, such as the Apple LaserWriter.

### **File Transfer Protocol (FTP)**

1. The Control Data application-to-application protocol that enables applications programs executing on a NOS or NOS/VE host to exchange information with applications programs that execute on other NOS or NOS/VE hosts.
2. TCP/IP protocol that provides the file transfer server and user functions.

### **Format Effectors**

Any character used to control the positioning of printed or displayed data.

### **Forms Code**

A 1- through 6-character identifier associating a print file with a certain printer form ensures output will be routed to a printer which prints in the format needed. For example, one printer at a site can be defined as using an 8-1/2 by 11-inch print form by specifying a forms code of DOC (document) on the command that configures the printer (DEFINE\_BATCH\_DEVICE). Another printer can be defined to print perforated checks and have a forms code of CHECKS, and one defined to print on carbon paper could have a forms code of CARBON. When output is routed to printers, the appropriate forms code (DOC, CHECKS, or CARBON) can be specified so that output will be printed by the appropriate printer.

### **FPP**

Refer to File Prefix Procedure.

### **FTP**

Refer to File Transfer Protocol.

## **G**

### **Gateway**

A software interface between systems with different architectures and protocols.

### **Gateway Title**

The logical title assigned to a gateway during logical configuration.

## **H**

### **HASP**

Refer to Houston Automatic Spooling Program.

### **HASP Protocol**

A job control protocol for transmitting data processing files and jobs between certain models of computers. It is also called the Houston Automatic Spooling Program.

**HASP Workstation**

A bisynchronous terminal with associated batch devices. HASP workstations are used for remote batch input from card readers and output to line printers, card punches, and plotters. Each workstation must have a console device that can be used as a normal interactive device with limited screen and formatting capabilities. Each HASP workstation can support the following: up to seven card readers; a combined total of eight batch output devices, (line printers and card punches which can be replaced with plotters), with a maximum of seven devices of the same type; and one console device (required).

**HDLC**

Refer to High-Level Data Link Control.

**High-Level Data Link Control (HDLC)**

The International Standards Organization's (ISO) bit-oriented protocol for the data link layer of the Open Systems Interconnection (OSI) reference model.

**Hop**

Within a network of interconnected gateways, a hop is the process of forwarding a packet from one gateway to another.

**Host**

Refer to Host Computer.

**Host Computer**

A mainframe computer system, connected to a communications network, which provides primary services, such as database access, user application execution, or program compilation. For CDCNET, a host computer provides network support functions, including maintenance of device interface load files. Also called a host.

**Host Console**

The keyboard and display screen used to manage the host computer. Also used in CDCNET to access the Network Operator Utility (NETOU) to monitor and control the CDCNET. See also System Console.

**Host Operating System**

The host containing applications and maintenance software available to the device interface.

**Host Service Name**

A logical name for the host computer. The host service name is the name that terminal users provide when connecting to the host using the CREATE\_CONNECTION command.

**Host System**

A mainframe computer and its operating system that provides applications and services to the computer network. CDCNET must have at least one host running NOS, NOS/VE, or dual-state NOS and NOS/VE.

**Houston Automatic Spooling Program (HASP)**

A job control protocol for transmitting data processing files and jobs between certain models of computers.

# I

## I/O Station

A logical grouping of batch devices into a single named unit for routing jobs and files to the batch devices and for controlling the devices. Devices belonging to an I/O station may all connect to the same line, to several lines on one device interface, or to lines distributed among several device interfaces.

## ICA

Refer to Integrated Communications Adapter.

## Independent Log Management Entity (Independent Log ME)

1. Also known as the recorder logging function. Software resident in a host-connected device interface that works with the Independent File Access ME to write log messages generated by network device interfaces to a file on a host called the network log file.
2. A service on NOS/VE host computers that writes log messages generated by network device interface to a host-resident file called the network log file.

## Initialization Procedure

A CDCNET load procedure that defines data to be sent to a printer when the printer's communication line becomes active.

## Integrated Communications Adapter (ICA)

A hardware device that interconnects a single 16-bit Integrated Controller Interface (ICI) channel of a host computer with CDCNET. The ICA is installed in the CYBER 930 series host computer mainframe.

## International Standards Organization (ISO)

A worldwide standards group similar in function to the American National Standards Institute (ANSI). ANSI is a member of International Standards Organization.

## Internet Protocol (IP)

A term used in DDN networks that refers to a connectionless, point-to-point protocol corresponding to the CDCNET Internet layer. This protocol is required for connection to MILNET, ARPANET, and TCP/IP workstations.

## IP

Refer to Internet Protocol.

## IP Address

Internet Protocol (IP) uses a 32-bit IP address field containing the Internet Address. Each IP system or host in the DDN is assigned a unique IP address. A host may have one or more IP addresses; however, a CDC CYBER host basically supports only one IP address per host.

## ISO

Refer to International Standards Organization.

## Isolation

Identification of a failing hardware or software component.

## K

### K Display

A NOS host console display that enables operators to interact with various operating system utilities (for example, those controlling user validation and NAM subsystem interaction).

## L

### LCA EEPROM

Refer to Logic Cell Array Electronically Erasable Programmable Read Only Memory.

### Line

A circuit that connects a terminal to a device interface. A line is dedicated to carrying data to and from that terminal. It does not carry data that is routed through the rest of the network, nor does it use the CDNA protocol. Also known as a communication line.

### LLC2

See Logical Link Control 2.

### Load Procedure (LP)

A file containing commands specifying information to be downloaded to a printer. Load procedure types include initialization procedures (IPs), file prefix procedures (FPPs), code set procedures, and VFU load procedures (VLPs).

### Log File

A file that is created and maintained by the operating system for storing error information and usage data concerning network elements.

### Log Group

A logging function that is distributed among several device interfaces. A collection of device interfaces and the set of log messages associated with these device interfaces.

### Log Management Entity (Log ME)

Software that manages the transmission and recording of log messages generated by device interface software. Consists of Dependent and Independent Log Management Entities. Dependent Log Management Entities, residing in device interfaces, are sources of log messages. Independent Log Management Entities, residing in a host-connected device interface, work with host applications or a NOS/VE host to write the log messages to the network's log file on the host.

### Log Support Application (LSA)

Also known as the Dependent Log Management Entity and/or source logging function. Software that manages the generation and transmission of log messages generated by device interface software. Resident in every device interface.

### Logging

The process of issuing messages for network activity and recording the messages in a log file.



**Logic Board**

A printed circuit board with data storage and/or processing components installed; sometimes called a board, card, or module.

**Logic Cell Array Electronically Erasable Programmable Read Only Memory (LCA EEPROM)**

Contains the configuration data for the XILINX logic cell arrays which contain the bulk of the random logic on the MPB-II. See also EEPROM.

**Logical Configuration**

The process of assigning names and values and setting variables throughout the CDCNET to define network elements (mainframes, terminals, lines, network solutions, device interfaces, gateways, and other elements), so that all network elements follow a uniform naming and addressing scheme. After logical configuration, network elements accept all data and commands directed to or through themselves, and reject all other data and commands. Also known as network definition.

**Logical Link Control 2 (LLC2)**

OSI connection-oriented data link protocol utilized by CONS/X.25 when running over ESCI.

**Logical Name**

A name assigned to a CDCNET component (device interface, network solution, communication line, gateway) in the logical definition of the network. Many network operations commands refer to CDCNET components by their logical names. Contrast with Title.

**Logical Unit (LU)**

A 3270 terminal device from which a 3270 terminal interface program (TIP) accepts an interactive session.

**Loopback Test**

A failure management test that checks the integrity of a hardware element by sending data through the element and back again.

**LP**

Refer to Load Procedure.

**LSA**

Refer to Log Support Application.

**LU**

Refer to Logical Unit.

**M****Main Processor Board II (MPB-II)**

Processor board containing a high performance architecture consisting of MC68030 32-bit processor and 512 K bytes of local onboard memory.

**Main Processor Board (MPB)**

The logic board within a CDCNET device interface that provides the primary processing power for the device interface.

**Mainframe Channel Interface (MCI)**

An optional logic board within a CDCNET device interface that connects the device interface to a 12-bit CYBER host channel.

**Mainframe Device Interface (MDI)**

The CDCNET device interface variant that interconnects a 12-bit channel of host computers operating under NOS or NOS/VE with an Ethernet (IEEE 802.3) local area network.

**Mainframe/Terminal Device Interface (MTI)**

The CDCNET device interface variant that interconnects 12-bit NOS and NOS/VE host computers with terminals, workstations, and unit record equipment without requiring a local area network.

**Manage CDCNET Configuration (MANCC) Utility**

A CDCNET host utility for NOS that helps create, edit, and display CDCNET configuration files.

**Management Entity (ME)**

CDCNET software that performs network management functions. CDCNET supports various MEs to perform specific network tasks.

**MANCC**

Refer to Manage CDCNET Configuration Utility.

**MCI**

Refer to Mainframe Channel Interface.

**MDI**

Refer to Mainframe Device Interface.

**ME**

Refer to Management Entity.

**Memory Dump**

The process and result of writing device interface memory to a host-resident file. Memory dumps are forced when the contents of device interface memory are at risk of being lost.

**Metrics**

Statistics which are collected and reported for CDCNET hardware and software components.

**MILNET**

A Defense Data Network (DDN) evolved from ARPANET that supports operational communication requirements.

**Mode 4**

A data communications protocol, consisting of variants 4A, 4B, and 4C. The Mode 4 protocol supports two-way alternate communications (where messages may be sent in one direction or another, but not in both directions simultaneously) on switched or dedicated synchronous lines within a line speed range of 1200 to 19200 bits-per-second.

The CDCNET Mode 4 terminal interface program supports the 4A and 4C variants of the Mode 4 protocol.

**MPB**

Refer to Main Processor Board.

**MPB-II**

Refer to Main Processor Board II.

**MTI**

Refer to Mainframe/Terminal Device Interface.

**N****NAM**

Refer to Network Access Method.

**NAM K Display**

A display on the host console screen that allows operator interface to Network Access Method (NAM). A CDCNET operator at the host console communicates with the CDCNET through the NAM K display.

**NAM/VE**

Refer to Network Access Method/Virtual Environment.

**NDI**

Refer to Network Device Interface.

**NETCU**

Refer to Network Configuration Utility.

**NETLS**

Refer to Network Log Server.

**NETOPS**

A NOS user name under which files are stored for use during CDCNET installation and by CDCNET-host operations. NETOPS contains files created and written by NAM while NAM is operating, the network directory file (NETDIR), and the NAMSTRT procedure.

**NETOU**

Refer to Network Operator Utility.

**Network Access Method (NAM)**

The access method that resides under NOS; allows host-based network applications programs to exchange information with communications networks.

**Network Access Method/Virtual Environment (NAM/VE)**

The access method that resides under NOS/VE; allows host-based network applications programs to exchange information with communications networks.

**Network Architecture**

A set of functional layers in which each layer performs a specific set of functions and services; together, the layers interact to provide total, end-to-end network operation. Each layer uses a protocol and has its relationship with other layers defined.

**Network Configuration Utility (NETCU)**

A CDCNET utility on NOS/VE that logically configures CDCNET.

**Network Definition**

The process of assigning logical names to network components and assigning values to variable parameters for CDCNET software. See also Logical Configuration.

**Network Delay Measurement**

A software feature used to measure one-way delay time between two network DIs.

**Network Device Interface (NDI)**

The standard CDCNET device interface variant that transfers data between networks (for example, between two local area networks; between a local area network and a communications line; or between a local area network and a public data network).

**Network File System (NFS)**

A software product of Sun Microsystems, Inc. that allows a variety of machines and operating systems to share files.

**Network Identifier**

A unique identifier (32-bit character string) assigned to a network solution.

**Network Job Entry Facility (NJEF)**

The network applications software that supports IBM's Network Job Entry (NJE) protocol on NOS.

**Network Log File**

A file on a host computer that contains CDCNET log messages sent from the network's device interfaces and serves as a record of the network's activity.

**Network Log Server (NETLS)**

A CDCNET host application that writes CDCNET log messages generated by device interfaces to the network log file on the host.

**Network Logfile Termination (NLTERM) Utility**

A CDCNET host utility on NOS that terminates the currently-active network log file to which NETLS is writing log messages, and renames the terminated log file. NLTERM also provides information about previously-terminated log files as an aid in managing log files.

**Network Operator**

A person who monitors CDCNET activity, has the ability to control CDCNET hardware and software, makes occasional network configuration changes, and performs elementary troubleshooting by sending commands to the network's device interfaces. A network operator may perform these tasks from a host console or a remote terminal.

**Network Operator Utility (NETOU)**

A group of programs residing on a host computer and in a (NOS) mainframe device interface or mainframe terminal interface connected to the mainframe. NETOU allows a network operator to access, monitor, control, and configure a CDCNET from the host console or a remote terminal. Using NETOU, network operators can send CDCNET operations commands to specific device interfaces or to all the device interfaces in the network.

**Network Performance Analyzer (NPA)**

The CDCNET software utility that generates statistical reports based on its analysis of the network log file or generates event/error reports based on log messages in the network log file.

**Network Products Gateway**

A gateway that allows information transfer between CDCNET and a non-CDNA host such as a NOS host. File transfers between NOS hosts over CDCNET require Network Products gateways to be defined in the MDIs connected to the hosts.

**Network Products (NP)**

Programs that run under NOS in a host mainframe to allow data and computer applications to be transmitted from the mainframe through a computer network. Network Products include Network Access Method (NAM) and Network Definition Language (NDL). Network Products and CDCNET have different architectures. For hosts to send data through CDCNET, the Mainframe Device Interfaces connected to the mainframes must have gateways to translate between Network Products and CDCNET protocols.

**Network Products Terminal Gateway**

A gateway that allows both interactive and remote batch terminal users to connect to a NOS host through CDCNET (by specifying the appropriate service title on the CREATE\_CONNECTION command). There are two parts to the NP Terminal gateway: the Interactive Virtual Terminal gateway (IVT gateway) and the Remote Batch Facility gateway (RBF gateway). The batch gateway is dependent on the interactive gateway. If a network configuration is going to support terminal connections to NOS, the MDI or MTI connected to the NOS host must contain an NP Terminal gateway.

**Network Service Access Point Address (NSAP Address)**

An address used in the OSI protocol stack that uniquely identifies a CDCNET system and a user of the OSI Network layer within that system. An NSAP address consists of two parts: a Network Entity Title and an NSAP selector. The Network Entity Title uniquely identifies a CDCNET system. The NSAP selector uniquely identifies a user of the OSI Network layer in that system.

**Network Solution**

A communications medium over which data is transmitted between interconnected network resources, and which uses CDCNET protocols. In OSI terminology, a network solution is also referred to as a subnet. A network solution differs from other communications lines because it is shared by multiple network resources (it is not solely dedicated to the handling of data transmissions between a single pair of network resources). Network solutions differ from trunks because they can carry network management traffic such as log and alarm messages.

**Network Transfer Facility (NTF)**

An application providing a fully symmetric queue file transport facility between a NOS/VE host and another host in a geographically dispersed network. NTF supports IBM's Network Job Entry (NJE) protocol and HASP multileaving protocol for communication between hosts.

**Network Validation**

A system security feature requiring users to enter a valid username and password to use CDCNET.

**NFS**

Refer to Network File System.

**NJEF**

Refer to Network Job Entry Facility.

**NLTERM**

Refer to Network Logfile Termination Utility (NLTERM).

**NP**

Refer to Network Products.

**NP IVT Gateway**

Network Products Interactive Virtual Terminal Gateway. A program which runs in a Mainframe Device Interface (MDI) or Mainframe Terminal Device Interface (MTI) connected to a host mainframe, and which allows the host mainframe to send applications through CDCNET to interactive terminals. The gateway acts as a protocol converter between the host's Network Products protocols and CDCNET protocols. Also known as the NP terminal gateway.

**NP Terminal Gateway**

Refer to NP IVT Gateway.

**NPA**

Refer to Network Performance Analyzer.

**NSAP Address**

Refer to Network Service Access Point Address.

**NTF**

Refer to Network Transfer Facility.

**NVT**

Refer to TELNET Network Virtual Terminal.

## O

### Octet

An 8-bit byte.

### Online Diagnostics

Optional diagnostics for the device interface that can be executed while the device interface is connected to and operating as part of the CDCNET.

### Online Loader

A CDCNET service that loads software into device interfaces when the software is needed while the network is operational, as opposed to initial loader, which loads software into device interfaces only when they are started up (initialized).

### Open System Interconnection (OSI)

The International Standards Organization's (ISO's) reference model for network processing. This model is based on a network architecture that segregates network functions into seven layers.

### Operations Station

The remote terminal or host console from which CDCNET network operations are performed through the Network Operations Utility (NETOU).

### Operator-Configured I/O Station

An I/O station that is logically configured when an I/O station operator invokes a terminal definition procedure (TDP) to define the I/O station. The station operator must define the I/O station before it can be used, and the devices in the I/O station are not active until the TDP executes. Contrast with Auto-configured I/O Station. Configuring an Operator-configured I/O station is necessary when the devices of an I/O station do not always connect to the same device interface port. An example of an Operator-configured I/O station is a dial-up HASP workstation. Also known as a dynamically defined I/O station.

### Operator Console

An interactive terminal in an I/O station that can be used to control the other batch devices in the I/O station. On NOS/VE, the operator console is used for entering OPERATE\_STATION (OPES) utility subcommands to control the devices. On NOS, the operator console is used for entering Remote Batch Facility (RBF) commands to control the devices.

### OSI

Refer to Open System Interconnection.

### Outcall Gateway

A gateway that provides both terminal and device outcall services. See also Gateway.

## P

### **Packet Assembly/Disassembly (PAD)**

(ISO) A functional unit that enables data terminal equipments (DTEs) not equipped for packet switching to access a packet-switched network.

### **PAD**

Refer to Packet Assembly/Disassembly.

### **Page Memory Management Unit (PMMU)**

Provides address translation and memory protection for a demand paged virtual memory system.

### **Passthrough**

Refer to Terminal Passthrough.

### **PDN**

Refer to Public Data Network.

### **Physical Name**

A name assigned to a hardware device in a device interface: boards, ports, and memory banks, such as \$CIM3 (physical name for CIM board in slot 3) and \$LIM5\_PORT2 (physical name for second port on LIM board in slot 5.)

### **Physical Record Unit (PRU)**

The amount of information transmitted by a single physical operation of a specified device. For mass storage files, a PRU is 64 central memory words (640 characters); for magnetic tape files, the size of the PRU depends upon the tape format. A PRU that is not full of user data is called a short PRU; a PRU that has a level terminator but no user data is called a zero-length PRU.

### **PMM**

Refer to Private Memory Module.

### **PMMU**

Refer to Page Memory Management Unit.

### **Port**

The physical connection on the device interface through which data is transferred to/from the device interface. Each port is numbered and supports a single communication line.

### **PostScript**

An industry standard page description language for describing text, graphic entities, and digitized images for printed pages. PostScript can also be used to control aspects of a printer's operation. PostScript page descriptions are programs run by an interpreter in the printer. PostScript programs are generated by application programs running on a system to which the printer is connected.

### **Primary MDI**

The Mainframe Device Interface (MDI) to which the operator sends commands and receives responses and alarms. At any time, only one MDI can communicate with the operator.



**Printer Support Utility (PSU)**

The network applications software that supports standalone CDCNET printers on NOS.

**Private I/O Station**

An I/O station used to submit and receive jobs and output files only for the user that is operating it. A station operator must monitor and control the I/O station for it to be active. Contrast with Public I/O Station.

**Private Memory Module (PMM)**

The logic board within a CDCNET device interface that provides additional random access memory dedicated for use by the main processor board (MPB) of the device interface.

**Program EEPROM**

Refer to Program Electronically Erasable Programmable Read Only Memory.

**Program Electronically Erasable Programmable Read Only Memory (Program EEPROM)**

Contains the boot and diagnostic code for the MPB-II. Also contains the PMMU translation tables. Mostly synonymous with MPB ROM on the MPB-I. See also EEPROM.

**Programming System Report (PSR)**

An official report to Control Data of a problem with Control Data software. A PSR can be sent to Control Data either in hard-copy form, or by using the on-line SOLVER program.

**Protocol**

A set of conventions that must be followed to achieve complete communications between the computer-related resources in a network. A protocol can reflect the following:

1. A set of pre-defined coding sequences, such as the control byte envelopes added to (or removed from) data exchanged with a terminal.
2. A set of data addressing and division methods, such as the block mechanism used between a network application program and Network Access Method.
3. A set of procedures that control communications, such as the supervisory message sequences used between a network application program and Network Access Method.

**Protocol Stack**

A collection of protocols in successive layers. CDCNET is based on ISO's Open System Interconnection (OSI) reference model, where each system includes a set of layers and each layer supports one or more protocols.

CDCNET phase 2 of OSI support includes support for OSI and TCP/IP protocols for layers 3 and 4. Therefore, CDCNET supports two protocol stacks: OSI and TCP/IP.

**PRU**

Refer to Physical Record Unit.

**PSR**

Refer to Programming System Report.

**PSU**

Refer to Printer Support Utility.

**Public Data Network (PDN)**

A commercial packet-switching network that supports the communications interface described in CCITT protocol X.25.

**Public I/O Station**

An I/O station shared by many users who may submit jobs through it and receive output. The operator who controls a public I/O station does not own the files sent to or read from it. Routing of output files for a public I/O station is controlled through the I/O station's name. A station operator does not have to monitor and control a public I/O station for it to be active. Contrast with Private I/O Station.

**PVC**

Permanent virtual circuit.

**R****Radix**

The base of a number system. For example, 2 is the binary system radix and 10 is the decimal system radix.

**RBF**

Refer to Remote Batch Facility.

**Recorder Log Group**

A logging function in which device interfaces that are sources of log messages report their log messages to a device interface which works with a host application to record the log messages in a network log file. The Independent Log ME controls the log recording function.

**Relay**

Process occurring when CDCNET receives a data unit from a directly connected network solution and transmits the data unit to another directly connected network solution.

**Remote Batch Facility (RBF)**

The network applications software that supports remote batch processing (remote job entry) on NOS.

**Remote Line Monitor**

Displays and/or records all received and transmitted characters on an LIM and port supported by the standard CDCNET CIM firmware and that use protocols defined for Remote Line Monitor.

**RS-232-C**

An Electrical and Electronic Industries Association (EIA) standard that describes the interface between terminals or other Data Terminal Equipment (DTE) and modems or other Data Communications Equipment (DCE) employing a serial binary interchange.

**RS-449**

1. A physical interface standard for data communications used with high speeds and long communication lines.
2. A newer standard than RS-232-C, also used for serial communications. Eventually meant to replace RS-232-C, but backward compatibility is specified in RS-449.

**S****SCL**

Refer to System Command Language.

**SCL Comment**

A comment within a SCL command. The comment is enclosed by quotation marks and is ignored during command processing.

**SDLC**

Refer to Synchronous Data Link Control.

**Segment**

The unit of data exchanged by TCP modules. This term also describes the unit of exchange between any transport protocol modules.

**Server TELNET**

Provides a mechanism for an interactive terminal that uses TCP/IP TELNET services on a foreign host to communicate with the interactive services of NOS/VE.

**Service**

An entity that is external to CDCNET but is registered within CDCNET as being capable of conducting input and output with a terminal or with another service. Services have names. Terminal users connecting to a host are connecting to a service. An example of a service is the Interactive Facility (IAF) on a host.

**Simple Mail Transfer Protocol (SMTP)**

A mail exchange protocol used between hosts on a TCP/IP network. SMTP does not define the end-user interface. However, SMTP provides a program interface to the local mail system.

**SMM**

Refer to System Main Memory.

**SMM4**

A 4 M byte version of the SMM (see System Main Memory).

**SMTP**

Refer to Simple Mail Transfer Protocol.

**SNA**

Refer to Systems Network Architecture.

**SNA3270 TIP**

A terminal interface program that provides IBM 3270 Information Display System users access to CDCNET through an SNA network.

**SNPA Address**

Subnetwork point of attachment address. An address representing the attachment or connection of a system to a subnet. Generally, the SNPA address is a layer 1 address. For Ethernet, the Ethernet station ID represents the SNPA address. For an X.25 subnet, the DTE address represents the SNPA address.

**Socket**

A TCP/IP address used to locate a process on a host. This address is used by Transmission Control Protocol (TCP) and User Datagram Protocol (UDP). It consists of the 32-bit IP address and a 16-bit port number.

**SOLVER**

An online utility maintained by Control Data that contains a database of reported software problems and solutions. SOLVER can be used for writing a PSR to report a problem with software.

**Source Log Group**

A logging function in which device interfaces that are sources of log messages maintain a list of log messages which they will send to recorder device interfaces. The source logging function is controlled by the Dependent Log ME, also known as Log Support Application (LSA).

**SRI International**

A network information center (NIC) providing administrative support services to the Department of Defense for TCP/IP and DDN networks.

**Station Operator**

A person in charge of controlling batch devices in an I/O station by sending commands to the equipment from the station operator console. On NOS/VE, the station operator uses OPERATE\_STATION (OPES) utility commands to control the devices. On NOS, the station operator uses the Remote Batch Facility (RBF) commands to control the devices.

**Statistics**

Refer to Metrics.

**Status**

Information about the current state of a network component: Device Interface (DI), the hardware components (boards, ports) of a device interface, lines and network solutions connected to the device interface, and device interface software.

**Status Command**

A command that requests and displays the operational status of a particular network component, such as a device interface or a network solution.

## Subnet

The concept of a subnet is used both in OSI and TCP/IP. Therefore, there are two definitions of subnet.

1. OSI: In CDCNET, individual systems are connected to each other via different media such as Ethernet and HDLC. A medium connecting two or more CDCNET systems is called a network solution or a subnet. For OSI, a subnet refers to one and only one network solution.
2. TCP/IP: TCP/IP subnetting is a required Internet standard. Subnetting allows a configuration consisting of many physical networks to be addressed with a single IP network number. Each physical network is assigned a subnet number. Each host is addressed based on its network number, subnet number, and host number. These three fields make up the IP address.

## Subnet Identifier

An identifier that identifies a subnet in a CDCNET network. It must be unique, and must not be associated with more than one subnet in a CDCNET network.

## Switched Line

A communication line connected with one device interface, but able to be connected to any one of several terminals via a switching mechanism, such as a dialed telephone line. Contrast with Dedicated Line.

## Synchronous Command Entry Mode

A command control mechanism that prevents operators from entering a command before a previously sent command has executed and returned a response.

## Synchronous Data Link Control (SDLC)

Bit-oriented data link control protocol developed by International Business Machines (IBM).

## System Address

The unique address assigned to a device interface in the network. The system address corresponds to the system title, so that commands and data sent by system title are received at the proper device interface address. See also System Identifier.

## System Command Language (SCL)

The NOS/VE command language on which CDCNET network operations, and configuration and terminal user commands are based.

## System Console

A component of a host operating system that is used to monitor and control the operating system. The system console can also be used to monitor and control CDCNET through the Network Operator Utility (NETOU). See also Host Console.

## System Identifier

At the time of its manufacture, each device interface is assigned a unique 48-bit identification number from a pool of numbers allocated to Control Data by Xerox. This number is written into battery-backed RAM and is used throughout the catenet as the system identifier for that device interface.

The system identifier is used as the Ethernet address for any system that is locally connected to one or more Ethernet network solutions.

See also System Address.

**System Main Memory (SMM)**

A device interface board containing dynamic RAM accessible by all interfaces and the resident main processor board (MPB).

**System Title**

The title assigned to a device interface during logical configuration. This title corresponds to the device interface's system address, so that commands sent to a device interface by system are received at the proper device interface address.

**Systems Network Architecture (SNA)**

IBM standard defining the layers and layer protocols to be used within an IBM network.

**SYSTEMX**

A NOS user name that is used to store files for NOS and CDCNET installation and operations.

**T****T-to-A**

Refer to Terminal-to-Application.

**TCP**

Refer to Transmission Control Protocol.

**TCP/IP**

Refer to Transmission Control Protocol/Internet Protocol.

**TDI**

Refer to Terminal Device Interface.

**TDP**

Refer to Terminal Definition Procedure.

**TELNET Network Virtual Terminal (NVT)**

A TCP/IP protocol that provides presentation layer services for other application protocols. TELNET NVT protocol is roughly equivalent to VTP in the ISO model. It establishes connections and controls interactive virtual circuits.

**Terminal Definition Procedure (TDP)**

An optional configuration file that defines a terminal device or devices connected to a line whenever the line becomes active. A TDP can be used to define a terminal device that differs from the default terminal device type defined by the TIP that controls the line.

**Terminal Device Interface (TDI)**

The CDCNET device interface variant that interconnects terminals, workstations, and unit record devices with an Ethernet local area network.

**Terminal Interface Program (TIP)**

CDCNET software that resides in terminal device interfaces (TDIs) and enables terminals/workstations that employ specific terminal protocols (such as async, HASP, and IBM 3270) to communicate in CDCNET networks.

**Terminal Passthrough**

A CDCNET feature that allows interactive asynchronous terminal traffic to pass through the network transparently. The hosts and terminals interface with each other as if they were directly connected. Terminal passthrough allows a CDCNET-connected terminal user to access non-CDCNET supported hosts, such as NOS/BE and VAX.

**Terminal-to-Application (T-to-A)**

A type of network processing that enables the exchange of data between applications programs that reside on host computers and user terminals or workstations. In this case, protocol conversions occur so that transmitted data is understood both at the host and at the terminal or workstation.

**Terminal User Procedure (TUP)**

An optional configuration file that defines attributes of terminals and connections. A TUP can be used to define attributes for a particular terminal model or a group of terminals. A TUP for a terminal is executed when the communication line from the terminal to the supporting device interface becomes active.

**Test**

Software and/or microcode that provides detection and confidence capabilities. Also known as a diagnostic.

**TIP**

Refer to Terminal Interface Program.

**Title**

A string of 1 through 255 ASCII characters that identify a network service component such as a device interface or a gateway. The Directory Management Entity refers to the component by its title.

A name used to identify services available in the network. Titles are known throughout the catenet. Contrast with Logical Names, which are local to individual device interfaces.

**Transmission Control Protocol/Internet Protocol (TCP/IP)**

The name given to a suite of protocols that support the ARPANET community. TCP/IP protocol implementation is required within CDCNET for connectability to Defense Data Networks (MILNET or ARPANET) and to workstations that use TCP/IP.

**Transmission Control Protocol (TCP)**

A term used in DDN networks that refers to an end-to-end, connection-oriented protocol corresponding to the CDCNET Transport layer. This protocol is required for connection to MILNET, ARPANET, and TCP/IP workstations.

**Transmission Media**

Provides the physical channel used to interconnect device interfaces in a network.

**Transport Layer**

Open Systems Interconnection (OSI) layer 4. Provides end-to-end control of a communication session once the path has been established. It allows processes to exchange data reliably and sequentially, regardless of which systems are communicating.

**Trunk**

A logical definition of a line and the communications software that allows the line to carry data between communications controllers. These controllers could be device interfaces or devices for other networks. Trunks going to other networks, such as DECNET or SNA, are not recognized as network solutions.

**TUP**

Refer to Terminal User Procedure.

**U****UDP**

See User Datagram Protocol.

**ULP**

Refer to Upper Layer Protocols.

**Unit Record Interface (URI)**

A Line Interface Module (LIM)-type peripheral circuit board that interfaces with the LIM bus and is used with the Communications Interface Module (CIM). The URI provides an 8-bit parallel interface for the operation of character or line printer. The URI includes all necessary drivers, receivers, timing, and control circuitry to drive one printer at a time.

**Upper Layer Protocols (ULP)**

A collective term for layers 5, 6, and 7 of the Open System Interconnection (OSI) network reference model.

**URI**

Refer to Unit Record Interface.

**User Datagram Protocol (UDP)**

A layer of TCP/IP interface software. UDP provides datagram-oriented services that are unreliable (connectionless), but low overhead, to upper layer protocols such as Domain Name resolver and server and NFS.

**User TELNET**

Allows a CDCNET terminal to connect to a foreign host's interactive service using TCP/IP TELNET communications.



## V

### VE Interface

A channel between a NOS/VE host and an MDI or ICA-II that uses the OSI protocol stack.

### Version

A four-digit hexadecimal number indicating the release version of the software loaded in a device interface.

### Vertical Format Unit (VFU) Load Image

A fixed or loadable image that defines format control channels and vertical spacing for a printer.

### VFU

Refer to Vertical Format Unit (VFU) Load Image.

### VFU Load Procedure (VLP)

A vertical format unit (VFU) load image that is defined in a procedure file. Commands in the procedure file specify the location of printer format control channels. When the procedure file executes, a binary version of the VFU load image is loaded into the printer.

### Virtual Circuit

A connection between a source and a receiver in a network that may be realized by different circuit configurations during data transmission. Also called a logical circuit.

### VLP

Refer to VFU Load Procedure.

## W

### WAN

Refer to Wide Area Network.

### Well-Known Port

Ports used in TCP to name the ends of logical connections which carry long-term conversations. For the purpose of providing services to unknown callers, a service contact port is defined. A contact port is sometimes referred to as a well-known port.

### Wide Area Network (WAN)

A wide area network (WAN) such as ARPANET or DDN.

### Wildcard Characters

Characters that can be used in place of other characters as variables. Wildcard characters can be used to replace single characters, to replace strings of characters, or to match characters to those specified in a list.

## **X**

### **X.PC**

An asynchronous data communications protocol that improves the networking capabilities of personal computers. It also allows users to have multiple active virtual circuits.

### **X.25 Asynchronous TIP**

Also known as X.29 PAD, this is a CDCNET feature that allows asynchronous terminals to access CDCNET either by a Public Data Network (PDN) that supports the X.3 Packet Assembly/Dissassembly (PAD) facility or by the terminals operating in X.25 mode.

### **X.25 Gateway**

A gateway used to transfer data from a host connected to CDCNET to a host in another network at the other end of the X.25 circuit. The X.25 gateway allows host-to-host (A-to-A) connections to take place over an X.25 circuit. A-to-A connections over X.25 circuits are provided by the Network Products applications.

### **XID**

An identifier used for SNA3270 configurations. The XID is a psuedo-model ID that identifies a DI in the SNA network. CDCNET commands use the variable part of the XID, which contains five hexadecimal digits called the terminal identifier. An SDLC station returns this identifier in an SDLC exchange identification command. The DI adds a fixed prefix to this variable part to create a 6-byte XID.



# Character Set

## B

This appendix lists the ASCII character set, with conversions to decimal, hexadecimal and octal codes.

**Table B-1. ASCII Character Set**

| Decimal Code | Hexadecimal Code | Octal Code | Graphic or Mnemonic | Name or Meaning           |
|--------------|------------------|------------|---------------------|---------------------------|
| 000          | 00               | 000        | NUL                 | Null                      |
| 001          | 01               | 001        | SOH                 | Start of heading          |
| 002          | 02               | 002        | STX                 | Start of text             |
| 003          | 03               | 003        | ETX                 | End of text               |
| 004          | 04               | 004        | EOT                 | End of transmission       |
| 005          | 05               | 005        | ENQ                 | Enquiry                   |
| 006          | 06               | 006        | ACK                 | Acknowledge               |
| 007          | 07               | 007        | BEL                 | Bell                      |
| 008          | 08               | 010        | BS                  | Backspace                 |
| 009          | 09               | 011        | HT                  | Horizontal tabulation     |
| 010          | 0A               | 012        | LF                  | Line feed                 |
| 011          | 0B               | 013        | VT                  | Vertical tabulation       |
| 012          | 0C               | 014        | FF                  | Form feed                 |
| 013          | 0D               | 015        | CR                  | Carriage return           |
| 014          | 0E               | 016        | SO                  | Shift out                 |
| 015          | 0F               | 017        | SI                  | Shift in                  |
| 016          | 10               | 020        | DLE                 | Data link escape          |
| 017          | 11               | 021        | DC1                 | Device control 1 (X-ON)   |
| 018          | 12               | 022        | DC2                 | Device control 2          |
| 019          | 13               | 023        | DC3                 | Device control 3 (X-OFF)  |
| 020          | 14               | 024        | DC4                 | Device control 4          |
| 021          | 15               | 025        | NAK                 | Negative acknowledge      |
| 022          | 16               | 026        | SYN                 | Synchronous idle          |
| 023          | 17               | 027        | ETB                 | End of transmission block |
| 024          | 18               | 030        | CAN                 | Cancel                    |
| 025          | 19               | 031        | EM                  | End of medium             |
| 026          | 1A               | 032        | SUB                 | Substitute                |
| 027          | 1B               | 033        | ESC                 | Escape                    |
| 028          | 1C               | 034        | FS                  | File separator            |
| 029          | 1D               | 035        | GS                  | Group separator           |
| 030          | 1E               | 036        | RS                  | Record separator          |
| 031          | 1F               | 037        | US                  | Unit separator            |

*(Continued)*

Table B-1. ASCII Character Set (Continued)

| Decimal Code | Hexadecimal Code | Octal Code | Graphic or Mnemonic | Name or Meaning     |
|--------------|------------------|------------|---------------------|---------------------|
| 032          | 20               | 040        | SP                  | Space               |
| 033          | 21               | 041        | "                   | Exclamation point   |
| 034          | 22               | 042        | #                   | Quotation marks     |
| 035          | 23               | 043        |                     | Number sign         |
| 036          | 24               | 044        | \$                  | Dollar sign         |
| 037          | 25               | 045        | %                   | Percent sign        |
| 038          | 26               | 046        | &                   | Ampersand           |
| 039          | 27               | 047        | '                   | Apostrophe          |
| 040          | 28               | 050        | (                   | Opening parenthesis |
| 041          | 29               | 051        | )                   | Closing parenthesis |
| 042          | 2A               | 052        | *                   | Asterisk            |
| 043          | 2B               | 053        | +                   | Plus                |
| 044          | 2C               | 054        | ,                   | Comma               |
| 045          | 2D               | 055        | -                   | Hyphen              |
| 046          | 2E               | 056        | .                   | Period              |
| 047          | 2F               | 057        | /                   | Slant               |
| 048          | 30               | 060        | 0                   | Zero                |
| 049          | 31               | 061        | 1                   | One                 |
| 050          | 32               | 062        | 2                   | Two                 |
| 051          | 33               | 063        | 3                   | Three               |
| 052          | 34               | 064        | 4                   | Four                |
| 053          | 35               | 065        | 5                   | Five                |
| 054          | 36               | 066        | 6                   | Six                 |
| 055          | 37               | 067        | 7                   | Seven               |
| 056          | 38               | 070        | 8                   | Eight               |
| 057          | 39               | 071        | 9                   | Nine                |
| 058          | 3A               | 072        | :                   | Colon               |
| 059          | 3B               | 073        | ;                   | Semicolon           |
| 060          | 3C               | 074        | <                   | Less than           |
| 061          | 3D               | 075        | =                   | Equals              |
| 062          | 3E               | 076        | >                   | Greater than        |
| 063          | 3F               | 077        | ?                   | Question mark       |
| 064          | 40               | 100        | @                   | Commercial at       |
| 065          | 41               | 101        | A                   | Uppercase A         |
| 066          | 42               | 102        | B                   | Uppercase B         |
| 067          | 43               | 103        | C                   | Uppercase C         |
| 068          | 44               | 104        | D                   | Uppercase D         |
| 069          | 45               | 105        | E                   | Uppercase E         |
| 070          | 46               | 106        | F                   | Uppercase F         |
| 071          | 47               | 107        | G                   | Uppercase G         |

(Continued)

**Table B-1. ASCII Character Set (Continued)**

| Decimal Code | Hexadecimal Code | Octal Code | Graphic or Mnemonic | Name or Meaning |
|--------------|------------------|------------|---------------------|-----------------|
| 072          | 48               | 110        | H                   | Uppercase H     |
| 073          | 49               | 111        | I                   | Uppercase I     |
| 074          | 4A               | 112        | J                   | Uppercase J     |
| 075          | 4B               | 113        | K                   | Uppercase K     |
| 076          | 4C               | 114        | L                   | Uppercase L     |
| 077          | 4D               | 115        | M                   | Uppercase M     |
| 078          | 4E               | 116        | N                   | Uppercase N     |
| 079          | 4F               | 117        | O                   | Uppercase O     |
| 080          | 50               | 120        | P                   | Uppercase P     |
| 081          | 51               | 121        | Q                   | Uppercase Q     |
| 082          | 52               | 122        | R                   | Uppercase R     |
| 083          | 53               | 123        | S                   | Uppercase S     |
| 084          | 54               | 124        | T                   | Uppercase T     |
| 085          | 55               | 125        | U                   | Uppercase U     |
| 086          | 56               | 126        | V                   | Uppercase V     |
| 087          | 57               | 127        | W                   | Uppercase W     |
| 088          | 58               | 130        | X                   | Uppercase X     |
| 089          | 59               | 131        | Y                   | Uppercase Y     |
| 090          | 5A               | 132        | Z                   | Uppercase Z     |
| 091          | 5B               | 133        | [                   | Opening bracket |
| 092          | 5C               | 134        | \                   | Reverse slant   |
| 093          | 5D               | 135        | ]                   | Closing bracket |
| 094          | 5E               | 136        | ^                   | Circumflex      |
| 095          | 5F               | 137        | _                   | Underline       |
| 096          | 60               | 140        |                     | Grave accent    |
| 097          | 61               | 141        | a                   | Lowercase a     |
| 098          | 62               | 142        | b                   | Lowercase b     |
| 099          | 63               | 143        | c                   | Lowercase c     |
| 100          | 64               | 144        | d                   | Lowercase d     |
| 101          | 65               | 145        | e                   | Lowercase e     |
| 102          | 66               | 146        | f                   | Lowercase f     |
| 103          | 67               | 147        | g                   | Lowercase g     |
| 104          | 68               | 150        | h                   | Lowercase h     |
| 105          | 69               | 151        | i                   | Lowercase i     |
| 106          | 6A               | 152        | j                   | Lowercase j     |
| 107          | 6B               | 153        | k                   | Lowercase k     |
| 108          | 6C               | 154        | l                   | Lowercase l     |
| 109          | 6D               | 155        | m                   | Lowercase m     |
| 110          | 6E               | 156        | n                   | Lowercase n     |
| 111          | 6F               | 157        | o                   | Lowercase o     |

*(Continued)*

**Table B-1. ASCII Character Set (Continued)**

| <b>Decimal Code</b> | <b>Hexadecimal Code</b> | <b>Octal Code</b> | <b>Graphic or Mnemonic</b> | <b>Name or Meaning</b> |
|---------------------|-------------------------|-------------------|----------------------------|------------------------|
| 112                 | 70                      | 160               | p                          | Lowercase p            |
| 113                 | 71                      | 161               | q                          | Lowercase q            |
| 114                 | 72                      | 162               | r                          | Lowercase r            |
| 115                 | 73                      | 163               | s                          | Lowercase s            |
| 116                 | 74                      | 164               | t                          | Lowercase t            |
| 117                 | 75                      | 165               | u                          | Lowercase u            |
| 118                 | 76                      | 166               | v                          | Lowercase v            |
| 119                 | 77                      | 167               | w                          | Lowercase w            |
| 120                 | 78                      | 170               | x                          | Lowercase x            |
| 121                 | 79                      | 171               | y                          | Lowercase y            |
| 122                 | 7A                      | 172               | z                          | Lowercase z            |
| 123                 | 7B                      | 173               | {                          | Opening brace          |
| 124                 | 7C                      | 174               |                            | Vertical line          |
| 125                 | 7D                      | 175               | }                          | Closing brace          |
| 126                 | 7E                      | 176               | -                          | Tilde                  |
| 127                 | 7F                      | 177               | DEL                        | Delete                 |

# DI Reset Codes

C

This appendix lists the DI reset codes numerically and suggests actions based on them. Table C-1 provides the numerical list of reset codes. The Action Code column in table C-1 is keyed to the suggested actions, which follow the table.

**Table C-1. Numerical List of DI Reset Codes**

| Numeric Code | Reason Code                     | Issuing Component        | Action Code |
|--------------|---------------------------------|--------------------------|-------------|
| 00(16)       | power_up_reset                  | MPB ROM                  | DA          |
| 02(16)       | manual_reset                    | MPB ROM                  | DA          |
| 03(16)       | halt_memory_fault               | MPB ROM                  | HW          |
| 04(16)       | dead_man_time_out               | MPB ROM                  | SW          |
| 05(16)       | pp_channel_master_clear         | ICA Boot                 | DA          |
| 06(16)       | reset_function                  | ICA Boot                 | DA          |
| 08(16)       | sram_parity_error_reset         | MPB-II ROM               | HW          |
| 10(16)       | load_software_too_big           | Initialization Bootstrap | LF          |
| 11(16)       | improper_first_module           | Initialization Bootstrap | LF          |
| 12(16)       | unsatisfied_external            | Initial Loader           | LF          |
| 13(16)       | sysconfig_not_loaded            | Initial Loader           | LF          |
| 14(16)       | post_load_routines_not_found    | Initial Loader           | LF          |
| 15(16)       | reset_at_end_of_quiesce         | Initialization Bootstrap | DA          |
| 16(16)       | unrecognizable_object_text      | Initial Loader           | LF          |
| 17(16)       | duplicate_entry_point           | Initial Loader           | LF          |
| 18(16)       | task_error_no_recovery_proc     | System Ancestor          | SW          |
| 19(16)       | task_error_exceed_max_recovers  | System Ancestor          | SW          |
| 1a(16)       | task_error_unrecoverable        | System Ancestor          | SW          |
| 1b(16)       | no_configuration_file_obtained  | Configuration Procurer   | OP          |
| 1c(16)       | configuration_file_read_error   | Configuration Procurer   | OP          |
| 1d(16)       | not_enough_memory_for_buffers   | Loader                   | LF          |
| 1e(16)       | identification_record_expected  | Loader                   | LF          |
| 1f(16)       | unexpected_idr_encountered      | Loader                   | LF          |
| 20(16)       | premature_eof_on_file           | Loader                   | LF          |
| 21(16)       | absolute_length_too_large       | Loader                   | LF          |
| 22(16)       | invalid_object_text_version     | Loader                   | LF          |
| 23(16)       | invalid_module_kind             | Loader                   | LF          |
| 24(16)       | invalid_module_attribute        | Loader                   | LF          |
| 25(16)       | invalid_section_ordinal         | Loader                   | LF          |
| 26(16)       | duplicate_section               | Loader                   | LF          |
| 27(16)       | invalid_section_kind            | Loader                   | LF          |
| 28(16)       | invalid_allocation_alignment    | Loader                   | LF          |
| 29(16)       | invalid_offset                  | Loader                   | LF          |
| 2a(16)       | storage_allocation_failed       | Loader                   | OP/LF       |
| 2b(16)       | undefined_section               | Loader                   | LF          |
| 2c(16)       | reference_outside_of_section    | Loader                   | LF          |
| 2d(16)       | invalid_address_kind            | Loader                   | LF          |
| 2e(16)       | invalid_number_of_bytes_spanned | Loader                   | LF          |
| 2f(16)       | transfer_sym_entry_pt_not_found | Loader                   | LF          |
| 30(16)       | parameter_verification_error    | Loader                   | LF          |
| 31(16)       | loader_table_not_found          | Loader                   | LF          |

(Continued)



**Table C-1. Numerical List of DI Reset Codes (Continued)**

| <b>Numeric Code</b> | <b>Reason Code</b>              | <b>Issuing Component</b> | <b>Action Code</b> |
|---------------------|---------------------------------|--------------------------|--------------------|
| 32(16)              | kill_system_with_dump           | KILS Command             | DA                 |
| 33(16)              | kill_system_without_dump        | KILS Command             | DA                 |
| 34(16)              | stop_executive                  | Executive                | SW                 |
| 35(16)              | module_checksum_is_invalid      | System Audits            | LF                 |
| 36(16)              | software_dead_stop              | DEAD STOP                | SW                 |
| 37(16)              | fatal_parity_error              | Executive                | HW                 |
| 38(16)              | ac_low_error                    | Executive                | OP                 |
| 39(16)              | temperature_shutdown_error      | Executive                | OP                 |
| 3A(16)              | reset_from_debugger             | Hardwired in Debugger    | DA                 |
| 3B(16)              | overflowed_stack                | Exec/System Audits       | SW                 |
| 3C(16)              | system_data_not_found           | Initial Loader           | LF                 |
| 3D(16)              | boot_file_media_mismatch        | Boot Start-up Code       | OP/LF              |
| 3E(16)              | cybil_detected_error            | CYBIL Routines           | SW                 |
| 3F(16)              | hard_failure                    | Executive                | HW/SW              |
| 40(16)              | well_known_configuration_change | Configuration Procurer   | NA                 |
| 41(16)              | mpb_ram_ptr_not_found           | Initial Loader           | LF                 |
| 42(16)              | timer_task_module_missing       | Initial Loader           | LF                 |
| 43(16)              | task_received_unknown_itm       | Any Task                 | SW                 |
| 44(16)              | sna-3270_tip_dhcf_abort         | SNA 3270 TIP_DHCF        | SW                 |
| 45(16)              | configuration_cmd_read_error    | Configuration Procurer   | OP                 |
| 46(16)              | eeprom_updated                  | Configuration Procurer   | NA                 |
| 47(16)              | loader_bus_error                | Initial Loader           | LF                 |

## Suggested Actions Based on DI Reset Codes

The remainder of this appendix describes the circumstances in which DIs reset and suggests actions to be taken based on various DI reset codes. This information is keyed to the Action Code column in table C-1 through the abbreviation given for each reset title. Reset code descriptions are organized numerically within the action code groups.

Some of the actions suggested here require tools or facilities that might not be available at your site. If you need further assistance, submit a programming system report (PSR) to Control Data.

### Deliberate Action (DA)

These resets are due to human intervention. For resets that generate dumps, the following steps can be taken to obtain more information:

- Display the executive error table with the Dump Analyzer DISEET subcommand.
- Use the DISSCT subcommand to check for memory and/or buffer regulation.
- Display calls for the running task.
- Use the DISC subcommand to find any task calling DEAD\_STOP, RESET\_DI, or ABORT\_SYSTEM.

Following are descriptions of the causes and suggested actions for the DI resets classified as deliberate actions:

**00(16) = POWER\_UP\_RESET**

No dump file is written under this condition.

**02(16) = MANUAL\_RESET**

The toggle switch on the MPB was manually reset. Additional information should be obtained from the person who reset the system.

**05(16) = PP\_CHANNEL\_MASTER\_CLEAR**

The ICA-II is reset during the host deadstart.

**06(16) = RESET\_FUNCTION**

The ICA-II is reset via a reset function from the PP.

**15(16) = RESET\_AT\_END\_OF\_QUIESCE**

This occurs if a DI is manually reset while the onboard diagnostics are running, or if there was a channel error. If the host error log indicates a channel error, follow the hardware error reporting process. See chapter 5.

**32(16) = KILL\_SYSTEM\_WITH\_DUMP**

The system was reset by the KILL\_SYSTEM operator command. Additional information should be obtained from the person who reset the system.

**33(16) = KILL\_SYSTEM\_WITHOUT\_DUMP**

The system was reset by the KILL\_SYSTEM operator command. Additional information should be obtained from the person who reset the system. No dump file is written under this condition.

**3A(16) = RESET\_FROM\_DEBUGGER**

The RS command was entered from the DI Resident Debugger. Additional information should be obtained from the person who reset the system.

## No Action (NA)

This type of reset does not require any human intervention.

### 40(16) = WELL\_KNOWN\_CONFIGURATION\_CHANGE

The system was reset to immediately and automatically force the changes specified in the configuration file for the MPB RAM.

There are a number of configurable values (such as which protocol stacks are enabled and data buffer size) that are associated with this reset. In addition, if a change in configuration affects the allocation of PMM, reset 40 is invoked. In any case, a dump is never taken when a reset 40 occurs.

### 46(16) = EEPROM\_UPDATED

The system was reset to immediately and automatically force the changes just installed on the MPB-II board and/or one or more SMM4 boards in the DI. A dump is never taken when a reset 46 occurs.

## Operational (OP)

The probable cause for each of these resets is something that can most likely be corrected on-site in the software or environmental conditions. The following suggested actions should be taken.

### 1B(16) = NO\_CONFIGURATION\_FILE\_OBTAINED

Verify proper DI SYSTEM\_ID at location 8400(16) by putting the DI in maintenance mode and using the DI console (see the CDCNET Hardware Installation and Troubleshooting manual). If your network is operating under NOS/VE, issue the ACTIVATE\_NETWORK\_FILE\_ACCESS command. If there is no configuration file for the CDCNET system (or if it is busy or otherwise unavailable), an error is reported on the NOS/VE system job log display. Also, inspect the OCU library for a configuration file with the appropriate system identifier.

Under NOS, verify that NETFS is running properly by examining the NAM K-display. Also, use NETFM to list or attach the configuration file (using the NF parameter).

If no configuration file exists, create one. See the CDCNET Configuration Guide.

### 1C(16) = CONFIGURATION\_FILE\_READ\_ERROR

A configuration file read error occurred or the host file server became unavailable. Check the configuration file and check the status of the file server. If your network is operating under NOS/VE, examine the system job log display to determine if Network File Access restarted or terminated abnormally.

Under NOS, verify that NETFS is running properly by examining the NAM K-display.

**2A(16) = STORAGE\_ALLOCATION\_FAILED**

This indicates that not enough memory was available when the Initial Loader was building the loader data structures for a module. Add more memory or remove modules from the boot file before reloading. This reset code is also listed under Load File (LF) action.

**38(16) = AC\_LOW\_ERROR,**  
**39(16) = TEMPERATURE\_SHUTDOWN\_ERROR**

Environmental problems are suspect. Contact installation management personnel or customer engineers.

**3D(16) = BOOT\_FILE\_MEDIA\_MISMATCH**

The boot file type loaded in the DI did not match the medium it was loaded across; for example, a channel boot file was loaded over ESCI instead of a channel. Look at field boot\_map\_entry\_address in MPB RAM to find out what medium the DI was loaded across. See also this reset under the Load File (LF) heading.

**41(16) = MPB\_RAM\_PTR\_NOT\_FOUND**

The system MPB\_RAM\_PTR entry point (in EXEC\_MPB or ICA\_EXEC\_MPB) is missing from the boot file. Rebuild the boot file, adding this module, before reloading.

**42(16) = TIMER\_TASK\_MODULE**

The TIMER\_TASK\_MODULE (EXEC\_PMM or ICA\_EXEC\_MPB) is missing from the boot file. Rebuild the boot file, adding this module, before loading.

**45(16) = CONFIGURATION\_CMD\_READ\_ERROR**

A configuration command read error occurred or the host file server became unavailable while a configuration file command was executing. Check the configuration file and check the status of the file server. Additionally, the log messages in the dump file should show which command this error occurred on. If your network is operating under NOS/VE, examine the system job log display to determine if Network File Access restarted or terminated normally.

Under NOS, verify that NETFS is running properly by examining the NAM K-display.

## Load File (LF)

The probable cause for each of these resets is a bad load file. If the load file has never been used successfully before, get a correct file. If this load file has been used successfully before, a software or hardware problem is likely. The following descriptions assume the latter to be true.

### **10(16) = LOAD\_SOFTWARE\_TOO\_BIG**

The boot file is too large to fit into SMM. Remove unnecessary modules from the boot file library or add more SMM before reloading.

This reset may also indicate that the on-board diagnostics detected an SMM failure and have marked a block of SMM as unavailable. The remaining SMM is not sufficient for loading the boot file.

### **11(16) = IMPROPER\_FIRST\_MODULE**

The first module in the boot file was not the Initial Loader (INITLDRABS). Check the boot file for irregularities, or to see if the library file might have been moved into a boot file by mistake.

### **12(16) = UNSATISFIED\_EXTERNAL**

The initial load failed because an entry point was referenced that was not externally declared by any module in the boot file. Missing entry point names are displayed on the DI console. Do a test link (using SES procedure) of the boot file object library after deleting any ABS modules.

### **13(16) = SYSCONFIG\_NOT\_LOADED**

The SYS\_CNFG table (in EXEC\_MPB) is missing from the boot file.

**14(16) = POST\_LOAD\_ROUTINES\_NOT\_FOUND**

The entry INITIALIZE\_EXECUTIVE (in POST\_LOADER\_PROCESSING) is missing from the boot file.

16(16) = UNRECOGNIZABLE\_OBJECT\_TEXT,  
 1E(16) = IDENTIFICATION\_RECORD\_EXPECTED,  
 1F(16) = UNEXPECTED\_IDR\_ENCOUNTED,  
 20(16) = PREMATURE\_EOF\_ON\_FILE,  
 21(16) = ABSOLUTE\_LENGTH\_TOO\_LARGE,  
 22(16) = INVALID\_OBJECT\_TEXT\_VERSION,  
 23(16) = INVALID\_MODULE\_KIND,  
 24(16) = INVALID\_MODULE\_ATTRIBUTE,  
 25(16) = INVALID\_SECTION\_ORDINAL,  
 26(16) = DUPLICATE\_SECTION,  
 27(16) = INVALID\_SECTION\_KIND,  
 28(16) = INVALID\_ALLOCATION\_ALIGNMENT,  
 29(16) = INVALID\_OFFSET,  
 2B(16) = UNDEFINED\_SECTION,  
 2C(16) = REFERENCE\_OUTSIDE\_OF\_SECTION,  
 2D(16) = INVALID\_ADDRESS\_KIND,  
 2E(16) = INVALID\_NUMBER\_OF\_BYTES\_SPANNED,  
 2F(16) = TRANSFER\_SYM\_ENTRY\_PT\_NOT\_FOUND

Unknown or unsupported loader text records were found in the boot file or loader library. Check the file module library for irregularities. Check whether newly added modules were compiled with DIDEBUG on or by the wrong compiler or assembler.

**17(16) = DUPLICATE\_ENTRY\_POINT**

A duplicate entry point was detected. Do a test link (using SES procedure) of the boot file module library after deleting any ABS modules.

**1D(16) = NOT\_ENOUGH\_MEMORY\_FOR\_BUFFERS**

There must be enough memory after the initial load for allocation of 100 descriptor buffers and 65535 bytes of data buffers. If not, this reset code is issued. Remove unnecessary modules from boot file library before reloading.

**2A(16) = STORAGE\_ALLOCATION\_FAILED**

This indicates that not enough memory was available when the Initial Loader was building the loader data structures for a module. Add more memory or remove modules from the boot file before reloading. This reset code is also listed under Operational (OP) action.

### **30(16) = PARAMETER\_VERIFICATION\_ERROR**

A compilation-time error was detected: the named procedure XDCL and XREF parameters don't match either in type or number. Types must match exactly; they may not match by synonyms or aliases. Assembler entry points must precede CYBIL references when the CYBIL references do not agree.

### **31(16) = LOADER\_TABLE\_NOT\_FOUND**

A crucial loader data structure was not found. This structure is in module OLL\_PROGRAM\_INTERFACE\_PROCS. Under NOS/VE, use the DISPLAY\_OBJECT\_LIBRARY command to examine the boot file.

Under NOS, do a test link (using the SES.LINK68K procedure) on the object file to determine whether this module is in the boot file.

If the module is missing, add it before reloading.

### **35(16) = MODULE\_CHECKSUM\_IS\_INVALID**

SYSTEM\_AUDITS aborted the system because a loaded module was corrupted. Use the Dump Analyzer to examine the SYSTEM\_AUDITS stack for the module name and section ordinal, then use DISM to examine the affected memory for recognizable patterns. To locate the SYSTEM\_AUDITS stack:

- Use DISTCB, with TI=ALL.
- Examine the output for task name SYSTEM\_AUDITS.
- Display stack length number of bytes from the stack segment address in the SYSTEM\_AUDITS TCB. This is the SYSTEM\_AUDITS stack.

### **3C(16) = SYSTEM\_DATA\_NOT\_FOUND**

The SYSTEM\_DATA entry point (in SYSTEM\_AUDITS) is missing from the boot file. Rebuild the boot file, adding this module before reloading.

### **3D(16) = BOOT\_FILE\_MEDIA\_MISMATCH**

The boot file type loaded in the DI did not match the medium it was loaded across; for example, a channel boot file was loaded over ESCI instead of a channel. Look at field boot\_map\_entry\_address in MPB RAM to find out what medium the DI was loaded across. Look at the XDCL'ed variable abort\_message to see what the boot file type is.

### **47(16) = LOADER\_BUS\_ERROR**

A bus error occurred during the initial load sequence. If any SMM errors occurred while leaving on-board diagnostics, the fault LED remains lit on the respective board(s).

## Hardware (HW)

A hardware problem is the probable cause for each of these resets. Perform the suggested hardware problem isolation or correction.

### **03(16) = HALT\_MEMORY\_FAULT**

A double-bit SMM error occurred. Check NPA reports to identify failing SMM board.

Board failure might show on indicator light if onboard diagnostics failed; this is seen after the DI resets and is going through diagnostics. See the CDCNET Hardware Installation and Troubleshooting manual.

### **08(16) = SRAM\_PARITY\_ERROR\_RESET**

A parity error occurred reading MPB-II causing a hardware reset. The reset recovery register indicates to the onboard diagnostics that a SRAM parity error was the cause of the reset. The contents of the reset recovery register is saved in the card map table. The reset recovery register also contains the memory bank which has the parity error on the byte. The failure management software logs information pertaining to the SRAM parity error at system restart.

### **37(16) = SMM\_DOUBLE\_BIT\_ERROR**

A double-bit SMM error occurred. Try the reset or power-on diagnostics to isolate the failing SMM board. See the CDCNET Hardware Installation and Troubleshooting manual.

### **3F(16) = HARD\_FAILURE**

This reset code is part of CDCNET's failure management feature. A hard failure is defined as one from which recovery is not possible; it can be caused by hardware or software.

In the error log file, this message indicates the board slot number for the DI subsystem where the failure occurred. A separate log message is issued for the failing subsystem or its failed software. Examine the executive error table for clues.



## Software (SW)

A software bug is the probable cause for each of these resets. Submit a PSR with the dump file and CDCNET log file.

### 04(16) = DEAD\_MAN\_TIME\_OUT

A running task took too long to execute, preventing SYSTEM\_AUDITS from resetting the timer.

Use the Dump Analyzer to determine why the task timed out:

1. Use the DISTCB subcommand to identify the task with the task state RUNNING—this is the task that timed out.

2. Use the DISSCT subcommand to look at the following values:

INTERRUPT FIREWALL CHAIN ADDRESS. This identifies the interrupt processor.

BINARY TIME-OF-DAY. This indicates the millisecond clock value at the time of failure.

3. Use the DISM subcommand to look at the LAST\_DEADMAN\_RESET value in the system data record.

If the difference between the binary time-of-day and LAST\_DEADMAN\_RESET is less than 10,000(10) and the interrupt firewall chain address was 0, then the error is probably hardware-related. Try to isolate the problem using the CDCNET Hardware Installation and Troubleshooting manual before writing a PSR.

18(16) = TASK\_ERROR\_NO\_RECOVERY\_PROC,  
 19(16) = TASK\_ERROR\_EXCEED\_MAX\_RECOVERS,  
 1A(16) = TASK\_ERROR\_UNRECOVERABLE,  
 36(16) = SOFTWARE\_DEAD\_STOP

The task that caused the reset has a task state of RUNNING or SUSPEND.

### 34(16) = STOP\_EXECUTIVE

Use the Dump Analyzer DISEET or DISM subcommands to examine the executive error table for error information. The field STOP\_SUPERVISOR\_STACK\_POINTER contains the supervisor stack pointer at the time of the reset. Using DISM, display this stack. The top of the stack contains the return address to the caller of STOP\_EXEC.

**3B(16) = OVERFLOWED\_STACK**

A stack overflow was detected on a call to the Executive when the value of register A7 was numerically less than the first byte address of the stack, or by SYSTEM\_AUDITS after a task had stopped. Use the VALSA subcommand to reveal violations of stack areas. Or, use DISC to check the affected task for recursive calling. Move large variables off the stack or increase the stack size. Use ALLOCATE/FREE rather than PUSH CYBIL statements, if feasible.

**3E(16) = CYBIL\_DETECTED\_ERROR**

CYBIL run-time routines detected an error (when compiled with range checking on). Correct code and rebuild the boot file before reloading.

**3F(16) = HARD\_FAILURE**

This reset code is part of CDCNET's failure management feature. A hard failure is defined as one from which recovery is not possible; it can be caused by hardware or software. See the description of this reset code under the Hardware (HW) heading.

**43(16) = TASK\_RECEIVED\_UNKNOWN\_ITM**

This reset code indicates that an unknown ITM task message was received by a task.

**44(16) = SNA\_3270\_TIP\_DHCF\_ABORT**

This reset code occurs when the TIP software traps an invalid request response unit.



# Procedures to Enhance Operator Environment

---

**D**

This appendix describes a number of NOS/VE and NOS batch jobs and procedures that facilitate CDCNET network management. The batch jobs are part of the CDCNET product. The procedures are not part of the CDCNET product and PSRs cannot be written against them. CYBER Software Support will answer questions you may have about them. These procedures have been used internally to manage CDCNET and we are now making them available for our customers to use as well.

## CDCNET Network Management Procedures for NOS/VE

The following is a summary of the jobs and procedures available for use on NOS/VE. The batch jobs are part of the CDCNET product. The SCL procedures are in the answer text for PSR CSFA094. The \*EOR separates procedures from one another. Log on to SOLVER to get the source for the procedures.

For more information on SCL procedures, see the NOS/VE System Usage Manual.

The jobs and procedures available under NOS/VE to help CDCNET network management include:

- BROADCAST\_CONFIGURATION\_FILES
- CREATE\_COMMAND\_CONNECTION
- DISPLAY\_PHYSICAL\_NAMES
- DISPLAY\_SYSTEM\_NAMES
- INFORM\_USERS
- PROCESS\_DUMP\_FILES
- SEND\_COMMAND\_EVERYWHERE
- PROCESS\_LOG\_JOB

## **BROADCAST\_CONFIGURATION\_FILES Procedure**

This procedure broadcasts a file containing CDCNET configuration procedures to one or more NOS/VE systems and uses the standard CDCNET procedure REPLACE\_CONFIGURATION\_FILE to replace the procedures on each system. This allows your site to maintain equivalent configuration files on all machines in the CDCNET network. The QTF/PTF product is required to run this procedure.

## **CREATE\_COMMAND\_CONNECTION Procedure**

This procedure allows you to select a group of DIs to work with. Once selected, all following commands are sent to those DIs without entering the SEND\_COMMAND command. Only the command itself needs to be entered.

## **DISPLAY\_PHYSICAL\_NAMES Procedure**

This procedure displays CDCNET device names such as \$DI\_ and \$ICA\_ prefixed names.

## **DISPLAY\_SYSTEM\_NAMES Procedure**

This procedure displays the names in the network typically registered by the CDCNET DEFINE\_SYSTEM command. The content of the display is determined by the title pattern specified by the SYSTEM parameter.

## **INFORM\_USERS Procedure**

This procedure accepts an infinite number of message lines and then uses the WRITE\_TERMINAL\_MESSAGE command to send the message to CDCNET users with active connections. This message can be restricted to users of a particular service or those connected to DIs with a particular title pattern. This procedure resides on \$SYSTEM.OSF\$SITE\_COMMAND\_LIBRARY.

## PROCESS\_DUMP\_FILES Procedure

This procedure allows you to select a group of dump files and to perform management functions on those files. The following menu displays for each dump file:

| Press         | To                                      |
|---------------|---|
| A             | Analyze dump                            |
| B             | Save dump to a backup file              |
| C             | Copy dump                               |
| D             | Delete dump and select another          |
| M             | Move dump to an administrator's catalog |
| V             | Select dump analyzer version            |
| W             | Write summary dump analysis to file     |
| <cr>          | Select another dump                     |
| QUIT          | Stop processing dumps                   |
| anything else | Process as a NOS/VE command             |

The procedure allows management of the dump files without being familiar with the dump analyzer or dump file catalog structure.

## SEND\_COMMAND\_EVERYWHERE Procedure

This procedure allows you to send any CDCNET command to all DIs/ICAs or to a group of DIs/ICAs with a particular title pattern.

## PROCESS\_LOG\_JOB (NPA)

The NPA process log job consists of the following three separate jobs:

```
PROCESS_LOG_JOB
GENERATE_NPA_REPORTS
ARCHIVE_NPA_DATABASES
```

All three jobs reside in file \$SYSTEM.CDCNET.VERSION\_INDEPENDENT.PROCESS\_LOG\_JOB. They are delimited by nested JOB/JOBEND statements. NOS/VE Network Log Management submits the PROCESS\_LOG\_JOB, which, depending on conditions, may create and submit the GENERATE\_NPA\_REPORTS job. This in turn creates and submits the ARCHIVE\_NPA\_DATABASES job.

## PROCESS\_LOG\_JOB

This batch job resides in file \$SYSTEM.CDCNET.VERSION\_INDEPENDENT.PROCESS\_LOG\_JOB. It is submitted by NOS/VE Network Log Management and performs the following functions:

1. Reformats all inactive cycles of the CDCNET log file to NPA databases in catalog \$SYSTEM.CDCNET.ANALYSIS.
2. Copies all processed cycles of \$SYSTEM.CDCNET.LOG to file \$SYSTEM.CDCNET.PROCESSED\_LOG\_FILES and deletes the originals.
3. Submits the GENERATE\_NPA\_REPORTS job once per day to generate NPA reports for the previous day and back up \$SYSTEM.CDCNET.PROCESSED\_LOG\_FILES to tape.

This job saves its output and job log to file \$SYSTEM.CDCNET.ANALYSIS.PROCESS\_LOG\_JOB\_OUTPUT. No output is printed unless a problem occurs.

## GENERATE\_NPA\_REPORTS

This batch job originates as text within the PROCESS\_LOG\_JOB batch job. It is submitted by the PROCESS\_LOG\_JOB batch job and performs the following functions:

1. Generates selected NPA reports, saving them in catalog \$SYSTEM.CDCNET.ANALYSIS.CURRENT\_REPORTS. Existing copies of reports are deleted.
2. Saves the date on which reports were last generated on file \$SYSTEM.CDCNET.ANALYSIS.LAST\_REPORT\_DATE. This file is used by the PROCESS\_LOG\_JOB batch job to decide when to submit the report generator job.
3. Backs up processed raw log file(s) (\$SYSTEM.CDCNET.PROCESSED\_LOG\_FILES) to tape and deletes the file(s).
4. Saves the date of last backup in file \$SYSTEM.CDCNET.LAST\_BACKUP\_DATE. This is used to prevent accidental backup twice in one day (which would result in loss of data) should the job be run more than once.
5. Submits the ARCHIVE\_NPA\_DATABASES batch job to clean up databases.

This job saves its output and job log to file \$SYSTEM.CDCNET.ANALYSIS.GENERATE\_NPA\_REPORTS\_OUTPUT.

## ARCHIVE\_NPA\_DATABASES

This batch job originates as text within the GENERATE\_NPA\_REPORTS batch job. It is submitted by the GENERATE\_NPA\_REPORTS batch job and performs the following functions:

1. Archives the data in the NPA databases residing in catalog \$SYSTEM.CDCNET.ANALYSIS.
2. Eliminates old data from the NPA databases and discards it.

This job saves its output and job log to file \$SYSTEM.CDCNET.ANALYSIS.ARCHIVE\_NPA\_DATABASES\_OUTPUT. No output is printed unless a problem occurs.

## **CDCNET Network Management Procedures for NOS**

The following is a summary of the procedures and jobs available under NOS. These procedures assume a file PROCFIL resides on user name SYSUN on the default family. This user name must be validated for secondary user commands. Many of these procedures require XEDIT.

Log on to SOLVER to get the source for these procedures and batch jobs. They are in the answer text for PSR CSFA081. The \*EOR separates procedures from one another.

The procedures and jobs available under NOS to help CDCNET network management include:

- NPAARC
- NPANLA
- NPANLR
- NPANLT
- NPAREPS

### **NPAARC Procedure**

This procedure is in file NPAARC on username NETADMN along with a FORTRAN program that calculates which databases are more than four days old. Database information older than four days is archived (data deleted).

### **NPANLA (Batch Job)**

This batch job is in file NPANLA on username NETADMN. The main function of NPANLA is to call the procedure NPAARC which archives databases. This job is submitted daily by NPAREPS.



## **NPANLR (Batch Job)**

This batch job is in file NPANLR on username SYSUN. NPANLR is submitted from the system startup procedure. It reformats the previously terminated log file; executes NPANLP to purge log files; and submits another job, NPAREPS; which runs NPA reports.

## **NPANLT Procedure**

This procedure is in file PROCFIL on username SYSUN. NPANLT should be called from the system closedown procedure once per day. NPANLT terminates the active log file and copies all processed raw log files to tape. It also creates a procedure (NPANLP/UN=SYSTEMX) that deletes log files successfully dumped to tape (to be executed later).

## **NPAREPS (Batch Job)**

This batch job is in file NPAREPS on username NETADMN. NPAREPS generates NPA reports and writes them to a file NETREPT on username NETADMN.

It then submits another batch job, NPANLA, to archive databases.

# MPB Memory Map

E

This appendix maps the DI's Main Processor Board (MPB) memory. The addresses given are not offsets, but actual DI memory locations. Figure E-1 shows an overall picture of MPB board slot addressing.

| Address | Slot |   |
|---------|------|---|
| 03FFFF  |      |   |
| 040000  | #0   | CARD_SLOTS  |
| -----   |      |   |
| 050000  | #1   | The MPB may access 16x64K byte segments of non-SMM space. Four of these segments are assigned permanently as MPB local address space. The remaining 12 slots are provided for direct peripheral memory access by the MPB. The board slots logically occupy 050000 through 0FFFFFFF. The numbers allocated represent the physical location or board number to be assigned during installation. Each slot contains 64K bytes of contiguous address space which, when addressed, allow the associated board to logically connect its address bus to the Internal System Bus (ISB). |
| -----   |      |   |
| 060000  | #2   |   |
| -----   |      |   |
| 070000  | #3   |   |
| -----   |      |   |
| 080000  | #4   |   |
| -----   |      |   |
| 090000  | #5   |   |
| -----   |      |   |
| 0A0000  | #6   | Only MCI boards allow direct access. Whether the board allows access or not is determined during startup via the ISB control bus. Attempted access to a nonconfigured board evokes the same response as the attempt to address any nonexistent address; that is, an instruction timeout error is issued to the component attempting the access.   |
| -----   |      |   |
| 0B0000  | #7   |   |
| -----   |      |   |
| 0C0000  | #8   |   |
| -----   |      |   |
| 0D0000  | #9   |   |
| -----   |      |   |
| 0E0000  | #10  | The local RAM of an intelligent peripheral is placed in a dump file at the corresponding board slot address. For example, if a CIM board was installed in slot #5, its memory can be displayed with the following Dump Analyzer subcommand:   |
| -----   |      |   |
| 0F0000  | #11  |   |
| -----   |      |   |
|         |      | DISM A=90000(16) BC=6000(16)  |

Figure E-1. Board Slot Addressing

## MPB RAM Tables

Table E-1 provides information about fixed address memory within MPB RAM. Memory at these addresses is battery-backed. If the DI's AC power source is interrupted for any reason, memory at these addresses is protected and is used to reinitialize the DI.

The offsets given below are actual DI addresses, expressed in hexadecimal.

**Table E-1. MPB RAM Tables**

| Offset | Field Name                   | Description   |
|--------|------------------------------|---|
| +0     | vector                       | An array of pointers to cells that constitute the vector space        |
| +400   | system_id                    | Unique identifier for this hardware box                               |
| +406   | system_id_checksum           | System_id checksum  |
| +408   | table_format_version         | Version of RAM table format   |
| +40A   | status                       | The MPB status register is found in lower four-bits                   |
| +40B   | mpb_ram_zeroed               | A flag that indicates if MPB RAM has been zeroed (box was powered-on) |
| +40C   | smm_size                     | The number of contiguous usable SMM bytes from address 100000(16)     |
| +410   | boot_map_entry_address       | A pointer to the map entry used as the bootstrap board                |
| +414   | auto_dump_table_address      | A pointer to the Auto Dump Table                                      |
| +418   | reset_status                 | The reset status saved from the most recent reset                     |
| +419   | reset_code                   | The reset code (from both software and hardware)                      |
| +41A   | software_error_code          | The software error code   |
| +41B   | hardware_reset_code          | The possible hardware cause for reset                                 |
| +41C   | version                      | Version code found within last accepted help offer PDU                |
| +41E   | network_id                   | The network identifier found within the last accepted help offer PDU  |
| +422   | help_system_id               | The system identifier found within the last accepted help offer PDU   |
| +428   | auto_dump_subroutine_address | A pointer to the routine that generates the Auto Dump Table           |

*(Continued)*

**Table E-1. MPB RAM Tables (Continued)**

| Offset | Field Name                    | Description   |
|--------|-------------------------------|---|
| +42C   | auto_dump_subroutine_length   | Length of the routine that generates the Auto Dump Table, in 16-bit words |
| +42E   | auto_dump_subroutine_checksum | A checksum of the routine that generates the Auto Dump Table              |
| +430   | map_table                     | The Board Map Table is described later in this appendix                   |
| +550   | reserved_4_bytes              | Reserved for future use   |
| +554   | mpb_error_routine_pointer     | A pointer to the MPB error routine  |
| +558   | mpb_error_routine_length      | The length of the MPB error routine, in 16-bit words                      |
| +55A   | pmm_error_routine_pointer     | A pointer to the PMM error routine  |
| +55E   | pmm_error_routine_length      | The length of the PMM error routine, in 16-bit words                      |
| +560   | smm_error_routine_pointer     | A pointer to the SMM error routine  |
| +564   | smm_error_routine_length      | The length of the SMM error routine, in 16-bit words                      |
| +566   | expected_smm_interrupt_flag   | A pointer to the expected SMM interrupt flag                              |
| +56A   | ept_address                   | A pointer to the entry point table  |
| +56E   | loaded_module_list            | A pointer to first loaded module entry                                    |
| +57A   | unsatisfied externals         | A pointer to the unsatisfied externals table                              |
| +57E   | checksum_value                | Checksum value  |
| +580   | checksum_length               | Length of checksummed area in words                                       |
| +582   | checksum_format               | Currently unused  |
| +584   | desbuflen                     | The configured length of descriptor buffers                               |
| +588   | datbuflen                     | The configured length of data buffers                                     |
| +58C   | reserved_memory               | Reserved memory, critical use   |
| +58E   | master_date                   | Master date for system  |
| +592   | reset_time                    | Time at last system reset   |
| +596   | date_initialized              | Flag indicating if master_date or default date value should be used       |

*(Continued)*

Table E-1. MPB RAM Tables (Continued)

| Offset | Field Name                      | Description   |
|--------|---------------------------------|---|
| +597   | time_initialized                | Flag indicating if the real-time clock or default time value should be used |
| +598   | max_pmm_required                | Maximum PMM required  |
| +59C   | channel_max_frame_sizes         | Number of slots in a DI   |
| +5AC   | cdcnet_nsap_address_prefix      | CDCNET address prefix type  |
| +5B7   | cdcnet_nsap_address_size        | CDCNET address size range   |
| +5B7:5 | pad_for_nsap_addr_size          | Unused  |
| +5B8   | cdcnet_nsap_address_prefix_size | Size of the CDCNET address prefix   |
| +5B8:4 | pad_for_nsap_addr_prefix_size   | Unused  |
| +5B9   | osi_protocol_stack_enabled      | True if OSI protocol enabled  |
| +5BA   | unused_carry_over_from_r142     | Unused 1 byte   |
| +5BB   | preferred_protocol_stack        | Preferred protocol is either OSI or XNS                                     |
| +5BB:1 | mpb_ram_initialized             | If true, MPB RAM is initialized   |
| +5BB:2 | pad_for_preferred_stack         | Unused  |
| +5BC   | sys_cnfg_ptr                    | A pointer to Executive's System Configuration Table                         |
| +5C0   | system_ancestor_task_id         | A pointer to the system ancestor TCB  |
| +5C4   | current_transport_selector      | Next transport_selector   |
| +5C6   | data_unit_identifier            | Data unit identifier for CLNS   |
| +5C8   | unused_carry_over_from_r142     | Unused 2 bytes  |
| +5CA   | initial_loader_active           | True if initial loader is active  |
| +5CC   | mpb2_reset_recovery_reg         | Reset recovery register   |
| +5CE   | lwb_filler                      | Two byte filler   |
| +5DO   | system_failure_table            | The system failure table  |
| +682   | reset_40_array                  | Reset reason for 4 latest resets  |
| +684   | reset_40_array_index            | Index to array (a word must be filled up)                                   |
| +686   | mpb_end                         | First header of MPB extent chain  |

## Board Map Table

From byte offset 430(16) to 550(16) in fixed-address memory, there is a table used to record information about the modular hardware installed in a DI. Space is reserved in this table for each of the eight major board slots, as follows:

|                   |     |     |     |     |     |     |     |     |
|-------------------|-----|-----|-----|-----|-----|-----|-----|-----|
| Board Slot Number | 0   | 1   | 2   | 3   | 4   | 5   | 6   | 7   |
| Starting Address  | 430 | 454 | 478 | 49C | 4C0 | 4E4 | 508 | 52C |

The first 14 bytes of each entry in this table have the same structure. The structure of bytes 15 through 24 of each entry depends on the type of board installed in that slot.

### Board Map Common Information

Table E-2 gives descriptions of the fields found in the first 14 bytes of any board map entry.

**Table E-2. Board Map Common Information**

| Offset | Field Name  | Description   |
|--------|---|---|
| +0     | slot_number   | The main board slot number of this board  |
| +1     | icb_read_reg_zero   | The contents of ICB read register zero (see table E-3)                                  |
| +2     | icb_write_register_zero                                       | The contents of ICB write register zero   |
| +3     | icb_write_register_one  | The contents of ICB write register one  |
| +4     | qck_lk_diag_status  | Quicklook diagnostics status; if not zero, testing failed                               |
| +6     | card_version  | Name code extension for this board  |
| +7     | status_extension  | Status extension for this board   |
| +8     | intllgnt_card   | Intelligent board flag; set to zero if the board is not an intelligent peripheral       |
| +9     | byte_wide   | Set to zero if board is not byte wide ROM   |
| +A     | id_rom_tbl_address  | A pointer to the ROM table; set to zero if none exists                                  |
| +E     | icb_address   | The ICB address for this slot   |
| +10    | itb_address   | The ITB address for this slot   |
| +14    | See Board Map Type-Specific Information next in this appendix | Board type-specific fields; see to Board Map Type-Specific Information in this appendix |

**Table E-3. ICB Read Register Zero**

| Bit(s)                  | Description   |                |      |       |                        |   |     |   |     |   |      |     |          |        |   |     |   |     |     |          |                 |   |      |   |     |   |          |                         |   |                |
|-------------------------|---|----------------|------|-------|------------------------|---|-----|---|-----|---|------|-----|----------|--------|---|-----|---|-----|-----|----------|-----------------|---|------|---|-----|---|----------|-------------------------|---|----------------|
| 7                       | If 0, local secondary power bad or quicklook phase 1 failed; if 1, no fault on board  |                |      |       |                        |   |     |   |     |   |      |     |          |        |   |     |   |     |     |          |                 |   |      |   |     |   |          |                         |   |                |
| 6                       | If 0, device not available; if 1, device available  |                |      |       |                        |   |     |   |     |   |      |     |          |        |   |     |   |     |     |          |                 |   |      |   |     |   |          |                         |   |                |
| 5                       | If 0, attention switch is set to off; if 1, attention switch on   |                |      |       |                        |   |     |   |     |   |      |     |          |        |   |     |   |     |     |          |                 |   |      |   |     |   |          |                         |   |                |
| 4                       | If 0, bootstrap not allowed over this board; if 1, bootstrap allowed  |                |      |       |                        |   |     |   |     |   |      |     |          |        |   |     |   |     |     |          |                 |   |      |   |     |   |          |                         |   |                |
| 3-0                     | Board code, as follows:   |                |      |       |                        |   |     |   |     |   |      |     |          |        |   |     |   |     |     |          |                 |   |      |   |     |   |          |                         |   |                |
|                         | <table><tr><th>Category</th><th>Code</th><th>Board</th></tr><tr><td rowspan="4">Intelligent Peripheral</td><td>0</td><td>MPB</td></tr><tr><td>1</td><td>CIM</td></tr><tr><td>2</td><td>ESCI</td></tr><tr><td>3-7</td><td>Reserved</td></tr><tr><td rowspan="3">Memory</td><td>8</td><td>PMM</td></tr><tr><td>9</td><td>SMM</td></tr><tr><td>A-B</td><td>Reserved</td></tr><tr><td rowspan="3">Dump Peripheral</td><td>C</td><td>DISC</td></tr><tr><td>D</td><td>MCI</td></tr><tr><td>E</td><td>Reserved</td></tr><tr><td>Power on MC in Progress</td><td>F</td><td>All except MPB</td></tr></table> | Category       | Code | Board | Intelligent Peripheral | 0 | MPB | 1 | CIM | 2 | ESCI | 3-7 | Reserved | Memory | 8 | PMM | 9 | SMM | A-B | Reserved | Dump Peripheral | C | DISC | D | MCI | E | Reserved | Power on MC in Progress | F | All except MPB |
| Category                | Code  | Board          |      |       |                        |   |     |   |     |   |      |     |          |        |   |     |   |     |     |          |                 |   |      |   |     |   |          |                         |   |                |
| Intelligent Peripheral  | 0   | MPB            |      |       |                        |   |     |   |     |   |      |     |          |        |   |     |   |     |     |          |                 |   |      |   |     |   |          |                         |   |                |
|                         | 1   | CIM            |      |       |                        |   |     |   |     |   |      |     |          |        |   |     |   |     |     |          |                 |   |      |   |     |   |          |                         |   |                |
|                         | 2   | ESCI           |      |       |                        |   |     |   |     |   |      |     |          |        |   |     |   |     |     |          |                 |   |      |   |     |   |          |                         |   |                |
|                         | 3-7   | Reserved       |      |       |                        |   |     |   |     |   |      |     |          |        |   |     |   |     |     |          |                 |   |      |   |     |   |          |                         |   |                |
| Memory                  | 8   | PMM            |      |       |                        |   |     |   |     |   |      |     |          |        |   |     |   |     |     |          |                 |   |      |   |     |   |          |                         |   |                |
|                         | 9   | SMM            |      |       |                        |   |     |   |     |   |      |     |          |        |   |     |   |     |     |          |                 |   |      |   |     |   |          |                         |   |                |
|                         | A-B   | Reserved       |      |       |                        |   |     |   |     |   |      |     |          |        |   |     |   |     |     |          |                 |   |      |   |     |   |          |                         |   |                |
| Dump Peripheral         | C   | DISC           |      |       |                        |   |     |   |     |   |      |     |          |        |   |     |   |     |     |          |                 |   |      |   |     |   |          |                         |   |                |
|                         | D   | MCI            |      |       |                        |   |     |   |     |   |      |     |          |        |   |     |   |     |     |          |                 |   |      |   |     |   |          |                         |   |                |
|                         | E   | Reserved       |      |       |                        |   |     |   |     |   |      |     |          |        |   |     |   |     |     |          |                 |   |      |   |     |   |          |                         |   |                |
| Power on MC in Progress | F   | All except MPB |      |       |                        |   |     |   |     |   |      |     |          |        |   |     |   |     |     |          |                 |   |      |   |     |   |          |                         |   |                |

## Board Map Type-Specific Information

The last 16 bytes of each board map entry are used to store board type-specific information, regardless of the board type installed.

The board type can be determined from the major card status table (MCST) described in appendix F.

### MPB/MPB-II Board

| Offset | Field Name              | Description  |
|--------|-------------------------|--|
| +14    | mpb_error_count         | The number of MPB errors since last reset  |
| +16    | MPB-II_SCSI_error       | Non-zero value indicates an SCSI failure. These are treated as non-fatal errors.   |
| +17    | mpb_short_test          | Non-zero indicates that full power-up diagnostics were not run due to MPB switch 5 being ON  |
| +18    | MPB-II_ram_parity_error | Contents of the Reset Recovery Register for the first recovered RAM MPB-II parity error<br><br>Bit 9 - 1 = RAM Parity Error Reset<br>Bit 4 - 0 = Bank 0 1 = Bank 1<br>Bit 3 - 1 = Byte 3 Parity Error<br>Bit 2 - 1 = Byte 2 Parity Error<br>Bit 1 - 1 = Byte 1 Parity Error<br>Bit 0 - 1 = Byte 0 Parity Error |
| +1A    | mpb_ram_address         | A pointer to the first failing MPB RAM location. The address given is biased by 8000(16) because RAM and ROM are swapped during error testing.   |
| +1E    | mpb_ram_errors          | The number of MPB RAM read parity errors   |
| +20    | unused                  | Bytes 21 through 24 are not used in an MPB entry   |

### ESCI Board

| Offset | Field Name              | Description                      |
|--------|-------------------------|----------------------------------|
| +14    | esci_reserved_status    | ESCI board status; reserved area |
| +15    | esci_transceiver_status | Transceiver status flag          |



**PMM Board**

| Offset | Field Name       | Description                                     |
|--------|------------------|---|
| +14    | pmm_mem_blk_size | The size of each PMM memory block               |
| +15    | filler_2         | Not used  |
| +1A    | pmm_address      | A pointer to the first failing PMM address      |
| +1E    | pmm_errors       | The number of PMM read parity errors            |
| +20    | unused           | Bytes 21 through 24 are not used in a PMM entry |

**SMM Board**

| Offset | Field Name        | Description  |
|--------|-------------------|--|
| +14    | smm_mem_blk_size  | The size of each SMM memory block. Shift left 16 bits for size in bytes; 8 = 512 K; 20 = 2 M |
| +15    | smm_start_blk_0   | The starting address of SMM block zero; if zero, unavailable                                 |
| +16    | smm_start_blk_1   | The starting address of SMM block 1  |
| +17    | smm_start_block_2 | The starting address of SMM block 2  |
| +18    | smm_start_block_3 | The starting address of SMM block 3  |
| +19    | filler_3          | Not used   |
| +1A    | smm_sbe_log       | The contents of the error log for the first SMM single-bit error                             |
| +1C    | smm_sbe_errors    | The number of SMM single-bit errors  |
| +1E    | smm_mbe_log       | The contents of the error log for first SMM multi-bit error                                  |
| +20    | smm_mbe_errors    | The number of SMM multi-bit errors   |
| +22    | smm_rom_version   | The SMM board ROM version number   |

**CIM Board**

| Offset | Field Name | Description  |
|--------|------------|--|
| +14    | lim        | LIM configuration table; 2 bytes per LIM, indicating type and status |

## MPB-II Memory Map and Address Mapping

On the MPB-II there is a Paged Memory Management Unit (PMMU). The PMMU provides address translation and memory protection for a demand-paged virtual memory system. In figure E-2, the logical addresses, when accessed, are mapped to the given physical addresses by the PMMU.

The MPB-II memory map is equivalent to the MPB memory map with the following exceptions (comparisons are made between MPB-II and MPB.).

- Local MPB RAM on the MPB-II is located at \$1000000 to \$0107FFFF. Addresses above \$FFFFFF do not exist on the MPB (i.e. the MC68000 has only a 24-bit address bus). On the MPB, local RAM is located from \$00000000 to \$00003FFF.
- Note that on the MPB-II logical addresses \$00000000 to \$00003FFF and \$01000000 to \$010003FFF are both mapped to physical addresses \$01000000 to \$01003FFF to provide compatibility between MPB post ROM/RAM swap and MPB-II.
- On the MPB-II, logical addresses \$00008000 to \$0000FFFF are used for the Electronically Erasable Programmable Read Only Memory (EEPROM). On the MPB, addresses \$00008000 to \$0000BFFF are used for MPB ROM; however addresses \$0000C000 to \$0000DFFF are unused and \$0000E000 to \$0000FFFF is local I/O. Note that MPB Memory Mapped Input/Output is equivalent with the MPB-II local I/O addresses.
- The Internal Transfer Bus (ITB) and Card Slot addressing is equivalent on the MPB and MPB-II. However, on the MPB-II the local I/O is expanded to include addressing for the SCSI device.
- On the MPB-II, logical addresses \$01080000 to \$01083FFF are mapped to physical addresses \$01004000 to \$01007FFF. Logical addresses \$01004000 to \$01007FFF are not mapped so that Executive stack underflow results in a bus error.
- On the MPB-II, logical addresses \$0108C000 to \$0108FFFF are used for the Logic Cell Array Electronically Erasable Programmable Read Only Memory (LCA EEPROM). The LCA EEPROM contains the configuration data for the XILINX logic cell arrays which contain the bulk of the random logic on the MPB-II.
- On the MPB-II, the logical address sections from \$00000000 to \$00003FFF and from \$0108C000 to \$0108FFFF are only accessible in supervisor state. Accesses to these ranges in user state result in bus errors.
- The following logical address ranges are write-protected from user state programs: \$00000000 to \$00003FFF, \$00008000 to \$0000BFFF, \$0000C000 to \$0000FFFF, \$01000000 to \$01003FFF and \$0108C000 to \$0108FFFF.
- The Program EEPROM and LCA EEPROM on the MPB-II can be automatically updated by software.

| Logical<br>Address |                            | Physical<br>Address          |
|--------------------|----------------------------|------------------------------|
| \$00000000         | Local<br>RAM               | \$01000000                   |
| \$00003FFF         |                            | \$01003FFF                   |
| \$00004000         | Not Used                   | \$00004000                   |
| \$00005FFF         |                            | \$00005FFF                   |
| \$00006000         | Local I/O                  | \$00006000                   |
| \$00007FFF         |                            | \$00007FFF                   |
| \$00008000         | Program<br>EEPROM #1       | \$00000000                   |
| \$0000BFFF         |                            | \$00003FFF                   |
| \$0000C000         | Program<br>EEPROM #2       | \$00008000                   |
| \$0000FFFF         |                            | \$0000BFFF                   |
| \$00010000         | Not Used                   | Undefined                    |
| \$0003FFFF         |                            | Bus Error                    |
| \$00040000         | Card Slot<br>Address       | \$00040000                   |
| \$000FFFFF         |                            | \$000FFFFF                   |
| \$00100000         | Internal<br>Transfer Bus   | \$00100000                   |
| \$00FFFFFF         |                            | \$00FFFFFF                   |
| \$01000000         | Local RAM                  | \$01000000                   |
| \$01003FFF         |                            | \$01003FFF                   |
| \$01004000         | Local RAM                  | Exec Stack Underflow         |
| \$01007FFF         |                            | Bus Error                    |
| \$01008000         | Local RAM                  | \$01008000                   |
| \$0107FFFF         |                            | \$0107FFFF                   |
| \$01080000         | Local RAM                  | \$01004000                   |
| \$01083FFF         |                            | \$01007FFF                   |
| \$01084000         | Not Used                   | Undefined                    |
| \$0108BFFF         |                            | Bus Error                    |
| \$0108C000         | Logic Cell<br>Array EEPROM | \$0000C000                   |
| \$0108FFFF         |                            | \$0000FFFF                   |
| \$01090000         | Not Used                   | Undefined                    |
| \$1FFFFFFF         |                            | Bus Error                    |
| \$20000000         | Not Used                   | Variant results because the  |
| \$FFFFFFFF         |                            | upper seven bits are ignored |

Figure E-2. MBP-II Memory Map

This appendix describes several tables and control blocks maintained in D1 memory for use by software components. They are:

- Executive error table including the error buffer
- System configuration table
- System data record
- Hardware status tables
  - Major card status table
  - LIM status table
  - Port status table
  - SMM bank status table
  - PMM bank status table
  - Link information block
- Timer queue
- Directory data stores
  - Registration data store
  - Translation data store
  - Translation request data store
- Routing data stores
  - Least cost routing data store
  - Local DCN data store
  - Received DCN data store
- Terminal support debug table
- Batch data service debug table
- Batch gateway debug table
- Operator support application table
- Loader entry point table
- System memory management table
- Tree root structure

---

**NOTE**

All data structures described in this appendix are valid for CDCNET Version 1.4 and above. All offsets are quoted in hexadecimal.

---

## Executive Error Table

The executive error table is initialized by the DI Executive and is used to maintain information regarding software errors. Preselected fields from this table can be displayed using the Dump Analyzer DISEET subcommand.

The first 28 bytes of the executive error table record general DI error information. These fields are followed by a number of error buffers, one for each error recorded in the executive error table. The total length of the executive error table structure is  $28(16) + (8C(16) * \# \text{ error buffers})$ .

An executive error table that contains one error buffer can be displayed from a dump file using the following Dump Analyzer subcommand:

```
DISM A=EXEC_ERROR_TABLE RC=0B4
```

Table F-1 summarizes the fields in the executive error table. Table F-2 describes the error buffers. All offsets are expressed in hexadecimal. An example showing an exploded view of each table follows table F-4.

**Table F-1. Executive Error Table**

| Offset | Field Name                    | Description  |
|--------|-------------------------------|--|
| +0     | stop_supervisor_stack_pointer | Executive stop supervisor stack pointer                              |
| +4     | last_error_address            | Pointer to last error  |
| +8     | lock_last_error               | Last error pointer being updated                                     |
| +0A    | address_error_being_processed | Flag: address error being processed                                  |
| +0C    | number_of_spurious_interrupts | Number of spurious interrupts  |
| +0E    | smm_error_count               | Number of single-bit SMM errors; two bytes per card                  |
| +1E    | total_error_count             | Total errors inserted into buffers                                   |
| +20    | system_ancestor_tcb           | Pointer to System Ancestor TCB for error intertask messages          |
| +24    | debug_address_called_on_error | Address of DI Debugger, called on error (assumes DI Debugger loaded) |
| +28    | error_buffers                 | Error information structures; see table F-2                          |

### NOTE

Error buffers are not necessarily in chronological order.

Table F-2. Error Buffers

| Offset | Field Name                 | Description  |
|--------|----------------------------|--|
| +0     | executive_error_code       | Type of error; see executive_error_codes below                                   |
| +2     | lock_error_buffer          | Buffer locked for processing   |
| +4     | binclock_at_time_of_error  | Binary clock value at time of error  |
| +8     | d0_thru_d7                 | Registers D0 through D7; 4 bytes per register                                    |
| +28    | a0_thru_a6                 | Registers A0 through A6; 4 bytes per register                                    |
| +44    | status_register            | Status register  |
| +46    | supervisor_stack_pointer   | Supervisor stack pointer   |
| +4A    | user_stack_pointer         | User stack pointer   |
| +4E    | program_counter            | Pointer to program counter 2 through 10 bytes past instruction causing the error |
| +52    | tcb_for_running_task       | Pointer to TCB of task running at time of error                                  |
| +56    | module_name                | Name of module of task running at time of error                                  |
| +76    | module_offset              | Offset in module of task running at time of error                                |
| +78    | error_during_firewall      | Flag: error during firewall  |
| +7A    | firewall_procedure_address | Firewall procedure address   |
| +7E    | mpb_status_register        | MPB status register, case exec error codes of bus and address errors             |
| +80    | CASE exec_error_codes      | See tables F-3 and F-4   |

**Executive\_Error\_Codes**

|                                |                                 |
|--------------------------------|---------------------------------|
| 00(16) = unused_0              | 0A(16) = line_1010_interrupt_i  |
| 01(16) = unused_1              | 0B(16) = line_1111_interrupt_i  |
| 02(16) = bus_error_i           | 0C(16) = smm_single_bit_error_i |
| 03(16) = address_error_i       | 0D(16) = smm_double_bit_error_i |
| 04(16) = illegal_instruction_i | 0E(16) = task_runs_too_long_i   |
| 05(16) = zero_divide_i         | 0F(16) = smm_bus_parity_error_i |
| 06(16) = chk_instruction_i     | 10(16) = format_error           |
| 07(16) = trapv_instruction_i   | 11(16) = mmu_config_error_i     |
| 08(16) = privilege_violation_i | 12(16) = dead_man_timeout_i     |
| 09(16) = trace_interrupt_i     | 13(16) = manual_reset_i         |

**Table F-3. CASE exec\_error\_codes of bus\_error\_i, address\_error\_i for MPB**

| Offset | Field Name                    | Description                   |
|--------|-------------------------------|-------------------------------|
| + 80   | first_failure_capture_address | First failure capture address |
| + 84   | bus_exception_status          | Bus/address exception status  |
| + 86   | access_address                | Access address                |
| + 8A   | instruction_register          | Instruction register          |

**Table F-4. CASE exec\_error\_codes of smm\_single\_bit\_error\_i, smm\_double\_bit\_error\_i**

| Offset | Field Name    | Description                   |
|--------|---------------|-------------------------------|
| + 80   | smm_card_slot | Major board slot of SMM board |
| + 82   | smm_error_log | SMM error log                 |

**Table F-5. CASE exec\_error\_codes of ICA-II**

| Offset | Field Name               | Description          |
|--------|--------------------------|----------------------|
| + 80   | ica_fault_address        | Fault address        |
| + 84   | ica_special_status_word  | Special status word  |
| + 86   | ica_access_address       | Access address       |
| + 8A   | ica_instruction_register | Instruction register |

**Table F-6. CASE exec\_error\_codes of bus\_error\_i, address\_error\_i for MPB-II**

| Offset | Field Name                       | Description                       |
|--------|----------------------------------|-----------------------------------|
| +80    | mpb2_nmi_recovery_register       | NMI recovery register             |
| +82    | mpb2_bus_error_recovery_register | Bus error recovery register       |
| +84    | mpb2_cpu_root_ptr_upper          | 68030 MMU CPU root pointer        |
| +88    | mpb2_cpu_root_ptr_lower          | 68030 MMU CPU root pointer        |
| +8C    | mpb2_translation_control         | 68030 Translation control reg.    |
| +90    | mpb2_special_status_word         | Special status word               |
| +92    | mpb2_instruction_pipe_c          | Instruction pipe stage C          |
| +94    | mpb2_instruction_pipe_b          | Instruction pipe stage B          |
| +96    | mpb2_data_fault_address          | Data cycle fault address          |
| +9A    | mpb2_stage_b_address             | Stage B address; long format only |



## Example:

Following is a section of DI memory that includes the executive error table. This display was made from a dump file using the Dump Analyzer's DISM subcommand. The memory is first presented exactly as it would be displayed by the Dump Analyzer. It is then exploded and tagged for identification of the executive error table fields.

From DISM:

STARTING ADDRESS: 0A58

| HEX ADDR | HEXADECIMAL DATA                        | ASCII DATA       |
|----------|---|------------------|
| 0A58     | 0000 3FEC 0000 0A80 0000 0000 0000 0000 | ?1               |
| 0A68     | 0000 0000 0000 0000 0000 0000 0000 0001 |                  |
| 0A78     | 0010 30DC 0000 0000 0003 FFFF 0196 BE2C | =\ > ,           |
| 0A88     | 0000 0001 0000 0184 0000 0004 0000 FFFF |                  |
| 0A98     | 0000 0004 0000 0001 0000 FFFF 0010 4996 | I                |
| 0AA8     | 001A 07CA 001E 0D0F 001A 0C06 001A 0C30 | J 0              |
| 0AB8     | 0000 0964 001A 374A 0002 F7EA 0000 0000 | d 7J wj          |
| 0AC8     | 3FFE 0002 F78E 0019 DA32 001A 374A 4F50 | ?~ w Z2 7JOP     |
| 0AD8     | 4552 4154 4F52 5F53 5550 504F 5254 5F41 | ERATOR_SUPPORT_A |
| 0AE8     | 5050 4C49 4341 5449 4F4E 2020 2020 3486 | PPLICATION 4     |
| 0AF8     | 0000 0000 0000 6980 0000 6107 3361 001E | i a 3a           |
| 0B08     | 0D25 337C                               | %3               |

## Executive Error Table, Exploded View:

| Hex Address | Hexadecimal Data                   | Field Name                    |
|-------------|------------------------------------|-------------------------------|
| 0A58        | 0000 3FEC                          | stop_supervisor_stack_pointer |
| 0A5C        | 0000 0A80                          | last_error_address            |
| 0A60        | 0000                               | lock_last_error               |
| 0A62        | 0000                               | address_error_being_processed |
| 0A64        | 0000                               | number_of_spurious_interrupts |
| 0A66        | 0000                               | smm_error_count               |
| 0A68        | 0000 0000 0000 0000 0000 0000 0000 | smm_error_count (cont'd)      |
| 0A76        | 0001                               | total_error_count             |
| 0A78        | 0010 3DDC                          | system_ancestor_tcb           |
| 0A7C        | 0000 0000                          | debug_address_called_on_error |

**Error Buffers, Exploded View:**

| Hex Address | Hexadecimal Data                        | Field Name                           |
|-------------|---|--------------------------------------|
| 0A80        | 0003                                    | executive_error_code                 |
| 0A82        | FFFF                                    | lock_error_buffer                    |
| 0A84        | 0196 BE2C                               | binclock_at_time_of_error            |
| 0A88        | 0000 0001 0000 0184 0000 0004 0000 FFFF | d0_thru_d3                           |
| 0A98        | 0000 0004 0000 0001 0000 FFFF 0010 4996 | d4_thru_d7                           |
| 0AA8        | 001A 07CA 001E 0D0F 001A 0C06 001A 0C30 | a0_thru_a3                           |
| 0AB8        | 0000 0964 001A 374A 0002 F7EA           | a4_thru_a6                           |
| 0AC4        | 0000                                    | status_register                      |
| 0AC6        | 0000                                    | supervisor_stack_pointer             |
| 0AC8        | 3FFE                                    | supervisor_stack_pointer (cont'd)    |
| 0ACA        | 0002 F78E                               | user_stack_pointer                   |
| 0ACE        | 0019 DA32                               | program_counter                      |
| 0AD2        | 001A 374A                               | tcb_for_running_task                 |
| 0AD6        | 4F50 4552 4154 4F52 5F53 5550 504F 5254 | module_from_program_counter          |
| 0AE6        | 5F41 5050 4C49 4341 5449 4F4E 2020 2020 | module_from_program_counter (cont'd) |
| 0AF6        | 3486                                    | offset_into_module                   |
| 0AF8        | 0000                                    | error_during_firewall                |
| 0AFA        | 0000 0000                               | firewall_procedure_address           |
| 0AFE        | 6980                                    | mpb_status_register                  |
| 0B00        | 0000 6107                               | first_failure_capture_address1       |
| 0B04        | 3361                                    | bus_exception_status1                |
| 0B06        | 001E 0D25                               | access_address1                      |
| 0B0A        | 337C                                    | instruction_register                 |

## System Configuration Table

The system configuration table is a data structure that retains the status of essential CDCNET system variables. It is a record with fields indicating such things as the highest address in MPB RAM and the states of memory and buffers. Selected fields of the system configuration table in a dump file can be displayed using the DISSCT subcommand.

The entire system configuration table can be displayed from a dump file using the following subcommand:

```
DISM A=SYS_CNFG RC=19E
```

Table F-7 summarizes the fields in the system configuration table. All offsets are expressed in hexadecimal.

**Table F-7. System Configuration Table**

| Offset | Field Name | Description  |
|--------|------------|--|
| +0     | maxprior   | Highest valid priority; lowest is zero                       |
| +2     | databac    | Number of available data buffers                             |
| +4     | descbac    | Number of available descriptor buffers                       |
| +6     | lwfill01   | Fill to keep on long word boundaries                         |
| +8     | lbufflen   | Length of data space, in bytes                               |
| +0C    | sbufflen   | Length of descriptor buffer, in bytes                        |
| +10    | stdstack   | Standard stack allocation                                    |
| +14    | running    | Task pointer to running task                                 |
| +18    | curprior   | Priority of currently running task                           |
| +1A    | schprior   | Highest scheduled priority                                   |
| +1C    | pmtok      | Task preemption permission flag                              |
| +1E    | lwfill02   | Fill to keep on long word boundaries                         |
| +20    | vecslic    | Vector for time slice interrupt                              |
| +24    | vecintvl   | Vector for interval timer interrupt                          |
| +28    | vecclck    | Vector for millisecond interrupt                             |
| +2C    | mpbramtop  | Largest numerical address in MPB RAM                         |
| +30    | privatetop | Largest numerical address in the private memory module (PMM) |
| +34    | globfree   | Number of bytes of free global memory                        |

(Continued)

**Table F-7. System Configuration Table (Continued)**

| Offset | Field Name | Description  |
|--------|------------|--|
| +38    | locfree    | Number of bytes of free private memory                     |
| +3C    | mpbfree    | Number of bytes of free MPB RAM memory                     |
| +40    | globfrag   | Number of extents of free global memory                    |
| +42    | locfrag    | Number of extents of free private memory                   |
| +44    | mpbfrag    | Number of extents of free MPB RAM memory                   |
| +46    | deloadtyp  | Type of memory to release flag for deload task             |
| +48    | deloadtcb  | Task pointer of deload task                                |
| +4C    | deloadmpb  | Deloadable bytes of MPB RAM                                |
| +4E    | lwfill03   | Fill to keep on long word boundaries                       |
| +50    | deloadpmm  | Deloadable bytes of private memory                         |
| +54    | deloadsmm  | Deloadable bytes of global memory                          |
| +58    | mpbthresh  | Deload threshold for MPB RAM                               |
| +5A    | lwfill04   | Fill to keep on long word boundaries                       |
| +5C    | pmmthresh  | Deload threshold for private memory                        |
| +60    | smmthresh  | Deload threshold for global memory                         |
| +64    | pmtreq     | If 1, task yields on next trap 1 or trap 4, if set         |
| +66    | retryflag  | Flag to indicate that a retry is in progress               |
| +68    | clocktyp   | Clock type: if 0, millisecond clock; if 1, real-time clock |
| +6A    | lwfill05   | Fill to keep on long word boundaries                       |
| +6C    | timertcb   | Task pointer of timer task                                 |
| +70    | diagflag   | Current debug support tools set                            |
| +72    | lwfill06   | Fill to keep on long word boundaries                       |
| +74    | binclock   | Binary time of day, accurate to 0.1 second                 |

*(Continued)*

**Table F-7. System Configuration Table (Continued)**

| Offset | Field Name              | Description  |
|--------|-------------------------|--|
| +78    | decclock                | Binary-coded-decimal date/time, accurate to 0.1 second   |
| +80    | assumed__year           | Assumed year (used by the Executive)   |
| +82    | lwfill07                | Fill to keep on long word boundaries   |
| +84    | firewall                | Address of interrupt firewall chain  |
| +88    | prilist                 | Eight entries, one for each task priority level (starting with priority 0); each 16-byte entry is in the form of a QCB, described in appendix H, and indicates information about the tasks ready to execute at that priority |
| +108   | globmem                 | Global memory extent list; a 16-byte entry in the form of a QCB, described in appendix H   |
| +118   | privmem                 | Private memory extent list; a 16-byte entry in the form of a QCB, described in appendix H  |
| +128   | mpbmem                  | MPB RAM memory extent list; a 16-byte entry in the form of a QCB, described in appendix H  |
| +138   | iptlist                 | Defined interrupts list; a 16-byte entry in the form of a QCB, described in appendix H   |
| +148   | lbuffq                  | Data buffer queue; a 16-byte entry in the form of a QCB, described in appendix H   |
| +158   | sbuffq                  | Descriptor buffer queue; a 16-byte entry in the form of a QCB, described in appendix H   |
| +168   | data_buffer_count       | Number of data buffers   |
| +16A   | descriptor_buffer_count | Number of descriptor buffers   |
| +16C   | expire_stp              | Expire state transition processor timer  |
| +16E   | lwfill08                | Fill to keep on long word boundaries   |
| +170   | stack_overflow_space    | Size of allocated stack overflow area  |
| +174   | task_overflowed         | Task pointer of task that has overflowed its stack   |

*(Continued)*

**Table F-7. System Configuration Table (Continued)**

| Offset | Field Name             | Description   |
|--------|------------------------|---|
| +178   | pc_chkinst_address     | Program counter (PC) where CHK instruction executed       |
| +17C   | usp_chkinst_address    | Value of User Stack Pointer when CHK instruction executed |
| +180   | mpb_light_state        | Status of MPB lights                                      |
| +184   | idle_loop_count        | Number of executions of idle loop since last cleared      |
| +186   | lwfill09               | Fill to keep on long word boundaries                      |
| +188   | reservetop             | Largest numerical address in reserved memory              |
| +18C   | rsvfree                | Number of bytes of reserved RAM memory                    |
| +190   | rsvfrag                | Number of extents of reserved global memory               |
| +192   | lwfill10               | Fill to keep on long word boundaries                      |
| +194   | rsvmem                 | Reserved RAM memory extent list                           |
| +1A4   | memory_state           | 0=GOOD, 1=FAIR, 2=POOR, 3=CONGESTED                       |
| +1A6   | buffer_state           | 0=GOOD, 1=FAIR, 2=POOR, 3=CONGESTED                       |
| +1A8   | stp_timer              | Timer identifier of state transition processor            |
| +1AC   | cio_b                  | CIO port B bit settings                                   |
| +1AE   | cio_c                  | CIO port C bit settings                                   |
| +1B0   | supervisor_state_ok    | If 1, supervisor state OK; if 0, user task                |
| +1B2   | mpb_type               | If 0, MPB; if 1, MPB-II; if FF, ICA                       |
| +1B4   | pmm_allocated_any      | Amount of PMM allocated                                   |
| +1B8   | available_to_any       | Amount of PMM available                                   |
| +1BC   | current_pmm_required   | Current amount of PMM required                            |
| +1C0   | maximum_pmm_required   | Maximum amount of PMM required                            |
| +1C4   | deload_pmm_any         | Deloadable amount of PMM                                  |
| +1C8   | boot_startup_completed | If FALSE, not completed; if TRUE, completed               |

## System Data Record

The system data record contains information useful in dump analysis. Its address may be found using the DISMM subcommand. The system data record is structured according to the `system_data_type`, which is defined below.

The entire system data record can be displayed using the following Dump Analyzer subcommand:

```
DISM A=SYSTEM_DATA RC=0A2
```

Table F-8 summarizes the fields in the system data record. All offsets are in hexadecimal.

**Table F-8. System Data Record**

| Offset | Field Name                                  | Description  |
|--------|---|--|
| + 0    | <code>system_name</code>                    | Length in characters of system name                                |
| + 22   | <code>system_state</code>                   | The current state of the system;<br>0000(16) indicates operational |
| + 24   | <code>mpb_use</code>                        | MPB busy percent; average of last ten<br>10-second periods         |
| + 3A   | <code>last_deadman_reset</code>             | The BCD clock value at time of last<br>deadman time-out reset      |
| + 3E   | <code>time_system_became_operational</code> | 15 four-bit fields indicating system<br>startup date/time          |
| + 46   | <code>system_address</code>                 | Network address of the system                                      |
| + 50   | <code>master_clock</code>                   | Pointer to master clock task                                       |
| + 54   | <code>default_channel_trunk_defined</code>  | Set TRUE if default channel trunk is<br>defined                    |
| + 55   | <code>routing_system</code>                 | This system forwards routing<br>information.                       |
| + 56   | <code>default_channel_trunk</code>          | Channel trunk name   |

(Continued)

Table F-8. System Data Record (Continued)

| Offset | Field Name                | Description   |
|--------|---------------------------|---|
| +78    | build_level               | Software build level installed  |
| +7A    | smd_serial_number         | 8-character string indicating this system's serial number                       |
| +82    | abort_system              | Set TRUE if KILL_SYSTEM command is being executed                               |
| +84    | library_version           | Version code found within the last accepted help offer PDU for the current load |
| +86    | helping_system_id         | System identifier found within the last accepted help offer PDU                 |
| +8C    | boot_lib_ptr              | Pointer to boot library   |
| +90    | osi_primary_subnet_state  | Primary subnet state type   |
| +92    | cdcnetsap_address_prefix  | Configured CDCNET NSAP address  |
| +9E    | title_threshold_cost      | Cost of routing title threshold   |
| +A2    | start_configuration       | If TRUE, configuration started  |
| +A3    | validate_user             | Network validation defined for this DI  |
| +A4    | default_validation_domain | Domain used for network validation login when none specified                    |
| +C6    | maximum_login_attempt     | Retry limit for network validation login  |

Example:

Following is a section of DI memory that includes the system data record. This display was made from a dump file using the Dump Analyzer's DISM subcommand.

STARTING ADDRESS: 11684C

| HEX ADDR | HEXADECIMAL DATA                        | ASCII DATA |
|----------|---|------------|
| 11684C   | 0006 4D44 495F 3745 2020 2020 2020 2020 | MDI_7E     |
| 11685C   | 2020 2020 2020 2020 2020 2020 2020 2020 |            |
| 11686C   | 2000 0000 0013 0002 000F 0013 0026 000F | &          |
| 11687C   | 001A 0002 0019 002C 0006 0005 0D5C 8809 | , \        |
| 11688C   | 2713 5421 1940 0000 0001 0800 2510 007E | ' T        |
| 11689C   | 0000 0000 0100 0005 244D 4349 3720 2020 | \$MCI7     |
| 1168AC   | 2020 2020 2020 2020 2020 2020 2020 2020 |            |
| 1168BC   | 2020 2020 2020 2000 5504 2343 4443 4E45 | U #COCNE   |
| 1168CC   | 5423 0000 5514 0000 0000 0000 0010 7430 | T# U t0    |
| 1168DC   | 0101 0003 0000 0000 0000 0000 0000 0000 |            |
| 1168EC   | 0000                                    |            |



## Hardware Status Tables

The following hardware status tables are described in this subsection:

- Major card status table
- LIM status table
- Port status table
- SMM bank status table
- PMM bank status table

### Major Card Status Table

The major card status table (MCST) is used to record the status of each of the DI's major boards. Each board has its own MCST entry as shown in table F-9. Chapter 9 describes how to locate and interpret the MCST from a DI dump file using the DI Dump Analyzer.

**Table F-9. Major Card Status Table Entry**

| Offset | Field Name              | Description  |
|--------|-------------------------|--|
| +0     | device                  | Board-identification string                                    |
| +C     | state                   | Board state; see table 9-3                                     |
| +E     | status                  | Board status; see table 9-4                                    |
| +10    | slot_number             | Major card slot number   |
| +12    | card_type               | Card type of major card  |
| +14    | version                 | Major card version number                                      |
| +16    | rom_level               | ROM level of board in slot                                     |
| +18    | status_extension        | Status extension for this board                                |
| +1A    | board                   | Board status type  |
| +1E    | icb_write_register_zero | Contents of the Internal Control Bus (ICB) write register zero |
| +20    | icb_write_register_one  | Contents of ICB write register one                             |
| +22    | qk_look_diag            | Quicklook diagnostics status; if non-zero, testing failed      |
| +24    | icb_address             | The ICB address for this slot                                  |
| +28    | itb_address             | The ITB address for this slot                                  |
| +2C    | table_address           | Address of user's configuration table                          |
| +30    | dst_ptr                 | Diagnostic status table pointer                                |
| +34    | pst_address             | ICA port table pointer   |

## LIM Status Table

Each LIM board slot in the DI has a LIM status table (LST) entry associated with it that records the associated LIM's status. Chapter 9 describes how to locate and interpret the LST from a DI dump file using the DI Dump Analyzer.

The structure of an LST entry is described in the following table.

**Table F-10. LIM Status Table Entry**

| Offset | Field Name       | Description   |
|--------|------------------|---|
| +0     | device           | Board-identification string   |
| +C     | state            | Board state; see table 9-3  |
| +E     | status           | Board status; see table 9-4   |
| +10    | pst_address      | PST pointer   |
| +14    | lim_number       | LIM card slot   |
| +16    | board_in_slot    | TRUE=LIM board physically in LIM slot   |
| +17    | degraded         | TRUE=LIM is degraded  |
| +18    | cim_sw_8_primary | TRUE=switch is on   |
| +19    | cim_sw_10_local  | TRUE=switch is on   |
| +1A    | lim_kind         | Kind or type of LIM board:<br>0000 RS-449<br>0001 RS-232<br>0002 URD_BP1500<br>0003 URD_B300<br>0004 URD_E_SERIES<br>0005 URD_LINE_WRITER<br>0006 URD_FASTBAND<br>0007 URD_DATA_PRODUCTS_BASIC<br>0008 URD_CENTRONICS_360X_720X<br>0009 URD_CENTRONICS_703<br>000A V.35<br>000B X.21<br>000C LIM_SLOT_EMPTY |
| +1C    | lim_id           | Value of ID read from the LIM   |
| +1E    | parent_cim_slot  | Parent CIM card slot  |
| +20    | ports_supported  | Number of PORTs on LIM  |
| +22    | dst_ptr          | Diagnostic status table pointer   |

Port Status Table

The status of each port associated with a LIM is recorded in its own port status table (PST) entry. Chapter 9 describes how to locate and interpret a PST from a dump file using the DI Dump Analyzer.

Each PST entry has the structure described in the following table.

Table F-11. Port Status Table Entry

| Offset | Field Name  | Description  |
|--------|-------------|--|
| +0     | device      | Port-identification string   |
| +C     | state       | Port state; see table 9-3  |
| +E     | status      | Port status; see table 9-4   |
| +10    | port_number | Port slot number   |
| +12    | port_owner  | Port owner:<br><br>0000 Port available<br>0001 HDLC owner<br>0002 X.25 owner<br>0003 LCM owner |
| +14    | table_ptr   | Address of user configuration table  |
| +18    | dst_ptr     | Diagnostic status table pointer  |

## SMM Bank Status Table

Each system main memory (SMM) board has an SMM bank status table (SBST) associated with it that records its status. Chapter 9 describes how to locate and interpret an SBST from a DI dump file using the DI Dump Analyzer.

The SBST is structured as described in the following two tables. The main structure is described in table F-12. The bank tables field in this table contains one entry for each SMM memory bank (the number of memory banks is indicated in the first field of the SBST). Each of the bank tables field is structured as described in table F-13.

**Table F-12. SMM Bank Table Type**

| Offset | Field Name        | Description            |
|--------|-------------------|------------------------|
| +0     | number_of_banks   | Number of memory banks |
| +2     | memory_block_size | SMM memory block size  |
| +6     | bank tables       | See table F-13         |

**Table F-13. Bank Tables Field (SMM Bank Table Type)**

| Offset | Field Name    | Description                     |
|--------|---------------|---------------------------------|
| +0     | device        | SMM bank-identification string  |
| +C     | state         | Bank state; see table 9-3       |
| +E     | status        | Bank status; see table 9-4      |
| +10    | block_address | Start of memory block address   |
| +14    | dst_ptr       | Diagnostic status table pointer |

## PMM Bank Status Table

If there is a private memory module (PMM) in the DI, it has a PMM bank status table (PBST) associated with it that records its status. Chapter 9 describes how to locate and interpret a PBST from a DI dump file using the DI Dump Analyzer.

The PBST structure is described in the following table.

**Table F-14. PMM Bank Table Type**

| Offset | Field Name        | Description                     |
|--------|-------------------|---------------------------------|
| +0     | memory_block_size | PMM memory block size           |
| +4     | device            | PMM bank-identification string  |
| +10    | state             | Bank state; see table 9-3       |
| +12    | status            | Bank status; see table 9-4      |
| +14    | dst_ptr           | Diagnostic status table pointer |

## Link Information Block

Link information blocks (LIB) contain link related information needed to provide the services and functions associated with a particular link.

The following example shown in table F-15 features the common part of all LIBs.

**Table F-15. Link Interface Block**

| Offset | Field Name                     | Description   |
|--------|--------------------------------|---|
| +0     | next_linked_lib                | Next LIB on network solution list   |
| +4     | nib_ptr                        | Pointer to owning NIB   |
| +8     | output_qcb                     | Queue control blocks  |
| +48    | total_qcb_qcharacters          | Total bytes in all queues   |
| +4C    | interactive_data_amount        | Amount of data to transmit from interactive queue before selecting data from batch priority queue |
| +50    | interactive_bandwidth          | Factor of interactive data to be transmitted for every datagram of batch data                     |
| +52    | batch_bandwidth                | Factor of batch data to be transmitted for every datagram of interactive data                     |
| +54    | output_queue_limit             | Configured value for number of bytes in queue before considered congested                         |
| +58    | previous_queuing_bytes_delay   | Delay to transmit message   |
| +5C    | network_significant_difference | Significant difference based on speed   |
| +5E    | sixty_seconds_of_bytes         | Sixty-seconds worth of bytes  |
| +62    | current_congested_byte_limit   | Current value for number of bytes in queue before considered congested                            |

*(Continued)*

**Table F-15. Link Interface Block (Continued)**

| Offset | Field Name                  | Description                                  |
|--------|-----------------------------|--|
| +66    | nxt_lib_ptr                 | Chain to next LIB on rotary                  |
| +6A    | link_status                 | Status of this link                          |
| +6C    | previous_link_status        | Previous link status of this link            |
| +6E    | ssr_task_id                 | SSR task identifier                          |
| +72    | ssr_tracing                 | Diagnostic trace                             |
| +73    | ssr_collecting_stats        | Collecting statistics                        |
| +74    | ssr_sleeping_lock           | Intranet LIB lock                            |
| +75    | ssr_sleeping                | SSR needs wake-up call                       |
| +76    | ssr_waiting_normal_data     | Wakeup SSR for normal data                   |
| +77    | ssr_waiting_priority_data   | Wakeup SSR for priority data                 |
| +78    | lib_defined                 | LIB defined or booted                        |
| +79    | congested                   | Link is congested                            |
| +7A    | ssr_data_req_proc           | Get data                                     |
| +82    | ssr_data_ind_proc           | Send data                                    |
| +8A    | ssr_status_ind_proc         | Send status                                  |
| +92    | link_type                   | Owner of LIB                                 |
| +94    | trunk_name                  | Name of LIB                                  |
| +B6    | lmcb                        | Link monitor control block                   |
| +FC    | traffic_type                | Network traffic type, must = traffic type on |
| +FE    | last_operational_transition | Used by DISNS for D and T of last transition |
| +108   | why_link_went_down          | Last link down reason                        |
| +10A   | stay_down                   | Time left for unstable trunk to stay down    |
| +10C   | stay_down_period            | Unstable trunk stay down period              |

# Timer Queue

The timer queue manages timers associated with system tasks that must be scheduled for timed or periodic execution. The queue control block (QCB) structure for this queue is at entry point TIMQCB and can be displayed with the following Dump Analyzer subcommand.

```
DISM A=TIMQCB BC=0C
```

Output from this subcommand is formatted as follows:

| STARTING ADDRESS | 10008                         |            |
|------------------|-------------------------------|------------|
| HEX ADDR         | HEXADECIMAL DATA              | ASCII DATA |
| 10008            | 0020 107C 0019 66E2 0010 2512 | f %        |

The second four bytes in this display point to the first entry in the timer queue. The third set of four bytes point to the last entry in the queue.

Continuing this example, use the following Dump Analyzer subcommand to display a linked list of all entries in the timer queue.

```
DISLL A=1966E2 L0=0 BC=1C
```

Output from this subcommand is formatted as follows:

| DISPLAY_LINKED_LIST             |   |            |
|---------------------------------|---|------------|
| START ADDRESS: 1966E2           |   |            |
| HEX ADDR                        | HEXADECIMAL DATA                        | ASCII DATA |
| 1966E2                          | 0010 2408 0016 2154 494D 000E 0004 FFB0 | \$ ITIM    |
| 1966F2                          | 0000 03E8 001E 16A4 001D EF20           |            |
| ADDRESS OF NEXT ELEMENT: 102408 |   |            |
| HEX ADDR                        | HEXADECIMAL DATA                        | ASCII DATA |
| 102408                          | 0010 2538 0016 2154 494D 000E 0005 0014 | %8 ITIM    |
| 102418                          | 0000 03E8 0011 7012 0011 4EDE           | D N        |
| ADDRESS OF NEXT ELEMENT: 102538 |   |            |
| HEX ADDR                        | HEXADECIMAL DATA                        | ASCII DATA |
| 102538                          | 0010 27E4 0016 2154 494D 000E 0005 0014 | ' ITIM     |
| 102548                          | 0000 0888 0010 6822 0011 847A           | k" z       |
| .                               | .                                       | .          |
| .                               | .                                       | .          |
| .                               | .                                       | .          |

Use table F-16 to interpret information in timer queue entries.



**Table F-16. Timer Queue**

| Offset | Field Name             | Description   |
|--------|------------------------|---|
| +0     | next_one               | Pointer to next timer in queue  |
| +4     | length                 | Length of remaining fields in entry   |
| +6     | timer entry identifier | The identifying string 'TIM'  |
| +A     | code                   | Identifying code, as follows:<br><br>0E(16) = Periodic timer<br>0F(16) = Interval timer<br>10(16) = At-time timer<br>11(16) = Periodic timer beginning<br>at-time |
| +C     | tod                    | Time of day to execute timed procedure<br>(in milliseconds)   |
| +10    | period                 | Time of day period, if periodic timer (in<br>milliseconds)  |
| +14    | param                  | Pointer to cell holding subroutine<br>parameter(s)  |
| +18    | proc                   | Address of subroutine   |

## Directory Data Stores

The Directory Management Entity (ME) in each DI maintains title information in the three data stores described in table F-17.

**Table F-17. Directory Data Stores**

| Data Store                            | Description   |
|---------------------------------------|---|
| Registration data store (RDS)         | This data store contains all the currently registered titles. There is no maximum number of entries in this data store. Entries are forward-chained from top to bottom, by the most recent binary clock value.  |
| Translation data store (TDS)          | This data store contains a list of the most recent translation data units received from other systems. Entries are ordered top-to-bottom in a least-recently-used chain. When the maximum number of entries is reached (currently 100), the least-recently-used entry is deleted. The structure of this data store is like that of the registration data store. |
| Translation request data store (TRDS) | This data store contains all the currently active translation requests. Entries are ordered top-to-bottom, in a forward chain, by most recent binary clock value. There is no maximum number of entries in this data store.   |

The addresses of these data stores can be found with the following Dump Analyzer subcommand:

```
DISM A=DIR_DS BC=0C RC=3
```

Output from this subcommand is formatted as follows:

|                  |                               |            |
|------------------|-------------------------------|------------|
| STARTING ADDRESS | 1403AC                        |            |
| HEX ADDR         | HEXADECIMAL DATA              | ASCII DATA |
| 1403AC           | 5452 4453 001C B652 7FFF FFFF | TRDS 6R    |
| 1403B8           | 5244 532D 0010 8AE6 0005 2616 | RDS f &    |
| 1403C4           | 5444 532D 0027 1358 7FFF FFFF | TDS ' X    |

The address of the RDS is in bytes 10(16) through 13(16) of this display. The address of the TDS is in bytes 1C(16) through 1F(16). The address of the TRDS is in bytes 4 through 7.

## The Registration Data Store

The RDS can be displayed with the Dump Analyzer `DISPLAY_LINKED_LIST` subcommand, using the address found in bytes 10(16) through 13(16) of the display from address `DIR_DS`. Use a byte count of 75(16) to show each complete RDS entry with the first 26(10) bytes of the associated title.

The following subcommand continues with the example in progress.

```
DISLL A=108AE6 BC=75 LO=4
```

Display from this subcommand is formatted as follows:

```
DISPLAY_LINKED_LIST
```

```
START ADDRESS 108AE6
```

| HEX ADDR | HEXADECIMAL DATA                        | ASCII DATA       |
|----------|---|------------------|
| 108AE6   | 5244 5320 0021 95A4 0005 2616 A06D 0027 | RDS              |
| 108AF6   | 1358 0000 0000 0800 2510 007E 8809 2713 | x % ~ '          |
| 108B06   | 5430 4100 0000 0000 0000 0010 8B42 0011 | TOA B            |
| 108B16   | 0000 0000 0000 0000 0000 0007 0F00 0000 |                  |
| 108B26   | 0000 0000 0008 0025 1000 7E01 7374 6163 | % ~ stac         |
| 108B36   | 6B7E 9B26 7374 6163 0103 C000 2449 5F4C | k~ &stac @ \$I_L |
| 108B46   | 4F47 5F4D 455F 4341 5445 4E45 5400 0000 | OG_ME_CATENET    |
| 108B56   | 0000 0000 00                            |                  |

```
ADDRESS OF NEXT ELEMENT 2195A4
```

| HEX ADDR | HEXADECIMAL DATA                        | ASCII DATA       |
|----------|---|------------------|
| 2195A4   | 5244 5320 0010 6D36 0005 B14C 9070 0027 | RDS m6 1L p '    |
| 2195B4   | 3ED6 0000 0000 0800 2510 007E 8809 2713 | >V % ~ '         |
| 2195C4   | 5304 0130 0003 0000 0000 0021 9600 0013 | S 0              |
| 2195D4   | 0021 9613 0001 0000 0000 0007 0F00 0000 |                  |
| 2195E4   | 0000 0000 0008 0025 1000 7E01 0000 0000 | % ~              |
| 2195F4   | 0000 9B22 C90A 001D 0103 C04F 2449 5F41 | "I @OSI_A        |
| 219604   | 4C41 524D 5F4D 455F 4341 5445 4E45 5431 | LARM_ME_CATENET1 |
| 219614   | 3938 372C 20                            | 987,             |

```
ADDRESS OF NEXT ELEMENT 106D36
```

| HEX ADDR | HEXADECIMAL DATA                        | ASCII DATA        |
|----------|---|-------------------|
| 106D36   | 5244 5320 0010 7398 000E 09CB 8074 0000 | RDS s K t         |
| 106D46   | 0000 0000 0000 0800 2510 007E 8809 2713 | % ~ '             |
| 106D56   | 5154 2550 0000 0000 0000 0010 6D92 0018 | QTXP m            |
| 106D66   | 0000 0000 0000 0000 0000 0007 0F00 0000 |                   |
| 106D76   | 0000 0000 0008 0025 1000 7E01 6B7E 0101 | % ~ k~            |
| 106D86   | 7374 03FE 6B7E 0102 0103 8057 2453 5953 | st ~k~ W\$SYS     |
| 106D96   | 5445 4D5F 2444 495F 3038 3030 3235 3130 | TEM_\$DI_08002510 |
| 106DA6   | 3030 3745 4F                            | 007E0             |

Use table E-18 to interpret the contents of each RDS entry.

**Table F-18. Registration Data Store**

| Offset | Field Name          | Description  |
|--------|---------------------|--|
| +0     | table_id            | 4-character ASCII string 'RDS'                                   |
| +4     | link                | Pointer to next RDS entry  |
| +8     | binclock            | Time to broadcast entry; no broadcast if 7FFFFFFF                |
| +C     | pdu_sent            | Indicates TDU has been sent                                      |
| +C:1   | broadcast_counter   | Decrementing counter   |
| +C:4   | indication_returned | Not used   |
| +C:5   | length              | Length of entry, in bytes  |
| +E     | key_link            | Forward link for same hash of title                              |
| +12    | dir_id              | Directory entry identifier; system address and BCD date and time |
| +24    | refresh_counter     | Not used   |
| +26    | change_counter      | Identifies the number of changes to the title                    |
| +28    | trds_usage_count    | Not used   |
| +2A    | title_ptr           | Pointer to title string  |
| +30    | userinfo_ptr        | Pointer to string of user information                            |
| +36    | password            | A password must be supplied to change or delete the title        |
| +3A    | address             | Address associated with the title                                |
| +58    | priority            | Priority of the title (1..0ff(16))                               |
| +59    | service             | Directly accessible service                                      |
| +5A    | translation_domain  | Domain where title may be translated                             |
| +5A:1  | distribute_title    | Boolean; set to distribute the title over translation domain     |
| +5A:2  | class               | Title class (ordinal: cdna_internal, cdna_external)              |
| +5C    | title               | The title (maximum length 255 characters)                        |

## The Translation Data Store

The TDS can be displayed with the Dump Analyzer `DISPLAY_LINKED_LIST` subcommand, using the address found in bytes 1C(16) through 1F(16) of the display from address `DIR_DS`. Use a byte count of 75(16) to show each complete TDS entry with the first 26(10) bytes of the associated title.

The following subcommand continues with the example in progress.

```
DISLL A=271358 BC=75 LO=4
```

Output from this subcommand is formatted as follows:

```
DISPLAY_LINKED_LIST

START ADDRESS      271358

HEX ADDR          HEXADECIMAL DATA          ASCII DATA

271358 5444 5320 0027 3ED6 0003 72FE 006D 0021  TDS  '>V r~ m
271368 95A4 0000 0001 0800 2510 0088 8809 2613  $    %    &
271378 4502 3070 0003 0000 0000 0027 13B4 0011  E Op      ' 4
271388 0000 0000 0000 000D 0000 0002 0000 0001
271398 0800 2510 0088 8205 6B7E 2020 2020 2020  %    k~
2713A8 2000 0000 0000 0000 0103 8020 2449 5F4C  $I_L
2713B8 4F47 5F4D 455F 4341 5445 4E45 5420 2020  OG_ME_CATENET
2713C8 2020 2020 20

ADDRESS OF NEXT ELEMENT.  273ED6

HEX ADDR          HEXADECIMAL DATA          ASCII DATA

273ED6 5444 5320 001E 115E 0003 730F 0070 0000  TDS  ^ s p
273EE6 0000 0000 0001 0800 2510 0088 8809 2613  %    &
273EF6 4405 9420 0003 0000 0000 0027 3F32 0013  D      '2
273F06 0027 3F45 0001 0000 0000 0002 0000 0001  '?E
273F16 0800 2510 0088 81E6 2020 2020 2020 2020  %    f
273F26 2000 0000 0000 0000 0103 8006 2449 5F41  $I_A
273F36 4C41 524D 5F4D 455F 4341 5445 4E45 5431  LARM_ME_CATENET1
273F46 0001 0001 00

ADDRESS OF NEXT ELEMENT:  1E115E

HEX ADDR          HEXADECIMAL DATA          ASCII DATA

1E115E 5444 5320 0000 0000 0004 6024 0067 0000  TDS      g
1E116E 0000 0000 0000 0800 2510 0088 8809 2613  %    &
1E117E 4245 9140 0003 0000 0000 001E 11BA 0008  BE @
1E118E 0000 0000 0000 0000 0000 0002 0000 0001
1E119E 0800 2510 0088 81E1 3D61 2020 2020 2020  %    a=a
1E11AE 2000 0000 0000 0000 0103 807E 2449 5F43  ~$I_C
1E11BE 4C4F 434B 5F4D 4574 6163 6B7E 1000 00E4  LOCK_MEtack~ d
1E11CE 00A1 0000 00
```

Use table F-19 to interpret the contents of each TDS entry.

**Table F-19. Translation Data Store**

| Offset | Field Name          | Description   |
|--------|---------------------|---|
| +0     | table_id            | 4-character ASCII string 'TDS'                                    |
| +4     | link                | Pointer to next TDS entry   |
| +8     | binclock            | Binary time of day TDS entry added to the data store or last used |
| +C     | pdu_sent            | Not used  |
| +C:1   | broadcast_counter   | Not used  |
| +C:4   | indication_returned | Not used  |
| +C:5   | length              | Length of entry, in bytes   |
| +E     | key_link            | Forward link for same hash of title                               |
| +12    | dir_id              | Directory entry identifier; system address and BCD date and time  |
| +24    | refresh_counter     | Identifies the need for refreshing cache; 0 if refresh needed     |
| +26    | change_counter      | Identifies the number of changes to the title                     |
| +28    | trds_usage_count    | Identifies the number of translation requests using the TDS entry |
| +2A    | title_ptr           | Pointer to title string   |
| +30    | userinfo_ptr        | Pointer to string of user information                             |
| +36    | password            | Not used  |
| +3A    | address             | Address associated with the title                                 |
| +58    | priority            | Priority of the title (1..0ff(16)) where 1 is highest             |
| +59    | service             | Directly accessible service                                       |
| +5A    | translation_domain  | Not used  |
| +5A:1  | distribute_title    | Not used  |
| +5A:2  | class               | Title class (ordinal: cdna_internal, cdna_external)               |
| +5C    | title               | The title (maximum length 255 characters)                         |

## The Translation Request Data Store

The TRDS can be displayed with the Dump Analyzer `DISPLAY_LINKED_LIST` subcommand, using the address found in bytes 4 through 7 of the display from address `DIR_DS`. Use a byte count of 60(16) to show each complete TRDS entry with the first 26(10) bytes of the associated title.

The following subcommand continues with the example in progress.

```
DISLL A=1CB652 BC=60 LO=4
```

Output from this subcommand is formatted as follows:

```
DISPLAY_LINKED_LIST
START ADDRESS      1CB652

HEX ADDR           HEXADECIMAL DATA           ASCII DATA
1CB652  5452 4453 001C B5BA 7FFF FFFF 8872 0000  TRDS  5:      r
1CB662  0000 2020 2020 2020 2020 2020 2020 2020
1CB672  2020 2020 2020 2020 2000 001C B698 002B          6 +
1CB682  0024 BC1A 0015 1FF2 0000 0000 7FFF FFFF  $<      r
1CB692  00C0 0000 0000 2449 5F41 4C41 524D 5F4D  @  $I_ALARM_M
1CB6A2  455F 4341 5445 4E45 5420 2020 2020 2020  E_CATENET

ADDRESS OF NEXT ELEMENT:  1CB5BA

HEX ADDR           HEXADECIMAL DATA           ASCII DATA
1CB5BA  5452 4453 0000 0000 7FFF FFFF 8870 0000  TRDS      p
1CB5CA  0000 0000 454E 4420 4F46 204C 494E 4520          END OF LINE
1CB5DA  2020 2020 2020 2020 2000 001C B600 0029          6 )
1CB5EA  0025 34EE 0015 0546 0000 0000 7FFF FFFF  %4n  F
1CB5FA  00C0 0000 0000 2449 5F4C 4F47 5F4D 455F  @  $I_LOG_ME_
1CB60A  4341 5445 4E45 5420 2020 2020 2020 2020  CATENET
```

Use table F-20 to interpret the contents of each TRDS entry.

**Table F-20. Translation Request Data Store**

| Offset | Field Name             | Description   |
|--------|------------------------|---|
| +0     | table_id               | 4-character ASCII string 'TRDS'                                 |
| +4     | link                   | Pointer to next TRDS entry                                      |
| +8     | binclock               | Time to broadcast request; no broadcast if 7FFFFFFF             |
| +C     | pdu_sent               | Indicates TRDU has been sent                                    |
| +C:1   | broadcast_counter      | Decrementing counter  |
| +C:4   | indication_returned    | Indicates dir_indication returned                               |
| +C:5   | length                 | Length of entry, in bytes                                       |
| +E     | wait_parms_ptr         | Pointer to sleeping task parameters                             |
| +12    | request_system_address | Address of the system requesting the translation                |
| +27    | version3_request       | Request was a Version 3 Directory PDU.                          |
| +28    | searching_tds          | Boolean; set if TDS is being searched to satisfy the request    |
| +2A    | title_ptr              | Pointer to title string   |
| +30    | user_id                | User identifier   |
| +34    | translation_if         | Address of user procedure to return translation                 |
| +3C    | time                   | Integer   |
| +40    | service                | Directly accessible service                                     |
| +41    | search_domain          | Directory domain (ordinal: local_system, catenet)               |
| +41:1  | recurrent_search       | Boolean; set if recurrent search                                |
| +41:2  | class                  | Title class (ordinal: cdna_internal, cdna_external)             |
| +41:3  | wild_card              | Boolean; set if wild-card title translation                     |
| +42    | non_one_priority_rds   | Linked list of non_one_priority RDS entry information           |
| +46    | rds_tds_scan           | Boolean; set if RDS and TDS tables are currently being searched |
| +48    | title                  | The title (maximum length 255 characters)                       |



## OSI IS-IS Routing Data Store


The OSI IS-IS routing support maintains routing information in the three data stores described in table F-21.

**Table F-21. IS-IS Routing Data Stores**

| Data Store                               | Description   |
|--|---|
| Least cost routing data store (LCRDS)    | This data store is used by IS-IS routing support for determining how to send network protocol data units (NPDUs) to their next intermediate destination.  |
| Local DCN data store (Local DCNDS)       | This data store describes the networks that are directly connected to the DI.   |
| Received DCN data store (Received DCNDS) | This data store records information about networks that are not directly connected to the DI, but that are directly connected to other (relay) systems on this network solution. Entries are built from routing information data units (RIDUs). |

### Least Cost Routing Data Store

The LCRDS is organized into rows, each row pointing to a linked list of the data store entries that apply to a single network. Figure F-1 illustrates the relationship between LCRDS rows and entries.



**Figure F-1. Least Cost Routing Data Store**

A pointer to the first row structure for the least cost routing data store can be displayed with the following Dump Analyzer subcommand:

```
DISM A=11_CURRENT_LCRDS BC=4
```

Output from this subcommand is formatted as follows:

```
STARTING ADDRESS      1340CE
HEX ADDR              HEXADECIMAL DATA      ASCII DATA
1340CE 001C 6462                                db
```

Continuing this example, a linked list of the least cost routing data store *rows* can be displayed with the following Dump Analyzer subcommand:

```
DISLL 1C6462 BC=1A LO=16
```

Output from this subcommand is formatted as follows:

```
DISPLAY_LINKED_LIST
START ADDRESS:      1C6462
HEX ADDR           HEXADECIMAL DATA      ASCII DATA
1C6462 0000 0001 0000 0100 0100 0900 25FF FFFF      %
1C6472 0001 001C BFAC 001C B522                    ", 5"
ADDRESS OF NEXT ELEMENT      1CB522
HEX ADDR           HEXADECIMAL DATA      ASCII DATA
1CB522 0000 0002 0000 0000 0100 0900 25FF FFFF      %
1CB532 0002 001C C2A4 001C BC8E                    BS <
ADDRESS OF NEXT ELEMENT      1CBC8E
HEX ADDR           HEXADECIMAL DATA      ASCII DATA
1CBC8E 0000 0003 0000 0000 0100 0900 25FF FFFF      %
1CBC9E 0002 001C C362 001C BF86                    Cb ?
ADDRESS OF NEXT ELEMENT      1CBFB6
```

Use table F-22 to interpret information in an LCRDS row.

**Table F-22. Least Cost Routing Data Store Row**

| Offset | Field Name              | Description  |
|--------|-------------------------|--|
| +0     | network_id              | Network identifier                                   |
| +4     | pseudo_subnet           | Boolean; if true, network is a pseudo 180 subnet     |
| +5     | changed                 | Boolean  |
| +6     | directly_connected      | Boolean  |
| +7     | alias_exists            | Boolean  |
| +8     | multicast               | Boolean  |
| +A     | broadcast_address       | System identifier                                    |
| +10    | valid_lcrds_entry_count | Count of valid LCRDS entries                         |
| +12    | first_lcrds_entry       | Pointer to first least cost routing data store entry |
| +16    | next_row                | Pointer to next row                                  |

To display the entries associated with a row, enter the following Dump Analyzer subcommand (continuing the example with the first row from the previous display):

```
DISLL 1CBFAC BC=30 LO=2C
```

Output from this subcommand is formatted as follows:

```

DISPLAY_LINKED_LIST
START ADDRESS    1CBFAC
HEX ADDR        HEXADECEIMAL DATA      ASCII DATA
1CBFAC 0000 000A 0000 0000 009D 0001 0000 0001
1CBFBC 0800 2510 0085 0000 0001 0000 0000 0100  %
1CBFCC 05D8 0000 0000 0000 0000 0000 0000 0000  X

```

Use table F-23 to interpret information in an LCRDS entry.

**Table F-23. Least Cost Routing Data Store Entry**

| Offset | Field Name           | Description  |
|--------|----------------------|--|
| + 0    | aggregate_cost       | Computed routing cost  |
| + 4    | aggregate_cost_ratio | Ratio used by IS-IS routing support balance traffic load; a negative value indicates that this entry is not valid for routing; 0 indicates this is only valid entry for the associated network |
| + 6    | pdu_count            | Protocol data unit count   |
| + A    | relay_count          | Relay count  |
| + C    | next_hop_network_id  | Next hop network identifier  |
| + 10   | next_hop_system_id   | Next hop system identifier   |
| + 16   | parent_network_id    | Network type   |
| + 1A   | congested            | Boolean  |
| + 1B   | relay_restricted     | Boolean  |
| + 1C   | unused               | Boolean  |
| + 1D   | obsolete             | Boolean  |
| + 1E   | directly_connected   | Boolean  |
| + 1F   | do_broadcast_in_3b   | Boolean  |
| + 20   | max_pdu_size         | Maximum protocol data unit size  |
| + 22   | congestion_beginning | System address   |
| + 2C   | next_entry           | Pointer to next entry  |

Local DCN Data Store

To display a pointer to the local DCNDS, use the following Dump Analyzer subcommand:

```
DISM A=11_FIRST_LOCAL_DCND_ENTRY BC=4
```

Output from this subcommand is formatted as follows:

|                  |                  |            |
|------------------|------------------|------------|
| STARTING ADDRESS |                  | 12FD8E     |
| HEX ADDR         | HEXADECIMAL DATA | ASCII DATA |
| 12FD8E           | 0026 5662        | &Vb        |

Continuing the example, a linked list of the local DCNDS entries can be displayed using the following Dump Analyzer subcommand:

```
DISLL 265662 BC=40 LO=32
```

Output from this subcommand is formatted as follows:

|                     |   |                  |   |   |  |  |  |  |  |            |  |  |
|---------------------|---|------------------|---|---|--|--|--|--|--|------------|--|--|
| DISPLAY_LINKED_LIST |   |                  |   |   |  |  |  |  |  |            |  |  |
| START ADDRESS       |   | 265662           |   |   |  |  |  |  |  |            |  |  |
| HEX ADDR            |   | HEXADECIMAL DATA |   |   |  |  |  |  |  | ASCII DATA |  |  |
| 265662              | 0100 0100 0001 0000 0000 000A 000A 0900 |                  |   |   |  |  |  |  |  |            |  |  |
| 265672              | 25FF FFFF 05D8 0000 0001 0800 2510 0085 | %                | X | % |  |  |  |  |  |            |  |  |
| 265682              | 000A 0051 0900 25FF FFFF 0000 0001 0000 | Q                | % |   |  |  |  |  |  |            |  |  |
| 265692              | 0000 0000 0000 0000 0000 4A6E 0008 6508 | J                | n | e |  |  |  |  |  |            |  |  |

Use table F-24 to interpret information in a local DCNDS entry.

**Table F-24. Local DCN Data Store Entry**

| Offset | Field Name                   | Description  |
|--------|------------------------------|--|
| +0     | cdna_route_info_nw           | Boolean  |
| +1     | do_broadcast_in_3b           | Boolean  |
| +2     | last_send_ridu_ok            | Boolean  |
| +3     | network_went_down            | Boolean  |
| +4     | network_type                 | Network type (HDLC, Ethernet, MCI, X.25, test, pseudo 180 network) |
| +6     | network_status               | Network status (up, inactive, up for remote load, terminate)       |
| +8     | number_of_ridu_timeouts      | Current number of RIDU timeouts on this network                    |
| +A     | last_cong_related_ridu_count | send_the_ridu .. send_congestion_ridu                              |
| +C     | last_sent_ridu_cost          | Routing cost on last RIDU  |
| +E     | configured_cost              | Configured cost  |
| +10    | cdna_routing_addr            | Routing system identifier  |
| +16    | max_pdu_size                 | Maximum protocol data unit size                                    |
| +18    | dcn_entry                    | DCN definition entry (see table F-26)                              |
| +2C    | ridus_transmitted            | Statistics collection  |
| +34    | next_entry                   | Pointer to next entry  |

## Received DCN Data Store

You can display both a pointer to the first received DCNDS entry and an indication of its length with the following Dump Analyzer subcommand:

```
DISM A=11_RECEIVED_DCNDS_PTR BC=8
```

Output from this subcommand is formatted as follows:

```
STARTING ADDRESS      131CBF
HEX ADDR              HEXADECIMAL DATA      ASCII DATA
131CBF 0026 7036 0000 003C                      &p6  <
```

The first four bytes of this display point to the first received DCNDS entry. The second four bytes indicate the byte length of the first entry's array of DCN definitions. These eight bytes are found at an offset of 0A(16) into each DCN data store entry. That is, each DCN data store entry holds a link to the next DCN data store entry in bytes 0A(16) through 12(16).

Continuing the example, a linked list of the first 56(16) bytes of all entries in the received DCN data store can be displayed with the following Dump Analyzer subcommand:

```
DISLL 267036 BC=56 LO=0A
```

Output from this subcommand is formatted as follows:

```
DISPLAY_LINKED_LIST
START ADDRESS:  267036
HEX ADDR        HEXADECIMAL DATA      ASCII DATA
267036 0000 004F 001D 5564 0003 001C B30E 0000      O Ud  3
267046 0026 0000 0001 0000 0001 0800 2510 0089      (    %
267056 000A 0011 0900 25FF FFFF 0000 0002 0800      %    %
267066 2510 0089 000A 0011 0900 25FF FFFF 0000      %    %
267076 0003 0800 2510 0089 000A 0011 0900 25FF      %    %
267086 FFFF 0000 0000
ADDRESS OF NEXT ELEMENT:  1CB30E
HEX ADDR        HEXADECIMAL DATA      ASCII DATA
1CB30E 0000 001C 001D 55A1 0002 001C 6488 0000      U
1CB31E 003C 0000 0001 0000 0001 0800 2510 008C      <    %
1CB32E 000A 0051 0900 25FF FFFF 0000 3333 0800      Q  %  33
1CB33E 2510 008C 000A 0051 0900 25FF FFFF 2020      %  Q  %
1CB34E 2020 2020 2020 1000 0026 F020 0000 0003      &p
1CB35E 0900 25FF FFFF      %
ADDRESS OF NEXT ELEMENT:  1CB488
.      .      .      .      .      .
.      .      .      .      .      .
.      .      .      .      .      .
```

Use table F-25 to interpret information in a received DCNDS entry. The number of DCN definitions in a received DCNDS entry is in bytes 8 and 9 of that entry. The link to the next entry is at a byte offset of 0A(16) into the entry, as described above.

**Table F-25. Received DCN Data Store Entry**

| Offset | Field Name  | Description  |
|--------|-------------|--|
| +0     | sequence_no | Sequence number; integer   |
| +4     | timestamp   | Timestamp  |
| +8     | dcn_count   | Number of DCNs   |
| +A     | deleted     | True if this entry is deleted  |
| +C     | next_entry  | Pointer to next entry  |
| +18    | dcn_entry   | Adaptable array of 14(16)-byte-long DCN definitions (see table F-26) |

The array of DCN definitions for any received DCNDS entry can be displayed separately using the Dump Analyzer DISPLAY\_MEMORY subcommand with the following parameter values:

- Use the next\_entry address found in the preceding received DCNDS entry.
- Use a BYTE\_OFFSET of 16(16).
- Use a BYTE\_COUNT of 14(16), the length of a single DCN definition.
- Use a REPEAT\_COUNT that corresponds with the dcn\_count in the received DCNDS entry.

For example, the array of DCN definitions for the second received DCNDS entry of the previous example can be displayed using the following subcommand.

```
DISM 1CB30E B0=16 BC=14 RC=2
```

where 1A1598 is taken from bytes 0A through 0D(16) of the first entry in the preceding display.

Output from this subcommand is formatted as follows:

```
STARTING ADDRESS: 1CB324

HEX ADDR          HEXADECEIMAL DATA          ASCII DATA
1CB324 0000 0001 0800 2510 008C 000A 0051 0900      %      Q
        25FF FFFF                                %
1CB338 0000 3333 0800 2510 008C 000A 0051 0900      33 %      Q
        25FF FFFF                                %
```

Each DCN definition has the structure described in table F-26.



**Table F-26. DCN Definition Entry**

| <b>Offset</b> | <b>Field Name</b>      | <b>Description</b>                                    |
|---------------|------------------------|---|
| +0            | sys_address            | DCN system address                                    |
| +A            | cost                   | Routing cost to DCN system                            |
| +C            | reserved_field         | Not currently used                                    |
| +D            | pseudo_subnet          | Boolean; if true, network is a pseudo 180 subnet      |
| +D:1          | routing_info_changed   | Boolean   |
| +D:2          | title_info_changed     | Boolean   |
| +D:3          | network_active         | Boolean   |
| +D:4          | sap_3a_congestion      | If 2, CONGESTED; if 0, UNCONGESTED; 1 not implemented |
| +D:6          | relay_restricted       | Boolean   |
| +D:7          | case broadcast_network | If true, then broadcast address                       |
| +E            | broadcast_address      | System identifier type                                |

## Terminal Support Debug Table

The terminal support debug table is created by the `ts_debug` program. It is used by a variety of DI software to record and access terminal support information. The terminal support debug table begins with an identifying string, `*TS-DEBUG*`, and ends with an identifying string, `*END-TS-DEBUG*`. In between is room for 40 terminal support debug records.

The entire table can be displayed with the following Dump Analyzer subcommand:

```
dism ts_debug rc=81e
```

Output from this subcommand is formatted as follows:

```
STARTING ADDRESS      1D95BA

HEX ADDR              HEXADECIMAL DATA              ASCII DATA

1D95BA 2A54 532D 4445 4255 472A 2A20 001D 9C2A  *TS-DEBUG*  *
1D95CA 4C43 4D20 001E C168 001E F74A 001D 82E2  LCM  Ah  wJ  b
1D95DA 0021 001E F74A 0000 0000 0006 001E 92F2  |  wJ      r
1D95EA 4C43 4D20 001E 92F2 001E F796 001D 82E2  LCM  r  w  b
1D95FA 0021 001E F796 0000 0000 0006 001E 92F2  |  w      r
1D960A 4C43 4D20 001E C272 001E C9B8 001D 82E2  LCM  Br  18  b
1D961A 0021 001E C9B8 0000 0000 0006 001E 92F2  |  18      r

1D9D8A 2020 2020 0000 0000 2020 2020 2020 2020
1D9D9A 2020 2020 2020 2020 2020 2020 0000 0000
1D9DAA 2020 2020 0000 0000 2020 2020 2020 2020
1D9DBA 2020 2020 2020 2020 2020 2020 0000 0000
1D9DCA 2A45 4E44 2D54 532D 4445 4255 472A  *END-TS-DEBUG*
```

Each terminal support debug record is 20(16) bytes long. They begin at address `ts_debug + 10`. This is a circular table, so after the last 20-byte-long segment of the table is written into, the next entry overwrites the first record in the table. That is, once the table has been filled, the latest record always overwrites the oldest record.

Location `ts_debug + 0C` contains the address of the last debug record written. From the previous display, this record is at address `1D9C2A`. The entry with `***` as the `receiver_name` is the next debug record to be written into.

Table F-27 describes the fields that are found in each terminal support debug record. All offsets are expressed in hexadecimal.

**Table F-27. TSD Debug Record**

| Offset | Field Name       | Description                 |
|--------|------------------|-----------------------------|
| +0     | receiver_name    | ASCII name of receiver      |
| +4     | sender_task_id   | Task identifier of sender   |
| +8     | user_info        | Bytes of user information   |
| +10    | message          | Bytes of intertask message  |
| +1C    | receiver_task_id | Task identifier of receiver |

## Terminal Support Debug Table

Another way to display the terminal support debug records from the terminal support debug table is to enter the following Dump Analyzer subcommand:

```
dism ts_debug bc=10 bc=20 rc=40
```

There are 40 blocks of 20 bytes each reserved for terminal support debug records, and these begin ten bytes after the ts\_debug entry point.

Display from this subcommand is formatted as follows:

```
STARTING ADDRESS: 1D95CA

HEX ADDR      HEXADECIMAL DATA      ASCII DATA

1D95CA  4C43 4D20 001E C168 001E F74A 001D 82E2  LCM  Ah  wJ  b
        0021 001E F74A 0000 0000 0006 001E 92F2  I  wJ      r
1D95EA  4C43 4D20 001E 92F2 001E F796 001D 82E2  LCM  r  w  b
        0021 001E F796 0000 0000 0006 001E 92F2  I  w      r
1D960A  4C43 4D20 001E C272 001E C9B8 001D 82E2  LCM  Br  18  b
        0021 001E C9B8 0000 0000 0006 001E 92F2  I  18      r
        .      .      .      .      .      .      .      .
        .      .      .      .      .      .      .      .

1D9D6A  2020 2020 0000 0000 2020 2020 2020 2020
1D9D8A  2020 2020 0000 0000 2020 2020 2020 2020
1D9DAA  2020 2020 0000 0000 2020 2020 2020 2020
```

## Batch Data Service Debug Table

The batch data service debug table begins with an identifying string, \*BDSM\_DLOG\*, and ends with an identifying string, \*END-DEBUG-LOG\*. In between is room for 50 batch data service debug records.

The entire table can be displayed with the following Dump Analyzer subcommand:

```
dism bds_log bc=0fc0
```

Output from this subcommand is formatted as follows:

```
STARTING ADDRESS. 295F30

HEX ADDR      HEXADECIMAL DATA      ASCII DATA

295F30  2A42 4453 4D5F 444C 4F47 2A20 0029 64E0  *BDSM_DLOG* )d
295F40  5343 4624 5250 4D45 5353 001A F868 0045  SCF$RPMESS  xh E
295F50  2181 1F53 4D44 5F57 4F52 4B5F 5354 4154  ! SMD_WORK_STAT
295F60  494F 4E5F 3120 2020 2020 2020 2020 2020  ION_1
295F70  2020 821F 4C50 3120 2020 2020 2020 2020  LP1
295F80  2020 2020 2020 2020 2020 2020 2020 2020
295F90  5343 4624 5249 544D 2020 0000 0000 0001  SCF$RITM
295FA0  0026 001A F868 0024 2BAA 0000 F868 68A8  & xh $** xhh(
295FB0  0000 FFFF 001B 68A8 001C D335 0000 FFFF  h( S5
295FC0  0404 001B 6852 001C BA0A 001B 0000 0045  hR - E
295FD0  7374 6163 0029 94D0 0011 43DE 0000 0000  stac ) P C^

295E90  5343 4624 5249 544D 2020 0000 0000 0001  SCF$RITM
295EA0  0026 001A F868 0023 1EFE 0000 F868 68A8  & xh # ~ xhh(
295EB0  0000 FFFF 001B 68A8 0025 3A37 0000 FFFF  h( % 7
295EC0  0404 001B 6852 001C BA0A 001B 0000 0045  hR - E
295ED0  7374 6163 0029 94D0 0011 43DE 0000 0000  stac ) P C^
295EE0  2A45 4E44 2D44 4542 5547 2D4C 4F47 2A20  *END-DEBUG-LOG*
```

Each batch data service debug record is 50(16) bytes long. They begin at address `bds_log + 10`. This is a circular table, so after the last 50-byte-long segment of the table is written into, the next entry overwrites the first record in the table. That is, once the table has been filled, the latest record always overwrites the oldest record.

Location `bds_log + 0C` contains the address of the last batch data service debug record written. From the previous display, this record is at address 2964E0. The entry with "\*\*\*" as the receiver\_name is the next debug record to be written into.

Table F-28 describes the fields that are found in each batch data service debug record. All offsets are expressed in hexadecimal.

**Table F-28. Batch Data Service Debug Record**

| Offset | Field Name | Description                                  |
|--------|------------|--|
| +0     | id         | Message identifier                           |
| +A     | log_cepid  | Pointer to connection identifier             |
| +E     | log_size   | Log message size                             |
| +10    | log_info   | Log message information; string up to 40(16) |

## Batch Data Service Debug Table

Another way to display the batch data service debug records from the batch data service table is to enter the following Dump Analyzer subcommand:

```
dism bds_log bo=10 bc=50 rc=32
```

There are 50 blocks of 50(16) bytes each reserved for batch data service debug records. Output from this subcommand is formatted as follows:

```
STARTING ADDRESS: 295F40

HEX ADDR      HEXADECIMAL DATA      ASCII DATA

295F40 5343 4624 5250 4D45 5353 001A F868 0045 SCF$RPMESS xh E
      2181 1F53 4D44 5F57 4F52 4B5F 5354 4154 ' SMD_WORK_STAT
      494F 4E5F 3120 2020 2020 2020 2020 2020 ION_1
      2020 821F 4C50 3120 2020 2020 2020 2020 LP1
      2020 2020 2020 2020 2020 2020 2020 2020
295F90 5343 4624 5249 544D 2020 0000 0000 0001 SCF$RITM
      0026 001A F868 0024 2BAA 0000 F868 68A8 & xh $+* xhh(
      0000 FFFF 001B 68A8 001C D335 0000 FFFF h( S5
      0404 001B 6852 001C BA0A 001B 0000 0045 hR : E
      7374 6163 0029 94D0 0011 43DE 0000 0000 stac ) P C~

296E40 5343 4624 5350 4D45 5353 001A F868 002A SCF$RPMESS xh *
      1681 1253 4D44 5F57 4F52 4B5F 5354 4154 SMD_WORK_STAT
      494F 4E5F 3182 0343 5231 0300 0400 0802 ION_1 CR1
      0907 0B00 8C02 0190 0F00 5450 5554 2020 TPUT
      2020 2020 2020 2020 2020 2020 2020 2020
296E90 5343 4624 5249 544D 2020 0000 0000 0001 SCF$RITM
      0026 001A F868 0023 1EFE 0000 F868 68A8 & xh # ^ xhh(
      0000 FFFF 001B 68A8 0025 3A37 0000 FFFF h( %:7
      0404 001B 6852 001C BA0A 001B 0000 0045 hR : E
      7374 6163 0029 94D0 0011 43DE 0000 0000 stac ) P C~
```

## Batch Gateway Debug Table

The batch gateway debug table is used by DI software to record and access batch gateway information. The batch gateway debug table begins with an identifying string, \*DEBUG-LOG\*, and ends with an identifying string, \*END-DEBUG-LOG\*. In between is room for 64 batch gateway debug records.

The entire table can be displayed with the following Dump Analyzer subcommand:

```
dism bgw_log bc=820
```

Output from this subcommand is formatted as follows:

```
STARTING ADDRESS. 1EAC32

HEX ADDR          HEXADECIMAL DATA          ASCII DATA

1EAC32 2A44 4542 5547 2D4C 4F47 2A20 001E B102 *DEBUG-LOG* 1
1EAC42 534C 4349 0002 001C 2522 0000 001D C2AE SLCI  %"  B.
1EAC52 002C 0001 FDCC 0010 6DF4 0012 3984 0001 ,  }L mt 9
1EAC62 4553 5443 00A1 001C 2522 001D C2AE 0019 ESTC  ' %' B
1EAC72 FD52 0001 FD6C 0001 0000 0013 0000 0000 }R  }1
1EAC82 4543 4F4E 0002 0027 DCE8 0000 0000 0019 ECON  '\h
1EAC92 FD52 0001 FD6C 0001 0000 0013 0000 0000 }R  }1

1EB402 4553 5443 00A1 001C 2522 0019 FD3E 0016 ESTC  ' %"  }>
1EB412 A202 0800 2510 0083 0000 0061 0000 0000 "  %  a
1EB422 4543 4F4E 0014 0027 DCE8 0000 0000 0016 ECON  '\h
1EB432 A202 0800 2510 0083 0000 0061 0000 0000 "  %  a
1EB442 2A45 4E44 2D44 4542 5547 2D4C 4F47 2A20 *END-DEBUG-LOG*
```

Each batch gateway debug record is 20(16) bytes long. They begin at address `bgw_log + 10`. This is a circular table, so after the last 20-byte-long segment of the table is written into, the next entry overwrites the first record in the table. That is, once the table has been filled, the latest record always overwrites the oldest record.

Location `bgw_log + 0C` contains the address of the last batch gateway debug record written. From the previous display, this record is at address 1EB102. The entry with "\*\*\*" as the receiver\_name is the next debug record to be written into.

Table F-29 describes the fields that are found in each batch gateway debug record. Offsets are expressed in hexadecimal.

**Table F-29. Batch Gateway Debug Record**

| Offset | Field Name | Description                                  |
|--------|------------|--|
| +0     | id         | Message identifier                           |
| +4     | log_info   | Log message information; string up to 28(16) |

The first field in a batch gateway debug record identifies the message, as listed in the following table:

| Identifier | Description  |
|------------|--|
| BIP        | BIP Indication Received                                      |
| BTSC       | BTF(S)/DI Connection Indication Received (via Session Layer) |
| BTSL       | BTF(S)/DI Layer Indication Received (via Session Layer)      |
| ECON       | Connection State Table Event                                 |
| EINP       | Input State Table Event                                      |
| EOUT       | Output State Table Event                                     |
| ERCV       | Receiver State Table Event                                   |
| ESND       | Sender State Table Event                                     |
| ESTC       | Status and Control State Table Event                         |
| RITM       | Intertask Message Received                                   |
| SLCI       | SCF/DI Connection Indication Received (via Session Layer)    |
| SLLI       | SCF/DI Layer Indication Received (via Session Layer)         |
| SVCC       | SVM Call Confirm Received                                    |

If the message identifier is for a state table event (those with identifiers that begin with the letter E), `log_info` contains the following fields:

| Field                 | Length  |
|-----------------------|---------|
| Event code            | 16 bits |
| Control block pointer | 32 bits |
| Event point           | 32 bits |
| Secondary event codes | 8 bits  |

The **event** and **secondary event** codes and their meanings vary depending on the state table. The information immediately following these fixed-sized fields depends on the event code. See the following examples:

- mark number
- suppress carriage control flag
- data block clarifier
- accounting data
- a pointer to a file transfer control block

For messages other than state table events (indications, intertask messages, and SVM call confirms), the actual event received gets put into the log.

Another way to display the batch gateway debug records from the batch gateway debug table is to enter the following Dump Analyzer subcommand:

```
dism bgw_log bo=10 bc=20 rc=40
```

There are 64 blocks of 20(16) bytes each reserved for batch gateway debug records. Output from this subcommand is formatted as follows:

[illegible]



## Operator Support Application Table

Mainframe Device Interfaces (MDIs) that run the operator support application (OSA) maintain an operator support table that provides information about network operators who are logged into OSA (for a NOS MDI, this is only true if there is a DEFOS command in the configuration file). The operator support table can be displayed with the following Dump Analyzer subcommand:

```
disa osa_basis rc=0ee
```

Output from this subcommand is formatted as follows:

| STARTING ADDRESS | 1F2200                                  |                 |
|------------------|---|-----------------|
| HEX ADDR         | HEXADECIMAL DATA                        | ASCII DATA      |
| 1F2200           | 3330 5F36 3035 6000 0098 0001 FFFF 0900 | 30_605          |
| 1F2210           | 25FF FFFF 0800 2510 0086 0059 0C0C 0301 | % % Y           |
| 1F2220           | 0401 0000 0001 0000 000A 0025 001F 2230 | % "0            |
| 1F2230           | 0000 0001 4F50 4552 0000 001C F69A 001F | OPER v          |
| 1F2240           | 2242 0000 0000 5850 5254 0000 0000 0000 | "B XPRT         |
| 1F2250           | 0000 0000 0001 0000 2345 0800 2510 0085 | #E %            |
| 1F2260           | 8809 2215 4234 2960 0002 0000 0000 0800 | " B4)           |
| 1F2270           | 2510 0085 2BE8 2020 2000 0000 0000 0000 | % +h            |
| 1F2280           | 0001 001E 6996 0000 0000 2BE8 0000 0000 | i +h            |
| 1F2290           | 2BE7 0000 0001 001D 3C00 0000 0000 0000 | +g <P           |
| 1F22A0           | 0000 0000 0000 0001 B888 0000 0000 7465 | 8 te            |
| 1F22B0           | 2061 6E64 2074 696D 6520 6F66 206C 6173 | and time of las |
| 1F22C0           | 7420 7265 6C6F 4F50 4552 5850 5254 001F | t re100PERXPRT  |
| 1F22D0           | 04AE 0000 0000 001F 06FE 0000 0000 001E | ^               |
| 1F22E0           | BD8C 0000 0000 001E 0F4E 0000 0000 0000 | =< _N           |
| 1F22F0           | 0001 2449 5F41 4C41 524D 5F4D           | \$I_ALARM_M     |

Table F-30 describes the fields in an operator support table.

**Table F-30. Operator Support Record**

| Offset | Field Name                      | Description  |
|--------|---------------------------------|--|
| + 0    | osa_password                    | Not currently used   |
| + 21   | log_operator_activity           | Boolean  |
| + 22   | max_active_operators_allowed    | Limit on # of operators when buffer or memory is congested; otherwise not used |
| + 26   | active_cmds_allowed_per_oper    | Not currently used   |
| + 2A   | last_used_operid                | Not currently used   |
| + 2C   | operator_table_ptr              | Pointer to numeric key used to maintain information on active operators        |
| + 30   | operator_table_root             | Root structure of operator tree  |
| + 3E   | xprtbl_ptr                      | Pointer to transport connection tree   |
| + 42   | xport_connection_table_root     | Root structure of transport connection tree                                    |
| + 50   | alarm_sap_status                | Transport status for independent alarm ME SAP                                  |
| + 52   | xport_sap_status                | Transport SAP status   |
| + 54   | osa_terminated                  | Flag indicating CANOS command issued   |
| + 55   | ind_alarm_me_title_registered   | Alarm ME title registered; Boolean   |
| + 56   | ind_alarm_me_dir_id             | Directory identifier of independent alarm ME's title                           |
| + 68   | dir_ind_alarm_transport_address | Directory transport address record of independent alarm ME                     |
| + 86   | ind_alarm_service_sapid         | Transport address of independent alarm ME                                      |
| + 8C   | osa_service_sapid               | Transport address of OSA   |
| + 92   | operator_alarm_list_hdr         | List of entries describing operators' alarm environment                        |
| + A6   | connection_mgmt_proc            | Transport data traffic procedure address                                       |

*(Continued)*

**Table F-30. Operator Support Record (Continued)**

| Offset | Field Name         | Description  |
|--------|--------------------|--|
| + AE   | max_request_length | Length limit on internet datagram  |
| + B0   | operator_table_id  | Used to validate operator table  |
| + B4   | xport_table_id     | Used to validate transport table   |
| + B8   | close_all_osa_saps | Procedure to close OSA SAPs when CANOS issued                                    |
| + C0   | display_line       | Procedure to display line at local console debugger                              |
| + C8   | osa_request_if     | Procedure to receive command displays from K-display and local console interface |
| + D0   | transmit_cdu       | Procedure to transmit commands to dependent command MEs                          |

At an offset of 2C(16) into the operator support table contains the address of the root of a tree used to maintain information about individual operators logged into the operator support application. Each node in this tree points to an operator table that describes a single operator. In the previous display, the tree root address is 1F2230.

You can display the entries associated with this tree with the Dump Analyzer `DISPLAY_TREE` subcommand. For example, the following subcommand displays the individual operator tables from the previous example:

```
dist 1f2230
```

Output from this subcommand is formatted as follows:

```
Tree Identifier      = OPER
Number of Nodes in Tree = 1
Tree Kind           = numeric

Node 1 of 1 ( 284 bytes). key = 203C

2512A6 0000 011C 4F50 4552 8809 2215 4234 2920 OPER " B4)
2512B6 0000 0000 0000 001F 4620 0000 0000 203C F <
2512C6 1800 0000 5348 5254 4C4F 4B00 0001 001C SHRTLOK
2512D6 C8E2 0018 0003 0007 0002 0001 0001 0001 Hb
2512E6 0005 0001 0009 0000 0000 2020 2020 2020
2512F6 2020 000B 0000 0000 2020 2020 2020 2020
251306 000D 0000 0000 2020 2020 2020 2020 000F
251316 0000 0000 2020 2020 2020 2020 0011 0000
251326 0000 2020 2020 2020 0001 001C EF54 0015 oT
251336 2020 2020 2020 2020 0015 0000 0000 2020
251346 2020 2020 2020 0017 0000 0000 2020 2020
251356 2020 2020 0019 0000 0000 2020 2020 2020
251366 2020 001B 0000 0000 2020 2020 2020 2020
251376 001D 0000 0000 2020 2020 2020 2020 001F
251386 0000 0000 002D 0025 1398 0025 13A6 0025 - % % & %
251396 13B4 0000 0000 434D 4454 0000 0000 0000 4 CMTD
2513A6 0000 0001 5243 4E54 0000 001C C84A 0000 RCNT HJ
2513B6 0000 414C 4941 0002 0000 0000 ALIA
```

Table F-31 describes the structure of an operator table, like the one in the previous display.

**Table F-31. Operator Table Entry**

| Offset | Field Name               | Description  |
|--------|--------------------------|--|
| +0     | tree_node_control        | Node control structure                                   |
| +8     | login_time               | BCD time of operator login                               |
| +10    | command_line_continued   | Boolean  |
| +12    | continued_command        | Pointer to command continuation                          |
| +16    | source_address           | Command request procedure address                        |
| +1E    | operator_id              | Operator identifier                                      |
| +20    | user_data_ptr            | User connection endpoint identifier                      |
| +24    | operator_user_name       | Username of operator                                     |
| +2C    | last_used_cmd_dest       | Destinations of last SENC command                        |
| +88    | last_used_cdu_command_id | Key to correlate the 1..n responses with the nth command |
| +8A    | command_table_ptr        | Pointer to command table root                            |
| +8E    | respnt_table_ptr         | Pointer to response table root                           |
| +92    | alias_table_ptr          | Pointer to alias table root                              |
| +96    | command_table_root       | Command table root                                       |
| +A4    | response_table_root      | Response table root                                      |
| +B4    | alias_table_root         | Alias table root   |

# Loader Entry Point Table

The loader entry point table is in the form of a tree structure. A pointer to the loader entry point tree root can be found at address 56A(16), in mpb\_ram. To display this address using the Dump Analyzer, enter the following subcommand:

```
DISM 56A BC=4
```

Output from this subcommand is formatted as follows:

|                  |                  |            |
|------------------|------------------|------------|
| STARTING ADDRESS | 56A              |            |
| HEX ADDR         | HEXADECIMAL DATA | ASCII DATA |
| 56A 0010 8674    |                  | t          |

The loader entry point tree for this dump file can then be displayed with the following command:

```
DIST 108674
```

Output from this subcommand is formatted as follows:

|  |       |                  |
|--|-------|------------------|
| Tree Identifier                                | =     | eptb             |
| Number of Nodes in Tree                        | =     | 793              |
| Tree Kind                                      | =     | string           |
| Node 1 of 793 ( 70 bytes)                      | key = | A3CPL_LOG        |
| 1737E6 4133 4350 4C5F 4C4F 4720 2020 2020 2020 |       | A3CPL_LOG        |
| 1737F6 2020 2020 2020 2020 2020 2020 2020 2001 |       |                  |
| 173806 0016 DE1A 0016 D658 0000 0084 0000 0000 |       | ^ VX             |
| 173816 0017 3850 334C E086 C7CC A450 0008 1000 |       | 8P3L GL\$P       |
| 173826 0026 0070 0001                          |       | & p              |
| Node 2 of 793 ( 70 bytes)                      | key = | A3CPR_RESPONSE   |
| 173858 4133 4350 525F 5245 5350 4F4E 5345 2020 |       | A3CPR_RESPONSE   |
| 173868 2020 2020 2020 2020 2020 2020 2020 2001 |       |                  |
| 173878 0016 E2AE 0016 D658 0000 0084 0000 0000 |       | b VX             |
| 173888 0017 38C2 8430 6BB2 BD8E 4410 0008 1000 |       | 8B 0k2= D        |
| 173898 0026 0070 0000                          |       | & p              |
| Node 3 of 793 ( 70 bytes)                      | key = | A3_PMM_INTERFACE |
| 1172A6 4133 5F50 4D4D 5F49 4E54 4552 4641 4345 |       | A3_PMM_INTERFACE |
| 1172B6 2020 2020 2020 2020 2020 2020 2020 2001 |       |                  |
| 1172C6 0001 697A 0011 7D9A 0000 0042 0000 0000 |       | iz } B           |
| 1172D6 0011 7310 2085 C2E6 69CA 0870 0008 1000 |       | s Bf iJ p        |
| 1172E6 0026 0070 0000                          |       | & p              |

Table F-32 describes the structure of a loader entry point, such as those displayed in the format above.

**Table F-32. Loader Entry Point**

| Offset | Field Name                    | Description  |
|--------|-------------------------------|--|
| + 0    | node                          | Node control   |
| + 8    | name                          | Program name   |
| + 27   | declaration_matching_required | Declaration matching required for this module; Boolean |
| + 28   | address                       | MC68000 address  |
| + 2C   | module_header_address         | Module header pointer                                  |
| + 38   | link_address                  | Link address   |
| + 3C   | declaration_matching_value    | Declaration matching value; string (8)                 |
| + 44   | language                      | Module language  |

## System Memory Management Table

Table F-33 records information about the state of buffers and system memory in the DI.

**Table F-33. System Memory Management Table**

| Offset | Field Name              | Description                                     |
|--------|-------------------------|---|
| +0     | percentage_data_buffers | Percent of memory in form of data buffers       |
| +2     | stp_period              | Integer   |
| +6     | total_reserved_memory   | Amount of reserved memory                       |
| +A     | total_alloc_memory      | Amount of allocated memory                      |
| +E     | total_data_buffers      | Total number of data buffers                    |
| +12    | initial_data_buffers    | Initial number of data buffers                  |
| +16    | initial_desc_buffers    | Initial number of descriptor buffers            |
| +1A    | buffer_percentage       | Array of percentages for the four buffer states |
| +20    | memory_percentage       | Array of percentages for the four memory states |
| +26    | system_configured       | Boolean   |
| +27    | change_mm_lock          | Boolean; change memory management lock          |

# Tree Root Structure

The tree root structure provides information about a binary tree. Each tree root is 14 bytes long, as described in table F-34.

Table F-34. Tree Root Structure

| Offset | Field Name | Description  |
|--------|------------|--|
| +0     | num_nodes  | Total number of nodes in the tree                    |
| +4     | dump_id    | Validity check, should contain user value            |
| +8     | type_node  | Key type for tree access; (numeric, pointer, string) |
| +A     | link       | Pointer to node                                      |

Following is an example of a tree root displayed using the DI Dump Analyzer:

```
1A2A74 0000 0001 4F50 4552 0000 001B 3590 001A      OPER      5
```

This tree has just one node, and its key type is numeric.





This appendix documents the following line and terminal control blocks:

- Allocated line control block (ALCB)
- Configured line control block (CLCB)
- Terminal cluster control block (TCCB)
- Terminal device control block (TDCB)
- Data connection control block (DCCB)
- Batch device control block (BDCB)
- Batch output connection control block (BOCCB)
- Batch input connection control block (BICCB)
- Batch input/output station control block (IOSCB)
- SCFS connection control block (SCCB)
- TIP interface record table (TIRT)
- Printer terminal model record

Chapter 9 describes how to locate many of these control blocks in a DI dump file using the DI Dump Analyzer.

# Allocated Line Control Block

Figure G-1 shows the general structure of the allocated line control block (ALCB). Table G-1 describes the fields in the ALCB.




Figure G-1. ALCB Record

Table G-1. Allocated Line Control Block (ALCB)

| Offset | Field Name        | Description                             |
|--------|-------------------|---|
| +0     | add_req_to_tip    | Requested TIP to add; Boolean           |
| +0:1   | to_be_deleted     | Need to delete control block            |
| +0:2   | delete_req_to_tip | Requested TIP to delete; Boolean        |
| +0:3   | tip_type          | Owning TIP type (debug use)             |
| +1     | cb_type           | Type of control block                   |
| +2     | cb_name           | ASCII name of control block (debug use) |
| +6     | clcb_pointer      | Pointer to first CLCB                   |

## Configured Line Control Block

Table G-2 describes the fields in the CLCB.

**Table G-2. Configured Line Control Block (CLCB)**

| Offset | Field Name            | Description  |
|--------|-----------------------|--|
| +0     | add_req_to_tip        | Requested TIP to add; Boolean  |
| +0:1   | to_be_deleted         | Need to delete control block   |
| +0:2   | delete_req_to_tip     | Requested TIP to delete; Boolean   |
| +0:3   | tip_type              | Owning TIP type (debug use)  |
| +1     | cb_type               | Type of control block  |
| +2     | cb_name               | ASCII name of control block (debug use)  |
| +6     | tccb_pointer          | Pointer to first-owned TCCB  |
| +A     | alcb_pointer          | Pointer to owning ALCB   |
| +E     | clcb_pointer          | Pointer to next CLCB   |
| +12    | tip_extension_pointer | Pointer to optional TIP extension  |
| +16    | dvmid                 | Pointer to device manager  |
| +1A    | ln                    | Line name  |
| +1C    | lim_adr               | LIM and port number  |
| +1E    | tbs                   | Transmission block size  |
| +20    | tdp                   | Terminal definition procedure name   |
| +22    | tup                   | Terminal user procedure name   |
| +24    | lst                   | Line subtype   |
| +26    | ls                    | Defined line-speed   |
| +28    | tt                    | Defined TIP type   |
| +29    | lt                    | Line type (switched, dedicated)  |
| +2A    | ft                    | Framing type (async, sync, sdlc)   |
| +2B    | ct                    | Carrier type (constant, controlled)  |
| +2C    | ar                    | Type of (async) auto recognition   |
| +2D    | cct                   | Connection connect time-out (4-second units)   |
| +2E    | cdt                   | Connection disconnect time-out   |
| +2F    | ucl                   | User connection limit  |
| +30    | c                     | Clocking for LIM   |
| +31    | dp                    | Initial data parity  |
| +32    | efc                   | EIA flow control (RTS/CTS); Boolean  |
| +32:1  | pseudo                | Pseudo line (for example, X.25 PAD)  |
| +32:2  | vu                    | Validate user  |
| +32:3  | vus                   | Validate user specified  |
| +34    | lcsn_task_id          | Task identifier of LCSM  |
| +38    | control_task_id       | Task identifier of controlling task  |
| +3C    | tip_task_id           | Task identifier of TIP   |
| +40    | conf_cmd_queue_ptr    | Configuration command queue pointer  |
| +44    | tirt_ptr              | Address of TIRT entry  |
| +48    | a@d                   | Case 0, 2 Byte word 0..0ffff(16); Case 1, upper 1 Byte indicates # of times a delete_cb sent to TIP, lower 1 Byte indicates # of add_cbs sent to TIP |
| +4A    | activity_count        | Number of \$io connections and batch activity count  |

(Continued)

**Table G-2. Configured Line Control Block (CLCB) (Continued)**

| Offset | Field Name            | Description   |
|--------|-----------------------|---|
| +4C    | line_speed            | Auto-recognized line speed                          |
| +4E    | state                 | LCM state-of-the-line                               |
| +4F    | down_reason           | Line down reason code                               |
| +50    | tip_type              | Auto-recognized TIP type                            |
| +51    | code_set              | Auto-recognized code set                            |
| +52    | parity_type           | Auto-recognized parity                              |
| +53    | connect_timer         | Line (dis)connect timer                             |
| +54    | auto_tup_timer        | TUP re-execution timer                              |
| +55    | line_re_enabled_timer | Line re_enabled timer (4 second units)              |
| +56    | line_re_enabled_count | Number of times line re_enabled since timer was set |
| +57    | line_enabled          | Line is enabled by LCSM; Boolean                    |
| +57:1  | line_init             | Line is initialized by TIP; Boolean                 |
| +57:2  | defios_done           | At least one DEFIOS executed; Boolean               |
| +57:3  | tip_switch            | Switching from asynch to X.PC TIP; Boolean          |
| +58    | state                 | LCSM state (valid if LCSM active)                   |
| +59    | ar_state              | LCSM auto-recognition state                         |
| +5A    | itm_part              | Timer_itm_rec field of intertask message            |
| +60    | sys_task              | Pointer to task using timer_services                |
| +64    | sys_ptr               | System timer pointer                                |
| +68    | sds_buf1_ptr          | User-defined collection buffer 1                    |
| +6C    | sds_buf2_ptr          | User-defined collection buffer 2                    |
| +70    | group                 | Statistics group type                               |
| +72    | log_msg_number        | Log message number                                  |
| +74    | log_template_id       | Template identifier type                            |
| +76    | function_proc         | Statistics function procedure                       |
| +7E    | display_proc          | Display procedure                                   |
| +86    | next_header           | Pointer to sds_header                               |
| +8A    | collecting            | Collecting statistics and next reporting; Boolean   |
| +8B    | collecting_buf1       | TRUE=buffer1, FALSE=buffer2                         |
| +8C    | display_template_id   | Template identifier to use for display              |
| +8E    | input_characters      | Characters received                                 |
| +92    | input_blocks          | Blocks received                                     |
| +96    | output_characters     | Characters sent                                     |
| +9A    | output_blocks         | Blocks sent   |
| +9E    | input_errors          | Input blocks in error                               |
| +A0    | output_errors         | Output blocks in error                              |
| +A2    | time_outs             | Number of time-outs                                 |
| +BA    | stats_sap_id          | Statistics SAP identifier                           |

## Terminal Cluster Control Block

Table G-3 describes the fields in the TCCB.

**Table G-3. Terminal Cluster Control Block (TCCB)**

| Offset | Field Name        | Description                               |
|--------|-------------------|---|
| +0     | add_req_to_tip    | Requested TIP to add; Boolean             |
| +0:1   | to_be_deleted     | Need to delete control block              |
| +0:2   | delete_req_to_tip | Requested TIP to delete; Boolean          |
| +0:3   | tip_type          | Owning TIP type (debug use)               |
| +1     | cb_type           | Type of control block                     |
| +2     | cb_name           | ASCII name of control block (debug use)   |
| +6     | tdcb_ptr          | Pointer to first-owned TDCB               |
| +A     | clcb_ptr          | Pointer to owning CLCB                    |
| +E     | tccb_ptr          | Pointer to next TCCB                      |
| +12    | tip_eptr          | Pointer to optional TIP extension         |
| +16    | ca                | Terminal cluster address                  |
| +18    | protocol_mode     | For example, DCE, DTE, 4A, 4C, 2780, 3780 |
| +1A    | connect_time      | Connect time                              |
| +1E    | output_characters | Characters sent                           |
| +22    | output_blocks     | Blocks sent                               |
| +26    | input_characters  | Characters received                       |
| +2A    | input_blocks      | Blocks received                           |
| +2E    | procs_done        | Number of procedures done                 |
| +30    | xpc_active        | XPC active for ATAP                       |
| +32    | tip_aptr          | ATAP TIP accounting data pointer          |

## Terminal Device Control Block

Tables G-4 through G-8 describe the fields in the TDCB.

**Table G-4. Terminal Device Control Block (TDCB)**

| Offset | Field Name          | Description                                    |
|--------|---------------------|--|
| +0     | add_req_to_tip      | Requested TIP to add; Boolean                  |
| +0:1   | to_be_deleted       | Need to delete control block; Boolean          |
| +0:2   | delete_req_to_tip   | Requested TIP to delete; Boolean               |
| +0:3   | tip_type            | Owning TIP type (debug use)                    |
| +1     | cb_type             | Type of control block                          |
| +2     | cb_name             | ASCII name of control block (debug use)        |
| +6     | dccb_pointer        | Pointer to first-owned DCCB                    |
| +A     | tccb_pointer        | Pointer to owning TCCB                         |
| +E     | tdcb_pointer        | Pointer to next TDCB                           |
| +12    | tip_extension_ptr   | Pointer to optional TIP extension              |
| +16    | device_inactive     | Device inactive; Boolean                       |
| +16:1  | device_stopped      | Device stopped by operator; Boolean            |
| +16:2  | device_not_ready    | Device not ready; Boolean                      |
| +16:3  | device_down         | Device down; Boolean                           |
| +16:4  | input_flow_control  | Input flow control used; Boolean               |
| +16:5  | output_flow_control | Output flow control used; Boolean              |
| +18    | batch_x25_peer_ptr  | Pointer to X.25 peer (batch)                   |
| +1C    | da                  | Device address                                 |
| +1E    | dt                  | Device type                                    |
| +20    | dn                  | Device name                                    |
| +22    | tup                 | Terminal user procedure file name              |
| +24    | tbs                 | Transmission block size of device              |
| +26    | vu                  | Validate user                                  |
| +26:1  | vus                 | Validate user specified                        |
| +28    | partial_cmd_ptr     | Partial command/Control Data                   |
| +2C    | wc_dccb_ptr         | Pointer to DCCB of current working connection  |
| +30    | cr_dccb_ptr         | Pointer to DCCB of \$command_\$response dccb   |
| +34    | break_time          | Time of last break                             |
| +38    | nr_connects         | Number of \$input/\$output connections         |
| +39    | do_nesting          | Procedure nesting level                        |
| +3A    | command_q_count     | Number of commands in queue                    |
| +3B    | conn_pending        | Connections pending                            |
| +3C    | ios_operator_device | Required operator device; Boolean              |
| +3C:1  | initial_tup         | Initial DEFTD TUP executing; Boolean           |
| +3C:2  | auto_tup            | Re-execute TUP if no \$i_o connection; Boolean |
| +3C:3  | defuios_done        | At least one DEFUIOS executed; Boolean         |
| +3C:4  | device_down         | Device down (lcm_devd called); Boolean         |
| +3E    | output_queued_itm   | ITM on first output queued; Boolean            |
| +3E:1  | hold_page           | Set by TIP, reset by TDSM; Boolean             |
| +40    | connect_time        | Connect time                                   |
| +44    | output_characters   | Characters sent                                |
| +48    | output_blocks       | Blocks sent                                    |
| +4C    | input_characters    | Characters received                            |
| +50    | input_blocks        | Blocks received                                |
| +54    | procs_done          | Number of procedures done                      |

Table G-5. TDCB, Case CPT\_VTP

| Offset | Field Name                      | Description                                  |
|--------|---------------------------------|--|
| +56    | user_validated_or_not_required  | User validated or validation not required    |
| +57    | validation_retry_limit_exceeded | User exceeded number of validation attempts  |
| +58    | user_validation_state           | State of network validation                  |
| +5A    | val_rec_ptr                     | Pointer to associated validation record      |
| +5E    | domain                          | Network validation domain                    |
| +60    | username                        | User name entered                            |
| +62    | waiting_task                    | Task waiting for validation completion       |
| +66    | retry_count                     | Number of validation attempts                |
| +68    | delete_template_id              | Line deletion message                        |
| +6C    | tm                              | Terminal model                               |
| +6E    | eos                             | End output sequence                          |
| +73    | crs                             | Carriage-return output sequence              |
| +76    | lfs                             | Line-feed output sequence                    |
| +77    | ffs                             | Form-feed sequence                           |
| +82    | crd                             | Carriage-return delay (millisecond units)    |
| +84    | lfd                             | Line-feed delay (millisecond units)          |
| +86    | ffd                             | Form-feed delay (millisecond units)          |
| +88    | pl                              | Device page length                           |
| +89    | pw                              | Device page width                            |
| +8A    | bw                              | Backspace window                             |
| +8B    | ncc                             | Network control character                    |
| +8C    | blc                             | Beginning-of-line character                  |
| +8D    | epc                             | End-of-partial character                     |
| +8E    | elc                             | End-of-line character                        |
| +8F    | bc                              | Backspace character                          |
| +90    | clc                             | Cancel character                             |
| +91    | ac                              | Attention character                          |
| +92    | elp                             | CP after ELC (no, cr, lf, cl)                |
| +93    | epp                             | CP after EPC                                 |
| +94    | cs                              | Code set                                     |
| +95    | p                               | Parity (zero, mark, even, odd, none)         |
| +96    | sa                              | Status action                                |
| +97    | ra                              | Response action                              |
| +98    | hp                              | Hold page; Boolean                           |
| +98:1  | hpo                             | Hold page (OVER); Boolean                    |
| +98:2  | fl                              | Fold line; Boolean                           |
| +98:3  | e                               | Echoplex; Boolean                            |
| +98:4  | cfc                             | Character flow control (X-ON/X-OFF); Boolean |
| +99:4  | epa                             | End-of-page action (none, send FF sequence)  |
| +9A    | cs_name                         | Code name set                                |
| +9C    | xlate_tbl                       | Code translation table                       |
| +A0    | alt_xlate_tbl                   | Alternate code translation                   |
| +A4    | xlate_mask                      | Code translation mask                        |
| +A5    | alt_xlate_mask                  | Alternate code translation mask              |
| +A6    | ccr                             | Control character replacement                |
| +AA    | fkc_name                        | Function key class name                      |
| +AC    | fkc_ptr                         | Pointer to fkc record                        |
| +B0    | ios                             | Batch I/O station name                       |



**Table G-6. TDCB, Case CPT\_BTP**

| Offset | Field Name       | Description  |
|--------|------------------|--|
| +6C    | pptm             | Pointer-to-printer terminal model (see table G-22) |
| +70    | mfs              | Maximum file size                                  |
| +74    | tbs              | Transmission block size of device                  |
| +76    | pma              | Printer-message action                             |
| +77    | cca              | Carriage-control action                            |
| +78    | pl               | Page length  |
| +79    | pw               | Page width   |
| +7A    | CASE batch_usage | See tables G-7 and G-8                             |
| +92    | scc              | Suppress carriage control; Boolean                 |

**Table G-7. TDCB/CPT\_BTP, Case BU\_DEVICE**

| Offset | Field Name     | Description                             |
|--------|----------------|---|
| +7B    | cs             | Code set                                |
| +7C    | fs             | Form size                               |
| +7D    | specified_fs   | Specified form size                     |
| +7E    | pd             | Print density                           |
| +7F    | udfa           | Undefined format effector action        |
| +80    | usfa           | Unsupported format effector action      |
| +81    | dp             | Data parity                             |
| +84    | vfui_ptr       | Pointer to VFU load image               |
| +88    | cs_name        | Code set name                           |
| +8A    | ccr            | Control character replacement           |
| +8C    | xlate_tbl      | Code translation table                  |
| +90    | xlate_mask     | Code translation mask                   |
| +91    | cfc            | Character flow control; Boolean         |
| +91:1  | o26            | Default O26 (card reader only); Boolean |
| +91:2  | uvfu           | User changeable VFU; Boolean            |
| +91:3  | vpd_changeable | User changeable VPD                     |

**Table G-8. TDCB/CPT\_BTP, Case BU\_STREAM**

| Offset | Field Name | Description                          |
|--------|------------|--------------------------------------|
| +7C    | spc        | Cards/lines to discard               |
| +7E    | s          | Batch stream auto start; Boolean     |
| +7F    | tm         | Process data as transparent; Boolean |

## Data Connection Control Block

Tables G-9 through G-11 describe the fields in the DCCB.

**Table G-9. Data Connection Control Block (DCCB)**

| Offset | Field Name          | Description  |
|--------|---------------------|--|
| +0     | add_req_to_tip      | Requested TIP to add; Boolean  |
| +0:1   | to_be_deleted       | Need to delete control block   |
| +0:2   | delete_req_to_tip   | Requested TIP to delete; Boolean   |
| +0:3   | tip_type            | Owning TIP type (debug use)  |
| +1     | cb_type             | Type of control block  |
| +2     | cb_name             | ASCII name of control block (debug use)  |
| +6     | output_queue_ptr    | Pointer to first-owned output queue  |
| +A     | tdcb_ptr            | Pointer to owning TDCB   |
| +E     | dccb_ptr            | Pointer to next DCCB   |
| +12    | tip_eptr            | Pointer to optional TIP extension  |
| +16    | cn                  | Name of connection   |
| +18    | sn                  | Name of selected service   |
| +1A    | ctype               | Type of connection   |
| +1B    | pctype              | Type of protocol   |
| +1C    | lower_layer_id      | Session layer connection identifier  |
| +22    | cb_qualifier        | Unique qualifier   |
| +24    | sub                 | If ctype = ct_\$command_\$response:<br><br>+24: status_q_ptr: Status output queue<br>+26: status_q_count: Messages in queue<br>+28: banner_sent: CDCNET banner sent; Boolean<br><br>If ctype = ct_\$input_\$output:<br><br>+24: destination_adr: Destination SAP address |
| +30    | partial_input_ptr   | Partial input data pointer   |
| +34    | delete_reason       | Reason for deleting DCCB   |
| +36    | sl_delete_reason    | Template identifier received on session clear  |
| +38    | owner_task_id       | Task_id of owner task  |
| +3C    | io_task_id          | I/O processor task_id (TIP)  |
| +40    | connection_state    | State of peer connection   |
| +41    | output_q_count      | Number of messages in output queue   |
| +42    | input_ovf_count     | Input passed over IFC limit  |
| +43    | connection_number   | Connection number  |
| +44    | queue_put_open      | Output queue open for puts; Boolean  |
| +44:1  | queue_get_open      | Output queue open for gets; Boolean  |
| +44:2  | queue_on_hold       | Output queue on hold; Boolean  |
| +44:3  | ifc_active          | Input flow control active (transport); Boolean   |
| +44:4  | ofc_active          | Output flow control active (transport); Boolean  |
| +44:5  | ofc_end_active      | End output flow control ITM send; Boolean  |
| +44:6  | expedited_fc_active | Expedited flow control active (transport); Boolean   |
| +44:7  | user_int_active     | User interrupt in progress; Boolean  |
| +45    | partial_input       | Partial input sent upline; Boolean   |
| +45:1  | ios_operator        | I/O station operator connection; Boolean   |
| +45:2  | inp_sync            | Synchronous on input; Boolean  |

(Continued)

**Table G-9. Data Connection Control Block (DCCB) (Continued)**

| Offset | Field Name      | Description  |
|--------|-----------------|--|
| +45:3  | out_sync        | Synchronous on output; Boolean                       |
| +45:4  | if_cancel       | If cancel character last character of input; Boolean |
| +45:5  | marked_output   | Marked output ITM queued                             |
| +46    | cmd_timer       | Time of the last terminal user command execution     |
| +4A    | cmd_count       | Count of terminal user commands to execute           |
| +4C    | input_solicited | Set by TIP, reset by TDSM; Boolean                   |
| +4C:1  | suppress_elp    | TIP suppressing ELP for connection; Boolean          |
| +4C:2  | suppress_e      | TIP suppressing echo for connection; Boolean         |

**Table G-10. DCCB, Case CPT\_VTP**

| Offset | Field Name    | Description   |
|--------|---------------|---|
| +4E    | ibs           | Input block size  |
| +50    | tml           | Transparent message length  |
| +52    | tfc           | Transparent forwarding characters   |
| +57    | ttc           | Transparent termination characters  |
| +5C    | tfm           | Transparent forwarding mask   |
| +7C    | iom           | Input/output mode   |
| +7D    | iem           | Input editing mode  |
| +7E    | titi          | Transparent character time-out interval                                   |
| +7F    | aca           | Attention character action  |
| +7F:4  | bka           | Break key action  |
| +80    | tcm           | Transparent character mode: (None, Terminate, Forward, Forward/Terminate) |
| +80:2  | tlm           | Transparent length mode   |
| +80:4  | ttm           | Transparent time-out mode   |
| +80:6  | tpm           | Transparent protocol mode   |
| +81    | pcf           | Partial character forwarding; Boolean                                     |
| +81:1  | snd           | Store NULs and DELs; Boolean  |
| +81:2  | sbc           | Store backspace character; Boolean  |
| +81:3  | ee: boolean   | Echo enable   |
| +81:4  | ifce: boolean | Input flow control enable   |
| +81:5  | ofce: boolean | Output flow control enable  |
| +81:6  | pe: boolean   | Parity enable   |
| +81:7  | ace: boolean  | Attention character enable  |

Table G-11. DCCB, Case CPT\_BTP

| Offset | Field Name                   | Description                                     |
|--------|------------------------------|---|
| +4E    | bdc_b_ptr                    | Pointer to BDCB                                 |
| +52    | bccb_ptr                     | Pointer to BOCCB or BICCB                       |
| +56    | input_q_ptr                  | Pointer to input queue                          |
| +60    | partial_input_file_id        | Pointer to partial input from output device     |
| +61    | current_file_id              | Current file identifier                         |
| +62    | input_q_count                | Number of messages in input queue               |
| +63    | btbs                         | Batch transfer block size                       |
| +65    | data_state                   | Batch data transfer state                       |
| +66    | abort_status                 | Transfer abort status                           |
| +67    | etpr_sent                    | ETPR sent to peer application; Boolean          |
| +67:1  | internal_disconnect          | Internal disconnect (v.s. line); Boolean        |
| +67:2  | device_logout                | Required operator; Boolean                      |
| +67:3  | device_stopped               | Device stopped by operator; Boolean             |
| +67:4  | device_stopped_eoi           | Device stopped by operator at next EOI; Boolean |
| +67:5  | device_not_ready             | Device not ready; Boolean                       |
| +67:6  | transparent_data             | Batch data is transparent; Boolean              |
| +67:7  | discarding_until_<br>next_cr | Discard input from output service; Boolean      |

## Batch Device Control Block

Tables G-12 through G-14 describe the fields in the BDCB.

**Table G-12. Batch Device Control Block (BDCB)**

| Offset | Field Name               | Description                                    |
|--------|--------------------------|--|
| +0     | add_req_to_tip           | Requested TIP to add; Boolean                  |
| +0:1   | to_be_deleted            | Need to delete control block                   |
| +0:2   | delete_req_to_tip        | Requested TIP to delete; Boolean               |
| +0:3   | tip_type                 | Owning TIP type (debug use)                    |
| +1     | cb_type                  | Type of control block                          |
| +2     | cb_name                  | ASCII name of control block (debug use)        |
| +6     | ioscb_ptr                | Pointer to IOSCB                               |
| +A     | bdc_b_ptr                | Pointer to next BDCB                           |
| +E     | tdcb_ptr                 | Pointer to TDCB                                |
| +12    | dn                       | Device name                                    |
| +14    | chabda_response_ptr      | Pointer to CHABDA response                     |
| +18    | state                    | Device state                                   |
| +19    | dt                       | Device type                                    |
| +1A    | file_status              | File status                                    |
| +1B    | signon_status            | Remote system sign-on status                   |
| +1C    | device_down              | Device temporarily down; Boolean               |
| +1C:1  | device_stopped           | Device disabled; Boolean                       |
| +1C:2  | device_not_ready         | Device not ready; Boolean                      |
| +1C:3  | device_loading_vfu       | Device VFU being loaded; Boolean               |
| +1C:4  | device_loading_fpp       | File prefix proc being loaded; Boolean         |
| +1C:5  | device_loading_ip        | Initialization procedure being loaded; Boolean |
| +1C:6  | default_vlp_load_error   | Default VFU not loadable; Boolean              |
| +1C:7  | down_fpp_load_error      | File prefix proc not loadable; Boolean         |
| +1D    | down_ip_load_error       | Initialization proc not loadable; Boolean      |
| +1D:1  | last_tip_error_type      | Type of tip last reported not loadable         |
| +1D:4  | device_available         | Device available to host; Boolean              |
| +1D:5  | signon_status_indication | Remote system sign-on indication; Boolean      |
| +1E    | pptm                     | Pointer-to-printer terminal model              |
| +22    | mfs                      | Maximum file size                              |
| +26    | tbs                      | Transmission block size of device              |
| +28    | pma                      | Printer-message action                         |
| +29    | cca                      | Carriage-control action                        |
| +2A    | pl                       | Page length                                    |
| +2B    | pw                       | Page width                                     |
| +2C    | CASE                     | See tables G-13 and G-14                       |
| +44    | fc1                      | Forms code                                     |
| +46    | fc2                      | Forms code                                     |
| +48    | fc3                      | Forms code                                     |
| +4A    | fc4                      | Forms code                                     |
| +4C    | ec1                      | External device characteristics                |
| +4E    | ec2                      | External device characteristics                |

(Continued)

**Table G-12. Batch Device Control Block (BDCB) (Continued)**

| Offset | Field Name           | Description                                |
|--------|----------------------|--|
| +50    | ec3                  | External device characteristics            |
| +52    | ec4                  | External device characteristics            |
| +54    | tm                   | Terminal model                             |
| +56    | da                   | Device aliases                             |
| +5C    | dvlp                 | Default VFU load procedure                 |
| +5E    | dvpd                 | Default vertical print-density             |
| +5F    | vpd                  | Vertical print-density selection           |
| +60    | vfus                 | VFU status                                 |
| +61    | bpc                  | Number of banner pages                     |
| +62    | bhf                  | Banner highlight field                     |
| +63    | vfut                 | Type of VFU load being executed            |
| +64    | trailer_page         | Trailer page to be printed; Boolean        |
| +64:1  | explicitly_specified | Trailer page explicitly specified; Boolean |
| +66    | scc                  | Suppress carriage-control; Boolean         |

**Table G-13. BDCB, Case BU\_DEVICE**

| Offset | Field Name     | Description                            |
|--------|----------------|--|
| +2D    | cs             | Code set                               |
| +2E    | fs             | Form size                              |
| +2F    | specified_fs   | Forms size specified on DEFBD or CHABD |
| +30    | pd             | Print density                          |
| +31    | udfa           | Undefined format effector action       |
| +32    | usfa           | Unsupported format effector action     |
| +33    | dp             | Data parity                            |
| +34    | vfui_ptr       | Pointer to VFU load image              |
| +38    | cs_name        | Code name set                          |
| +3A    | ccr            | Control character replacement          |
| +3E    | xlate_tbl      | Code translation table                 |
| +42    | xlate_mask     | Code translation mask                  |
| +43    | cfc            | Character flow control (ATAP only)     |
| +43:1  | o26            | Default O26 (card reader only)         |
| +43:2  | uvfu           | User-changeable VFU                    |
| +43:3  | vpd_changeable | User-changeable vpd                    |

**Table G-14. BDCB, Case BU\_STREAM**

| Offset | Field Name | Description                          |
|--------|------------|--------------------------------------|
| +2E    | spc        | Cards/lines to discard               |
| +30    | s          | Batch stream auto start; Boolean     |
| +31    | tm         | Process data as transparent; Boolean |

## Batch Output Connection Control Block

Table G-15 describes the fields in the BOCCB.

**Table G-15. Batch Output Connection Control Block (BOCCB)**

| Offset | Field Name        | Description                                     |
|--------|-------------------|---|
| +0     | cb_name           | ASCII name BOCB                                 |
| +4     | dccb_ptr          | DCCB pointer                                    |
| +8     | data_ptr          | Output banner/file position parameter pointer   |
| +C     | timer             | Abort transfer time-out timer                   |
| +E     | vlp               | VFU load procedure name                         |
| +10    | state             | Output transfer states                          |
| +11    | abort             | Reason for aborting transfer                    |
| +12    | file_size         | File size                                       |
| +16    | file_page_width   | File page width                                 |
| +1A    | old_byte_ordinal  | Last byte ordinal for amount transferred status |
| +1E    | byte_ordinal      | Current file position in bytes                  |
| +22    | record_ordinal    | Current file position in unit records           |
| +26    | acc_limit         | Accounting limit                                |
| +2A    | bytes             | Accumulated accounting data; # of bytes         |
| +2E    | records           | Accumulated accounting data; # of records       |
| +32    | system_id         | Accumulated accounting data; system_id          |
| +34    | user_name         | Accumulated accounting data; user_name          |
| +36    | user_family       | Accumulated accounting data; user_family        |
| +38    | markack_fac       | TRUE=mark acknowledgement facility selected     |
| +38:1  | compression_fac   | TRUE=compression facility selected              |
| +38:2  | tr                | TRUE=transparent file, FALSE = ASCII file       |
| +38:3  | cmp               | TRUE if file in compressed format               |
| +38:4  | hold              | Reason for suspending transfer                  |
| +39    | pd                | Print density                                   |
| +3A    | mws               | Mark acknowledgement window size                |
| +3B    | mro               | Number of checkmarks awaiting TIP response      |
| +3C    | lmr               | Last mark received                              |
| +3E    | lma               | Last mark acknowledged                          |
| +40    | timeout           | Transfer time-out interval in seconds           |
| +42    | activity_timer    | Activity timer                                  |
| +46    | peer_abort_status | Peer abort status code                          |
| +47    | user_file_name    | User file name                                  |
| +66    | sys_file_name     | System file name                                |

## Batch Input Connection Control Block

Table G-16 describes the fields in the BICCB.

**Table G-16. Batch Input Connection Control Block (BICCB)**

| Offset | Field Name            | Description                                  |
|--------|-----------------------|--|
| +0     | cb_name               | ASCII name 'BICB'                            |
| +4     | dccb_ptr              | DCCB pointer                                 |
| +8     | dir_trid              | Translation request identifier (^cell)       |
| +C     | actual_destination    | Actual destination                           |
| +E     | requested_destination | Requested destination family                 |
| +10    | jod                   | Job output destination                       |
| +12    | joun                  | Job output user                              |
| +14    | jouf                  | Job output family                            |
| +16    | bytes_transferred     | Bytes sent to peer                           |
| +1A    | dir_title_ptr         | Pointer to directory title                   |
| +20    | system                | Directory entry identifier; system_address   |
| +2A    | decclock              | Directory entry identifier; bcd_time         |
| +32    | state                 | Batch input transfer states                  |
| +34    | bytes                 | Accumulated accounting data; # of bytes      |
| +38    | records               | Accumulated accounting data; # of records    |
| +3C    | system_id             | Accumulated accounting data; system_id       |
| +3E    | user_name             | Accumulated accounting data; user_name       |
| +40    | user_family           | Accumulated accounting data; user_family     |
| +42    | activity_timer        | Activity timer                               |
| +46    | tr                    | TRUE=transparent file, FALSE = ASCII file    |
| +46:1  | abort                 | Status code for data transfer phase commands |
| +47:1  | peer_abort_status     | Peer abort status code                       |
| +49    | user_job_name         | User job name                                |
| +68    | system_job_name       | System job name                              |



## Batch Input/Output Station Control Block

Tables G-17 through G-19 describe the fields in the IOSCB.

**Table G-17. Input/output Station Control Block (IOSCB)**

| Offset | Field Name                     | Description  |
|--------|--------------------------------|--|
| +0     | cb_header                      | Control block header   |
| +6     | ioscb_ptr                      | Pointer to next IOSCB  |
| +A     | sccb_ptr                       | Pointer to SCCB  |
| +E     | bdc_b_ptr                      | Pointer to first BDCB  |
| +12    | tdcb_ptr                       | Pointer to console TDCB for user ios                             |
| +16    | timer_id                       | Timer request identifier   |
| +1A    | canios_taskid                  | Task identifier of CANIOS command processor                      |
| +1E    | state                          | Station state  |
| +20    | user_io_station                | Station defined by DEFUIOS command                               |
| +21    | predefined_io_station          | 0=dynamic, 1=predefined  |
| +22    | operator_login                 | 0=not logged in, 1=logged in                                     |
| +23    | check_ios_unique               | Operator login required  |
| +24    | connection_type                | 0=180, 1=170   |
| +26    | c170_bgw_address               | C170 batch gateway address                                       |
| +44    | user_name                      | Name of login private IOS user                                   |
| +46    | user_family                    | User family of private IOS user                                  |
| +48    | c180_control_facility          | C180 control facility name                                       |
| +4A    | io_station_name                | I/O station name (DEFIOS_REC)                                    |
| +4C    | control_facility               | Control facility name  |
| +4E    | default_destination            | Default input file destination                                   |
| +50    | store_forward_destination      | Job input, if requested, not available                           |
| +52    | destination_unavailable_action | 0=stop, 1=drop   |
| +54    | station_usage                  | CASE su_public, su_private, or su_ntf. See tables G-18 and G-19. |

**Table G-18. IOSCB, Case SU\_PUBLIC, SU\_PRIVATE**

| Offset | Field Name                     | Description                        |
|--------|--------------------------------|------------------------------------|
| + 54   | required_operator_<br>device   | Device name of controlling console |
| + 56   | io_station_alias               | Alias I/O station name             |
| + 6C   | pm_action                      | PM message action                  |
| + 6D   | file_acknowledgement           | File ACK on or off                 |
| + 6D:1 | route_job_command_<br>required | Route card required option         |

**Table G-19. IOSCB, Case SU\_NTF**

| Offset | Field Name                   | Description                            |
|--------|------------------------------|--|
| + 54   | default_file_<br>destination | Default file destination               |
| + 56   | arscb_ptr                    | Pointer to first ARSCB                 |
| + 5A   | next_add_accessible          | Pointer to next ARSCB to be configured |
| + 5E   | line_name                    | Name identifier record for line        |
| + 60   | terminal_user_<br>procedure  | Pointer to TUP                         |
| + 62   | line_speed                   | Line speed                             |
| + 64   | logical_line_number          | Logical line number                    |
| + 66   | inactivity_timer             | Inactivity timer                       |
| + 68   | authority_level              | Remote system authority level          |
| + 69   | wait_a_bit                   | Wait flag                              |
| + 6A   | positive_ack                 | Positive acknowledgement               |
| + 6B   | remote_system_<br>protocol   | BSC protocol type                      |
| + 6C   | local_system_name            | Local system name                      |
| + 6E   | route_back_position          | Position to insert route back          |
| + 6F   | remote_system_type           | Remote system type                     |
| + 6F:4 | request_permission_<br>retry | Resend Transmission permission         |

## SCFS Connection Control Block

Table G-20 describes the fields in the SCCB.

**Table G-20. SCFS Connection Control Block (SCCB)**

| Offset | Field Name          | Description                              |
|--------|---------------------|--|
| +0     | cb_header           | Control block header                     |
| +6     | sccb_ptr            | Pointer to next SCCB                     |
| +A     | ioscb_ptr           | Pointer to first IOSCB                   |
| +E     | cepid               | Connection endpoint identifier           |
| +14    | cb_qualifier        | Control block unique qualifier           |
| +16    | state               | Peer connection state                    |
| +18    | control_facility    | Control facility name                    |
| +1A    | timer_id            | Reconnect timer identifier               |
| +1E    | sap_address         | SAP of control facility                  |
| +3C    | connection_type     | 0=180, 1=170                             |
| +3E    | dir_priority        | Translate priority                       |
| +40    | dir_tid             | Save directory translate identifier      |
| +44    | system              | Directory identifier record; system_addr |
| +4E    | decclock            | Directory identifier record; bcd_time    |
| +56    | dir_title_ptr       | Pointer to directory title               |
| +5C    | flow_control_active | Session flow control on SCF; Boolean     |

## TIP Interface Record Table

Table G-21 describes the fields in the TIRT.

**Table G-21. TIP Interface Record Table (TIRT)**

| Offset | Field Name          | Description                                     |
|--------|---------------------|---|
| +0     | name                | TIP name  |
| +C     | min_name_length     | Minimum name length                             |
| +E     | default_tbs         | Default TBS                                     |
| +10    | default_ft          | Default FT                                      |
| +12    | default_lcs         | Default LCS                                     |
| +14    | min_line_speed      | Minimum line-speed                              |
| +16    | max_line_speed      | Maximum line-speed                              |
| +18    | tn                  | ASCII name of the TIP                           |
| +1A    | tup                 | Default terminal user procedure name            |
| +1C    | tbs                 | Default transmission block size                 |
| +1E    | ca                  | Default cluster address                         |
| +20    | da                  | Default device address                          |
| +22    | ft                  | Default framing type for TIP                    |
| +23    | lcs                 | Level of line-control support                   |
| +24    | vu                  | Validate user                                   |
| +26    | tip_defined         | DEFT command processed                          |
| +26:1  | tip_load_state      | State of TIP loading                            |
| +27    | nr_active_tasks     | Number of active TIP line tasks                 |
| +28    | single_tip_taskid   | Single TIP task identifier                      |
| +2C    | start_adr           | TIP entry address for line task                 |
| +34    | sds_buf1_ptr        | First user-defined collection buffer            |
| +38    | sds_buf2_ptr        | Second user-defined collection buffer           |
| +3C    | group               | Log group                                       |
| +3E    | log_msg_number      | Log message number                              |
| +40    | log_template_id     | Log template identifier                         |
| +42    | function_proc       | Statistics function procedure                   |
| +4A    | display_proc        | Display procedure                               |
| +52    | next_header         | Pointer to next SDS header                      |
| +56    | collecting          | Collecting statistics & next reporting; Boolean |
| +57    | collecting_buf1     | TRUE=buffer1, FALSE=buffer2                     |
| +58    | display_template_id | Template identifier used for display            |
| +5A    | stats_sapid         | Statistics SAP identifier                       |
| +5C    | input               | TIP input transmission block statistics         |
| +6C    | output              | TIP output transmission block statistics        |
| +7C    | validation_success  | Successful network validation login attempts    |
| +80    | validation_failures | Unsuccessful network validation login attempts  |
| +AC    | stack_size          | Stack size in 38 byte units                     |
| +AD    | max_nr_commands     | Maximum commands on LCM queue                   |
| +AE    | stack_residence     | Preferred stack residence                       |
| +AE:6  | delc\$net_action    | Delc net action                                 |
| +AF    | task_need           | Task requirement for the TIP                    |
| +B0    | control_task_id     | Controlling task (for example ATAP)             |

(Continued)

**Table G-21. TIP Interface Record Table (TIRT) (Continued)**

| Offset | Field Name           | Description  |
|--------|----------------------|--|
| +B4    | an@av_default_ptr    | Default values for an/av conn/term/batch attributes    |
| +C0    | an@av_validation_ptr | An/av validation array for conn/term/batch attributes  |
| +CC    | dedicated_delay      | Delay (seconds) after dedicated line down              |
| +CE    | disca_set            | DISCA displayed attributes (default all)               |
| +D2    | dista_set            | DISTA displayed attributes (default all)               |
| +D6    | input                | Input transmission block statistics distribution info  |
| +DC    | output               | Output transmission block statistics distribution info |

## Printer Terminal Model Record

Table G-22 describes the fields in a printer terminal model record.

**Table G-22. Printer Terminal Model Record**

| Offset | Field Name                | Description   |
|--------|---------------------------|---|
| +0     | ptm                       | Printer terminal model                              |
| +2     | nptm                      | Pointer to next printer model                       |
| +6     | old_pma_usage_count       | Count of devices using old printer model attributes |
| +A     | chapma_taskid             | CHAPMA command processor task_id                    |
| +E     | apec                      | Auto page-eject channel                             |
| +F     | bofc                      | Bottom-of-form channel                              |
| +10    | mvl                       | Maximum entries in VFU                              |
| +11    | cdc_defined_printer_model | Flag for Control Data-defined printer model         |
| +11:1  | fl                        | Fold line   |
| +11:2  | vtf                       | VFU top form  |
| +11:3  | micro_substitution        | Micro substitution to be done for FPP               |
| +12    | fpp                       | File prefix procedure name identifier               |
| +14    | fpp_status                | File prefix procedure load status                   |
| +15    | ffs                       | Form-feed sequence                                  |
| +1D    | fps                       | File prefix sequence                                |
| +3D    | fss                       | File suffix sequence                                |
| +5D    | nss                       | No space sequence                                   |
| +65    | sss                       | Single space sequence                               |
| +6D    | els                       | Eight LPI sequence                                  |
| +75    | sls                       | Six LPI sequence                                    |
| +7E    | Connection pro name id    | Connection name ID                                  |
| +80    | cs                        | Connection sequence                                 |
| +A0    | num_subst_entries         | Number of character substitution values             |
| +A2    | subst_values              | Character substitution values                       |
| +AE    | ssd                       | Single space/no space delay count                   |
| +7E    | ffd                       | Form-feed (skip channel 1) delay count              |
| +B0    | cssp                      | Channel skip sequences record pointer               |

# Task and Queue Control Blocks

## H

The task control block (TCB) describes a task to the Executive. The Executive manages TCBs using the queue control block (QCB). Both structures are defined in this appendix.

Information from a TCB found in a CDCNET dump file can be displayed using the DISTCB Dump Analyzer subcommand. Information from a QCB and its buffers can also be displayed using the DISTCB Dump Analyzer subcommand.

Table H-1 summarizes the fields in a TCB. All offsets are expressed in hexadecimal.

**Table H-1. Task Control Block**

| Offset | Field Name      | Description   |
|--------|-----------------|---|
| +0     | next_task       | Chain to next task_ptr  |
| +4     | id              | This field must be TCB  |
| +8     | stsiz           | The size of the current task segment  |
| +C     | chldq           | A pointer to the next sibling task  |
| +10    | adult           | A pointer to the parent task  |
| +14    | child           | A pointer to the next child task  |
| +18    | stack           | Address of the current stack segment  |
| +1C    | state_fill      | Not used  |
| +1C:4  | state           | The current state of this task:<br>0 Rigor Mortis<br>1 Ready<br>2 Running<br>3 Primitive Failure<br>4 Wait<br>5 Wait for any Message<br>6 Wait for Express Message<br>7 Suspend<br>8 Wait for any message or wakeup<br>9 .. 15 Not used (INVALID) |
| +1D    | transition_fill | Not used  |
| +1D:3  | trans           | Transition that entered this state  |
| +1E    | tran            | Count of transitions to date  |
| +42    | slices          | Count of time slice overruns to date  |

*(Continued)*

**Table H-1. Task Control Block** *(Continued)*

| Offset | Field Name     | Description  |
|--------|----------------|--|
| + 44   | flag_fill_1    | Upper five bits not used   |
| + 44:5 | preempted      | Flag: task has been preempted; registers all saved (else only A6 and D7) |
| + 44:6 | hold           | Flag: used by timer task to deflect timer requests into normal queue     |
| + 44:7 | wku            | Flag: wakeup pending if set  |
| + 45   | flag_fill_2    | Not used   |
| + 46   | express        | The express ITM QCB  |
| + 56   | normal         | The normal ITM QCB   |
| + 66   | preempt_permit | If zero, this task is not preemptible; otherwise, preemptible            |
| + 68   | cpriority      | Nominal priority   |
| + 6A   | priority       | Actual priority  |
| + 6C   | d_registers    | Only register D7 normally valid  |
| + 8C   | a_registers    | Only register A6 normally valid  |
| + A8   | usp            | User stack pointer   |
| + AC   | sr             | Status register  |
| + AE   | pc             | Pointer to program counter   |
| + B2   | tcbfrb         | Pointer to task failure recovery block                                   |
| + B6   | tcb_epa        | Pointer to task entry point  |
| + BA   | tcb_space      | Amount of unused space in reserved stack area                            |
| + BE   | tcbmhp         | Pointer to module header   |
| + CA   | age            | Age of task in dispatch queue  |
| + CC   | tcb_mem_own_id | Memory/buffer owner identifier   |
| + CE   | tcb_itm_length | Length in words of last directly copied task                             |

Table H-2 summarizes the fields in a QCB. All offsets are expressed in hexadecimal.

**Table H-2. Queue Control Block**

| Offset | Field Name  | Description   |
|--------|-------------|---|
| +0     | length      | Number of items currently queued                          |
| +2     | count       | Running number of items that have been queued to this QCB |
| +4     | qnext       | Pointer to next item in queue                             |
| +8     | qlast       | Pointer to last item in queue                             |
| +C     | qcharacters | Number of characters in queue                             |





# Stack Frames

## I

This appendix describes the stack frame structure, which is used to chain procedure calls for CDCNET tasks.

Each DI task that has been started has a task control block (TCB) that identifies (among other things) the stack starting address and length.

A stack's starting address and length can be found using the Dump Analyzer DISTCB subcommand. For example, the following subcommand displays information from the TCB at address 278B6C(16):

```
DISTCB TI=278B6C DO=FULL
```

Output from this subcommand is formatted as follows:

```
TASK CONTROL BLOCK DISPLAY

TCB ADDRESS                278B6C(16)
TASK NAME                   ASYNCTIP_MODULE
NEXT_TASK { CHAIN TO NEXT TASK POINTER } 0(16)
ID { TCB IDENTIFICATION } 1TCB
STSIz { SIZE OF CURRENT STACK SEGMENT } 4A0(16)
CHLDG { TASK POINTER OF NEXT SIBLING } 2290CA(16)
ADULT { TASK POINTER OF PARENT } 106072(16)
CHILD { TASK POINTER OF CHILD } 0(16)
STACK { ADDRESS OF CURRENT STACK SEGMENT } 23CF0(16)
STATE { CURRENT STATE } WAIT FOR ANY MESSAGE
PRIORITY { ACTUAL PRIORITY } 0
EXPRESS ITM { NUMBER EXPRESS INTER_TASK MSGS QUEUED } 0(10)
NORMAL ITM { NUMBER NORMAL INTER_TASK MSGS QUEUED } 0(10)
SR { STATUS REGISTER }
TRACE MODE NO
M68000 MODE USER
INTERRUPT MASK 000
RESULT EXTENDED YES
RESULT NEGATIVE NO
RESULT ZERO NO
OVERFLOW NO
CARRY NO
PC { PROGRAM COUNTER } 1016E(16)
A6 { STACK POINTER } 2404A(16)
A7 { STACK POINTER } 2404A(16)
MODULE NAME EXEC_PMM
OFFSET IN CODE SECTION 142(16)
OWNER_ID { ID GENERATED FOR MEMORY OWNERSHIP } F0BF(16)
```

The fields named STSIz and STACK give you the stack length and stack first byte address, respectively. You can use these two values to display stack memory. Use the DISM subcommand, from the stack starting address for stack number of bytes, as follows:

```
DISM A=23CF0 RC=4A0
```

Output from this subcommand is formatted as follows:

```

STARTING ADDRESS      23CF0

HEX ADDR      HEXADECIMAL DATA      ASCII DATA

23CF0  4F56 4552 464C 4F57 4F56 4552 464C 4F57  OVERFLOWOVERFLOW
23D00  4F56 4552 464C 4F57 4F56 4552 464C 4F57  OVERFLOWOVERFLOW
23D10  4F56 4552 464C 4F57 4F56 4552 464C 4F57  OVERFLOWOVERFLOW
23D20  4F56 4552 464C 4F57 4F56 4552 464C 4F57  OVERFLOWOVERFLOW
23D30  4F56 4552 464C 4F57 4F56 4552 464C 4F57  OVERFLOWOVERFLOW
23D40  4F56 4552 464C 4F57 4F56 4552 464C 4F57  OVERFLOWOVERFLOW
23D50  4F56 4552 464C 4F57 4F56 4552 464C 4F57  OVERFLOWOVERFLOW
23D60  4F56 4552 464C 4F57 4F56 4552 464C 4F57  OVERFLOWOVERFLOW
23D70  4F56 4552 464C 4F57 4F56 4552 464C 4F57  OVERFLOWOVERFLOW
23D80  4F56 4552 464C 4F57 4F56 4552 464C 4F57  OVERFLOWOVERFLOW
23D90  4F56 4552 464C 4F57 4F56 4552 464C 4F57  OVERFLOWOVERFLOW
23DA0  4F56 4552 464C 4F57 4F56 4552 464C 4F57  OVERFLOWOVERFLOW
23DB0  4F56 4552 464C 4F57 4F56 4552 464C 4F57  OVERFLOWOVERFLOW
23DC0  4F56 4552 464C 4F57 4F56 4552 464C 4F57  OVERFLOWOVERFLOW
23DD0  4F56 4552 464C 4F57 4F56 4552 464C 4F57  OVERFLOWOVERFLOW
23DE0  7374 6163 6B7E 0000 7374 6163 6B7E 0001  stack~ stack~
23DF0  7374 6163 6B7E 0002 7374 6163 6B7E 0003  stack~ stack~

.

24000  0017 0021 E8EE FFFF FFFF 0018 12D0 001E      'hn      P
24010  8E80 0000 002C 0018 12D0 0028 9674 0002      , P ( t
24020  4040 001E 8D50 0002 4058 0027 0002 40E4      @@ P @x ' @d
24030  001A 83C2 0000 0021 E89C 412A 0028 0002      B 'hn A* (
24040  4062 0027 E064 0021 E89C 0002 408E 001F      @o ' 'h @n
24050  BD40 0000 0010 0002 4114 001F E4EA 001E      =@ ' A d;
24060  A3FC 0027 8456 0027 8456 0001 0002 0002      #| ' V ' V
24070  417C 0027 E99A 0010 7980 0002 4170 0002      A| ' ' y0 Ap
24080  4114 0027 8456 0027 830A 0010 793C 0010      A ' V ' Z y<
24090  7300 6163 6B7E 0000 0000 0021 E850 0057      s ack~ 'hP W
240A0  7374 6163 6B7E 0058 7374 6163 6B7E 0059      stack~ Xstack~ Y
240B0  7374 0021 F008 005A 7374 6163 6B7E 005B      st 'p Zstack~ [
240C0  7374 6163 6B7E 005C 7374 6163 6B7E 005D      stack~ \stack~ ]
240D0  7374 6163 0007 0027 7D9E 0000 0000 000C      stac ' )
240E0  0011 7440 0027 DFB4 0002 417C 0027 DC16      t@ ' _4 A| ' \
240F0  0002 417C 007E 0062 0000 0002 007E 0063      A| ' b ' c
24100  0000 0000 0005 0002 0001 0000 007E 0065      ' e
24110  0000 0000 0107 0027 7D9E 0080 0011 7440      ' ) t@
24120  0000 0000 6B7E 0068 7374 0028 9674 0000      k~ hst ( t
24130  0000 0011 7440 0000 2580 0000 0000 0000      t@ %
24140  0001 0000 0000 0000 0000 0000 0000 0000
24150  0000 001F FC8A 0022 686A 0022 686A 0021      | 'hj "hj |
24160  E89C 0021 F008 0080 0028 9462 0028 943C      h 'p ( b ( <
24170  0001 0000 0002 0003 7374 6163 0002 4180      stac A
24180  0010 E86E 0000 0000 0000 0000 0000 0000      hn

```

The lowest-addressed 240 bytes of the stack are the reserved stack area. This area is preset with the pattern OVERFLOW. The rest of the stack area is preset with repetitions of the hexadecimal value 7374 6163 6B7E nnnn, where nnnn increments from 0000 to whatever value is necessary in order to fill the stack area. This hexadecimal number evaluates to the ASCII string stack~aa, where aa is the two-character ASCII string associated with hexadecimal value nnnn.

Program calls are chained using stack frames, which are written into the stack from the stack's high address toward its low address. The procedure call associated with the lowest-addressed stack frame is the only one that may execute, although all stack frames from there to the high address of the stack area may be considered active. When a program exits, its stack frame becomes inactive and the procedure call of the previous stack frame executes. The stack memory area associated with inactive calls is not reset to the stack^aa pattern.

Stacks should be long enough so that the reserved stack area is not overwritten. The Dump Analyzer VALSA subcommand identifies tasks whose reserved stack areas have been overwritten.

A stack frame may contain the following:

- A pointer to the previous stack frame (A6)
- An area for local variables and/or compiler temporary storage
- Any parameters being passed on the next call
- A procedure return address (RA)

Figure I-1 shows the relative locations of information in a stack.




Figure I-1. Stack Area Structure

The TCB maintains two pointers to locations within the stack:

- A pointer to the A6 value in the lowest-addressed stack frame
- A pointer to the lowest active address in the stack. This is known as the user stack point (USP), or A7

These two pointers are contiguous in the TCB. They may be displayed with the Dump Analyzer DISM subcommand. Use the address of the TCB for the desired task on the address parameter, a byte offset (BO) of 0A0(16), and a byte count (BC) of 8. For the example in progress, use the following subcommand:

```
DISM A=278D6C BO=0A0 BC=8
```

Output from this subcommand is formatted as follows:

```
STARTING ADDRESS    278C0C
HEX ADDR            HEXADECIMAL DATA      ASCII DATA
278C0C  0002 404A 0002 404A                @J  @J
```

where the first four bytes contain the A6 value of the lowest-addressed stack frame in the stack and the second four bytes are the USP (or A7).

The stack frames can be displayed individually using the Dump Analyzer DISPLAY\_CALL subcommand, with SF=TRUE. For example:

DISC T1=278B6C SF=TRUE

Output from this subcommand is formatted as follows:

```
TCB ADDRESS          278B6C(16)

TRACEBACK FROM MODULE EXEC_PMM + 142(16)
NEAREST PRECEDING ENTRY POINT CALL_SURE_BG

STACK FRAME STARTING AT 2404A(16) AND ENDING AT 2406D(16) .

  0 1 2 3 4 5 6 7 8 9 A B C D E F
-----
2404A 0002 406E 001F BD40 0000 0010 0002 4114 @n =@ A
2405A 001F E4EA 001E A3FC 0027 8456 0027 8456 dj #| ' V ' V
2406A 0001 0002

CALLED FROM - MODULE LINE_CONTROL_BOUND + 4C02(16)
NEAREST PRECEDING ENTRY POINT TS_DEBUG_GET_MSG

STACK FRAME STARTING AT 2406E(16) AND ENDING AT 2417B(16)

  0 1 2 3 4 5 6 7 8 9 A B C D E F
-----
2406E 0002 417C 0027 E99A 0010 79B0 0002 4170 A| '1 y0 Ap
2407E 0002 4114 0027 8456 0027 83DA 0010 793C A ' V ' Z y<
2408E 0010 7300 6163 6B7E 00D0 0000 0021 E850 s ack~ 'hP
2409E 0057 7374 6163 6B7E 0058 7374 6163 6B7E Wstack~ Xstack~
240AE 0059 7374 0021 F008 005A 7374 6163 6B7E Yst 'p Zstack~
240BE 005B 7374 6163 6B7E 005C 7374 6163 6B7E {stack~ \stack~
240CE 005D 7374 6163 0007 0027 7D9E 0000 0000 }stac '
240DE 000C 0011 7440 0027 DFB4 0002 417C 0027 t@ '4 A| '
240EE DC16 0002 417C 007E 0062 0000 0002 007E \ A| ~ b ~
240FE 0063 0000 0000 0005 0002 0001 0000 007E c ~
2410E 0065 0000 0000 0107 0027 7D9E 0080 0011 e '
2411E 7440 0000 0000 6B7E 0068 7374 0028 9674 t@ k~ hst ( t
2412E 0000 0000 0011 7440 0000 2580 0000 0000 t@ %
2413E 0000 0001 0000 0000 0000 0000 0000
2414E 0000 0000 001F FC8A 0022 686A 0022 686A | "hj "hj
2415E 0021 E89C 0021 F008 0080 0028 9462 0028 'h 'p ( b (
2416E 943C 0001 0000 0002 0003 7374 6163 < ' stac

CALLED FROM - MODULE ASYNCTIP_MODULE + 16C4(16)

STACK FRAME STARTING AT 2417C(16) AND ENDING AT 2417F(16)

  0 1 2 3 4 5 6 7 8 9 A B C D E F
-----
2417C 0002 4180 A
```

```
CALLED FROM - MODULE OLL_PROGRAM_INTERFACE_PROCS + 1772(18)
NEAREST PRECEDING ENTRY POINT START_NAMED_TASK_AND_PROCEED
```



# Dump Analyzer Error Messages

J

This appendix describes the Dump Analyzer error messages. Command parser errors encountered while running the Dump Analyzer under NOS are documented in the NOS Version 2 Operations Handbook; parser errors encountered under NOS/VE are documented in the NOS/VE Diagnostic Messages manual.

All of the following error messages have a product code of DA. If you are using the Dump Analyzer in FULL message mode, the product code and a unique message number appear in the message text immediately following the severity level. The error messages in this appendix are documented in the FULL message mode.

If you are using the Dump Analyzer under NOS, FULL message mode is the default. Under NOS/VE, BRIEF message mode is the default. With BRIEF message mode, neither the product code nor the message number are displayed. Because the messages in this appendix are sorted by message number, use the FULL message mode when identifying messages. See the NOS/VE Commands and Functions manual for a description of the SET\_MESSAGE\_MODE command, which lets you change from one message mode to the other under NOS/VE.

Message severity levels are ordered as follows, from the most severe to the least. To the right of each severity level are the numbers of the messages classified at that severity level.

|                     |  |
|---------------------|--|
| <b>Catastrophic</b> | 9, 12, 26, 77, 78  |
| <b>Fatal</b>        | 5-7, 10, 19, 20, 23, 27, 29, 31, 32, 38-46, 48, 49, 51, 128-131  |
| <b>Warning</b>      | 0, 1, 4, 21, 24, 25, 30, 33-35, 37, 47, 52, 79-82, 84-86, 89-95, 97-104, 106, 110-113, 118-124, 127, 132 |
| <b>Error</b>        | 2, 3, 8, 11, 13-18, 22, 28, 36, 88, 96, 105, 107-109, 114-117, 125, 126, 133-140                         |
| <b>Informative</b>  | 83, 87   |
| <b>Reserved</b>     | 50, 53-76  |

## NOTE

Error messages denoted with asterisks (\*) are only applicable to CDCNET version 1.0, as these errors are detected by a standard parser in later releases. Error messages denoted with double asterisks (\*\*) occur only during the integration (build) phase.

Following are the messages and their descriptions. They are sorted by message number.

### --WARNING DA 0-- The dump file value for [text] is invalid.

Description: The contents of the dump file corresponding to the specified structure are out of range, preventing further processing of the command.

User Action: Be aware that other commands using the specified structure may result in the same error.

### --WARNING DA 1-- Not all memory for the [text] at address [text] through [text] is in the dump file.

Description: The specified structure at the specified memory locations is not completely contained in the dump file.

User Action: A DISPLAY\_MEMORY of the specified addresses will show the available parts of the structure.



**--ERROR DA 2\*-- Byte offset value specified was too big.**

Description: The byte\_offset parameter of the previous command was greater than the maximum memory address.

User Action: Reenter the command with a byte offset parameter that is within range. See the Dump Analyzer ERS for the proper range of the byte\_offset parameter.

**--ERROR DA 3\*-- Incorrect parameter value specified.**

Description: The value of the parameter specified with the previous Dump Analyzer command is out of range. This message will no longer be used in R1.2 and beyond.

User Action: Reenter the command with the proper parameter value. See to the Dump Analyzer ERS for correct parameter ranges.

**--WARNING DA 4-- TCB tree list limit exceeded.**

Description: The internal limit of task control blocks was exceeded while building the TCB tree list, preventing successful construction of the list. This error suggests corruption of the dump file or misbehavior of the task scheduler as the number of TCBs exceeds the reasonable limit supported by the Dump Analyzer.

User Action: Examine the output from DISTCB ALL which may show where invalid task control blocks begin.

**--FATAL DA 5-- Internal error - Data length exceeds 48 bits.**

Description: Internal error in Dump Analyzer field packing process.

User Action: Submit a PSR to Control Data with the dump file and the input file directives that caused the error.

**--FATAL DA 6-- Internal error - Data length is not a multiple of 8 bits.**

Description: Internal error in Dump Analyzer field packing process.

User Action: Submit a PSR to Control Data with the dump file and the input file directives that caused the error.

**--FATAL DA 7-- Internal error - Byte offset in field is out of range.**

Description: Internal error in Dump Analyzer field packing process.

User Action: Submit a PSR to Control Data with the dump file and the input file directives that caused the error.

**--ERROR DA 8-- Expected command, found [text].**

Description: The string specified is not a valid Dump Analyzer command.

User Action: Enter a legal Dump Analyzer command.

**--CATASTROPHIC DA 9-- The auto dump table contains only one entry.**

Description: The auto dump table is used by the Dump Analyzer to process a D1 dump. It consists of a number of entries with each entry specifying the address and length of a D1 process structure. The first entry defines the rest of the ADT itself - if this is the only entry, no other D1 structure can be read and processed.

User Action: Since this dump cannot be processed by the Dump Analyzer, it must be analyzed manually or another dump file must be created and used.

**--FATAL DA 10-- Sufficient storage not available.**

Description: The Dump Analyzer allocates storage during execution in order to build module lists, TCB tree lists, etc. so various commands can be completed. This error message indicates the Dump Analyzer job has exceeded its allowed memory usage. Any further subcommands requiring memory allocation will not complete.

User Action: Rerun the Dump Analyzer job with more memory specified. If this error continues to occur when executing the same command, it may indicate the structure being processed contains corrupted values. Further examination of the structure using the DISPLAY\_MEMORY command should locate the problem.

**--ERROR DA 11-- Command expected but not found.**

Description: The Dump Analyzer did not recognize the latest input as a valid command.

User Action: Enter a valid Dump Analyzer command.

**--CATASTROPHIC DA 12-- Dump file [text] not found or contains no data.**

Description: The specified dump file was not found or contains no data. The Dump Analyzer on NOS must have the dump file attached as a local file. This is not a restriction on on NOS/VE.

User Action: Recheck accessibility and size of the dump file and re-invoke the Dump Analyzer.

**--ERROR DA 13\*-- Address value specified is too big.**

Description: The address value entered exceeded the maximum D1 memory address.

User Action: See the Dump Analyzer ERS for the maximum address value permissible and reenter the command with an address value that is within range.

**--ERROR DA 14-- The sum of the address and byte\_offset parameters is too big.**

Description: The sum of the address and byte\_offset values exceeded the maximum D1 memory address.

User Action: See the Dump Analyzer ERS for the maximum permitted value. Reenter the command, insuring the sum of the address and byte-offset parameters does not exceed this maximum.

**--ERROR DA 15\*-- A negative value was specified for the address value.**

Description: The address value specified was less than zero.

User Action: Reenter the command with an address value that is within range. Refer to the Dump Analyzer ERS for the correct range.

**--ERROR DA 16\*-- A negative value was specified for the byte\_offset parameter.**

Description: The byte\_offset value specified was less than zero.

User Action: Reenter the command with a byte\_offset value that is within range. Refer to the Dump Analyzer ERS for the range allowed for the byte\_offset parameter.

**--ERROR DA 17\*-- The value specified for byte\_count must be greater than zero.**

Description: The byte\_count value entered was less than or equal to zero.

User Action: Refer to the Dump Analyzer ERS for the range allowed for the byte\_count parameter. Reenter the command with a byte\_count parameter that is within range.

**--ERROR DA 18\*-- The value specified for repeat\_count must be greater than zero.**

Description: The repeat\_count value entered was less than or equal to zero.

User Action: Refer to the Dump Analyzer ERS for the range allowed for the repeat\_count parameter. Reenter the command with a repeat\_count parameter that is within range.

**--FATAL DA 19-- The number of bytes read does not match auto dump table info.**

Description: The auto dump table consists of entries specifying the address and length of a D1 structure and is used to read the dump file. The latest read performed by the Dump Analyzer did not match the length specified in the ADT. This error suggests a corrupted dump file.

User Action: Submit a PSR to Control Data with the dump file and the input file directives that caused the error.

**--FATAL DA 20-- Internal error - invalid bit displacement specified during alignment of dump file data.**

Description: Internal error - the bit displacement of the requested field is not on an 8-bit (byte) boundary.

User Action: Submit a PSR to Control Data with the dump file and the input file directives that caused the error.

**--WARNING DA 21-- Specified stack frame does not exist.**

Description: The stack frame associated with the structure being displayed does not exist.

User Action: Be aware that the command may not have completed. If this error occurs after a DISC command specifying a parameter, reenter DISC with START=1 and COUNT=ALL to display all available stack frames.

**--ERROR DA 22\*-- The COUNT parameter must be a positive integer or ALL.**

Description: The value specified for the COUNT parameter was not within the stated range.

User Action: Reenter the command with a COUNT parameter that is within range. Refer to the Dump Analyzer ERS for the correct range of the COUNT parameter.

**--FATAL DA 23-- Internal error - Field crossed a byte boundary.**

Description: Internal error in aligning data in the Dump Analyzer field packing process.

User Action: Submit a PSR to Control Data with the dump file and the input file directives that caused the error.

**--WARNING DA 24-- Invalid child task pointer [text] was encountered while building the TCB tree list. The chain cannot be followed - some TCBs may not be accessible to future commands.**

Description: While building the TCB tree list for use by the DISTCB command, a corrupted TCB was found at the specified address. Any further TCBs along that branch of the tree cannot be processed, but the rest of the TCBs are valid.

User Action: A DISPLAY\_MEMORY of the specified address will show what the corrupted TCB looks like and may yield clues as to why it is corrupted.

**--WARNING DA 25-- The dump file value for [text] is invalid. Some commands may be affected.**

Description: The specified structure is invalid. Commands referencing this structure may give incomplete results.

User Action: Be aware of this fact when using commands involving the specified structure.

**--CATASTROPHIC DA 26-- The dump file value for [text] is unusable. No further processing possible.**

Description: The specified structure is invalid, causing termination of the Dump Analyzer.

User Action: This dump cannot be processed by ANACD. Examine dump manually.

**--FATAL DA 27-- The well\_known ram locations (including module data pointers) are not available.**

Description: Key portions of the MPB\_RAM table are not available in this dump, including the module data pointers needed to build the module list.

User Action: Avoid use of commands requiring a module name as a parameter.

**--ERROR DA 28\*-- The START parameter value must be a positive integer not exceeding 4095.**

Description: The value entered for the START parameter was not within the range 1 .. 4095.

User Action: Reenter the command with a START parameter that is within range.

**--FATAL DA 29\*\*-- There is no table length entry for record [text].**

Description: Build error - the specified record does not have a corresponding table length entry in the module DADTL. The build will not complete.

User Action: Submit a PSR to Control Data with the dump file and the input directives that caused the error.

**--WARNING DA 30-- The data at address [text] is not a valid task control block.**

Description: The task control block header at the specified address has been corrupted.

User Action: A DISPLAY\_MEMORY of the specified address may yield relevant information as some TCB fields may be intact.

**--FATAL DA 31-- Internal error - Number of bytes exceeds result parameter size.**

Description: Internal error - the specified result parameter is too small to contain the requested number of bytes.

User Action: Submit a PSR to Control Data with the dump file and the input file directives that caused the error.

**--FATAL DA 32-- Internal error - PACK\_STRING\_FIELD byte number exceeds buffer size.**

Description: Internal error - the highest element to be accessed in the input array exceeds the upper bounds of the array.

User Action: Submit a PSR to Control Data with the dump file and the input file directives that caused the error.

**--WARNING DA 33-- Entry point [text] at address [text] is not in any section of module [text].**

Description: The specified entry point is not contained in the specified module.

User Action: A DISPLAY\_MEMORY of the area surrounding the specified address should reveal which module contains the specified entry point. The DISMM command may show more information about the specified module.

**--WARNING DA 34-- Invalid dump file value for [text] - entry point data is not available.**

Description: The specified DI structure is invalid, preventing availability of entry point data.

User Action: Avoid use of entry point parameters on subsequent commands.

**--WARNING DA 35-- Invalid dump file value for [text] - module/section data is not available.**

Description: The specified DI structure is invalid, preventing construction of the module list. Commands requiring a module list will not complete.

User Action: Be aware that commands requiring a module list may not complete successfully.

**--ERROR DA 36\*-- The value specified for display\_option must be E, S, or F.**

Description: The DISPLAY\_OPTION parameter entered was not ENTRY, SECTION, or FULL (or one of their letter abbreviations).

User Action: Refer to the explanation of the DISPLAY\_MEMORY\_MAP command in the Dump Analyzer ERS for the meaning of the DISPLAY\_OPTION parameter. Re-enter the command with a valid DISPLAY\_OPTION parameter.

**--WARNING DA 37-- A task has not been selected as the current task. Command cannot be completed.**

Description: Several Dump Analyzer commands default to the current task in the absence of a TASK\_IDENTIFIER parameter. The current task is either the task that was running at the time the dump was taken or a task specified with the SELECT\_TASK command. In this case, no task was running when the dump was taken and no specific task has been selected as the current task.

User Action: Use the SELECT\_TASK command to specify a current task and reenter the previous command, or reenter the previous command specifying a task by using the TASK\_IDENTIFIER parameter.

**--FATAL DA 38\*\*-- The file named [text] is not local to this job.**

Description: The specified object library file required for the GENFD build utility cannot be found.

User Action: Make the specified file accessible and rerun the job.

**--FATAL DA 39\*\*-- Library file [text] does not contain a library header record.**

Description: Build error - The file specified as input to the build utility, GENFD, is not recognized as an object library.

User Action: Submit a PSR to Control Data with the dump file and the input directives that caused the error.

**--FATAL DA 40\*\*-- The library file contains no symbol table records for module [text].**

Description: Build error - the object library segment for the specified module is corrupted.

User Action: Submit a PSR to Control Data with the dump file and the input directives that caused the error.

**--FATAL DA 41\*\*-- The library file does not contain module [text].**

Description: Build error - the specified module is not in the object library.

User Action: Submit a PSR to Control Data with the dump file and the input directives that caused the error.

**--FATAL DA 42\*\*-- The library file contains a format error for module [text].**

Description: Build error - the specified module is corrupted in the object library.

User Action: Submit a PSR to Control Data with the dump file and the input directives that caused the error.

**--FATAL DA 43\*\*-- Module [text] is not of type M680.**

Description: Build error - the object library was built incorrectly.

User Action: Submit a PSR to Control Data with the dump file and the input directives that caused the error.

**--FATAL DA 44\*\*-- The symbol table for module [text] contains a format error.**

Description: Build error - the specified module's symbol table is corrupted.

User Action: Submit a PSR to Control Data with the dump file and the input directives that caused the error.

**--FATAL DA 45-- An unexpected file mark has been found on file [text].**

Description: The specified file contains a format error.

User Action: If the specified file is an input to the build utility GENFD, submit a PSR to Control Data. If the specified file is a dump file, no further processing is possible.

**--FATAL DA 46\*\*-- There is no symbol table entry for field [text] of record [text].**

Description: Build error - the specified field was deleted in the DI software but not in the ANACD module DAMZZCD.

User Action: Submit a PSR to Control Data with the dump file and the input directives that caused the error.

**--WARNING DA 47-- Invalid sibling task pointer [text] was encountered while building TCB tree list. The chain cannot be followed - some TCBs may not be accessible to future commands.**

Description: While building the TCB tree list for use by the DISTCB command, a corrupted TCB was found at the specified address. Any further TCBs along that branch of the tree cannot be processed, but the rest of the TCBs are valid.

User Action: A DISPLAY\_MEMORY of the specified address will show what the corrupted TCB looks like and may yield clues as to why it is corrupted.

**--FATAL DA 48\*\*-- There is no symbol table item with symbol number = [text].**

Description: Build error - the specified symbol number does not have a symbol table item.

User Action: Submit a PSR to Control Data with the dump file and the input directives that caused the error.

**--FATAL DA 49\*-- There is no symbol table entry for record [text].**

Description: Build error - the specified record was deleted in the DI software but not in the ANACD software.

User Action: Submit a PSR to Control Data with the dump file and the input directives that caused the error.

**--FATAL DA 51-- Index sequential files not supported.**

Description: Internal error in file open process.

User Action: Submit a PSR to Control Data with the dump file and the input file directives that caused the error.

**--WARNING DA 52-- The value of [text] is [text], which is not within the TCB stack segment.**

Description: The specified value of the specified structure is not within the stack frame chain.

User Action: Use the DISM command or the DISMM command specifying the SF parameter to look at the stack segment for further information.

**--CATASTROPHIC DA 77-- Dump file length [text] too short to proceed.**

Description: The dump file length specified is so small that key dump file structures (such as mpb\_ram) are not contained in the dump, making any further processing impossible.

User Action: As this dump cannot be processed by the Dump Analyzer, manual analysis is required. If there is another dump for the same condition, it should be used with the Dump Analyzer.

**--CATASTROPHIC DA 78-- Internal error - Auto Dump Table entries exceed the limit of [text]. It is doubtful that this is a valid CDCNET dump.**

Description: The number of auto dump table entries exceeds the specified maximum, precluding further processing by the Dump Analyzer.

User Action: The high number of ADT entries indicates corruption of the dump file. Manual analysis may indicate the problem.

**--WARNING DA 79-- Auto Dump Table at [text] has been adjusted due to short dump file of length [text].**

Description: The size of the dump file was less than the size indicated by the auto dump table. To bring the size indicated by the ADT into agreement with the actual size of the dump, entries were removed from the end of the ADT until the lengths were in agreement.

User Action: Be aware that some information captured by the DI may not be contained in the dump.

**--WARNING DA 80-- Command cannot be processed due to absence of SCT in dump file.**

Description: The system configuration table is missing from the dump file. Any commands requiring the SCT will not complete.

User Action: Avoid commands requiring the SCT - for example, the DISSCT, DISTCB, and VALSA commands.

**--WARNING DA 81-- Loop in TCB chain--entry at [text] points to entry at [text].**

Description: A loop has been detected at the specified addresses during construction of the TCB tree list. An alternate method of construction will now be employed.

User Action: Be aware that the command will take significantly longer to complete.

**--WARNING DA 82-- TCB chain broken at address [text].**

Description: A break was detected at the specified address during construction of the TCB tree list. An alternate method will be employed.

User Action: Be aware that the command will take significantly longer to complete.

**--INFORMATIVE DA 83-- Scanning memory for TCB identifier to rebuild TCB chain. This process may take some time.**

Description: Due to a flaw in the TCB chain, the TCB tree list will be constructed by scanning memory for the literal !TCB. This method requires significant resource usage.

User Action: Be aware that the command will take significantly longer to complete.

**--WARNING DA 84-- The [text] value in the dump file is invalid.**

Description: The dump file value for the specified state is out of range. The display field will be filled with asterisks.

User Action: None required.

**--WARNING DA 85-- Integer to string conversion error--value cannot be displayed.**

Description: An error occurred during conversion of an integer value to a displayable string. The field will be filled with asterisks.

User Action: None required.

**--WARNING DA 86-- Dump Analyzer version [text] does not match dump file compiled version [text] recorded in SYSTEM\_DATA. Some display fields may contain erroneous values. If possible, use a Dump Analyzer of the same version as the compiled dump file.**

Description: The specified build level of the Dump Analyzer differs from the specified build level of the DI software. Since the Dump Analyzer uses DI software tables to access and display the corresponding DI structures, a version mismatch could result in erroneous display of DI structures.

User Action: Re-invoke the Dump Analyzer, specifying a version matching the dump file compiled version. If a matching version does not exist, use a Dump Analyzer version as close as possible to the dump file compiled version.

**--INFORMATIVE DA 87-- No task was running at time of dump.**

Description: There was no task active at the time the dump was taken.

User Action: User may wish to specify a current task for further processing by invoking the SELECT\_TASK command.

**--ERROR DA 88-- ADDRESS parameter must be a DI memory address or entry point name.**

Description: The ADDRESS parameter specified on the last command was not a valid address or DI entry point name.

User Action: Reenter the command using a valid ADDRESS parameter. Refer to the Dump Analyzer ERS for the correct range of this parameter.

**--WARNING DA 89-- Entry point [text] cannot be found in dump file.**

Description: The specified entry point was not contained in the dump file's module list.

User Action: Entering the DISPLAY\_MEMORY\_MAP command will yield a list of all the entry points contained in the dump file.

**--WARNING DA 90-- The CDCNET DI software compiled version recorded in SYSTEM\_DATA cannot be verified.**

Description: The dump file being processed does not contain the SYSTEM\_DATA table, which contains the DI software compiled version.

User Action: If the dump file loaded version seems valid and some displays appear erroneous, a Dump Analyzer version matching the dump file loaded version should be used with this dump.

**--WARNING DA 91-- Module [text] cannot be found in dump file.**

Description: The specified module could not be found in the dump file's module list.

User Action: Invoking the DISPLAY\_MEMORY\_MAP command will yield a list of all the module names contained in this dump file.

**--WARNING DA 92-- TCB at [text] pointed to by running task pointer is invalid.**

Description: The task control block at the specified address is corrupted. Since this is the running task TCB, there is now no current task.

User Action: If a current task is desired, it may be specified with the SELECT\_TASK command. A DISPLAY\_MEMORY of specified address may yield some useful information about the task running at the time of the dump.

**--WARNING DA 93-- Dump file value for running task is corrupted: new task must be specified.**

Description: The SELECT\_TASK command was entered with no Tl parameter, and the dump file value for the task running when the dump was taken is invalid.

User Action: Reenter the SELECT\_TASK command with a TASK\_IDENTIFIER specified.

**--WARNING DA 94-- No task was running at time of dump: new task address must be specified.**

Description: The SELECT\_TASK command was entered with no TASK\_IDENTIFIER specified, and no task was running when the dump was taken.

User Action: Reenter the SELECT\_TASK command with a TASK\_IDENTIFIER specified.

**--WARNING DA 95-- Bad link at [text] found in list chain.**

Description: The address specified was a bad link pointer discovered when processing a linked list. No further processing is possible.

User Action: Use the DISM command to examine the area surrounding the specified address. This may yield further information.

**--ERROR DA 96-- Command [text] not available in this version of the Dump Analyser.**

Description: The specified command is not available in this release.

User Action: Use other commands to find the desired information.

**--WARNING DA 97-- Buffer length not available in system configuration table-- using buffer size of [text] bytes.**

Description: The value for a data buffer's length is not available in the dump file, so the specified length will be used in generating the buffer display.

User Action: If the specified buffer size is known to be incorrect, the known size can be used with the DISPLAY\_MEMORY command to view the contents of the buffer.

**--WARNING DA 98-- Module header pointer in task control block is invalid.**

Description: The pointer to the structure containing the name of the task being processed is corrupted. The task name will be found using an alternate method.

User Action: None required.

**--WARNING DA 99-- Line name [text] not found in dump file.**

Description: The specified line name is not contained in the dump being analyzed.

User Action: Reenter the command with a different line name or the keyword ALL to see which line names are available in the dump.

**--WARNING DA 100-- Header for linked list entry at [text] is too large or linked list entry address too low.**

Description: Either the header size specified is too large or the list item address specified is too low. When the header is subtracted from the list item address the result is less than 1 (the minimum DI memory address).

User Action: Reenter the command with different values for either the header size parameter or the linked list starting address. The subcommand may have generated some output before terminating - check this if you think your parameter values were correct.



**--WARNING DA 101-- Address of link\_offset plus linked list entry at [text] exceeds the maximum DI memory address.**

Description: Either the link\_offset or the specified list item address is too high. When the link\_offset is added to the list item address the result is greater than the maximum DI memory address.

User Action: Reenter the command with different values for either the link\_offset parameter or the linked list starting address. The subcommand may have generated some output before terminating - check this if you think your parameter values were correct.

**--WARNING DA 102-- Stack extension allocated. Previous stack segment allocated at DI address [text] will not be processed.**

Description: A link to a previous stack segment has been detected, indicating that a stack extension has occurred. There may be information of interest in the previous stack frame(s).

User Action: Use DISPLAY\_MEMORY to look at previous stack segment at specified address if desired.

**--WARNING DA 103-- Output terminated by a user break sequence.**

Description: A user break 2 has been detected during the generation of subcommand display output. This sequence has been interpreted as a request to terminate the output generation from the current subcommand. This message appears in the NOS version of ANACD only.

User Action: Continue to enter subcommands at the prompt. Note this message may not appear if the generation of output was already complete before the break sequence was detected. In this case any output waiting to be displayed at the terminal will be discarded so the effect will be the same. If you desire to terminate the ANACD session entirely enter the QUIT subcommand or three (3) user break 2 sequences in succession. Consult your NOS operating system manual for more information on user break sequences. If you are running under NOS/VE this message will be replaced by a standard system message and user breaks will be handled entirely by the operating system in the standard way for NOS/VE utilities. Consult the SCL NOS/VE System Interface manual for further information.

**--WARNING DA 104-- File name [text] truncated to [text].**

Description: On the NOS operating system file names are limited to 7 characters. The parser for the subcommands will allow the full 31 characters but only the first seven will be used to identify the file on NOS. This warning only refers to files on subcommands which are normally output display files.

User Action: Make a note of the shortened file name. If the short name is the same as one already in use data will be appended as a NOS record. The execution of the subcommand will not be affected.

**--ERROR DA 105-- First seven characters ([text]), of specified file name does not constitute a valid NOS file name.**

Description: On the NOS operating system file names can only contain alphabetic or numeric characters but on NOS/VE the special characters ( \$ # @ \_ ) are also allowed. On NOS, file names specified as subcommand parameters are truncated to 7 characters and if any of these characters are in the set of 4 specials above then this message is issued and the subcommand must be rejected.

User Action: Reenter the subcommand with a valid NOS file name.

**--WARNING DA 106-- There are more than [text] TCBs in this dump. Only this limited number will be displayed.**

Description: The internal limit of task control blocks was exceeded while building the TCB tree list, preventing successful construction of the list. This error suggests corruption of the dump file or misbehavior of the task scheduler as the number of TCBs exceeds the reasonable limit supported by the Dump Analyzer.

User Action: Examine the output from DISTCB ALL which may show where invalid task control blocks begin.

**--ERROR DA 107-- Attempting to generate display onto file [text], which is the same as the dump file.**

Description: The name of a file specified by an output parameter on either the main ANACD call or a subcommand, is the same as the name of the specified dump file. The output file will not be accepted in order to safeguard the user from overwriting the dump file.

User Action: Choose another name for the output file and reenter command.

**--ERROR DA 108-- Output file [text] not writable.**

Description: The output file specified on the main ANACD call or the current subcommand was found to be read or execute only and therefore could not be opened for write mode.

User Action: Check your access mode permissions for the specified file or choose another file name and reenter command.

**--ERROR DA 109-- TASK IDENTIFIER parameter must be a DI memory address or a task name.**

Description: A task is identified by its TCB address or the name of the module that was scheduled as a task. Unscheduled modules are not task names.

User Action: Check the name or address of this task or TCB and reenter command.

**--WARNING DA 110-- Task name [text] is contained in more than one TCB - no task selection made.**

Description: The SELECT\_TASK subcommand allocates a single task or TCB to be the default selection for many task oriented subcommands. If a module has been scheduled more than once it will be the task name of more than one TCB so that the name alone does not uniquely identify the TCB.

User Action: Use DISTCB with the task name (BRIEF mode will do) to find the TCB addresses of all the tasks with that name. Select the TCB desired to be the default or 'selected' one and reenter the SELT subcommand with the T1 parameter equal to the desired TCB address.

**--WARNING DA 111-- Device name [text] is not currently supported. Device names must be of the form \$LIMn where n is the slot number.**

Description: The DISPLAY\_HARDWARE\_STATUS command only supports display selection by LIM and slot number. Selection of other DEVICE\_NAMES has the same effect as omitting the parameter or selecting DN=ALL; that is, status for all the major boards or all the LIMs is displayed.

User Action: None.

**--WARNING DA 112-- The [text] is not [text], which is the range expected. This may be due to invalid data in the SMM BANK STATUS TABLE or a new hardware configuration. Check the rest of this subcommand display for further inconsistencies.**

Description: The SMM\_BLOCK\_SIZE or NUMBER\_OF\_BANKS used to calculate the address of subsequent SMM boards for the hardware status display are outside the expected ranges. This version expects only 1MB boards with a breakdown into 1MB or 0.5MB block sizes. Other values may be valid for upgraded boards but the current version of ANACD will probably be inadequate in displaying the hardware status of a DI configured with upgraded boards.

User Action: Submit a PSR to Control Data with the dump file and the input directives that caused the error.

**--WARNING DA 113-- No configured line control block is associated with this port.**

Description: The Configuration Table pointer from the structure PORT\_STATUS\_TABLE is either NIL or the PORT\_OWNER in the same table is not LCM\_OWNER. This means no CLCB information is available for this port of a LIM (that is, no line name or protocol). This is normal if the slot is empty or the port has not been assigned to an active LIM.

User Action: Ensure that this is consistent with the rest of the displayed hardware status.

**--ERROR DA 114-- The value [text] entered for parameter kind [text] is too long.**

Description: The parameter string for this application name or integer kind is too long for a valid name or integer of any kind. This message will only appear on NOS/VE where application value kinds have been defined for some parameters; for example, an address parameter which may be a symbolic name or an integer whose default radix is hex instead of standard decimal.

User Action: Use the NOS/VE SCL command DISCI to display the parameter specifications for the subcommand being attempted and re-enter the subcommand with all parameter values having fewer characters than the maximum length of a name or the length of an integer of maximum size represented in its longest form.

**--ERROR DA 115-- The value [text] entered for parameter kind [text] is not a valid symbolic name.**

Description: An invalid name has been entered for a parameter defined to have an application value kind of SYMBOLIC\_ADDRESS. The value should be a valid CYBIL name since it must match an entry point or TCB name. This message will only appear on NOS/VE where application value kinds are defined for some parameters.

User Action: Re-enter subcommand with either an integer address value or a valid CYBIL name for those parameters with kind defined as SYMBOLIC\_ADDRESS. Use the SCL command DISCI to determine which parameters are defined as this kind.

**--ERROR DA 116-- The value [text] entered for parameter kind [text] may only be numeric. No symbolic interpretation is supplied for this parameter.**

Description: This message only appears on NOS/VE. The parameter kind named is an application value kind and limits the parameter to numeric values. A name has been encountered for a parameter of this kind which cannot be interpreted for this subcommand.

User Action: Re-enter the subcommand with parameter values which are integers of the kind specified not symbolic names. Use the SCL command DISCI to determine which parameters are of the specified kind if it is not obvious.

**--ERROR DA 117-- The parameter string is too long to add default hex radices to integers.**

Description: Integer parameters in ANACD are interpreted as being in the base 16 (hexadecimal), unless an explicit radix is included. This is contrary to the decimal default rule for CCL and SCL parsing, therefore hex radices are added to integers without radices before the parameter string is fully parsed. The addition of these radices (the string '16') may make the subcommand line longer than the maximum allowed by CCL or SCL and hence make it too long to parse.

User Action: Attempt to reduce the length of the subcommand entry by taking out excess spaces, using abbreviations wherever possible and converting integers in small radices to larger ones. Shorter file names might also be chosen if any are involved. If the message still appears then submit a PSR to Control Data.

**--WARNING DA 118-- Address [text] is not within the ranges of allocatable memory on any board. Only allocatable memory extents have usage headers.**

Description: This message is associated with the memory user subcommands and describes a situation where an address is outside of the allocatable memory ranges in a DI where memory usage information is located.

User Action: If the message pertains to an address that is an input parameter, reenter the command with an address that is within range. You can see the valid ranges by displaying memory at the entry point memory\_chain\_end\_points. Note though that the PMM end points are ignored if the SCT shows no bytes in private memory.

**--WARNING DA 119-- Memory header address [text] is not present in the dump file. The next memory header address, [text], is beyond the address specified on the request.**

Description: The extent containing the address specified on the subcommand request is probably not present in the dump. The first address specified in the message is the start of a nondumped extent, the second address is the start of the next extent that is in the dump.

User Action: Re-enter the subcommand with a different address.

**--WARNING DA 120-- No memory found for ownerid [text].**

Description: The Dump Analyzer has searched the memory extent areas in this dump and could not find any memory 'owned' by the specified ownerid.

User Action: None required.

**--WARNING DA 121-- The specified memory user [text] has no associated memory.**

Description: The Dump Analyzer has searched the memory extent areas in this dump and could not find any memory 'owned' by the specified memory user.

User Action: None required.

**--WARNING DA 122-- No ownerid found for description [text].**

Description: The Dump Analyzer has searched the predefined ownerid array and could not find an ownerid associated with the specified description.

User Action: Check the input description for an exact match with one of the descriptions in the predefined ownerid array.

**--WARNING DA 123-- [text] is not a valid owner\_id.**

Description: The specified value is not within the range of valid owner\_ids.

User Action: Refer to the DISPLAY\_MEMORY\_USERS command description in this document for the range of valid owner\_ids.

**--WARNING DA 124-- This command may take some time. There are [text] owner\_ids for which memory use will be displayed.**

Description: Several lists have to be searched to determine all the memory extents owned by all the distinct owner\_id's. The exact time taken depends on the machine and its load, but will vary directly with the number of owner\_id's quoted.

User Action: Be prepared to wait or terminate the subcommand with a user break 2. There will be a substantial amount of output displayed. Consider terminating and restarting the subcommand with output directed to a mass storage file, if it is currently directed to the terminal.

**--ERROR DA 125-- The overlay for command [text] was not found on the overlay file.**

Description: The code for the specified command cannot be loaded from the load file. This error is not caused by any user action, but indicates something wrong with the building or installation of the ANACD utility. Only applies to NOS.

User Action: Submit a PSR to Control Data with the dump file and the input directives that caused the error. In the mean time, attempt to use another version of ANACD, as close as possible to the version of your dump file.

**--ERROR DA 126-- The A7 pointer cannot be greater than the A6 pointer.**

Description: This error can occur while tracing stack frames generated by procedure calls in the D1. A7 is normally equal to A6, or sometimes smaller for partial frames. An A7 greater than A6 would imply less than zero bytes in the frame and hence no further frames can be displayed.

User Action: Inspect the A6 and A7 values shown in a full display of the TCB, to determine which one of them is corrupt.

**--WARNING DA 127-- The ANACD\_DIRECTIVES parameter will be ignored when DISPLAY\_OPTION = BRIEF.**

Description: The DISPLAY\_MEMORY\_USERS subcommand will produce a file of ANACD directives if the AD parameter is specified. However the directives are only generated for extents for which the extent type and extent size are displayed (that is, when display\_option = full). The brief display merely summarizes or counts extents and bytes, so there will be no directives generated.

User Action: Re-enter the subcommand with the full display option if the directives are desired.

**--FATAL DA 128\*-- There are no modules present on the object library.**

Description: This condition only occurs during execution of the build tool GENFD on a NOS/VE system. The object library input to GENFD contains no module information and therefore will contain no symbol tables from which to calculate the latest field lengths and offsets.

User Action: Submit a PSR to Control Data with the dump file and the input directives that caused the error.

**--FATAL DA 129\*-- Module is not a recognized load module type.**

Description: This condition only occurs during execution of the build tool GENFD on a NOS/VE system. The object library input to GENFD does not contain module information that can be used to calculate the latest field lengths and offsets.

User Action: Submit a PSR to Control Data with the dump file and the input directives that caused the error.

**--FATAL DA 130\*\*-- Dictionary type is not a module dictionary.**

Description: This condition only occurs during execution of the build tool GENFD on a NOS/VE system. The object library input to GENFD contains a type of dictionary which is unsuitable for locating the symbol definitions needed to calculate the latest field lengths and offsets.

User Action: Submit a PSR to Control Data with the dump file and the input directives that caused the error.

**--FATAL DA 131\*\*-- Object library version is not supported.**

Description: This condition only occurs during execution of the build tool GENFD on a NOS/VE system. The object library input to GENFD is of a version and hence format that this tool cannot interpret.

User Action: Submit a PSR to Control Data with the dump file and the input directives that caused the error.

**--WARNING DA 132-- Invalid owner\_id of [text] read from [text] address [text].**

Description: An owner\_id out of the valid range has been read from the dump file, either from an extent header or a TCB. This owner\_id cannot be used as a key for further searches.

User Action: Use DISPLAY\_MEMORY or DISPLAY\_MEMORY\_HEADER to investigate further for clues to corruption or initialization problems if the owner\_id was read from a memory extent header. Use DISPLAY\_TASK\_CONTROL\_BLOCK if the owner\_id was read from a TCB.

**--ERROR DA 133-- Node identifier does not match tree root identifier.**

Description: The tree\_root\_identifier, as defined in the root record, does not match the node identifier as defined in the node record for this node of the tree. An error has probably occurred in the building of the tree.

User Action: Investigate the tasks responsible for creating the tree and adding to it.

**--ERROR DA 134-- The node value for [text] is invalid.**

Description: The value for [text] as read from the dump file appears to be corrupted. The validity or usefulness of this value is questionable.

User Action: Use DISPLAY\_MEMORY to investigate further for clues to corruption or initialization problems.

**--ERROR DA 135-- The node\_control value for [text] is invalid.**

Description: The value for [text] as read from the dump file for this particular node control record appears to be corrupted. The validity or usefulness of this value is questionable.

User Action: Use DISPLAY\_MEMORY to investigate further for clues to corruption or initialization problems.

**--ERROR DA 136-- The specified tree is empty, or possibly not a tree structure.**

Description: The tree specified has no branches. The node pointer, as specified in the node control record, is NIL. The value may not have been initialized properly. It is also possible that this is not a tree structure at all.

User Action: Use DISPLAY\_MEMORY to investigate further for clues to corruption or initialization problems. Determine that this is indeed a tree structure.

**--ERROR DA 137-- The specified key value is invalid.**

Description: The key type specified is invalid. Only numeric, pointer, and string type keys are currently supported. Corruption of the key type might be considered as a possible cause.

User Action: Use DISPLAY\_MEMORY to investigate further for clues to corruption or initialization problems.

**--ERROR DA 138-- The specified log queue type is invalid.**

Description: The key type specified is invalid.

User Action: Refer to the CDCNET Commands Reference manual for queue type parameter values that are currently supported.

**--ERROR DA 139-- The specified log queue message buffer pointer is invalid.**

Description: The log message buffer pointer, as read from the dump file, is invalid. It might be corrupted.

User Action: Use DISPLAY\_MEMORY to look for clues to corruption or initialization problems.

**--ERROR DA 140-- The specified log queue message identifier is invalid.**

Description: The log message identifier, as read from the dump file, is invalid. It might be corrupted.

User Action: Use DISPLAY\_MEMORY to look for clues to corruption or initialization problems.



# Index

---

## A

- Account records 5-2
- Accounting database restrictions 5-8
- ACTIVATE\_ALARMS command (NOS/VE) 3-7
- Actual line control block
  - Locating the ALCB 9-24
- Adding terminal devices 4-25
- Addresses 1-12
- Alarms 2-10
  - Accessing alarm files (NOS) 3-13
  - Accessing alarm files (NOS/VE) 3-8
  - Activating (NOS/VE) 3-7
  - Control 4-32
  - Controlling alarm environment 4-33
  - Deactivating (NOS/VE) 3-7
  - Defining alarm messages 4-33
  - Definition 1-7
  - Description 2-10
  - Environment (NOS) 3-14
  - Format 2-11
  - History 3-15
  - Output 2-11
  - Responding (NOS) 3-15
  - Responding (NOS/VE) 3-8
  - Routing (NOS) 3-13
  - Routing (NOS/VE) 3-8
  - Severity levels 2-11
- ANALYZE\_CDCNET\_DUMP command 8-2
  - Summary of subcommands 8-15
- Analyzing the network 9-1
- Application-to-application 1-5
- Archive
  - Definition 5-3
  - How to enter ARCNDB in line mode format 5-28
  - How to enter ARCNDB in screen mode format 5-17
  - Network log files 4-35
- Archiving databases 5-3
- ASCII Character set B-1
- ASYN-ASCII display format 10-15
- ASYN-HEX display format 10-17

## B

- Board status tables summary 9-10
- Boards 1-8

## C

- CANCEL\_SOURCE\_ALARM\_MESSAGE command (NOS/VE) 3-7
- CDCNET operating environment 1-2
- CHANGE\_ALARM\_ENVIRONMENT command 3-14
- Change expected operating limits 5-4
- CHANGE\_OUTCALL\_GATEWAY command 4-15
- CHANGE\_WORKING\_CONNECTION command 3-13
- Changing the logging recorder 4-31
- Character set B-1
- Clock
  - Display date and time 4-11
  - Resetting master clock (NOS) 4-11
  - Synchronizing 4-11
- Command files (NOS)
  - Building 3-10
  - Definition 3-10
  - Executing 3-11
  - Writing 3-11
- Command files (NOS/VE)
  - Building 3-4
  - Definition 3-4
  - Executing 3-5
  - Writing 3-5
- Commands DI dump analyzer
  - ANALYZE\_CDCNET\_DUMP 8-2
  - DISPLAY\_DI\_SYSTEM\_STATUS 9-8
  - DISPLAY\_HARDWARE\_STATUS 9-14
  - DISPLAY\_LINE\_CONTROL\_BLOCKS 9-14
  - DISPLAY\_NETWORK\_STATUS 9-8
- Commands NETOU
  - Abbreviations 2-2
  - ACTIVATE\_ALARMS (NOS/VE) 3-7
  - Add 2-4
  - Alarms 1-7
  - Cancel 2-4
  - CANCEL\_SOURCE\_ALARM\_MESSAGE (NOS/VE) 3-7
  - Change 2-4
  - CHANGE\_ALARM\_ENVIRONMENT 3-14
  - CHANGE\_WORKING\_CONNECTION 3-13
  - DEACTIVATE\_ALARMS (NOS/VE) 3-7
  - Default parameter values 2-3
  - Define 2-4
  - Delete 2-4
  - Display 2-5
  - DISPLAY\_CATENET\_TITLES (NOS) 9-5



DISPLAY\_DATE\_AND\_TIME 4-11  
 DISPLAY\_HARDWARE\_STATUS 9-13  
 DISPLAY\_LOGICAL\_NAMES 1-11  
 DISPLAYING\_ALARM\_  
 ENVIRONMENT 3-14  
 Entry 2-3  
 EXECUTE\_COMMAND\_FILE 3-11  
 Execution order 2-4  
 Format 2-1  
 Logical names 1-11  
 Physical names 1-8  
 REQUEST\_NETWORK\_  
 OPERATOR 4-9  
 Response format 1-7  
 Responses 2-6  
 ROUTE\_ALARMS 3-13  
 ROUTE\_COMMAND\_  
 RESPONSE 3-13  
 SEND\_COMMAND 1-7  
 Sending 1-7  
 SET\_DATE\_AND\_TIME 4-11  
 Start 2-5  
 START\_NETWORK 4-6  
 Stop 2-5  
 STOP\_NETWORK 4-6  
 SYNCHRONIZE\_CLOCK 4-11  
 Syntax 2-1  
 Verbs 2-3  
 WRITE\_TERMINAL\_MESSAGE 4-8  
 Commands NPA  
 ARCNDDB 5-17  
 CHANGE\_EXPECTED\_OPERATING\_  
 LIMITS 5-19  
 CREATE\_CDCNET\_ANALYSIS\_  
 REPORT 5-11  
 EDIT\_CDCNET\_LOG\_  
 MESSAGES 5-4  
 Entering in line mode 5-28  
 Entering in screen mode 5-17  
 EXPLAIN\_CDCNET\_LOG\_  
 MESSAGES 5-4  
 REFORMAT\_CDCNET\_LOG\_  
 FILE 5-6  
 RELNDB 5-27  
 Communication line  
 Adding 1-13; 4-18  
 Definition 1-2.1  
 Deleting 4-18  
 Redefining 4-19  
 Starting 4-5  
 Stopping 4-5  
 Communication lines  
 Analyzing connections using  
 NETOU 9-27  
 Analyzing connections using  
 NPA 9-37  
 Analyzing connections using the dump  
 analyzer 9-29

Configuration  
 Analyzing hardware configurations  
 using NETOU 9-13  
 Analyzing hardware configurations  
 using NPA 9-23  
 Analyzing hardware configurations  
 using the DI dump analyzer 9-15  
 Analyzing network configuration using  
 NETOU 9-3  
 Changing the outcall gateway 4-15  
 Definition 1-12  
 How networks are formed 9-2  
 Logical 1-13  
 Physical 1-12  
 Configured line control block  
 Locating the CLCB chain 9-32  
 CREATE\_CDCNET\_ANALYSIS\_  
 REPORT command 5-11  
 CREATE\_CONNECTION command 2-13  
 Creating a customized NPA summary  
 accounting statistics report 7-13  
 Customized report example (NOS) 7-3  
 Customized report example  
 (NOS/VE) 7-4  
 Customized reports 7-1

## D

Data collection 5-5  
 Data connection control block  
 Locating a DCCB chain 9-35  
 Data logging 5-6  
 Data reformat 5-2  
 Data terminating equipment 1-2.1  
 DEACTIVATE\_ALARMS command  
 (NOS/VE) 3-7  
 DEFINE\_SYSTEM command 1-12  
 Dependent log management entity 5-6  
 Dependent log me (see Dependent log  
 management entity) 5-6  
 Device interface 1-2.1  
 Device outcall 1-6  
 DI dump analyzer  
 Analyzing network configurations 9-8  
 Conventions 8-4  
 Definition 8-1  
 Dump files 8-7  
 Error messages J-1  
 How to end a dump analyzer  
 session 8-12  
 How to initiate the dump analyzer  
 (NOS) 8-3  
 How to initiate the dump analyzer  
 (NOS/VE) 8-2  
 How to manage dump analyzer output  
 (NOS) 8-11  
 How to manage dump analyzer output  
 (NOS/VE) 8-10  
 How to retrieve a DI dump file  
 (NOS) 8-6

- How to retrieve a DI dump file (NOS/VE) 8-5
- How to transfer dump files between NOS/VE and NOS 8-12
- How to use the dump analyzer input file (NOS) 8-9
- How to use the dump analyzer input file (NOS/VE) 8-9
- Locating dump files 8-9
- Mapping 8-7
- DI reset codes C-1
- Directory management entity 1-12
- DISPLAY\_CATENET\_TITLES command (NOS) 9-5
- DISPLAY\_DATE\_AND\_TIME 4-11
- DISPLAY\_DI\_SYSTEM\_STATUS command 9-8
- Display formats 10-13
  - ASYN-ASCII 10-14
  - ASYN-HEX 10-16
  - HASP-ASCII 10-18
  - HASP-HEX 10-20
- Display function key 10-8
- DISPLAY\_HARDWARE\_STATUS sommand 9-143
- DISPLAY\_HARDWARE\_STATUS subcommand 9-14
- DISPLAY\_LINE\_CONTROL\_BLOCKS command 9-14
- DISPLAY\_LOGICAL\_NAMES command 1-11
- DISPLAY\_NETWORK\_STATUS command 9-8
- DISPLAYING\_ALARM\_ENVIRONMENT command 3-14
- Displaying date and time 4-11
- Displaying network status 9-7
- Displaying system status 9-6
- Displaying system titles (NOS) 9-5
- Displaying system titles (NOS/VE) 9-5
- Displaying the output queue 9-36
- Dump files
  - Creating CDCNET file names 8-7
  - File name 8-7
  - File name map 8-7
  - How to retrieve a DI dump file (NOS) 8-6
  - How to retrieve a DI dump file (NOS/VE) 8-5
  - Mapping 8-7
  - Using EDIT\_CATALOG to find dump files (NOS/VE) 8-9

## E

- EDIT\_CDCNET\_LOG\_MESSAGES 5-4
- Edit function key 10-11
- Ethernet coaxial cable 1-2.1
- Ethernet network solution
  - Adding 4-19
  - Deleting 4-22
  - Redefining 4-24
- Event records 5-2
- EXECUTE\_COMMAND\_FILE command 3-11
- EXPLAIN\_CDCNET\_LOG\_MESSAGES 5-4

## F

- File maintenance utilities
  - Reloading databases 5-3
- File management function key 10-6
- File name 8-7
- File name map 8-7
- Format and edit function key 10-9
- Formatted data 10-13

## G

- Gateways
  - Application-to application 1-5
  - Controlling TCP/IP gateways 4-28
  - Controlling X.25 gateways 4-27
  - Definition 1-4
  - Network product 1-5
  - Outcall 1-6
  - TCP/IP 1-5
  - Terminal-to-application 1-5
  - X.25 1-5

## H

- HASP-ASCII display format 10-18
- HASP-HEX display format 10-20
- HDLC network solution
  - Adding 4-20
  - Deleting 4-23
  - Redefining 4-24
- Help
  - How to get help on NPA procedures 5-35
  - Line mode (NOS) 5-36
  - Line mode (NOS/VE) 5-36
  - Screen mode 5-35
- Help file utilities
  - Edit log messages 5-4
  - Explain log messages 5-4
- High-level data link control 1-2.1
- Host computer 1-2, 2.1

## Host console

- Definition 2-23
- Exiting 2-25
- K-display format 2-23
- Login 2-24
- Logout 2-25

## I

- Independent log management entity 5-6
- Independent log me (see Independent log management entity) 5-6
- Information processing family version 2
  - Creating customized reports (NOS) 7-2
  - Definition 7-1
- Input file
  - How to use the dump analyzer input file (NOS) 8-9
  - How to use the dump analyzer input file (NOS/VE) 8-9
  - Sample input file 8-13
- IP host
  - Cancel and redefine 4-29

## K

- K-display
  - Console entry restrictions 2-27
  - Definition 2-23
  - Escape sequence 2-28
  - Exiting and resuming 2-25
  - Format 2-23
  - Login 2-24
  - Logout 2-25
  - Paging 2-27
  - Prompts 2-26

## L

- LIM status table
  - LIM name 9-17
  - LIM state 9-18
  - LIM status 9-18
  - LIM type 9-18
  - Locating and interpreting the LIM status table 9-17
- Line and terminal control block tables G-1
- Line interface module 1-2.1
- Line mode
  - How to get help (NOS) 5-36
  - How to get help (NOS/VE) 5-36
- Log files
  - Archiving 4-35
  - Definition 4-34
  - Terminating (NOS) 4-35
  - Terminating (NOS/VE) 4-34

## Log messages

- Adding 4-31
- Cancelling and redefining 4-31
- Defining 4-30
- Log message id 6-7
- Logging group 1-4
- Logging recorder DI (NOS)
  - Cancel 4-31
  - Redefine 4-31
- Logical names 1-11
- Logout (NOS) 2-22

## M

- Mainframe device interface
  - Selecting 2-20
- Mainframe terminal interface
  - Selecting 2-20
- Major card status table
  - Board name 9-15
  - Board state 9-15
  - Board status 9-15
  - Locating and interpreting the major card status table 9-14
- Manage CDCNET Configuration
  - Utility 2-15
- Message
  - Receiving 4-9
- Messages
  - Sending 4-8
- MPB memory map E-1

## N

- Network access method 2-23
- Network analysis
  - Analysis tools 9-1
  - Analyzing connections using NETOU 9-27
  - Analyzing connections using NPA 9-37
  - Analyzing connections using the dump analyzer 9-29
  - Analyzing DI hardware configurations using NETOU 9-13
  - Analyzing DI hardware configurations using NPA 9-23
  - Analyzing DI hardware configurations using the dump analyzer 9-14
  - Analyzing network configurations using NETOU 9-3
  - Analyzing network configurations using the dump analyzer 9-8
  - Displaying network status 9-7
  - Displaying system status 9-6
  - Displaying system titles (NOS) 9-5
  - Displaying system titles (NOS/VE) 9-5

- Network control
  - Changing configuration 4-17
  - Clock management 4-10
  - Controlling gateways 4-26
  - Controlling network service access 4-16
  - Definition 4-1
  - Displaying network status 4-4
  - Logging and alarm control 4-29
  - Receiving messages 4-9
  - Recordkeeping 4-1
  - Sending messages 4-8
  - Starting and stopping communication lines 4-5
  - Starting and stopping network solutions 4-6
  - Terminating and archiving log files 4-35
- Network delay measurement
  - Definition 1-14
  - Displaying results 4-36
- Network file management 8-7
- Network management procedures (NOS)
  - NPAARC D-5
  - NPANLA D-5
  - NPANLR D-6
  - NPANLT D-6
  - NPAREPS D-6
- Network management procedures (NOS/VE)
  - BROADCAST\_CONFIGURATION\_FILES D-2
  - CREATE\_COMMAND\_CONNECTION D-2
  - DISPLAY\_PHYSICAL\_NAMES D-2
  - DISPLAY\_SYSTEM\_NAMES D-2
  - INFORM\_USERS D-2
  - PROCESS\_DUMP\_FILES D-3
  - PROCESS\_LOG\_JOB D-3
  - SEND\_COMMAND\_EVERYWHERE D-3
- Network operation
  - Activities 1-4
  - Concepts 1-1
  - Host console 2-23
- Network operator utility
  - Accessing (NOS/VE) 2-13
  - Alarms 2-10
  - Break processing 2-9
  - Building command files (NOS/VE) 3-4
  - Command abbreviations 2-2
  - Command entry 2-3
  - Command format 2-1
  - Command responses 2-6
  - Command syntax 2-1
  - Command verbs 2-3
  - Creating a prolog (NOS) 2-21
  - Creating a prolog (NOS/VE) 3-4
  - Default parameter value 2-3
  - Definition 1-14
  - Description 2-1
  - Displaying job status (NOS) 2-22
  - Entering commands (NOS) 2-31
  - Entering network commands (NOS/VE) 2-16
  - Exiting (NOS/VE) 2-15
  - K-display format (NOS) 2-23
  - Login (NOS) 2-19
  - Logout (NOS) 2-22
  - Network control 1-14
  - Paging (NOS) 2-22
  - Paging (NOS/VE) 2-15
  - Parameter abbreviations 2-2
  - Parameter values 2-2
  - Prompts (NOS) 2-21
  - Prompts (NOS/VE) 2-15
  - Session control 1-14
  - Terminal display format (NOS) 2-19
  - Terminal display format (NOS/VE) 2-15
  - Using a host console (NOS) 2-23
- Network performance analyzer
  - Account records 5-2
  - Analyzing DI hardware configuration 9-24
  - Customized reports 7-1
  - Data collection 5-5
  - Data logging 5-6
  - Data reformat 5-2
  - Data reformatting 5-6
  - Data reporting 5-7
  - Definition 1-15
  - Event records 5-2
  - Expected operating limits 6-7
  - How to enter NPA commands in screen mode format 5-17
  - How to initiate NPA reports (NOS) 5-13
  - How to initiate NPA reports (NOS/VE) 5-12
  - IPF2 database files 7-1
  - Report data pages 6-5
  - Report formats 6-1
  - Report generator 5-3
  - Report headings 6-1
  - Report types 6-8
  - Reports 6-1
  - Statistic records 5-2
- Network product gateways
  - Controlling 4-26
  - Definition 1-5
- Network products 1-5
- Network solution
  - Adding 4-19
  - Definition 1-3
  - Deleting 4-22
  - Ethernet 4-19
  - HDLC 4-20
  - NP interface (NOS) 4-22
  - Redefining 4-24
  - Starting 4-6
  - Stopping 4-6

X.25 4-21  
 Network transfer facility 1-14  
 Network validation 1-13

## O

ommunications interface module 1-2.1C  
 Operating environment, CDCNET 1-2  
 Operations station 1-4  
 Outcall gateway 1-6; 4-15  
 Output file  
   How to manage dump analyzer output (NOS) 8-11  
   How to manage dump analyzer output (NOS/VE) 8-10  
   Sample output file 8-14

## P

Paging 2-22  
 Parameter values  
   Boolean 2-3  
   Default 2-3  
   Integer 2-3  
   Keyword 2-3  
 Periodic utility (SUBBJP) 5-4  
 Physical names 1-8  
 PMM bank status table  
   Locating and interpreting a PMM bank status table 9-22  
 Port status table  
   Locating and interpreting a port status table 9-19  
   Port name 9-19  
   Port state 9-19  
   Port status 9-19  
   Port user 9-20  
 Prolog  
   Creating (NOS) 3-9  
   Creating (NOS/VE) 3-4  
 Protocol 1-3

## R

Receiving messages from terminal users 4-9  
 Record function key 10-7  
 Recordkeeping 4-1  
 REFORMAT\_CDCNET\_LOG\_FILE command 5-6  
 Reload  
   Definition 5-3  
   How to enter RELNDB in line mode format 5-34  
   How to enter RELNDB in screen mode format 5-27  
 Remote line monitor 1-16  
   Definition 10-1

Remote Line Monitor  
   Cancelling 10-21  
   Edit screen 10-11  
   File management screen 10-6  
   Format and edit screen 10-10  
   Main menu screen 10-2  
   Security 10-21  
   Setup screen 10-4  
   Starting a session 10-1

## REMOTE\_LINE\_MONITOR

Command 10-1  
 Report generator 5-3  
 Reports (NPA)  
   Customized 7-1  
   Data pages 6-5  
   Expected operating limits 6-7  
   Formats 6-1  
   Headings 6-1  
   How to initiate (NOS) 5-13  
   How to initiate (NOS/VE) 5-12  
   Log message id 6-7  
   Types 6-8

## REQUEST\_NETWORK\_OPERATOR

command 4-9  
 Resetting the master clock 4-11  
 Response suppression (NOS) 2-10  
 Response suppression (NOS/VE) 2-9  
 ROUTE\_ALARMS command 3-13  
 ROUTE\_COMMAND\_RESPONSE command 3-13

## S

Screen mode  
   How to enter NPA commands (NOS) 5-17  
   How to get help 5-35  
 SEND\_COMMAND 1-7  
 SEND\_COMMAND (NOS) 2-31  
 SEND\_COMMAND (NOS/VE) 2-16  
 Sending messages to terminal users 4-8  
 Service access control  
   Controlling 4-16  
   Definition 4-16  
 Session control  
   Definition 1-14  
   Description 3-1  
 Session control (NOS)  
   Accessing routed responses and alarms 3-13  
   Building command files 3-10  
   Changing alarm environment 3-14  
   Creating a prolog 3-9  
   Displaying alarm environment 3-14  
   Displaying alarm history 3-15  
   Responding to alarms 3-15  
   Restoring alarm environment 3-15  
   Routing command responses and alarms 3-13

- Writing and executing command files 3-11
- Session control (NOS/VE)
  - Accessing responses and alarm files 3-8
  - Activating and deactivating alarms 3-7
  - Building command files 3-4
  - Creating a prolog 3-4
  - Matching names 3-2
  - Normal response 3-2
  - Response identifier 3-2
  - Routing command responses and alarms 3-7
  - SCL functions 3-2
  - Using SCL procedures 3-7
  - Wildcard characters 3-3
  - Writing and executing command files 3-5
- SET\_COMMAND\_MDI command 2-21
- SET\_DATE\_AND\_TIME command 4-11
- SMM bank status table
  - Locating and interpreting an SMM bank status table 9-21
  - SMM memory banks 9-21
- START\_NETWORK command 4-6
- Statistics
  - Commands 5-11
  - Control 5-8
  - Groups 5-9
  - Message numbers 5-11
  - Obtaining statistics results 5-11
  - Records 5-2
  - Starting and stopping 5-10
- Status
  - Displaying 4-4
  - Displaying job status (NOS) 2-22
- STOP\_NETWORK command 4-6
- SYNCHRONIZE\_CLOCK 4-11
- Synchronizing DI time clocks 4-11
- System control language
  - Definition 2-2
  - Functions 3-2
- System tables F-1
- System titles
  - Definition 9-4
  - Displaying (NOS) 9-4
  - Displaying (NOS/VE) 9-4

## T

- Task and queue control block tables H-1
- TCP/IP gateway
  - Controlling 1-5
  - Definition 1-5
- Terminal cluster control block
  - Locating the TCCB chain 9-33
- Terminal control blocks summary 9-24
- Terminal device control block
  - Locating a TDCB 9-34
- Terminal interface program
  - Available TIPs 1-3
  - Definition 1-3
- Terminal passthrough 1-6
- Terminal-to-application 1-5
- Terminating network log files (NOS) 4-35
- Terminating network log files (NOS/VE) 4-34
- Titles 1-12
- Transmission control protocol/internet protocol 1-4
- Trunks 1-2.1

## U

- Unformatted data 10-12
- Unit record interface 1-2.1

## W

- Wildcard characters 3-3
- WRITE\_TERMINAL\_MESSAGE command 4-8

## X

- X.25 gateway
  - Controlling 4-27
  - Definition 1-5
- X.25 network solution
  - Adding 4-21
  - Deleting 4-23
  - Redefining 4-24

100

101

102

103

104

105

Please fold on dotted line;  
seal edges with tape only.

FOLD

FOLD

FOLD

**BUSINESS REPLY MAIL**

First-Class Mail Permit No. 4760 St. Paul, MN

POSTAGE WILL BE PAID BY ADDRESSEE

**CONTROL DATA**

Technical Publications

ARH219

4201 N. Lexington Avenue

Arden Hills, MN 55126-9983

NO POSTAGE  
NECESSARY  
IF MAILED  
IN THE  
UNITED STATES





We would like your comments on this manual to help us improve it. Please take a few minutes to fill out this form.

**Who are you?**

- ☐ Manager  
☐ Systems analyst or programmer  
☐ Applications programmer  
☐ Operator  
☐ Other \_\_\_\_\_

**How do you use this manual?**

- ☐ As an overview  
☐ To learn the product or system  
☐ For comprehensive reference  
☐ For quick look-up  
☐ Other \_\_\_\_\_

What programming languages do you use? \_\_\_\_\_

**How do you like this manual? Answer the questions that apply.**

- | Yes                      | Somewhat                 | No                       |   |
|--------------------------|--------------------------|--------------------------|---|
| <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | Does it tell you what you need to know about the topic?   |
| <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | Is the technical information accurate?  |
| <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | Is it easy to understand?   |
| <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | Is the order of topics logical?   |
| <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | Can you easily find what you want?  |
| <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | Are there enough examples?  |
| <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | Are the examples helpful? ( <input type="checkbox"/> Too simple? <input type="checkbox"/> Too complex?) |
| <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | Do the illustrations help you?  |
| <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | Is the manual easy to read (print size, page layout, and so on)?  |
| <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | Do you use this manual frequently?  |

Comments? If applicable, note page and paragraph. Use other side if needed.

Check here if you want a reply: ☐

Name \_\_\_\_\_

Company \_\_\_\_\_

Address \_\_\_\_\_

Date \_\_\_\_\_

Phone \_\_\_\_\_

Please send program listing and output if applicable to your comment.

102680331



